[variable] <= [expression]

只能用于 always block 中

In a nonblocking assignment, the evaluated expression is assigned at the end of the always block (所有的 state 都是同步更行.同时赋值)

rule: using nonblocking assignment in sequential circuit.