

LODIMEKE[®]

Smart Watch

User Manual



P133

All pictures in this manual are for illustration purpose only. Actual product may vary due to product firmware upgrade and app upgrade. Please feel free to contact us via orders if you have any product questions.

Packing List	02
Appearance Description	02
Charging	03
App Installation	04
Function Introduction	06
Product Specifications	11
Frequently Asked Questions	12

◆ Packing List



Smart Watch





Charging Cable



User Manual

◆ Appearance Description



◆ Charging

Note: For the initial activation, you need to charge the device using the included charging cable.

Please follow the instructions as shown in the figure below:


(1) Use the magnetic charging cable provided with the product to align with the charging contacts on the back of the watch.

(2) Insert the USB end into a power adapter, computer, or power bank for charging (the adapter is not included in the package). Do not use a power adapter with an output voltage exceeding 5V or an output current exceeding 1A (including fast chargers that exceed these specifications), as this may cause charging malfunctions and potentially damage the watch.

(3) Ensure that the charging plug is securely connected to the port. When the charging icon appears on the screen, it indicates that the charging is normal.



(4) The charging process takes about 2.5 hours. Do not overcharge. After charging is complete, unplug the power supply immediately.



◆ App Installation

Download the app

During first use, you must connect to the "FitCloudPro" app for initial setup. Do not directly pair the watch through your phone's Bluetooth settings.

You can download the app by searching for "FitCloudPro" in the APP Store/Google Play or by scanning the QR code below.



FitCloudPro app is compatible with:



iOS 9.0 and above



Android 5.0 and above




Bluetooth 4.0 and above

Note: Only works with smartphones. It cannot work with tablets and personal computers.

Device pairing

1. On the app page, tap "Device" → "Add Peripheral Now/Bind Smartwatch" → "Search Now". Select "P133" from

- the device list that appears and tap it for pairing.
2. On the smart watch, tap "V" to confirm pairing.
 3. During the pairing process, your phone will prompt you to grant FitCloudPro necessary permissions (e.g., notifications, location). These are required for core features like message reminders and exercise tracking. You can manage these permissions at any time in your phone's settings.
 4. After a successful connection, you will be prompted "Pair with P133?". Please select "Pair".
 5. iOS users: After successful connection, tap "Allow P133 to Receive Your iPhone Notifications". Otherwise, the watch will not receive message notifications.



Note:

(1) Please pair the watch with your phone within the FitCloudPro app, not through your phone's Bluetooth settings.

(2) Android phones must allow the app to obtain permissions and run in the background. Otherwise, the user experience may be affected.

(3) For iPhones with iOS 13 or later, a one-tap connection is available in the app. For iPhones with iOS versions earlier than 13, after connecting in the app, a second connection to P133 is required in the phone's Bluetooth settings. Both connections must use the same ID to enable features such as making calls and playing music.

(4) If the device cannot be found, check the Bluetooth list to see if it is already connected. If so, please forget the device.

(5) When connecting, ensure the phone and watch are within 1 meter of each other, the watch screen is on, and the battery is sufficiently charged.

If it doesn't work after following the steps above, please restore the watch to factory settings, uninstall and reinstall the app, and follow the above steps to reconnect.

◆ Function Introduction

Power Button Description

	Press	Long Press
 Power Button	(1) Turn on (2) Return to main interface (3) Pause/End exercise (4) Enter the interface of Function lists	(1) Power on (2) Power off/Restart



1. Watch Face:

On watch: You have 3 ways to change the watch face on watch.

First: Long-press the watch face interface. Once the watch vibrates and displays available watch faces, swipe the watch screen horizontally to select your desired one. Second: After turning on the watch, swipe down on the screen to locate and tap "Settings - Display - Switch Watch Face", then swipe horizontally to choose your preferred watch face and tap it to complete the change. Third: You can also rotate the power button to switch between watch faces.

In App: Tap "Devices" → "Watch Face Settings" to select a watch face. Tap the first watch face at the top-left corner of "Watch Face Center" to customize the image wallpaper.

Besides displaying the time, different watch faces can also show information such as heart rate, step count, calories, and weather.



2. Data:

It displays the number of steps, calories burned, and exercise distance recorded since you put on the watch that day. The data will be reset to zero the next day.



3. Heart Rate Monitor:

Swipe to this page and stay on it; the heart rate measurement will start automatically. After the watch vibrates, the result value will be displayed, allowing you to check your current heart rate status.

Swipe up to view the all-day heart rate data.

For more detailed information analysis and data records, you can check them in the app. If you need 24/7 real-time heart rate monitoring, please go to "Devices" → "Continuous Monitoring" on the app and enable the continuous monitoring function.

Note: The product's measurement results are for reference only and cannot be used as a medical purpose or basis.



4. Sleep Analysis:

Wear the watch correctly while sleeping, and it can record and display the total duration of your sleep last night. It can store sleep data for up to 7 days, and more detailed information can be viewed in the app after synchronization.



5. Blood Pressure Monitor:

Swipe to this page and stay on it; the blood pressure measurement will start automatically.

After the watch vibrates, the result value will be displayed, allowing you to check your current blood pressure status. Swipe up to view the latest 7 blood pressure readings. For more detailed information analysis and data records, you can check them in the app.

Note: The product's measurement results are for reference only and cannot be used as a medical purpose or basis.



6. Blood Oxygen Monitor:

Swipe to this page and stay on it; the blood oxygen measurement will start automatically. After the watch vibrates, the result value will be displayed, allowing you to check your current blood oxygen status. Swipe up to view the latest 7 blood oxygen readings. For more detailed information analysis and data records, you can check them in the app. Note: The product's measurement results are for reference only and cannot be used as a medical purpose or basis.



7. Call Function:

After the watch is connected to your phone via Bluetooth, you can make calls by selecting Dial Pad, Frequently Used Contacts, or Call History.

Note: To view contacts, you need to go to "Devices" → "Frequently Used Contacts" on the app, authorize access to your phone's address book, and add quick contacts.



8. Message Notification:

When the watch is connected to the "FitCloudPro" app on your phone, you have enabled the message push function in "Devices" → "Message Reminders" within the app, and your phone has granted the FitCloudPro app permission to receive messages, the watch can receive notifications including incoming calls, text messages, emails, as well as alerts from Facebook, X (Twitter), Instagram, WhatsApp and more. Note: This function requires the watch to maintain a connection with the "FitCloudPro" app on your phone, and your phone must allow the corresponding apps to send message reminders.



9. Sports Modes and Workout:

The watch supports multiple sport modes, including walking, running, hiking, cycling, etc. Additionally, you can manually add other sport items such as dancing, ball games, combat sports, and more. Select a sport item and start exercising; the watch will display real-time sport data. Short-press the power button to pause, resume, or end the exercise (and save the sport data). Sport records can be viewed on the watch, or you can check detailed data and analysis reports via the app.



10. Weather:

The watch can display the weather conditions of the current city for the next 3 days. This function requires a connection to the app, and your phone must have GPS positioning enabled as well as grant the app permission to access the phone's location.



11. Music Control:

When the watch is connected to the "FitCloudPro" app on your phone, it can control the phone's music player to switch to the previous track, next track, pause, or play. Note: This function requires you to first open the music player on your phone before you can control it via the watch.



12. Voice Assistant:

When the watch is connected to both the "FitCloudPro" app and your phone via Bluetooth, it can activate the voice assistant on your phone (e.g., Siri for iPhone) through this function. Note: Before using this function, ensure that the voice assistant function on your phone has been set up properly.



13. Quick Settings:

Swipe down on the home screen to access the Quick Settings Panel, which includes brightness adjustment, Do Not Disturb mode, Flashlight, Watch Audio Switch, Settings, Find Phone, and more.

Among these: the Watch Audio Switch can turn on/off the watch's call audio and media audio.

14. Additional Functions:

This watch also has functions such as Remote Camera Control, Breathing Training, Timer/Alarm/Stopwatch, Women's Health, and Find Phone. Through the "FitCloudPro" app, you can also set functions like Water Reminder, Sedentary Reminder, Find Watch, and connect to Apple Health.

◆ Product Specifications

Model:	P133	Screen Type:	1.96 inches
Battery Capacity:	300mAh	Charging Voltage:	5V
Charging Time:	About 2.5 hours	Bluetooth Version:	5.2
Battery Type:	Li-ion battery	Watch Size:	H: 47.2mm W: 39.6mm D: 11.1mm
Resolution Ratio:	320*386	Screen Type:	TFT
Strap Width:	22mm	Usage Time:	About 3-7 days

◆ Frequently Asked Questions

1. How to Receive Message Alerts on the Watch?

(1) Mobile Phone Settings

Ensure notification permissions are enabled on your phone: the app notifications should display normally in the phone's notification panel, and permissions like "Show on Lock Screen" and "Floating Notifications" must be granted. Exit the chat interface of the app, and log out of the same app on devices such as computers or tablets to avoid suppressing notification pushes to the phone.

(2) Connection and System-Specific Checks

Verify that Bluetooth is enabled on your phone, the watch remains connected to the "FitCloudPro" app, and the distance between the watch and phone is within 5 meters.

For Android phones: Check that the "FitCloudPro" app is allowed to run in the background and that its notification access permission is enabled.

For iOS phones: Go to Settings > Bluetooth > P133 >  > Share System Notifications and verify the setting is enabled.

(3) Watch Do Not Disturb Mode Check

If Do Not Disturb mode is enabled on the watch, swipe down from the home screen to access the Quick Settings Panel, then find and turn off the Do Not Disturb switch. Alternatively, disable it via Settings > Do Not Disturb.

(4) Troubleshooting If Above Steps Fail

Try uninstalling and reinstalling the "FitCloudPro" app, resetting the watch to factory settings, then reconnecting and reconfiguring the device.

2. How to Maintain Connection Between the Watch and "FitCloudPro" App?

(1) For the first-time connection, please refer to the "App Installation - Device Pairing" section above.

(2) If the watch fails to connect to the "FitCloudPro" app, please check the watch's connection status and follow the corresponding steps below:



Connected



Not Connected

A. If the watch shows a "Connected" status: Confirm whether the watch is connected to another phone. First, go to the Bluetooth settings on that phone, find the watch device, and select "Forget Device". Then, open the "FitCloudPro" app, navigate to "Devices", and select "Unbind Device". Restart the watch and wait until it shows a Disconnected status, then re-initiate the connection process in the app.

B. If the watch shows a "Disconnected" status: Place the watch within 1 meter of your phone. Ensure the watch is powered on and has sufficient battery. Reset the watch by going to "Settings > System > Factory Reset" on the watch. Next, uninstall the "FitCloudPro" app from your phone, re-download and install it, then open the app and follow the "first-time device pairing" steps to reconnect.

3. Why Is the Health Data Measured by the Watch Inaccurate?

(1) Wearing Posture

The watch must be worn in the correct posture—incorrect wearing will affect heart rate measurement. Wearing the watch too tightly, or making a fist while lifting your wrist, can impair blood circulation and may also interfere with heart rate signals.

(2) Measurement Method

During measurement, keep your arm flat, relaxed, and stationary.

At the same time, ensure the watch is in close contact with your arm (no gaps between the watch back and the skin).

Note: Even with correct wearing, individual differences such as skin tone, arm hair, tattoos, and scars may still affect heart rate signals.

(3) Usage Limitation

This watch is not intended for medical use. All measured values are for general fitness purposes only.

4. Why Does the Watch's Recorded Sleep Data Disagree with Actual Sleep?

(1) Wearing Posture

When sleeping, the watch must be worn in the correct posture. A wristband that is too loose or too tight will both affect the accuracy of sleep data.

(2) Sleep Habits

The watch's sleep data monitoring algorithm is designed based on the normal sleep schedule of the general population and only records regular nighttime sleep data. Abnormal data may occur if you get up during the night, toss and turn excessively, stay up late, or engage in other movements with a large range of motion.

Note: If you place the watch on an object with a texture or color similar to human skin at night, there is a certain probability of misidentification. This may cause the watch to generate false sleep recording data.

5. What to Do If the Watch Cannot Be Charged

(1) Please confirm whether you are using the original magnetic charging cable included in the package. Also, check if the magnetic contacts on the charging cable and the contact points on the back of the watch are clean (free of dust, sweat, or debris).

(2) Verify if you are using a power adapter (or fast charger) with a power output exceeding 5V/1A. If so, the watch may fail to

charge due to overload caused by incompatible power specifications.

(3) If the watch has not been used for a long time, please use a low-power (5V/1A) power adapter to charge it continuously for more than 2 hours before attempting to turn it on.

Note: If you no longer plan to use the watch temporarily, please shut it down first via Settings > System > Power Off and then store it. To maintain normal battery life, charge the watch at least once every 60 days.



LODIMEKE.COM/P133

Scan the QR code above to access more product usage tips.
24/7/365 Customer Service Support is available for assistance.



RoHS



Made in China