

LODIMEKE®

IDW26 Smart Watch User Guide



FAQs for IDW26 Smart Watch


Q1. How to pair the watch with VeryFit app and your phone?	1
Q2. Is the nylon strap suitable for swimming or high-intensity water sports?	1
Q3. How to use Alexa voice assistant on your smart watch?	2
Q4. How to use Bluetooth calling?	2
Q5. How to get notifications on the watch?	3
Q6. How to use the watch to measure heart rate, blood oxygen, stress correctly?	6
Q7. How to accurately measure step count?	6
Q8. How to correctly measure your sleep data?	7
Q9. How to customize your shortcut access interface on your watch?	7
Q10. How to customize workout modes and set goals for specialized training?	7
Q11. How to charge the watch correctly?	9
Q12. How long does the watch battery last? How to extend it?	9
Q13. How to set the vibration mode and sound?	10
Q14. How to customize watch face?	10
Q15. How to control music on the watch?	12
Q16. How to set menstrual reminder?	12

Q1. How to pair the watch with VeryFit app and your phone?

1. Please download the VeryFit app by scanning the following QR code, or directly search for VeryFit app in App Store on iPhone or in Google Play on Android phones and download it.



2. Turn on the VeryFit app, click '**Device - Add Device - Watch/bracelet**' and choose IDW26 to pair. After pairing it, '**Bluetooth pairing request**' will prompt and please allow it.



Q2. Is the nylon strap suitable for swimming or high-intensity water sports?


Not recommended. This nylon strap uses a hook-and-loop (Velcro) closure for for easy adjustment and breathable comfort, but it may not be secure enough for water activities:

1. **Reduced adhesion when wet:** Water weakens the grip, increasing the risk of loosening.
2. **Water resistance during activity:** Swimming or fast movement may pull the strap loose, causing the watch to fall off.
3. **Long-term durability:** Frequent wetting without proper drying can wear out the fastener over time.

Q3. How to use Alexa voice assistant on your smart watch?


1. Turn on VeryFit app, click '**Device - Alexa**' and login it with Amazon account
2. You can launch Alexa voice assistant in three ways.
 - a. Long press the side button of the watch until the Alexa runs on the screen.
 - b. Short press the side button to enter the menu and select Alexa.
 - c. Swipe rightwards on the screen, and click the icon of Alexa to use it.
3. Then you can speak your request to the smart watch.

More details can be viewed in '**Alexa User Guide**' in the app.



Q4. How to use Bluetooth calling?

1. Keep your watch connected with your smart watch and your phone's Bluetooth.
2. You can click '**Device - Calls - Frequent contacts**' in the app and add up to 20 contacts to the smart watch.




3. Short press the side button of the watch to enter the menu, select 'Phone', then you can choose Dialpad or Frequent Contacts to make calls.




Q5. How to get notifications on the watch?

1. If you have already allowed all permissions on the first connection, VeryFit app will automatically pop up message notification settings. Click '**Message notifications**' and turn on the apps you want to receive notifications.




2. If you did not allow all permissions on the first connection, please choose any of the following methods to obtain message notifications:


1) Please reinstall the app and allow all permissions, then click '**Device - Notifications**' and turn on the apps you want to receive notifications.



2) For iPhone users, you need to turn on **'Share System Notifications'** of IDW26 smart watch in your phone's Bluetooth firstly, and choose **'Show Previews Always'**, then repeat above steps.



For Android phone users, click **'Device - Notifications - System Notifications permission'** and allow notifications of VeryFit app, then repeat above steps.



Note:

- a. The watch requires pairing with your smartphone's Bluetooth and companion app for full functionality.*
- b. Notifications mirrored on the watch are limited to messages appearing in your phone's notification panel.*
- c. Ensure the devices remain within a 5-meter range to maintain stable connectivity.*
- d. Functionality may vary depending on the smartphone model and operating system settings.*

Q6. How to use the watch to measure heart rate, blood oxygen, stress correctly?

Please follow the steps below:

1. Fill in your personal information correctly in the app, such as gender, birthday, height and weight.
2. Wear the watch snugly on your wrist (not too tight or loose).
3. Keep your arm still during measurement.

Factors to influence the measurements:

Fit matters: A loose watch leads to inaccurate readings.

Skin contact: Ensure the sensor is clean and unobstructed.

Environmental factors: Avoid extreme temperatures or bright light.

Note:

Smartwatches are not medical devices, the data cannot be intended for medical use, all measurements are for general fitness purposes.

Q7. How to accurately measure step count?

1. Set up your profile: Enter your gender, age, height, and weight in the app for personalized tracking.
2. Wear it right: Place the watch about two fingers' width below the wrist bone, snug but not too tight or too loose. Proper fit ensures accurate step detection.
3. Walk naturally: Take at least 30 continuous steps for the watch to calibrate and record your steps more accurately.

Note:


- a. Avoid invalid movements like shaking hands or raising your arm repeatedly.*
- b. Pushing a cart/stroller - Your arms stay still, so steps may be significantly undercounted.*
- c. Holding a phone while walking – Limited arm movement may result in slightly fewer steps recorded.*

Q8. How to correctly measure your sleep data?

1. Wear the watch on your non-dominant hand while sleeping (e.g., left hand if you're right-handed).
2. Sleep tracking is only available for nighttime sleep.
3. Make sure the device screen faces up and the watch is worn just behind the wrist bone, snug against your skin. Avoid wearing it too loose or too tight, as this may affect sleep data accuracy.

Q9. How to customize your shortcut access interface on your watch?

1. Open the VeryFit app and go to 'Device - More settings - Tiles'.
2. To hide a function, tap the '-' icon; to show a function, tap the '+' icon.
3. Press and hold the  icon, then drag it up or down to change the display order.
4. Tap Save to confirm your changes.
5. Swipe left on the watch screen to view the corresponding function data.




Q10. How to customize workout modes and set goals for specialized training?

Edit Workouts:

1. Open the VeryFit app and go to 'Device - Sports Setup - Sports Type'.

2. Tap 'Edit' - the 'Add' option will appear; Then select it.
3. Use '+' or '-' to add or remove workout modes on your device.
(Note: You can add up to 20 modes.)
4. Tap 'Done' to return to the previous screen, then tap 'Done' again to save your settings.



Set Goals:

1. Press the side button to enter the menu list.
2. Select 'Workout - .
3. Set your desired goals like duration, calories, distance and etc.



Q11. How to charge the watch correctly?

1. Use a dry, soft cloth to gently wipe the metal contact points on the back of the watch and the charger's surface to avoid dust or sweat residue affecting conductivity.
2. Bring the magnetic charging interface close to the watch's back. The magnets will automatically align and attach. Do not force it (a audible click indicates proper alignment).
3. Plug the charger into a low-power USB port (e.g., an adapter or computer USB port). Avoid using fast-charging adapters, as their high voltage output may damage the battery.
4. The watch screen will typically display a charging icon.

Q12. How long does the watch battery last? How to extend it?

The smart watch can be used 5-7 days and 30 days on standby. In order to extend the battery lifespan, please follow the tips below:

1. Turn off continuous heart rate measurement and automatic measurements (e.g., stress, SpO2).
2. Disable Bluetooth when unused.
3. Limit notifications to essential apps.

4. Enable power-saving mode and disable background app refresh.
5. Update software regularly for optimized efficiency.
6. Avoid extreme temperatures during charging/usage.
7. Reduce screen brightness & shorten screen timeout.

Q13. How to set the vibration mode and sound?

Short press the side button to enter the menu, click '**Settings - Sounds and Vibration**'. You can adjust ringer volume and vibration intensity. If you choose silent mode, the watch will be silent the incoming calls, alarms and message notifications.



Q14. How to customize watch face?

Switch dials on the watch:


Long press the home screen of the watch, or short press the side button of the watch to enter the menu, then click '**Settings - Watch Faces**' and then swipe left or right to switch dials.



Switch dials in the app:

Turn on your app, click '**Device - Watch Face Market**' and choose the dials you like.


Click '**Photo - Select from album / Take a photo**' and you can choose your favorite photos as the watch dial. You can set the font colour and location.



Q15. How to control music on the watch?

Turn on your app, click '**Device - More Settings - Music Control**', you can turn on it and then you can control the phone music on the watch.

Note: The watch will not play music.



Q16. How to set menstrual reminder?

Turn on your app, click '**Device - Health tracking Settings - Menstrual cycle**', then set the Menstruation Cycle, Cycle length and starting time of last menstruation and click '**Start to Use**'.

