


Arduino Libraries Installation Guideline

DR. TAN WOOI HAW


Installing DHT11 Library (1)

• Click on the library icon on the sidebar, search for DHT11 and install DHT sensor library by Adafruit according to the steps shown below.




Installing DHT11 Library (2)

Install all the dependencies for Adafruit DHT sensor library.



Installing Blynk Library (1)

• Click on the library icon on the sidebar, search for blynk and install Blynk library according to the steps shown below



Installing Blynk Library (2)

Install all the dependencies for Blynk library.

