¶included w/License Lamp Assy	19 Arm, Bumper Mtg	R 52181-01020	31.	10101A MR2 2000-05
HIGH MOUNT STOP LAMP	20 Bolt, Arm (3/Side) Pad, Step	L 52182-01010 R/L 90105-10511	. 31.	18 TOYOTA MR2 2000-05
	Dealer Installed	PT278-02021	.2 39	® SECTION INDEX
$\begin{bmatrix} 3 \\ 2 \end{bmatrix}$				A/C /HEATER/VENTILATION
1				A/C REFRIGERANT CAPACITIES 1861 ABS/BRAKES 1863
Separate Sep				AIR BAG SYSTEM
4				AIR CLEANER
044-07176				CLEAR COAT IDENTIFICATION
1 Lamp Assy, Stop 81570-01070 .2 92.	92	•		CONVERTIBLE TOP
1 Lamp Assy, Stop 81570-01070 .2 92 2 Bulb 9 90080-81065 .2 2 3 Socket, Bulb 9 90075-60037 7 #Included w/Stop Lamp Assy 4 Cover, Lamp 81977-01060 .1 31. 5 Cilp, Cover RL 90467-07071-22	43 74			COOLING
				ELECTRICAL 1870
5 Clip, Cover R/L 90467-07071-22	71			EMISSION SYSTEM
REAR BUMPER				ENGINE LID
Use Procedure Explanations 27 and 28 with the following text.				ENGINE/TRANS MOUNTS
Refinish Rear Cover 2.2 Refinish Center Spoiler				EXHAUST 1869 FRONT BUMPER 1860
Refinish Side Spoiler R/L .5 R&I Rear Cover 1.5				FRONT DOOR 1866
O/H Bumper Assy (Includes R&I) 2.6				FRONT FENDER 1861 FRONT INNER STRUCTURE 1862
Add to R&R Rear Cover or O/H Bumper Assy w/Spoiler3				FRONT LAMPS
w/Step Pad				FRONT SEAT
NOTE: All Parts in this section are included in overhaul unless noted otherwise.				FRONT STEERING LINKAGE/GEAR
				FUEL TANK 1864
19—17				HARDTOP
19—16 🕅		•		HOOD
A A REAL				INSTRUMENT PANEL 1865
20				PAINT CODE LOCATION
1 18 2				REAR BODY 1870
6 15 4 9			* ;	REAR BUMPER 1871
8		7		REAR DRIVE AXLE 1869 REAR LAMPS 1871
-3)a				REAR SUSPENSION
13				ROCKER/PILLARS/FLOOR
9—14				SEAT BELTS
8 10			1.5	STEERING PUMP
044-07177 7 12 11			200	STEERING WHEEL/COLUMN 1864 UNDERHOOD DIMENSIONS 1862
				WHEEL 1863
1 Cover, Bumper (P) wSpoiler 52159-02914 2.2 196	oe .			WINDSHIELD 1864
w/o Spoiler 52159-02913 2.2 196				SPECIAL CAUTIONS
(P) Paint to Match 2 Bolt, Cover (2/Side) P/L 90109-06354	74			AIR BAGS
4 Support, Side R 52155-02080 31	86 47			Refer to Procedure Explanation 29 for Supplemental Restraint/Air Bag
5 Bolt, Support (2/Side)	.63		t y	Special Cautions.
L 52592-02050 21	.46 .46			ELECTRICAL COMPONENTS
7 Spoiler, Center (P) XR, XRS Model 76871-02901 #.2 369	.69			Manufacturer advises that battery leads should not be disconnected while the engine is running. Negative (-) terminal should be disconnected and
8 Spoiler, Side (P) XR, XRS Model R 76895-02900 #.2 104	29			isolated prior to any electrical repair or charging of battery.
L 76896-02900 #.2 104 (P) Paint to Match	.29			SUSPENSION
#R&R Complete .3 9 Protector, Side Spoiler				Manufacturer advises that some new fasteners must be used whenever old fasteners are loosened or removed.
XR, XRS Model	57			WELDING
L 76882-02020-C0 5 Gray R 76881-02020-B0 5	57 57 57			Before initiating any repair involving the use of an electric welder, the
L 76882-02020-B0 5	57 57			ignition must be in the off position and the negative (-) battery terminal disconnected.
L 76882-02020-E0 5	57			
XR, XRS Model R 76893-02020 2	.06			PAINT CODE LOCATION
11 Protector, Center Spoiler XR, XRS Model				Paint code located on inside of driver's door.
Black R/L 76872-02020-C0 3	.46 .46			CLEAR COAT IDENTIFICATION
Nory R/L 76872-02020-E0 3 12 Cover, Inner Ctr Spoiler	46			All colors are clear coat. Code 051 is three stage.
XR XRS Model R/I 76893-02010 2	.00			INFORMATION LABELS
13 Retainer, Center Spoiler	.26			INI ONWATION LABELS
14 Retainer, Side Spoiler (5/Side) XR, XRS, Model F/L 76853-10010 5 About Model F 2015 00070 10 10 17	.83			Illustration Located in Next Column
16 Reinf, Absorber 52172-AA010 31	.14 .24			
17 Reinf, Bumper 52023-02090 IOH 158 18 Bracket, Bumper Reinf R/L 52175-01010 14	.96 .69		1.6.1	1 Label, Power Steering Fluid 44391-17020 4.46
	. [1

R/L 53271-12060 R/L 90981-13055 R/L 90075-65002 R/L 90981-13043 9.26 38.58 7.77 4.20 7.66 1.00 INFORMATION LABELS Cont'd 2003-05 #.2 2.2 Refinish Front Cover #2 Refinish Hole Cover. 90075-99080 2 R&I Cover Assy..... O/H Bumper Assy (Includes R&I). Add to R&R or O/H Front Cover 1.8 Socket, Clearance Seal, Housing Repair Kit, Housing Upper 7.77 9.52 10 R/L 53182-17030 .3 R 81193-17010 L 81194-17010 R 81195-17010 L 81196-17010 7.32 7.32 6.34 6.34 NOTE: All Parts in this section are included in overhaul unless noted 6 #w/Combination Lamp Assy Removed 044-06023 2 16 **COMBINATION LAMP** Label, A/C Information Label, Spare Tire 88723-17050 5.24 1.74 1.57 3.49 1.69 1.49 2.03 1.97 1.71 1.71 1.71 1.71 1.71 1.71 3.89 2.03 3.43 1.46 00-02 03-05 42668-12010 42668-20020 82683-17030 74571-32010 2003-05 15 Label, Fuse Block Cover, Film Label, Air Bag Caution Label, Tire Pressure R&I Combination Lamp Assy RA #1.3 #includes R&I Front Bumper Assy & R&R Compartment Cover, R&I Both Sides 1.5 74599-06010 42661-17260 42661-17310 00-02 03 10 NOTE: R&R Does Not include aim lamps. 42661-17340 11298-22100 11298-22101 11298-22102 11298-22103 Label, Vehicle Emissions 02 03 13 04-05 11298-22105 00-01 17792-22040 02-05 17792-22041 Label, Vacuum Hose 6 Label, Spark Plug Caution Label, A/C Caution Label, Throttle Link Label, Theft Warning Label, Removeable Roof 17792-2204 11289-50010 88723-03010 31191-17010 74515-17010 63299-17080 12 044-07419 13-FRONT BUMPER 1 Cover, Front (P) (P) Paint to Match 52119-17924 1.5 180.57 Use Procedure Explanations 1 and 28 with the following text. **O** -12 Bolt, Cover Grommet, Bolt Support, Side Bracket, Side R/L 90159-60431 R/L 90189-06210 R/L 52115-17020 R 5.29 2000-02 044-07415 R 52143-17020 L 52144-17010 12.09 12.09 & Housing R 81130-17220 #1.3 262.2 L 81170-17220 #1.3 262.2 #includes R&I Front Bumper Assy & R&R Compartment Cover, R&R Both Sides 1.5 II, Housing (1982-1 Refinish Front Cover...... 2.2 R&I Cover Assy .. 262.27 262.27 1 Lens & Housing 6 Cover, Hole Black (Code 202) O/H Bumper Assy (Includes R&I). Add to R&R or O/H Front Cover 1.8 L 52040-17010-C0 19.8 Blue naR Both Side: Bushing, Housing (2/Side) Bracket, Mounting Repair Kit, Housing Lower Code 8M6 Code 8R2 52040-17010-J0 Code 8M6 L 52040-17010Code 8R2 L 52040-17010Red (Code 3P0) L 52040-17010Red (Code 3P0) L 52040-17010Silver (Code 1E7) L 52040-17010White (Code 576) L 52040-17010Yellow (Code 576) L 52040-17010T Hook, Tow L 51093-17021 Sopoler Screw, License Bracket Assy Gerille, Bumper A6851-17070 Spoller 76851-17070 Spol 52040-17010-J1 52040-17010-G0 R/L 90189-06210 R/L 53271-12060 .63 9.26 NOTE: All Parts in this section are included in overhaul unless noted 198 19.81 19.81 19.81 19.81 27.04 27.01 52040-17010-D0 52040-17010-B1 R 81195-17010 L 81196-17010 R 81193-17010 L 81194-17010 6.34 6.34 7.32 7.32 L 52040-17010-A0 L 52040-17010-F0 L 51093-17021 12 3.88 16.30 .83 43.47 1.00 7.77 7.77 7.66 7.77 9.52 .83 128.10 @ B 13-IOH .2 20.86 SIDE MARKER LAMP PTS03-000BK PTS03-0001C PTS03-0001G Black Chrome 37.00 46.00 .R/L Bra Kit, Front Dealer Installed PT218-17030 #.3 149.00 #Not Included in R&R or O/H 10 **100**0 FRONT LAMPS 11 **COMBINATION LAMP** 044-07418 2000-02 044-06026 1 Cover, Front (P) (P) Paint to Match 2 Bolt, Cover Aim Lamps . 52119-17911 1.5 183.12 R 81731-14170 L 81741-14160 R/L 00234-00194 1 Lens & Housing, Lamp 90159-60431 R&I Both Sides 1.5 Grommet, Bolt Support, Side Bracket, Side 5.29 12.09 12.09 5.06 27.01 R/L R/L R 90189-06210 52115-17020 52143-17020 2 Bulb, Side Marker R. #R&R One Side Comple NOTE: R&R Does Not include aim lamps. Included in R&R or O/H Front Cover 52144-17010 52127-17010 52121-17070 Cover, Hole 52121-17070 Bracket Assy, License 52121-17070 Screw, License Bracket (a) (3) 90080-15090 (a) Included w/License Bracket Assy Grille, Center 53111-17010 Grille, Side R 53112-17020 Spoiler 75441-16286 Hook, Tow 51093-17021 Rainforcement, Bumper 52021-17050 Socket, Bulb Wire, Socket R/L 90075-99012 R/L 81735-17070 .2 12.23 10 O **FOG LAMP** 9 Grille, Cent 10 Grille, Side 16.30 36.93 R&i Fog Lamp Assy#Included in R&R or Off Front Cover .R/L 36.93 43.47 20.86 27.04 128.10 Ø Plate Kit, License Dealer Installed Black 8 9 To the second PTS03-000BK 12 PTS03-0001C PTS03-0001G -2-044-08372 044-07416 Bra Kit, Front 1 Lens & Housing, Lamp er Installed PT218-17020 #Not Included in R&R or O/H #.3 139.00 R 81130-17170 L 81170-17170 #1.3 #1.3 177.71 177.71 Assy, Fog R 81211-52070 L 81221-52070 #Included in R&R or OH Front Cover 1 Lamp Assy, Fog 110.65 110.65 #includes R&I Front Bumper Assy & R&R Compartment Cover, R&R Both Sides 1.5

2.77

R/L 90075-10811

2 Bearing¶

R/L 90189-06210

2 Bushing, Housing (2/Side)

¶included w/Fog Lamp Assy 3 Bulb, Fog Lamp #included in R&I/R&R Fog Lamp Assy	#.2	19.61
HOOD		
Use Procedure Explanations 4 and 28 with the following tea	rt.	
Refirish Hood Outside	2.2	
Add for Underside	1.3	. 1
R&I Hood AssyR&I Washer NozzīeR/L	.4	
#Included in R&R Hood	#.2	
2-0		I
3-8/		
5		
	<u>.</u>	
4 9	16	
12 8 7	USe	
		3
13 14		
16	8 7	
10	-	_
15—VILLS &—17	6	
044-06027		
1 Panel, Hood 00-02 53301-17070	1.0	283.46
03-05 53301-17070 2 Plug, Hood R/L 90950-01444	. 1.0	283.46 1.46
3 Bumper, Hood (2/Side) R/L 90541-15018	.1	4.83 14.58
5 Clip, Seal' (6) 90467-A0009	•	.97
fincluded w/Hood Seal Assy 6 Hinge Assy, Hood R 53410-17050	#.2	24.86
L 53420-17050 #w/Hood Removed	#.2	24.86
Pad. Hinge (a)		1.29
8 5mm Thickness R/L 53497-12070		1.06
(a) Included w/Hood Hinge Assy 9 Rod, Hood Support 53440-17030	.2	10.37
10 Grommet, Hood Rod 90480-15024 11 Clip, Rod Hold-Down 53455-20040 12 Latch Assy, Hood 53510-17100		2.06 1.40
12 Lafch Assy, Hood 53510-17100 13 Spring, Large Latch (b) 90506-18080	.3	42.47 2.97
13 Spring, Large Latch (b) 90506-18080 14 Spring, Small Latch (b) 90506-09050 (b) Included w/Hood Latch Assy		1.60
15 Cover, Latch 53525-32040	4.0	11.89
17 Retainer, Cable 90959-01369	1.0	21.29 1.84
Nozzle, Washer-See Windshield Section		
COOLING		
Use Procedure Explanations 5 and 28 with the following to	xt.	
R&I Radiator	2.0	
7		
3 5		
5		\
	് ക്കി	B
	T	
	8	
6		
4 1	-06028	
1 Radiator 16400-22110 2 Support, Radiator R 16533-22020	2.0	433.62 26.15
2 Support, Radiator R 16533-22020 L 16534-22010 3 Cushion, Upper R/L 16523-74010		14.95 6.52
4 Cushion, Lower 17/L 303 10-04004	#.8	9.40 50.99
L 16361-22050	#.8	46.59
7 Shroud, Fan 16711-22060	#.8	8.71 73.45
8 Motor, Fan R 16363-22060 L 16363-22050	#.8 #.8	156.90 168.13
#R&R Complete, Deduct .5 w/Radiator Removed 9 Bolt, Fan Motor (3/Side) R/L 90099-04117	, e	.34
	11.5	~
	152	




28 O44-06030 28 Pump Assy, Water 16100-29095 m 2.0 63.37 29 Gasket, Pump¶ 90301-69006 m 3.83 #Included w/Water Pump Assy 30 Tensioner, Bett 16620-22012 m .8 166.82

A/C REFRIGERANT CAPACITIES


A/C R-134a Refrigerant Capacity 16.64-18.72 Ozs (1.04-1.17 Lbs), 472-531 g

A/C /HEATER/VENTILATION


ι	ise Procedure Explanation 6 with the following text.	
	R&I Condenserm	#1.8
	#w/Radiator Removed Deduct .8	
	Evacuate & Recharge Systemm	1.4
	Recover Refrigerantm	.3
	NOTE: R&R Does Not include recover, evacuate and rech	arge system.



	88460-17140	m	#1.8	479.76
#w/Radiator Removed De	educt .8			
2 Pipe, Condenser Inlet	88715-17311	m		95.68
3 Pipe, Condenser Outlet	88716-17241	m		58.25
4 Switch, Pressure	88645-08010	m	.5	74.32
5 Support, Pipe	88688-17400			4.18
6 Pipe, Evaporator Outlet	88717-17230	m		75.80
7 Pipe, Discharge Connecting	88715-17290	m		68.98
8 Pipe, Suction Connecting	88717-17240	m		88.87
9 Pipe, Compressor Discharge	88715-17300	m		78.66
10 Pipe, Compressor Suction	88717-17250	m		107.68
11 Hose, Compressor Discharge 00-02	88703-17050	m	#1.3	84.06
13.05c, compressor biscialige 00-02	88703-17060	m	#1.3	80.64
	88704-17050	m	#1.3	88.32
	88704-17060	m	#1.3	82.27
#R&R Complete 1.8	00704-17000	""	# 1.O	QE.E.
	00000 47440 04	٠ .	40	D070.04
	88320-17110-84		1.9	R678.94
	88320-17120-84	m	1.9	R693.94
14 Clutch Assy, Compressor	00440 50000			000.00
2000-02	88410-52090	m	#.3	356.88
2003-05	88410-17090	m	#.3	388.32
#w/Compressor Remove	a ,			
15 Hub, Clutch	20,020,000			. 1111
2000-02¶	88403-16020	m		49.04
2003-05-Serviced w/Compresso	or Clutch Assy			
16 Pulley, Clutch				
2000-02¶	88412-52020	. ; / m	5 ,	185.37
2003-05-Serviced w/Compresso	or Clutch Assy			
17 Magnet, Clutch				
2000-02¶	88411-16070	m		136.62
2003-05-Serviced w/Compresso	or Clutch Assy			
¶Included w/Compressor (Clutch Assy			111
1				



110	Evaporator Assy	00010-17000	111 1.5	047.54
19	Evaporator (a)	88501-17080	m #2.3	247.54
20	Valve, Expansion (a)	88515-16060	m #2.3	74.06
	Pipe, Expansion Valve (a)	88710-17150	m #2.3	67.72
ļ	#R&R Complete	3011011100		· · · · ·
22	Housing, Upper (a)	88521-17030	m	104.45
23	Housing, Lower (a)	88521-17040	m	104.45
24	Gasket, Evaporator (a)	88578-22210	m	4.95
	(a) Included w/Evapora			
25	Resistor, Blower			
	2000			
	To 6-00	87138-16140	m .5	23.60
7.	From 6-00	87138-17050	m .5	73.39
	2001-05	87138-17050	m .5	73.39
26	Thermistor	88625-17130	m	10.55
27	Cover	88891-20240	•••	.32
	Hose, Drain	88539-17060		4.95
28	nuse, prain			
29	Seal, Drain Hose	88467-52030		2.05
30	Seal, Pipe	88897-17010		5.13




31 32	Heater Assy Core, Heater (b) #Includes R&I Instrument	87150-17290 87107-17100 Panel		#5.6 #5.9	574.11 309.15
34	Duct, Air (b) Cover, Heater (b) (b) Included w/Heater Assy	87220-17020 87114-17020	m		54.04 22.75
35 36	Blower Assy Fan & Motor (c) (c) Included w/Blower Assy	87130-17100 87103-17040	n N	*	492.57 1 32. 15

FRONT FENDER


Use Procedure Explanations 7 and 28 with the following	lowing te	ext.
Refinish Front Fender	R/L	2.0
Add to Edge Fender	R/L	.5
Refinish Mudguard	R/L	.6
R&I Fender Assv	R/I	#1.9
#Includes R&I Front Bumper Assy & R&I Lamp, R&I Both Sides 2.7	R&R Co	mbination
R&I Mudguard	R/L	.3

FRONT FENDER Cont'd



1 Fender	00-02 R			#2.5	
	20 00 0	53802-		#2.5	
	03-05 R	53802-	1/120	#2.5 #2.5	
#Includes R&I Fr					
Lamp, R&R Bot			y a navn	idin Commina	nuo:
2 Liner, Fender		53805-	17020	.4	36.01
,	L			A	
3 Retainer, Liner (2/Side)					1.71
4 Pad, Wheel Opening 5 Clip, Liner (3/Side) 6 Seal, Fender		53851-			11.89
5 Clip, Liner (3/Side)		90189-			.71
5 Seal, render		61995-			2.92
7 Protector, Fender		53827-			20.01
Clin Dentantos (7/Rida)	ارم	53828- 90467-	07184		20.01 1.44
B Clip, Protector (7/Side) 9 Mudguard	IVL	3040/-	07 104		1.44
Black (Code 202)	R	76621-	17030-C0	.3	82.48
			17030-C0		82.48
Blue					
Code 8M6			17030-J0	.3	82.48
0.1.000			17030-J0	.3	82.48
Code 8R2			17030-J1	3	82.48
Dark Groon (Code CD4			17030-J1		82.48
Dark Green (Code 6R4	7. T		17030-G1 17030-G1	.,	82.48 82.48
Green (Code 6S1)			17030-G0		82.48
Circuit (COOR CO.1)	ï	76622	17030-G0	- 9	82.48
Red (Code 3P0)			17030-D0	3	82.48
54 (5555 51 5)			17030-D0	. 3	82.48
Silver	_				
Code 1D0	R		17030-B0		82.48
	Ļ		17030-B0		82.48
Code 1E7			17030-B2		82.48
UE-11- (O-1-040)			17030-B2		82.48
White (Code 040)			17030-A0		82.48
Vollow (Codo E76)			17030-A0 17030-F0		82.48 82.48
Yellow (Code 576)			17030-F0		82.48
10 Clip, Mudguard (3/Side		90168		•	, 02.40 49
				1.0	

UNDERHOOD DIMENSIONS



FRONT INNER STRUCTURE


Use Procedure Explanations 8 and 28 with the following text:


	SHEET META	L	
Refinish Radiator S	Support Assy	1	.5
Refinish Upper T	ie Bar		.5
	inforcement	R/L	.5
Refinish Lower T	e Bar		.5 .3
	Brace		.3
Refinish Apron/Sid	emember Assy		2.0
	SSV		.0
	Extension		.5
Refinish Front A	pron	R/I	.5
	mber Assy		ŏ

Section Sidemember	
#w/Radiator Support Removed, w/Fron	nt Apron Removed Deduct
1.5	•
Add to R&R Radiator Support	
To R&I Base Model Mechanical Components	m #.5
#Includes R&I/R&R A/C Condenser	
To Aim Lamps	

NOTE: For sectioning methods refer to Manufacturer's Body Repair

Evacuate & Recharge System . Recover Réfrigerant






Support Assy, Radiator	53201-17020	s #7.5	184.30
#Includes R&I Front Co			.amps,
Radiator Fans, Motors			
Compartment Cover,			
Disconnect & Connec	t Hood Release Ca	ble, Wiring &/o	r
Harness			

L 57152-17031 s	#1.5 #1.5 ved .3 1.0	41.81 41.81
L 57152-17031 s	#1.5 ved .3	41.81
L 57152-17031 s #w/Upper Tie Bar & Upper Tie Bar Extension Remo	ved .3	41.81
#w/Upper Tie Bar & Upper Tie Bar Extension Remo	ved .3	- 21.76
	.3	
4 Brace, Vertically 53215-17030 5 Bar. Lower Tiefl 57161-17040 s	1.0	
		68.52
6 Bracket, Horn Mount¶ 53235-17010		7.72
fincluded w/Radiator Support Assy		122.2
7 Extension, Upper Tie Bar R 53213-17040 s		29.71
L 53214-17040 s	1.0	29.71
8 Apron Assy R 53701-17900 s	#8.5	133.18
L 53702-17900 s	#8.5	133.18
Fincludes R&R Upper Tie Bar Extension & Dash Gu		,
9 Bracket, Fuse Box (a) L 53255-17010		5.43
	#2.0	26.7
	#2.0	26.75
	#4.0	20./3
#w/Dash Gusset Removed		
	3.5	20.8
	3.5	20.89
12 Brkt, Fender Mount (a) R 55168-17010		15.80
L 55169-17010	٠.,	15.80
(a) Included w/Apron Assy		
	2.5	56.70
L 53708-17040 8	2.5	56.7
	1.0	33.2
	1.0	
L 57118-17900 s	1.0	33.2
15 Bracket, Brake Hose R/L 57249-06010		6.4
	3.5	101.9
	3.5	100.2
	#8.5	163.7
L 57028-17901 s	#8.5	163.7
#Deduct 3.0 w/Apron Assy Removed, Deduct 1.5 w	/Front	Apron


	#Deduct 3.0 w/Apro Removed	on Assy Removed, Deduc	t 1.5 w	/Front	Apron
3	Mount, Bumper (b)	R 52141-17020 L 52142-17020		.6 .6	31.04 31.04
	(b) Included w/Siden	nember Assy			
9	Hook, Tie-Down Plate, Brace	L 51962-17031 R 52257-17010 L 52258-17010		.2	22.58 59.13 59.13
1	Rod, Brace	R 53687-17020 L 53688-17020		.2 .2 .2	58.79 58.79
3	Crossmember, Lower Crossmember, Upper Reinf, Sidemember	57301-17090 57307-17120 R 57033-17020 L 57034-17020	\$ \$	2.0 1.5	242.90 128.09 26.78 26.78
5	Plate, Spare Tire Mount Box, Torque	R/L 51919-17010 R 57197-17020 L 57198-17020		4.5 4.5	11.26 83.57 83.57

INTERIOR TRIM




	FLEOT	DIGAL COMPONENTO	_	
14	Support, Spare	R/L 51936-17010		20.09
13	Retainer, Spare	51931-17010		9.46
12	Cover, Spare Tire	64771-17020		40.75
	(a) Included w/Bo			
11	Plug, Drain (a)	90950-01250		2.21
10	Cushlon, Box (a)	75227-17010		3.20
9	Spacer, Bolt (a) (4)	90202-10019		69
8	Box Assy	75201-17011		343.10
7	Clip, Cover (9/Side)	R/L 90467-07076		d.63
6	Cover. Compartment	64427-17021	.3	265.30
•	¶Included w/Box	Cover Assy		
	Pad, Cover	90183-06022		.69
4	Rivet (4)	90269-04054		.57
3	Lock, Cover (2)	64606-17031		24.15
2	Weatherstrip, Cover	75232-17010		9.52
	2001-05	75205-17011		144.01
	From 1-00	75205-17011 75205-17011		144.01
	2000 To 1-00	75205-17011		144.01
1	Cover Assy, Box			

ELECTRICAL COMPONENTS



1	Harness Assy, Front Main		82181-17640 82181-17650	m		1002.26 1002.26
3	Box, Fuse¶ Cover, Lower Fuse Box¶	01-05	82660-17140 82663-17030	· m		88.00 22.75
	Cover, Lower Box¶ fincluded w/Front Ma	ain Ha				9.55
6	Cover, Upper Box Cover, Upper Fuse Box		82662-17030 82662-17020		<u>:</u>	12.69 17.55

PROTECTIVE COVERS



2	Bolt,	ld, Prot Shield Shield	ective (4/Side)
J	Glip,	Silielu	

R/L	57381-17020 90159-60395
	90467-07166
	20101-01-100

.3 113.80 .72 .92

AIR BAG SYSTEM


Use Procedure Explanation 30 with the following text.

Disable & Enable Air Bag Systemm	.3
Diagnose Air Bag System (If Required)m	#. 5
#Includes Disconnect & Connect Scan Tool & Retri	eve/Clear
Trouble Codes	

NOTE 1: R&R Does Not include disable and enable or diagnose Air Bag System.

NOTE 2: Refer to Procedural Explanation 30 for Supplemental Restraint/Air Bag System Component Inspection and Replacement

NOTE 3: For Air Bag System Service procedures, refer to Manufacturer's Service Repair Manual or Mitchell's Air Bag Service and Repair Manual.




2	Module, Passenger Air Bag Control Unit Cable, Spiral	73970-17041-C0 89170-17050	m	.8 .6	759.62 322.39
	5 Speed Trans w/Sequential Shift Trans w/o Sequential Shift Trans 6 Speed Trans	84306-32030 84306-52020 84306-44010	m m	.7 .7 .7	239.84 239.84 239.50
5	Sensor, Air Bag 00-02 R	89173-19315 89174-19115 89173-19315 89174-19115	m m m	#.6 #.6 #.6	61.25 61.25 61.25 61.25
	#R&R Both Sides .8		***		

.3m

ABS/BRAKES

Bleed System ... NOTE: R&R Does Not include bleed brake system.



							7
	044-06040			4			
1	Actuator Assy, ABS		44050-		m	2.4 2.4	1027.84
2	Holder, Actuator¶ (2)	00-02	44050- 44545-	42020	m-	2.4	1580.97 4.29
3	insulator, Holder¶ (3)	00-02	44545- 44546-	42020			6.34 3.34 6.34
	¶included w/ABS Ac			42070			0.34
4	Bracket, Actuator	00-02	44590- 44590-				46.56 48.93
5	Wire, Front Sensor	Ŗ		17010	m		29.52 29.52
6	Sensor, Front ABS		89544-		. m	#2.2	133.33
-	#R&R Both Sides 3		00545	47000			400.54
- /	Sensor, Rear ABS	H	89545- 89546-		m	#.8 #.8	193.54 193.54
	#R&R Both Sides 1	12 -	09040-	17030	Ot	#.0	195.54
٥	Computer, ABS	.2	89540-	17160	m	.8	240.94
ğ		tor .	47201-		m	1.4	186.75
	Reservoir Assy (a)	, iGi	47220-		m	1.7	96.17
11	Cap, Reservoir (a) (b)		47230-				10.37
12	Filter, Reservoir (a) (b)		47299-				2.14
	(b) Included w/Rese	rvoir A	ssy			1.0	
13	Grommet, Reservoir (a) (2		31417-				2.14
	(a) Included w/Brak	e Maste					
14	Booster, Brake		44610-	17351	m.	#2.2	514.00

#Includes R&R Brake Master Cylinder


WHEEL

Use Procedure Explanation 10 with the following text.

ALLOY WHEEL


.2

Add to R&I Spare Wheel & Tire Assy.



1 Wheel, Alloy Front Rear	00-02 42611-17401 03-05 42611-17360 00-02 42611-17330 03-05 42611-17390	.3 337.42 .3 337.42 .3 345.58 .3 384.70
2 Cap, Center	42603-20640	13.55
Nut, Lug Front Rear Stem, Valve Lock Kit, Wheel	90084-94001 90942-01083 90080-45006	2.77 4.57 8.49
Dealer Installed	00276-00900	40.00

SPARE WHEEL & HARDWARE



1 Wheel, Spare	00-02 42611-1A240		87.22
· innonjopano	03-05 42611-17220		100.24
2 Jack	09111-17050		95.08
3 Handie, Jack	09113-52010		11.03
4 Wrench, Lua	09150-02020		34.30
5 Bolt, Spare Carrier	51934-17010		2.06
6 Bag. Tool	09120-17030		26.41
7 Stopper, Wheel	09184-00010		20.09
EBO!	NT CHEDENCIO	1	

OSC 1 10000016 Expansion 11 mai are following text	
R&I Suspension (One Side)R/Lm	1.8
O/H Suspension (Includes R&I)	
One SideR/Lm	3.2
Both Sidesm	
Adjust Four Wheel Alignmentm	1.4
Bleed Brake Systemm	

NOTE 1: R&I/R&R or O/H Does Not include alignment or bleed brake


NOTE 2: All Parts in this section are included in overhaul unless noted otherwise.

Illustration Located in Next Column


1 Rotor, Brake	R/L Noth Sides 1.0	43512-17131	m	#.6	94.26
		47730-17150	_	#.5	291.40
2 Caliper Assy	00-02 F		m		
	L	47750-17150	m	#.5	291.40
	03-05 R	47730-17160	. m	#.5	460.70
11.34 775	L	47750-17160	m	#.5	460.70
3 Bracket, Moun	tino1 R	47721-52020	m	¥.5	87.68
		47722-52020	m	#.5	87.68

¶Included w/Caliper Assy #R&R One Side Complet Both Sides .8 Rotor Removed Deduct .3, R&R

4 Pad Set, Brake	ch Caliper Removed	m	#1.0	45.95
5 Plate, Backing	R 47781-17050	m	#.2	20.29



	· · · · · · · · · · · · · · · · · · ·	L 47782-17050	m	#.2	20.29
	#w/Hub Removed			1	
6	Hub Assy #Includes R&R Rot	R/L 43550-17010	m	#1.0	230.36
	#Includes R&R Rol	tor, R&R Both Sides 1.8			,,,,,
7	Stud, Wheel (a)	R/L 90942-02049	m		3.26
	Stud, Wheel (a) (a) Included w/Hub	Assy			



		L 4	3212-1	7110	m	#1.6	168.45
	#Includes R&R h						
10	Arm. Lower Control	. R 4	18068-1	9176	m	#1.1	264.37
	Arm, Lower Control	Ľ 4	18069-1	9156	m	#1.1	264.37
ı	#w/Knuckie Rem	oved Dedu	uct .6. F	AR Bo	th Sides 2	2.0	
11		4					86.88
1"	#Includes R&R S	tahilizar A	er l ink	e Rush	inas A C	iamne	Not
	Included in O/I		-	w, 2441	my w w		, 1700
1,2	Link, Bar	DA A	10000.1	7050	m	1.4	33.64
	The state of the state of the						
۱۰۰	Washer, Cushion (2/Side Cushion (2/Side) Washer, Cushion Nut, Link Bushing, Stabilizer Bar Clamp, Stabilizer Bushing	V DA (20040 0	0000			1.83
13	Washer, Cushion (2/5)08) IVL	(10040- U	2002			1.00
14	Cushion (2/5/06)	TVL 4	100 / -	0470			6.20 3.40
15	Washer, Cushion	TVL S	70340- 0	21/0			3.40
110	Nut, Link	H/L S	54 82-1	7100		40	1.54
1/	Olean Cabilian Bushing	H/L 4	1-C1 001	7130	m	#.3 #.3	6.74
סו	Clamp, Stabilizer Busiling	PVL 4	10024-1	2040 Maded 1	- 04, 111	#.J	4.46
1	#nan vire slue	ouniprete,	MOI NU	ABUCU N	1 (7)		
19	Strut	00-02 R 4	18510-8	0049	m	#1.6	149.97
				9646		#1.6	149.97
		03-05 R 4	48510-8	0081	M	#1.6	149.97
١.,	0-4- 0-8	D# 4	18520-1	9835	M	#1.6	149.97
20	Spring, Coll	H/L 4	48131-1	/690	m	#1.6	41.09
2]	Bumper/Boot	H/L 4	18304-1	7010	m	#1.5	18.58
122	insulator, Spring	H/L 4	4815/-1	7030	m	#1.6	8.57
23	Seat, Spring	H/L 4	48U44-1	/030	w	#1.6	12.09
24	Spring, Coil Bumper/Boot Insulator, Spring Seat, Spring Plate, Washer Mount, Upper Plate, Spacer Plate, Spacer	H/L S	50303-2	2049	· m	#1.5	4.03
125	Mount, upper	H/L 4	40009-1	/051	· m	#1.5	73.05
126	Plate, Spacer	- H/L 4	48061-1	/U4U	m	#1.5	8.49
ı	#nan Viic side	compicie,	W/Knuk	жие Her	noved De	ouct 1	.2, H&H
1	Both Sides 2.0						

m #1.6

168.45

FRONT STEERING LINKAGE/GEAR


R/L 48684-12070

27 Cap, Nut


R&I Steering Gearm	1.7	
O/H Steering Gear (Includes R&I)m	3.9	

NOTE 1: R&I/R&R or O/H Does Not include adjust wheel alignment. NOTE 2: All Parts in this section are included in overhaul unless noted

FRONT STEERING LINKAGE/GEAR Cont'd




STEERING PUMP



1 Pump Assy 2 Clamp, Reservoir¶ 3 Reservoir, Fluid¶ 4 Cap, Reservoir¶	44310-17060 90460-99007 44367-17010 44305-17020	m m	1.3	697.63 8.79 46.21 17.41
¶included w/Pump Assy 5 Pipe & Hose, Fluid	44410-17060	m	1,5	307.43


STEERING WHEEL/COLUM	ΙN	
R&I Steering Columnm	2.0	
O/H Steering Column (Includes R&I)m	3.8	

NOTE: All Parts in this section are included in overhaul unless noted otherwise.




Wheel Assy, Steering 2000 2001-03	45100-2B690-C0	m	.5	538.5

w/Sequential Shift Trans w/Shift Switch on Whee w/o Shift Switch on Wh w/o Sequential Shift Tran 2004-05	el 45100-2B741-C0 eel 45100-2B731-C0	m M	.5 .5	878.28 840.33 538.53
Black			-	
Type 1	45100-2B741-C0	m	.5 .5	878.28
Type 2	45100-2B741-C3	m	.5	878.28
Gray				
Type 1	45100-2B740-C1	m	.5	878.28
Type 2	45100-2B690-C1	m	.5 .5	722.86
Type 3	45100-2B741-C1	m	.5	878.28
Red				
Type 1	45100-2B740-C2	m	.5	878.28
Type 2	45100-2B741-C2	m	.5	878.28
2 Switch, Trans Shift¶	84610-20021	m		179.02
3 Switch, Cruise Control	84630-20151	m		110.43
¶Included w/Steering				
Module, Driver Air Bag-Se		n		



					•
5	Cover, Column	45286-17902-C0	m	.3	66.28
	Switch, Wiper	84652-17120	m	#.9	127.72
7	Switch, Turn Signal	84140-06070	m	#.9	
,	#R&R Complete 1.			T.J	127.01
	Cable, Spiral-See Air Bag	00 00 00007 17170			104 60
9	Cyl & Key w/Transmitter	00-02 69057-17170	m	1.6	184.68
40	A	03-05 69057-17170	m	.6	184.68
10	Amp, Transponder	89783-52020	w	_	125.01
11	Switch, Warning	84052-32030	m	.7	19.89
12	Bolt, Lock Shear (2)	45897-12020	m		3.06
13	Clamp, Lock Housing	45271-16020	IIQ.	1.	8.35
14	Housing, Lock	45280-17040	m	2.1	181.39
15	Switch, Ignition	84450-52010	m	.6	81.54
	Bolt, Adjust Lever	45832-12010			3.12
17	Plate, Nut Retaining	45821-52010	m		2.06
	Lever Assy, Adjusting	45826-20170	m	.9	8.43
	Stopper, Pawi¶	45893-52010	m	372	3.03
	finduded w/Adjusti		***		~,~
20		90520-17269		13.40	1.40
21	Ring, Upper Retaining	45261-20010	m		2.31
21 22	Spring, Tension				
42	Support, Upper Column	45878-52010	m		12.78
23	Collar, Upper Support	45814-52010	m		1.34
24	Bolt, Adjusting	45831-52010	m		3.83
25	Support, Lower Column	45277-28030	m		7.72
26	Collar, Lower Support	45877-52010	m		4.20
27	Bushing, Lower Support (2)	R 45813-52010	m		.89
		L 45813-52020	m		.89
28	Ring, Lower Retaining	90520-17042	m		.86
29	Housing, Column	45205-20351	m	2.3	62.33
30	Shaft, Upper	45210-20340	m	1.9	326.47
31	Bushing, Shaft	45273-20060	m		12.92
32	Joint, Universal	45209-17020	m		109.06
33	Cover, Lever	45266-30010	m		1.86
ũ	Shaft, Lower	10200 00010	***		
٠4	2000-01	45260-17150	m	1.3	217.75
	2002	40200-17100	164	1.0	217.75
		45260-17150		1.3	217.75
	To 5-02		m		
	From 5-02	45260-17151	m	1.3	217.75
^-	2003-05	45260-17151	m	1.3	217.75
35	Clamp, Seal	90460-78006	m		0.00
36	Seal, Dust	45292-17030	m	٠٠ - څي	11.60
37	Plate, Retaining	45253-17010	m		8.49
38	Seal	45026-17010	m		17.06

	· · · · · · · · · · · · · · · · · · ·		
	FUEL TANK		
R&I Fuel Tank		2.4	
NOTE: R&I/R&R Does	Not include drain and refill.		



77300-20010 77300-53010 77300-53010

	2	Shield, Filler Pipe		77290-17020)		20.03
1	3	Shiet, Filter Pipe, Filter Pipe, Breather Bracket, Upper Pipe Bracket, Lower Pipe Hose, Filter Cover, Filter Hose	1. 137,611	77201-17130	j.		95.80
-	4	Pipe, Breather		77226-17010)		20.89
ı	5	Bracket, Upper Pipe		77217-17020)		10.75
	6	Bracket, Lower Pipe		77218-17010)		6.03
-	7	Hose, Filler		77213-17020 77219-44010) .		31.41
1	8	Cover, Filler Hose		77219-44010) 4		5.29
	9	Tank, Fuel		77001-17070) m	#2.6	343.84
		#Includes R&R Fue	el Pumj	o & Gauge Se	ender		
	10	Hose, Breather		77259-17030			12.49
	11	Cushion, Tank		77651-02040)		4.86
ŀ	12	Plate, Retaining		77168-52010)		13.35
	13	Protector, Mount		77643-17010			7.77
	14	ripe		77209-17010			18. <u>43</u>
	15	Clip, Pipe		77241-32060		17.99	·,77
	16	Plate, Fuel Pump Mount		77024-17020			56.07
	13%	Regulator, Fuel Pressure		23280-22010			119.61
	118	Pipe		77027-17030			11.63
	139	Seel	00.00	90301-09021		4.0	2.59
	120	Sender, Fuel Gauge		83320-17050		1.6	
	٠,	Filter, Fuel Tank	03-05	83320-17060 23300-23040		1.6	77.48
,		Pump, Fuel		23221-21020		1.6	28.89 314.19
,	1%	Filter Fuel Dump		23217-21030		1.0	9.52
1	2%	Filter, Fuel Pump Clip, Filter		23219-03010	ί .		.74
1	55	Rubber, Cushion		23249-74610	ί .		9.92
į	1%	Support, Fuel Pump		77175-52020			8.60
		Seal, Plate		77169-33020			6.06
3	28	Harness, Fuel Pump		77785-32010	ń		4.43
		Protector Check Valve		77393-52010	5		12.83
	30	Valve, Check Gasket, Check Valve		77390-20070	Ď		31.78
:	l ăi	Gasket, Check Valve		77177-33010	5		10.06
ί	132	Hose, Check Valve		77394-17010)		13.78
í	33	Hose, Check Valve Hose, Vent		77404-17010) .		13.12
į	34	Plate. Fuel Tank Side	R/L	77113-52020)		6.77
2	35	Bracket, Shield	R/L	77616-17010)		7.00
3	36	Shield, Tank		77641-17030)	#.4	109.75
1 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3				77642-17030)	#.4	109.75
3	1	#R&R Both Sides .					
,	37	Clip, Shield (3/Side)	R/L	90467-10018	В		. 1.11

	9-5	-8
2-//		
1-4-		
044-07420		- 4

WINDSHIELD

Use Procedure Explanation 13 with the following text. R&I Windshield Glass#Includes Clean Up Old Adhesive as Necessary

44.87

#3.5

		TOYOTA MR2 2000-05
#Included in R&I/R&R Windshield 3 Stopper, Windshield R/L 56115-33020 3.26	03-05 55700-17141 6.5 414.43 4 Panel, Side¶ R 55717-17030 26.78	
3 Stopper, Windshield RL 56115-33020 3.26 4 Dam, Windshield (2) 04562-12010 38.41 5 Panel, Roof 63101-17150 122.31 6 Trim, Pillar R 62211-17080-CO .2 58.79	L 55718-17030 26.78	39 41 41 42
6 Trim, Pillar R 62211-17080-C0 .2 58.79 L 62212-17080-C0 .2 58.79	ginctuded wickow Panel Assy 5 Gusset, Dash-See Front Inner Structure Section 6 Panel Assy, Dash 6 Panel Assy, Dash	9 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
7 Trim, Upper 00-02 63391-17010-C0 .2 60.67 03-05 63391-17010-C1 .2 64.86	2000 55101-1/903 314.55 2001-05	
	w/Sequential Shift Trans 55101-17901 314.55 w/o Sequential Shift Trans 55101-17903 314.55 7 Reinf, Dash Panel (a) R 53733-17010 33.67	
9 Base, Mirror 87853-0W010 3.69 10 Visor, Sun 2000-02	L 53734-17010 34.32	
2000-02 Right R 74310-17440-C0 2 41.13 Left		a—60
w/Sequential Shift Trans L 74320-17420-C0 .2 44.53 w/o Sequential Shift Trans L 74320-17400-C0 .2 41.13		37 5354 44
2003-05	INSTRUMENT PANEL	
Right R 74310-17440-C1 .2 37.87 Left 5 Speed Trans L 74320-17400-C1 .2 37.87 6 Speed Trans L 74320-17420-C1 .2 40.38	Use Procedure Explanation 14 with the following text. R&I instrument Panel Assy	59 58 57 55 4549
6 Speed Trans L 74320-17420-C1 .2 40.38	NOTE: All Parts in this section are included in R&R instrument Panel	T 47 40 = 50
WIPER SYSTEM	unless noted otherwise.	
1_	36	044-06052
3 3 3	35 7 4 6	37 Rhecetat 84119-17050 m 3 77.48
6	33 6 1 -8	38 Switch, Door Lock 84930-52010 62.85 39 Switch, Window Lock 84821-20020 50.96 40 Switch, Mirror 84870-34010 121.95
19 15 4 6	3431	40 Switch, Mirror 84870-34010 121.95 41 Clock 83910-17050 .3 245.27 42 Switch, Hazard 8432-20340 .3 44.43
18 21 22	30	43 Switch, Air Bag Deactivation Driver Side 69065-17020 m .5 166.13
17 20 22	32 30 14 1413 12 9 11	Paggangar Sida RUNKS_17010 m 5 159.97
8 15	27 26 27 19 15 16	03-05 55412-17170-C0 .3 84.25 45 Plate, Temp Control (c) 00-02 81942-17140 1.34
F6-14	29 21 17 16	03-05 81942-17210 2.46 46 Plate, Fan Control (c) 00-02 81942-17130 1.34
9/1/2		(1446 81442-1721) 2 AB
	28 21 18	47 Plate, Air Diverter (c) 00-02 81942-17110 10.35 03-05 81942-17180 2.46 48 Plate, Recirculate Air (c) 81942-17070 29 49 Plate, Fresh Air (c) 81942-17080 29 (c) Included w/Finisher Panel Assy
12 044-06049	18-60 -17 20 22 24 25	(c) Included w/Finisher Panel Assy
1 Blade Assy, Wiper R 85212-48040 .1 14.9 L 85222-60170 .1 20.4		
2 Insert, Wiper¶ R/L 85214-24050 .1 4.45 3 Backing, Insert¶ (2/Side) R 85224-35040 1.05	044-06051 23	53 Lens, Pass Air Bag 81942-17060 1.74 54 Knob, Fresh/Recirculate 55905-2B040 5.06
L 85224-02020 1.40 fincluded w/Miper Blade Assy	1 Panel, Instrument 55311-17071-C0 m 5.0 377.08 2 Lid Assy, Storage Compartment 55422-17031-C0 2 86.62	55 Module, Air Control 55910-17080 m .6 187.54 56 Lighter Asy 85500-12240 31.53 57 Element Lighter (d) 85500-20010 10.63
4 Arm, Wiper R 85211-17080 #.2 64.19 1. 85221-17070 #.2 50.89	2 Lid Assy, Storage Compartment 55422-17031-C0 2 86.62 3 Lock, Lid* 55460-17020-C0 2 9.23 4 Cushion, Lid* (2) 9054-16018 1.71	51 Button, Near Liemester 55905-17060 5.60 52 Button, A/C 55905-17070 5.60 53 Lens, Pass Air Bag 81942-17060 1.74 54 Knob, Fresh/Recirculate 55905-28040 5.06 55 Module, Air Control 55910-17080 m 6 56 Lighter Assy 85500-12240 31.53 57 Element, Lighter (d) 85520-28010 19.63 58 Socket, Element (d) 85510-16040 18.43 (d) Included w/Lighter Assy
#Includes R&R Wiper Blade Assy or Insert 5 Cover, Nut R 85292-01020 2.6 6. Nut, Arm R 90179-08113 1.0	#Included w/Storage Compartment Lid Assy 5 Module, Passenger Air Bag-See Air Bag System Section 6 Vent, Side 00-02 P 55570-77070-CD 2 65-25	58 Socket, Element (d) 85510-16040 18.43 (d) Included w/Lighter Assy 85533-AE010 28.58 59 Lans, Light 85533-AE010 28.58 60 Holder, Lighter 85513-02010 6.92
L 90176-08051 .7-7 7 Transmission Winer 95150-17000 169.5	L 55890-17040-C0 2 65.25 03-05 R 55670-17080-C0 2 67.62	CENTER CONSOLE
8 Motor, Wiper 85070-17130 .6 234.3 9 Reservoir Assy, Washer 85315-17100 53.0	L 55650-17050-C0 2 67.62 7 Vent, Center 00-02 55660-17050-C0 2 93.77	Use Procedure Explanation 14 with the following text.
10 Cap, Reservoir (a) 85316-42011 4.2: 11 Grommet, Motor (a) 90068-32002 1.9	03-05 55660-17060-C0 .2 98.86 8 Cover, Fuse Box R 55545-17010-C0 .11.40	R&I Console Assy
(a) included w/washer rieservoir Assy 12 Motor, Pump 85330-33020 46.3	1 9 Door, Glove Box 5550-17051-CU .3 128.75 10 Bracket, Glove Box 58902-17010 8.17	NOTE: All Parts in this section are included in R&R Center Console
13 Joint, Elbow 85355-16192 3.0 14 Joint, Coupler (2) 85349-89122 1.5 15 Hose (b) 90099-33080 6.4	#Included in R&R Glove Box Door	unless noted otherwise.
(b) Cut to Fit	12 Brace, Glove Box 55558-17010 8.49 13 Bracket, Lower 55313-17010 7.00 14 Cover, Hole (2) 55539-32010-C0 3.49	2—————————————————————————————————————
Holder Hose	15 Trim, Upper Brace 00-02 R 55394-17010 .2 15.55 L 55395-17010 .2 15.55	
18 No. 2 (4) 90469-07011 2.4	03-05 R 55394-17020 .2 15.52 1 55395-17020 .2 15.52	1
20 Hose 90099-33968 5.8		
21 Joint, "Y	17 Cover, Inner Brace RVL 55398-17010 10.09 18 Cover, Outer Brace 00-02 RVL 55349-17020 16.92	5-62
COWL & DASH	03-05 RAL 55349-17030 16.86 19 Finisher, Radio 55423-17040-C0 2 22.18 20 Plate, Ashtray 74161-17010 33.90	044-06257
Use Procedure Explanations 14 and 28 with the following text.	21 Bracket, Plate R 55381-17030 10.09 L 55382-17030 10.09	1 Console 58801-17140-C0 .6 142.51 2 Bezel, Shift Hole
Refinish Cowl Panel Assy 1:2		w/Sequential Shift Trans 58843-17020-C0 12.56 3 Boot, Shift Lever
A Company	22 Holder, Cup 55604-17010-C0 72.88 23 Ashtray Assy 74102-17060-C0 57.42 Holder, Ashtray (a) 28.87 24 Holder, Ashtray (a) 25 Ashtray (a) Serviced wi/Ashtray Assy 26 Radio 00-02 86120-28680 .8 1512.26	w/o Sequential Shift Trans 58808-17040-C0 #.4 24.35 4 Cover, Hole 58839-17010-C0 #.4 5.20
5 2 1	(a) Included w/Ashtray Assy 26 Radio 00-02 86120-28680 8 1512.26	#R&R Complete 5 Bracket, Mounting 58995-17030 11.20
	03-05 86120-17390 8 658.94 27 Bracket, Redio R 86211-17050 10.06 L 86212-17060 10.06	ROCKER/PILLARS/FLOOR
	28 Trim, Lower Desh 55046-17010-C0 3 107.35 29 Brace, Lower Trim 55465-17020 26.44	Control of the Contro
6-1-3	30 Trlm, Instrument 5541-17080 #.3 93.43 #Included in R&R Instrument Cluster Assy	SHEET METAL
The state of the s	31 Cluster Assy, instrument w/Sequential Shift Trans 00-02 83800-17030 m 1.0 554.34	Refinish Rocker Panel
8	03-05 83800-17120 m 1.0 550.97 w/o Sequential Shift Trans 00-02 83800-17040 m 1.0 534.18	THE HIRST OUTER PHAT ASSY
	03-05 83800-17130 m 1.0 530.81 32 Lens, instrument (b) 83852-17010 m 1.0 68.31 (b) included withstrument Cluster Assy	
044-06050	33 Brace, Dash R 55307-17070 29.89	
1 Louver, Cowl 55708-17081 .6 299.9 2 Plate, Louver 55786-17030 16.7	34 Bracket, Center Dash 55308-17010 9.95	
3 Panel Assy, Cowl 00-02 55700-17140 6.5 411.0	36 Reinf, Dash 55330-17110 245.96	
	landles Dage Must De Head with the Above Text for an Acquiste	Demana Penart 1965

ROCKER/PILLARS/FLOOR Cont'd SHEET METAL Cont'd 111111 Shell Assy 2000-02 758.56 758.56 758.56 758.56 R 67001-17120 044-06056 L 67002-17120 R 67001-17120 L 67002-17120 2003 2004 To 12-03 R 67001-17120 FRONT SEAT 044-06054 L 67002-17120 R 67001-17121 L 67002-17121 758.56 765.77 765.77 From 12-03 1 Panel, Outer Rocker R 61411-17060 L 61412-17060 233.38 233.38 Use Procedure Explanation 30 with the following text. #6.5 #6.5 R 67001-17121 L 67002-17121 2005 765.77 765.77 **R&I Front Seat Assy** R/L #w/Quarter Panel Re R 61413-17030 26.92 26.92 16.78 16.78 #Includes R&I/R&R Mirror 2 Reinf, Front Rocker Panel 61414-17030 61423-17020 61424-17020 R 67111-17040 L 67112-17040 2 Panel, Repair 3 Reinf, Rear Rocker Panel ¶included w/Shell Assy #Includes R&VR&R Mirror & Door Glass 53821-16010 61418-17020 61419-17020 4 Bracket, Quarter Panel 5 Reinf, Rocker Panel **EXTERIOR TRIM** 133.8 6 Brace, Reinf-See Quarter 7 Panel, Front Inner Rocker Section 57241-17010 Refinish Mirror Assy 90.03 R/L R&I Mirror Assy......#Includes R&I Trim Panel R&I Belt Moulding..... 57242-17010 57401-17010 1.5 2.5 2.5 6.5 1.0 1.0 R/L 8 Panel, Rear Inner Rocker 044-06057 201.80 201.80 57402-17010 R/L 61103-17010 61104-17010 61415-17030 61416-17030 178.34 178.34 9 Piliar Assy, Outer Track, Seat Passenger Side 00-02 R 72011-17020 L 72021-17020 03-05 R 72011-17030 L 72021-17030 203.17 203.17 203.17 203.17 203.17 #.7 #.7 #.7 #.7 39.41 39.41 5.43 10 Extension, Outer Rocker 11 Bracket, Front Fender¶ R/L 53821-16010 Included w/Out **Driver Side** 72022-17010 *Assy* R 61106-17042 12 Reinf Pillar 122 90 L 72012-17010 #R&R One Seat Complete, Includes R&I Seat Assy 1.5 1.5 3.0 3.0 1.0 203.1 H 61106-1/042 L 61107-17041 R 61023-17051 L 61024-17051 R 61123-17010 L 61124-17010 132.15 160.02 13 Panel, Inner Pillar 2 Lever, Seat Adjusting Passenger Side 3 Bar, Reclining Passenger Side 160.02 65.56 65.56 R/L 72201-20130 16.78 044-06068 14 Panel, Cowl Side Passenger Side 4 Cover, Seat Track Passenger Side R/L 72345-47010 19.69 Mirror Assy Black (Code 202) R 71811-20310-C0 L 71861-20140-C0 R 71862-20140-C0 46.90 R 87910-17330-C0 L 87940-17340-C0 197.97 197.97 #.3 30.75 30.75 Driver Side 87910-17330-J0 Code 8M6 #.3 197 97 87910-17330-J0 87940-17340-J1 87940-17340-J1 87940-17340-J1 87940-17340-G1 87940-17340-G0 87940-17340-G0 87940-17340-D0 5 Knob, Vertical Adjust #3 #3 #3 #3 #3 #3 #3 Driver Side Lever, Reclining L 72592-20040-C0 14.00 Code 8R2 197.97 197.97 197.97 R 72525-02030-C0 L 72526-02030-C0 10.46 10.46 Passenger Si Driver Side Dark Green (Code 6R4) 197.97 197.97 197.97 197.97 Green (Code 6S1) 29 **SEAT BELTS** Red (Code 3P0) Use Procedure Explanation 30 with the following text. Silver Code 1D0 87910-17330-B0 87940-17340-B0 87910-17330-B1 87940-17340-B1 87910-17330-A0 197.97 197.97 197.97 #3 #3 #3 #3 #3 #3 27 20 Code 1F7 044-06055 197.97 197.97 197.97 197.97 197.97 White (Code 040) 15 Panel, Front Floor 16 Xmbr, Floor 58111-17050 58111-17050 L 57451-17040 R 58117-17010 L 58118-17020 58123-17010 S8107-17010 R 57191-17050 L 57505-17010 R 57031-17010 L 57032-17010 L 57032-17010 87940-17340-A0 87910-17330-F0 62.53 62.53 Yellow (Code 576) 2.0 6.6 2.0 1.5 2.5 2.5 1.0 2.5 2.5 2.5 1.0 4.5 87940-17340-F0 17 Reinf, Seat Mounting 28.3 #w/Trim Ps R 87931-17330 L 87961-17340 2 Glass. Mirror1 36.80 36.80 26.32 109.40 90.03 154.59 154.59 72.36 85.60 Support, Shift Lever Reinf, Parking Brake Reinf, Front Floor ¶Included w/Mirror Assy R 75711-17031 L 75712-17031 3 Moulding, Outer Belt 57,07 57.07 21 Reinf, Rear Floor 22 Brace, Reinf R/I 044-05444 INTERIOR TRIM 57155-17030 57156-17030 57145-17030 23 Reinf, Floor 00-01 R 73210-17180-C0 L 73220-17160-C0 02-03 R 73210-17181-C0 L 73220-17161-C0 R&I Trim Panel. 196.41 196.41 201.49 201.49 201.49 101.94 101.94 27.58 46.56 47.44 54.73 1 Belt, Front Seal #.4 #.4 #.4 #.4 #.4 24 Reinf, Upper 25 Patch, Floor 26 Xmbr, Front Floor 27 Bracket, Suspension Mo NOTE: All Parts in this section are included in R&R Trim Panel unless R/L 57458-17030 57103-17030 57103-17030 R 57105-17070 L 57106-17070 58211-17020 R 87242-17010 L 87243-17010 04-05 R esion Mountine 73220-17240-C0 58.10 156.24 er Trim Ac 28 Panel, Rear Floor 29 Hose, Drain #w/Quarter Lo moved 2 Buckle Seat Belt 00-01 R 73230-2B010-C0 14.92 14.66 3.3.3.3 29.62 L 73230-20760-C0 02-05 R 73230-2B011-C0 L 73230-20761-C0 29.62 29.62 29.62 Cover, Service Hole Xmbr, Rear Floor 2900 26.78 12 57407-17021 5.5 774.5 2001-05 w/Sequ FRONT DOOR 11 w/Sequential Shift Trans w/o Sequential Shift Trans 57407-17010 57407-17021 Use Procedure Explanations 16 and 28 with the following text. **INTERIOR TRIM** SHEET METAL Refinish Door Outside. .P/L 2.0 Add for Jambs & Interior... 1.0 Illustration Located in Next Column Add for Jambs RA R&I Door Assy. R 67913-17070-C0 L 67914-17080-C0 R 62111-17040-C0 L 62112-17040-C0 1 Plate, Scuff 107.69 2222 NOTE: Manufacturer Advises that the Reinforcement Beam is High 107.69 58.79 58.79 Strength Steel and should never be repaired. 2 Trim, Side Cowl 044-06069

434.81 434.81

R 67610-17500-C0 L 67620-17460-C0

1 Panel Assy, Door Trim

		10YO1A MR2 2000-05
¶Black listed, Order by Application 2 Moulding, Inner Belt (a) R 68171-17011 23.47	12 Hinge, Lower R 68730-17030 #.2 42.81 L 68740-17030 #.2 42.81	
L 68172-17011 23.47 3 Grifle, Upper Speaker (a)00-02 R 67609-17010-00 594	#w/Door Assy Removed 13 Check, Door R 68610-17020 #.2 72.36 L 68620-17020 #.2 72.36	2
03-05 R 67609-17020-C0 5.94 L 67709-17020-C0 5.94	#w/Trim Panel Removed 14 Weatherstrip, Opening (On Door)	
4 Handle, Pull (a) 00-02 R 74630-17010 .2 37.73 L 74640-17010 .2 37.73 03-05 R 74630-17020 .2 38.07 L 74640-17020 .2 38.07	2000-03 R 67861-17040 .3 37.51 L 67862-17040 .3 37.51	'-
L 74640-17020 .2 38.07 (a) Included w/Door Trim Panel Assy	2004 To 12-03 R 67861-17040 .3 37.51 L 67862-17040 .3 37.51	7—8 5
5 Cover Handle Screw R 74611-17010-C0 4.03	From 12-03 R 67861-17041 .3 31.83	6
6 Plug, Screw R/L 90950-01800-C0 2.86 7 Screw, Panel R/L 90159-40141 .75	2005 R 67861-17041 .3 31.83 L 67862-17041 .3 31.83	24
8 Grommet, Screw RL 90189-04073 .69 9 Shield, Moisture R 57831-17050 # 12.06 L 67832-17050 # 12.06	GLASS & PARTS	25 9 10 2-12
10 Cover. Armrest R 74221-17020-C0 28.24		23
11 Speaker, Lower R/L 86160-22860 #.2 64.52 12 Speaker, Upper R 86160-17140 #.2 48.27	1 10	19 13 9 14
L 86160-17150 #.2 48.27 #w/Trim Panel Removed, Not included in R&R Trim Panel	15 11 13	
HARDWARE	10	21—————————————————————————————————————
Refinish Outside Handle	11 2 17	-18
Refinish Lower Hinge	11 50 12 17 19 20 20	22—
#Includes R&I Trim Panel	18 3-0 70 5	
9-8 8	2-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4-4	
7- 30-10	044-06071	9 Weatherstrip, Front R 62381-17060 2 35.87 L 62382-17060 2 55.87
	1 Class Davi	10 Weatherstrip, Rear R 62383-17010 2 41.93 L 62384-17010 2 41.93 11 Seal, Quarter-See Quarter Panel Section
	I 68102-17110 9 156.86	12 Cover, Moulding End R 75676-17021 25.58 L 75677-17021 25.58
	L FD20937G1N .9 246.951	13 Moulding, Rear Belt 75650-17011 .4 438.21 14 Cover, Moulding R 75678-17010 5.23
	2 Regulator Assy, Window R 69810-17070 #1.2 316.55 L 69820-17070 #1.2 316.55	L 75679-17010 5.23 15 Frame, Top Support 00-02 65430-17010 119.92 03-05 65430-17030 136.58
5-6-1	#Includes R&R Door Glass 3 Cover, Gear¶ R 69813-20050 6.63 L 69814-20050 6.63	16 Latch, Hold-Down 65904-17011 .2 86.97 17 Retainer, Rear Tarpaulin 65917-17010 49.61
(A)	1 4 Motor Regulator	.18 Seal, Lower 65758-17010 63.19 19 Cover, Side Opening
	¶Included w/Window Regulator Assy #w/Regulator Removed	Black R 64910-17011-C0 213.69 L 64920-17011-C0 213.69 Tan R 64910-17011-E0 213.69
12	5 Plate Assy, Window Guide R/L 67443-20080 7.06 6 Snap, Window Guide (a) R/L 67439-12020 3.40	Tan R 64910-17011-E0 213.69 L 64920-17011-E0 213.69 20 Retainer, Side Tarpaulin R 65916-17010 31.75
14—	(a) Included w/Window Guide Plate Assy 7 Spacer, Regulator P/L 69817-22020 3.72 8 Guide Assy, Front Window R 67401-14240 #.2 56.39	L 65925-17010 31.75 21 Seel Side B 65679-17011 50.30
	L 67402-14230 #.2 56.39 9 Run, Window (b) R/L 68141-14100 #.2 10.63	L 65689-17011 50.30 22 Panel, Trim 64270-17210 .4 135.52 23 Hook, Roof R 63217-17020 126.38
044-06070	(b) Included w/Front Window Guide Assy #w/Door Glass Removed	L 63218-1/020 126.38
1 Latch, Door R 69030-17130 #.3 231.36 L 69040-17130 #.3 231.38	10 Nut, Stopper (2/Side) R/L 90179-06033 2.11 11 Cushion, Stopper (2/Side) R/L 90209-09005 1.55 12 Stopper, Glass (2/Side) R/L 68147-30020 6.52	24 Trim, Upper-See Windshield Section 25 Weatherstrip, Upper 63251-17030 .5 61.62
#w/Trim Panel Removed 2 Holder, Cable (2/Side) R/L 69749-32040 2.83	12 Stopper, Glass (2 Stue) FVL 06147-50020 0.52	HARDTOP
3 Handle, Inside R 69205-17010-C0 2 33.92 L 69205-17010-C0 2 33.92 4 Striker, Latch R/L 69410-20110 2 17.78	15 Nut, Mounting (2/Side) R/L 90179-10191 2.11 16 Bolt, Adjusting R/L 69913-30090 3.46	Refinish Hardtop Shell
5 Bezel Assy, Inside Handle R 69277-22090-C0 13.92	17 Nut, Mounting (2/Side) R/L 90179-10192 1.00 18 Stop, Glass (2/Side) R/L 67211-30070 5.49	
6 Plug, Handle Bezel¶ R 69283-30040-C0 1.54 L 69284-30040-C0 1.54	18 Stop, Glass (2/Side) R/L 67211-30070 5.49 19 Stabilizer, Glass R 67235-12030 8.29 L 67236-12020 8.29 20 Shim, Adjusting (c) 8.29	2-4
¶included w/inside Handle Bezel Assy 7 Handle Assy, Outside Black (Code 202) R 69210-12290-C1 #.3 86.26	1mm R/L 63277-20030 1.60	12
L 69220-12290-C1 #.3 86.28		13-6
Blue Code 8M6 R 69210-12290-J9 #.3 86.25 L 69220-12290-J9 #.3 86.25		11-10-6
Code 8M6 R 69210-12290-39 #.3 86.25 Code 8R2 R 69210-12290-81 #.3 86.25 Code 8R2 R 69210-12290-R1 #.3 86.25 L 69220-12290-R1 #.3 86.25 Dark Green (Code 6R4) R 69210-12290-00 #.3 86.25 Green (Code 6S1) R 69210-12290-00 #.3 86.25 L 69220-12290-00 #.3 86.25 L 69220-12290-09 #.3 86.25 Red (Code 3P0) R 69210-12290-07 #.3 86.25 Red (Code 3P0) R 69210-12290-07 #.3 86.25	R&l Convertible Top Assy	21 9 14 9 8 7
L 69220-12290-Q0 #.3 86.25 Green (Code 6S1) R 69210-12290-G9 #.3 86.25	1	22 16-0
Green (Code 6S1) R 69210-12290-G9 #.3 86.2t L 69220-12290-G9 #.3 86.2t Red (Code 3P0) R 69210-12290-D7 #.3 86.2t L 69220-12290-D7 #.3 86.2t	1 Ton Assy Convertible	18 20
Silver		19
L 69220-12290-B7 #.3 86.20 Code 1E7 R 69210-12290-P0 #.3 86.20	03-05 65910-17012-C0 3.4 4246.13 Tan 00-02 65910-17022-E0 3.4 4246.13 03-05 65910-17022-E0 3.4 4246.13	25 23 24
Code 1D0 R 69210-12290-B8 #.3 86.21	2 Cover, Outer¶ Black 65911-17011-C0 #5.2 1678.08 Tan 65911-17021-E0 #5.2 1678.08	*
Code 1D0 R 69210-12290-B8 #.3 86.21 L 69220-12290-B7 #.3 86.21 Code 1E7 R 69210-12290-P0 #.3 86.21 White (Code 040) R 69210-12290-A0 #.3 86.21 L 69220-12290-A0 #.3 86.21 Yellow (Code 576) R 69210-12290-F1 #.3 94.81 L 69220-12290-F1 #.3 94.81		044.06050
#w/Trim Panel Removed	#R&R Complete 4 Moulding, Front Dripf R 75555-17010 .3 30.75	044-06059 1 Shell, Hardtop (P) 63204-17090 4.0 d2637.37
L 69242-12050 3.77 9 Clip, Rod (a) R 69293-12030 2.1	E Marthametria Daniel D/I CE007 17010 2 70/01	(P) Paint to Match 2 Glass, Rear
(a) Included w/Outside Handle Assy 10 Cvd Lock 10 Cvd L	L 75554-17020 .3 39.78 7 Handle Centers 65903-17010 .2 129.44	Toyota (Green) 64821-17011 2.0 312.15 NAGS (Green) FB20938GTN 2.0 703.70 3 Dam, Glass
10 Cyl, Lock R 69051-17110 #.3 50.3 £ 69052-17130 #.3 50.3 #w/Trim Panel Removed, included in R&R Outside Handle		108cm 64814-17010 11.49
11 Hinge, Upper R 68710-33020 #.2 42.8 L 68720-33020 #.2 42.8	filncluded w/Convertible Top Assy	230cm 64813-17020 20.12 4 Clip, Glass R 64827-17020 1.17 L 64828-17020 1.17
		E OTOEO 11 VEO 1111

TOYOTA MR2 2000-05		
HARDTOP Cont'd		
5 Bracket, Set R 58395-17020 32.24 L 58396-17020 d32.24 6 Protector, Side Roof R 75565-17010 24.89 7 Protector, Corner R 62437-17010 4.12 8 Weatherstrip, Side R 62252-17010 2 39.86 8 Weatherstrip, Side R 62252-17010 2 39.86 9 Retainer, Rear Weatherstrip R 62377-17020 16.15 10 Retainer, Front Weatherstrip R 62378-17020 16.15 11 Trim, Inner Side R 63498-17010 3 55.16 12 Panel, Headliner 63311-17070 1.0 49.34 13 Latch, Top R 69330-17020 3 228.41 4 14 Latch, Rear R/L 62203-17041 3 55.16 3 228.41 15 Plate, Rear Latch R 69341-17010 28.61 28.61 16 Hook, Latch R 69431-17010 28.61 28.61 17 Protector, Rear 63666-17030 25.58 18 Weatherstrip, Rear 63252-17040 4 60.03 19 Panel, Inner Trim 6321-17030 4 60.03 10 Protector, Rear 63666-17030	L 62908-17040-00 .3 66.93 Dark Green (Code 6R4) R 62907-17040-60 .3 66.93 L 62908-17040-00 .3 66.93 Red (Code 3P0) R 62907-17040-00 .3 66.93 Silver (Code 1E7) R 62907-17040-01 .3 66.93 L 62908-17040-01 .3 66.93 L 62908-17040-01 .3 66.93	2 6 8 10 3 15 15 15 15 16 17 12 14 16 17 12 17 18 18 17 18 18 17 18 18 17 18 18 17 18 18 18 18 18 18 18 18 18 18 18 18 18
QUARTER PANEL Use Procedure Explanations 20 and 28 with the following text.	Yellow (Code 576) R 62907-17040-F0 .3 66.93 L 62908-17040-F0 .3 66.93 2 Base, Manual Antenna R 86309-17100 1.2 36.05	22 Bezel, Lock 69365-17040 8.60
SHEET METAL	3 Ornament, Antenna Manual R 86392-17110 11.66	REAR SUSPENSION
Refinish Quarter Panel Outside	Power R 86392-17100 10,52	Use Procedure Explanation 23 with the following text. R&I Suspension (One Side) R/Lm 1.8 O/H Suspension (Includes R&I) R/Lm 3.7 One Side R/Lm 3.7 Both Sides m 7.0 Adjust Four Wheel Alignment m 1.4 Bleed Brake System a 3 NOTE 1: R&VR&R or O/H Does Not include alignment or bleed brake 1.8
9 12 12 12 11 11 11 11 11 11 11 11 11 11	7 4 6 7 1 2 8 8 1 1 2 044-06082	NOTE 2: All Parts in this section are included in overhaul unless noted otherwise.
1 Panel, Quarter 00-02 R 61601-17190 #3.1 338.76	1 *Trim, Upper Quarter R 74817-17010-C0 2 45.56 2 *Trim, Lower Quarter R 62511-17080-C0 3 92.92 3 *Box, Storage R 64429-17010-C0 2 178.68 4 *Door, Storage Box R 64429-17010-C0 2 178.68 4 *Door, Storage Box R 64419-1700-C0 196.71 5 *Trim, Upper 64712-17040-C0 A 161.05.60 6 *Deflector, Wind 63230-17030 3 137.61 7 *Panel, Package Tray Trim 64330-17010 A 209.26 **ENGINE LID** **Use Procedure Explanations 24 and 28 with the following text.** **Refinish Engine Lid Outside 2.1 Add for Underside 1.1 Refinish Hinge 7.1 **Refinish Hinge 1.5 **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGINE LID** **Trim, Upper 64712-17040-C0 A 161.05.60 **ENGINE LID** **ENGI	16 0 24 12 17 10 10 10 11 10 10 11 10 11 11 10 11 11
9 Reinf, Inner Quarter Panel R 61307-17012 1.5 28.78 10 Extension, Inner Reinf R 61308-17012 1.5 144.01 10 Extension, Inner Reinf R 61346-17020 1.0 24.55 11 Bracket, Liner R/L 61637-17030 3.3 11.09 12 Liner, Wheelhouse 0.0-1 R 65637-17010 4.85.60 0.0-1 R 65637-17010 4.85.60 0.0-2-05 R 65637-17020 4.85.60 0.0-2-05 R 65637-17020 4.85.60 0.0-2-05 R 65638-17020 4.85.60 13 Door, Fuel L 77350-17030 3.54.70 14 Spring, Door L 77350-17030 3.54.70 15 Cable, Door Release 0.0-03 L 77035-17070 8.25.15 0.0-03 L 77035-17070 8.25.15 0.0-04-05 L 77035-17071 8.25.15 16 Retainer, Door Lock L 77378-60020 1.29 17 Lever, Door Release L 69306-17050 62.53 EXTERIOR TRIM	R&I Engine Lid Assy	1 Nut, Axle R/L 90080-17238 5.86 2 Rotor, Brake #R/L 42431-17081 m #.6 123.94 3 Caliper Assy, Brake 00-02 R 47730-17120 m #.5 460.70


	L	42305-	17030	m	#1.9	214.35
#R&R One Side	Complete	, includ	es R&R l	Hub & Ro	tor, R8	R Both
Sides 3.6	* 11 N	* 1		14.	1.	- '
2 Arm, Trailing	R/I	48780.	17050		46	102.60
2 Arm, Trailing	moved De	winet 3	DLD RA	th Sides	เก๊	102.00
	norca be	48710-	17050			102.60
3 Arm, Lower Control						102.00
#w/Knuckie Re	noved De	DUCT .4,	nan Do			400.05
4 Arm, Track	H/L	48730-	1/060	m	7.0	120.95
#w/Knuckle Re	moved De	duct .3,	R&R BO		1.4	
5 Bolt, Camber Adjust 6 Cam, Camber Adjust	R/L	48190-	32010	m		8.20 12.69
6 Cam, Camber Adjust	R	48198- 48190-	32040			12.69
•				n n		82
7 Nut, Adjusting Bolt	R/L	90179-	12127	m		1.09
8 Strut	00-02 FL	48530-	80060	m	#1.6	178.72
	1	48540	19366			
	AG AF 5	40FOO	00070		. #4 6	470 7/
	00 00 11	48540-	19375	m	#1.6	178.72
9 Spring Coil	nn no RAÍ	48231.	17890	m	#1 6	54 00
a abindi con	03-05 DV	49231	1D250		#1.6	53 37
O Dumaer Caring	W-W IVE	40231	10120		#1.0 2 1#	25.10
O Duniper, Spring	- DA	400011	17050	111	#1.U	100 5
Support	D/L	40750	17000	111	#1.0	100.54
2 Plate, Spacer	HVL	48/50-	17040	m	#1.0	9.08
9 Spring, Coil 20 Bumper, Spring 21 Support 22 Plate, Specer 23 Collar #R&R One Side	- PVL	90000	30140		#1.0	0.20
		B, W/KEK	icitae ne	movea D	equet .	o, nan
Both Sides 3.		1				
Nut, Absorber 24 Link, Stabilizer #Not included	R/L	90080-	17217			2.46
24 Link, Stabilizer	R/L	48830-	17070	m	#.4	46.90
#Not Included	in O/H	1.1				
5 Bar, Stabilizer		48R12-	17150	m	#1.0	74.48
#Includes R&R	Stabilizer	Rer I in	ke Ruel	hinas & C	lamne	Not
included in C	AL		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	mgo u o	,uni,ipo	,
		40046	17150	_	#.3	13.12
26 Bushing, Stabilizer B 27 Clamp, Stabilizer Bar		40004	17150 20100	AII	#.3 #.3	
/ Clamp, Sulphizer bar	TVL	40024	20100		#.3	11.9
#R&R One Side	e Complet	e, not in	iciuaea i	n O/H		
8 Xmbr, Suspension-Se	e Rear Bo	dy Sect	ion	1. 31		
9 Sensor, Rear ABS-Se	e ABS/Bra	kes Sec	tion			
A Laboratoria						
DE	AR D	DIVE	- AY	IE		
n E	AN D	יועיות	- 4^	<u> </u>		
DOLD A-4- A				D/I		
R&I Drive Axle Assy	antidas De			FVLM	7.0	
				H/I (M	217	
O/H Drive Axle Assy (I						

2	
	3 5
	7 8 9
3	10
	11 20

NOTE: All Parts in this section are included in overhaul unless noted


						- 1
1 Axie Assy, Drive 2000		42330-1 42340-1		m	#.6 #.6	481.07 429.69
2001	-	42340-1	7131	III.	W.U	423.03
To 4-01	R	42330-1	7191	m	#.6	481.07
		42340-1		m	#.6	429.69
From 4-01		42330-1 42340-1		m	#.6 #.6	481.07 429.69
2002		42330-1		m	#.6	481.07
2002		42340-1		m	#.6	429.69
2003-05		43410-1		m	#.6	481.07
	. L	43420-1	17010	m	#.6	429.69
2 Shaft¶		43460-1	10766	m	#1.2	508.74
2000		43460-1		m	#1.2	523.76
2001		10100	101.70		W 1 cm.,	020.10
To 4-01	R	43460-1	19765		#1.2	508.74
		43460-1			#1.2	523.76
From 4-01		43460-1			#1.2	508.74
2002		43460-1 43460-1			#1.2 #1.2	523.76 508.74
2002		43460-1			#1.2	523.76
2003-05		43460			#1.2	497.41
		43470-8			#1.2	508.74
#w/Necessary		n Comp	onents	Removed	1	
3 Boot Assy, Outer/Inne		04400				00.04
2000 2001	HVL	04438-2	20132	m		33.84
To 4-01	R/I	04438-2	20132	m		33.84
From 4-01		04428-		m		33.84
2002		04428-		m		33.84
2003-05		04429-		m		40.67
4 Boot, Inner¶ (a)	00-02 R/L 03-05 R/L			m		21.04 25.41
(a) Included w/						20.41
5 Joint Assy, Innerfi	00-02 R			m	#1.2	370.25
o agus maji muni il		43040-			#1.2	304.72
April 1	03-05 R				#1.2	383.85
Annihi ana ara-		43030-			, #1.2	279.57
#w/Necessary	ouspensio	n Comp 43045-				58.79
6 Support Assy, Bearing 7 Ring, Snap (a) (b)		96153-		m		3.26
unity, sushii (a) (b)	п	30133	00000	111		3.20

8	Bearing¶ (a) (b)	R 90363-36004	m	38.58
ğ	Bearing¶ (a) (b) Pin, Guide¶ (a) (b)	R 90250-06003	m .	.91
	(b) Included w/Be	earing Support Assy		
10	Ring, Snap¶ (a)	R 90081-52006	m .	1.21
		L 90081-52005	m	2.56
11	Seal, Bearing¶ (a)	R 43458-20011	m	13.63
12	Seal, Dust¶ (a)	R 41336-06010	m	21.23
		L 41336-02030	m	3,54
	(a) Included w/Ini	ner Joint Assy		,
13	Ring, Inner Joints	R/L 90520-22005	m	1.29
	Ring, Inner Joint¶ * ¶Included w/Drive	e Axle Assy		
14	Support, Axle	R 43457-20080	m #.4	75.08
17	#w/Right Drive /	Axle Assy Removed		
	# William Cont.	THE PLOOP FIGURE		
	التحريف	ENGINE		
		ENGINE		
L	Ise Procedure Explanat	ion 12 with the following text	t.	-
-				j
	R&I Engine/Trans Assy.		m 12.6	
		~		
		∀ 1	1	
		9 —2-		



1	Cap Assy, Oil Filler 2000 2001	12180-0D011 12180-22011			9.2 9.2
	2002 To 2-02	12180-22011			9.2
2	From 2-02 2003-05 Gasket, Oil Filler Cap¶	12180-21021 12180-21021 90080-43032			9.2 9.2 4.4
3	¶Included w/Oil Filler (Panel, Valve Cover Finish	Cap Assy 11212-22061		.3	30.2
5	Cover, Valve Gasket, Valve Cover	11201-22060 11213-0D040 13470-22021	m	.8 .9	296.8 18.5 209.0
	Pulley, Crank Cover, Timing #includes R&R Crani	11321-22021	m	#4.0	188.8
9	Seal, Cover Dipstick, Eng Oll	90311-38078 15301-22040			10.2 12.6
11	Tube, Eng Dipstick Pan, Eng Oil	11452-22040 12101-0D010	, m	2.3	20.5 98.3

ENGINE/TRANS MOUNTS




w/Sequential Shift Trans	R	12321-22060	#2	41.44
	L	12311-22080	#.2	41.44 36.70
w/o Sequential Shift Trans	R	12321-22060 12301-22060	#.2 #.2	41.44 36.70
#w/Side Insulator Ren	nov	ed		
6 Insulator, Trans 7 Brkt, Trans Insulator		12372-22040 12325-22040	.9 #.2	86.22 52:33
#w/Trans Insulator Re	MMC	ved		
AIR	С	LEANER		

1	1	Cleaner Assy, Air	17/00-22090	.4	204.34
1	2	Cover Assy, Air Cleaner¶ #Includes R&R Fill	17705-22100	#.3	313.20
	-	#Includes R&R Fill	er Element		
1	3	Meter Assy, Air Flow (a)	22204-0D030 m	3	146.36
	4	Seal, Meter (a) (b)	90099-14141		1.14
7		Seal, Meter (a) (b) (b) Included w/Air F	low Meter Assy		4" × 10"
-		Valve, Air¶ (a)	90910-12222	. 17	47.84
		(a) Tricfuded w/Air C			12.6
7	- 6	Element, Filter	17801-16020-83	. 2	15,00
		Housing, Lower¶	17701-22080		123.66
1		¶included w/Air Cle	aner Assy	•	
	8	Hose Assy, Intake	17880-22010	.3	88.68
-	9	Resonator (a)	17894-11050		17.55
	l	(a) Iricluded w/Intak			
3	10	Bracket, Mounting	17853-22050		17.55
3	11	Duct. Air	17751-22050	.4	27.47
	12	Duct, Air Intake	17752-22010	.4	85.60
3					

044-06072

EXHAUST


R&I E	xhaust System Complete		.9
	Exhaust System Complete		#1.3
,	#w/Rear Bumper Cover Remo	ved. Does Not Inclu	ide R&R
1.0	Manifold or Shields		




	511 55577 .		_	
2	Shield, Upper Outer Shield, Lower Outer Manifold & Converter	17167-22050 17168-22050 17104-22061	m #1.6	105.66 55.04 648.89
۰	#includes RAR (Outer & Inner Shields		0.000
	Shield, Inner Gasket, Manifold Support, Manifold	17169-22010 17173-0D020	m	55.04 17.37
	Front 2000-01	17118-22080		28.47
	2002 To 5-02 From 5-02 2003-05 Rear	17118-22080 17118-22080 17118-22080 00-01 17119-22060 02-03 17119-22060		28.47 28.47 28.47 26.21 26.21
8	Gasket, Pipe (2) Pipe, Exhaust Gasket, Muffler	90080-43036 17410-22132 17451-22060	.9	8.09 1156.80 33.81
10	Muffler	00-02 17430-22090	1.1	283.44
		03 17430-22370	- 1.1	283.44
11	Baffle, Tailpipe	00-02 17408-16030 03 17408-74080 _{sm}		70.56 49.93

044-06085

2001-05





	01-02 82611-17030 03-05 82611-17041	.1 .1	25.0 25.0
5 Cover, Lower Fuse Box 6 Cover, Upper Relay Box	82611-17010 00 82662-17010 01-05 82662-17050	.1 .1	32.95 15.15 15.20
7 Cover, Lower Relay Box	82663-33010	•	9.5


REAR LAMPS

...R/L

.3

COMBINATION LAMP 2000-02


R&I Combination Lamp Assy



R 81551-17150	8.4	35.94 35.94
R 81553-17150	#.4	107.52
omplete .	₹.4	107.52
R/L 81554-17140 R/L 81555-17150		24.18 29.75
R/L 90981-15009	#.2 # 2	6.64 4.20
R/L 90981-13043	#.2	4.20 4.29
omplete, included in R&i/R&		
R/L 81496-17010		1.89
	L 81561-17190 R 81553-17150 L 81563-17190 I 81563-17190 I 81565-17150 R/L 81555-17150 R/L 90981-15009 R/L 90981-13043 R/L 90981-13043 R/L 90981-11048 pmplete, included in R&I/R&	L 81561-17190

COMBINATION LAMP 2003-05

R&I Combination Lamp Assy R/L



plete R/L 81554-17140 R/L 90159-60498 R/L 90189-06210 R/L 81496-17010 R/L 81555-17190 R/L 90981-15009 R/L 90981-13043

24.18 72 .63 1.89 29.72 6.64 4.20 4.20

11 Bulb, Stop		29
	One Side Complete, Included in R&I/R&R Combination Assy	
	LICENSE LAMP	
R&I Lamp Ho	singR/L #.2 ed in R&R or O/H Rear Bumper	
	3-0 1-044-06066	
1 Housing, La 2 Bulb, Lamp #R&F Ass	p R/L 81271-30240 #.2 17 R/L 00234-00192 #.2 1 one Side Complete, included in R&R or O/H Rear Bump	00
3 Socket, Bult	R/L 81275-17040 10	.83
	HIGH MOUNT STOP LAMP	
	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	




REAR BUMPER

Use Procedure Explanations 27 and 28 with the following text.

2000-02		
Refinish Bumper Cover R&I Bumper Assy. OH Bumper Assy (Includes R&I). #includes R&I/R&R Rear Combination Lamps	2.3 #1.2 #2.0	


NOTE: All Parts in this section are included in overheal unless noted otherwise.



						5 5 8
1	Cover, Bumper (P) (P) Paint to Match		52159-17910		#1.7	232.95
	#includes R&VR&R	Rear	Combination La	mos		
2	Support, Side		52115-17020	,		5.29
3	Griffe, Upper		52561-17030		.1	29.21
. 4	Plug, Lower Grille	Ŗ	52161-17010			7.46
	<u> </u>	L	52162-17010			7.46
- 5	Grille, Lower	. ∕R	52152-17020		.2	59.77
		L	52153-17020		. 2	59.77
6	Extension, Lower Grille	R	52163-17010			14.69
-		Ë	52164-17010			14.69
7	Hook, Tow	R/L	51093-17021		.1	27.04
Ř	Support, Bumper	R/L	52151-17010			24.32
ŏ	Cover. Hole		55797-46010			1.86
١ň	Reinf. Bumper		52023-17080		IOH	128.10
	Nameniate (Adheelys)		JEDEO 17 000		1011	120.10
11	Nameplate (Adhesive) "TOYOTA"		75443-20610		.2	20.03
12	"MR2"		PT413-17000-0	4	5	23.89
12	MINE		F1410-1/000-0		. 4	20.00
						· * .

	***	2003-05			
	Refinish Bumper Cove	ſ	*	2.3	
	Refinish Lower Grille			.3	
,	R&I Bumper Assy			#1.2	
	O/M Bumper Assy (Inc	ludes H&I)		#2.0	
	#Includes R&I	Rear Combination	Lamo Assembli	es	

NOTE: All Parts in this section are included in overhaul unless noted



1. Cover, Bumper (P)	52159-17910	#1.7	232.95
(P) Paint to Match			i je
	ear Combination Lamp Asse	embues	- còo
2 Support, Side 3 Bolt, Support	R/L 52115-17020 R/L 90164-60029		5.29
3 Bolt, Support 4 Bolt, Upper Cover	R/L 90119-06827		.63
5 Detainer Honer Count	52161-02020	44.7	1.86
5 Retainer, Upper Cover 6 Retainer, Lower Cover	52161-02020		1.86
¶As Required	02101.02020		1.00
7 Grille, Upper	52561-17030	1	29.21
8 Grille, Lower		1.479	
Black (Code 202)	R 52152-17030-C0	.2	49.36
	L 52153-17030-C0	.2	49.36
Blue	D =0.100 (5000 to	_	
Code 8M6	R 52152-17030-J0	2	49.36
Code 9D9	L 52153-17030-J0 R 52152-17030-J1	.2	49.36 49.36
Code 8R2	L 52153-17030-J1	100 marty 15 1	49.36
Green (Code 6R4)	R 52152-17030-G0		49.36
Globel) (Occae Ol H)	L 52153-17030-G0	5	49.36
Red (Code 3P0)	R 52152-17030-D0	2	49.36
1102 (0000 51 5)	L 52153-17030-D0	· 2	49.36
Silver (Code 1E7)	R 52152-17030-B1	.2	49.36
	L 52153-17030-B1	.2	49.36
White (Code 040)	R 52152-17030-A0	.2	49.36
Vallacio (Od 570)	L 52153-17030-A0	222222222222222222	49.36
Yellow (Code 576)	R 52152-17030-F0 L 52153-17030-F0	2	49.36 49.36
9 Extension, Lower Grille		-2	9.80
5 Laterision, Lower Gine	L 52162-17020		9.80
10 Hook, Tow.	RAL 51083-17021		27.04
11 Cover, Tow Hook	R 52163-17020		10.69
	1 52164-17020		10.69
12 Reinforcement Assy, B	umper 52023-17080	IOH	128.10
13 Hanger, Exnaust Piper	51902-17010	All the	23.84
¶included w/Bum	per Reinforcement Assy	with the second	
14 Cover, Hele	R/L 55797-46010		1.86
Nut, Reinf (3/Side)	R/L 90179-10113		1.03
15 Support, Bumper Nameplate (Adhesive)	R/L 52151-17010		24.32
16 "TOYOTA"	75443-20610	9	20.03
17 "MR2"	PT413-17000-01	.2	23.89
17 191116	1 1710 1700001		20.03

1 Lens, Combination Lamp 2 Housing, Lamp

Gasket Bolt, Lamp (2/Side) Grommet (2/Side) Guide, Mounting

7 Harness, Lamp 8 Bulb, Turn Signal 9 Bulb, Back-Up 10 Bulb, Side Marker

#R&R One Side Compl