
customize my phone



- You can customize your phone's interface to suit you
 - reorder main menu applications
 - move frequently used applications to the main menu
 - assign personal pictures as menu icons
- 1. To place your calculator in the main menu, press Office Tools > Calculator > Options.
- 2. Press Move to Folder > Back to Main Menu > Place. **Tip**: To place calculator at the top of Office Tools, press **Reorder** > **Grab**. Press • Up until you get to the top of the list, and press Insert.
- 3. To assign a personal picture to a main menu icon, press Options > Manage > Edit folder. Note: You can assign personal pictures to Multimedia, Office Tools, Games, Dialing Services, and folders you have created. To create a new folder in the main menu, press Options > Create New Folder.
- 4. Press Select folder graphic > Options > Go to Pictures > Pictures > image > Save. Tip: To create shortcuts to main menu items you use frequently, customize the navigation keys. From the home screen, press Options > Customize Home > Shortcut Keys.





