How to Dock Devices to Wi-Fi


Prerequisites

To accomplish this process, you will need:

- WP Securebook
- Red (Wi-Fi) Securebook Docking Station

To Access a Wireless Network with a Securebook, follow these steps:

- 1. Power Off the Securebook
- 2. Dock the Securebook onto the Red Docking Station



Note: If the Securebook is correctly situated on the docking station, A green light will light up on the side. If there is no light, the Securebook could be improperly mounted, powered off, or even be dead (0% power).

- 3. Power On the Securebook
- 4. Log in to an account

The Endless OS Justice Michigan Image has the Wi-Fi connection to RACHEL preconfigured, meaning that no additional steps are need to access the RACHEL device, given that the Securebook is Docked and in range of the RACHEL device. Users are not limited to using a singular Red Docking Station. Should the need arise, the user can

repeat the steps above on an entirely different Red Docking Station and achieve the same results. *Note*: For best results, make sure the Securebook is Turned Off when docking to a Red Docking Station.