

Chapter 8


Digital Design and Computer Architecture, 2nd Edition

David Money Harris and Sarah L. Harris



Chapter 8 :: Topics

- Introduction
- Memory System Performance Analysis
- Caches
- Virtual Memory
- Memory-Mapped I/O
- Summary






Introduction

- Computer performance depends on:
 - Processor performance
 - Memory system performance


Memory Interface





Processor-Memory Gap

In prior chapters, assumed access memory in 1 clock cycle – but hasn't been true since the 1980's





Memory System Challenge

Make memory system appear as fast as processor

Use hierarchy of memories

Ideal memory:


- Fast
- Cheap (inexpensive)
- Large (capacity)

But can only choose two!





Memory Hierarchy





Locality

Exploit locality to make memory accesses fast

- Temporal Locality:
 - Locality in time
 - If data used recently, likely to use it again soon
 - How to exploit: keep recently accessed data in higher levels of memory hierarchy
- Spatial Locality:
 - Locality in space
 - If data used recently, likely to use nearby data soon
 - How to exploit: when access data, bring nearby data into higher levels of memory hierarchy too

Memory Performance

- Hit: data found in that level of memory hierarchy
- Miss: data not found (must go to next level)

Hit Rate = # hits / # memory accesses

= 1 - Miss Rate

Miss Rate = # misses / # memory accesses

= 1 - Hit Rate

• Average memory access time (AMAT): average time for processor to access data

$$\mathbf{AMAT} = t_{\text{cache}} + MR_{\text{cache}}[t_{MM} + MR_{MM}(t_{VM})]$$



- A program has 2,000 loads and stores
- 1,250 of these data values in cache
- Rest supplied by other levels of memory hierarchy
- What are the hit and miss rates for the cache?



- A program has 2,000 loads and stores
- 1,250 of these data values in cache
- Rest supplied by other levels of memory hierarchy
- What are the hit and miss rates for the cache?

Hit Rate =
$$1250/2000 = 0.625$$

Miss Rate =
$$750/2000 = 0.375 = 1$$
 – Hit Rate



• Suppose processor has 2 levels of hierarchy: cache and main memory

• $t_{\text{cache}} = 1$ cycle, $t_{MM} = 100$ cycles

• What is the AMAT of the program from Example 1?



- Suppose processor has 2 levels of hierarchy: cache and main memory
- $t_{\text{cache}} = 1$ cycle, $t_{MM} = 100$ cycles
- What is the AMAT of the program from Example 1?

AMAT =
$$t_{\text{cache}} + MR_{\text{cache}}(t_{MM})$$

= $[1 + 0.375(100)]$ cycles
= **38.5** cycles



Gene Amdahl, 1922-

- Amdahl's Law: the effort spent increasing the performance of a subsystem is wasted unless the subsystem affects a large percentage of overall performance
- Co-founded 3 companies, including one called Amdahl Corporation in 1970







Cache

- Highest level in memory hierarchy
- Fast (typically ~ 1 cycle access time)
- Ideally supplies most data to processor
- Usually holds most recently accessed data



Cache Design Questions

- What data is held in the cache?
- How is data found?
- What data is replaced?

Focus on data loads, but stores follow same principles



What data is held in the cache?

- Ideally, cache anticipates needed data and puts it in cache
- But impossible to predict future
- Use past to predict future temporal and spatial locality:
 - Temporal locality: copy newly accessed data into cache
 - Spatial locality: copy neighboring data into cache too



Cache Terminology

- Capacity (C):
 - number of data bytes in cache
- Block size (b):
 - bytes of data brought into cache at once
- Number of blocks (B = C/b):
 - number of blocks in cache: B = C/b
- Degree of associativity (N):
 - number of blocks in a set
- Number of sets (S = B/N):
 - each memory address maps to exactly one cache set



How is data found?

- Cache organized into S sets
- Each memory address maps to exactly one set
- Caches categorized by # of blocks in a set:
 - Direct mapped: 1 block per set
 - N-way set associative: N blocks per set
 - -Fully associative: all cache blocks in 1 set
- Examine each organization for a cache with:
 - Capacity (C = 8 words)
 - Block size (b = 1 word)



Example Cache Parameters

C = 8 words (capacity)

b = 1 word (block size)

So, B = 8 (# of blocks)

Ridiculously small, but will illustrate organizations



Direct Mapped Cache

Address

11...111**111**11...111**110**11...111**101**11...111**100**

11...111**010**00 11...111**001**00

11...111**000**00

•

00...001**001**00

00...001**000**00

00...000**111**00

00...000**110**00

00...000**101**00

 $00...000 \\ \textbf{100} \\ 00$


00...000**011**00

00...000**010**00

00 0000010

00...000**001**00

00...00000000



mem[0xFF...F4]

mem[0xFF...F0]

mem[0xFF...EC]

mem[0xFF...E8]

mem[0xFF...E4]

mem[0xFF...E0]

mem[0x00...24]

mem[0x00..20]

mem[0x00..1C]

mem[0x00...18]

mem[0x00...14]

mem[0x00...0C]

mem[0x00...08]

mem[0x00...04]

mem[0x00...00]

2³⁰ Word Main Memory

2³ Word Cache Chapter 8 < 20 >



7 (111)

6 (110)

5 (101)

4 (100)

3 (011)

2 (010)


1 (001)

0 (000)



© Digital Design and Computer Architecture, 2nd Edition, 2012

Direct Mapped Cache Hardware





Direct Mapped Cache Performance

Byte



MIPS assembly code

addi	\$t0,	\$0 ,	5

loop: beq \$t0, \$0, done

lw \$t1, 0x4(\$0)

lw \$t2, 0xC(\$0)

lw \$t3, 0x8(\$0)

addi \$t0, \$t0, -1

loop

done:

V	Tag	Data	
0			Set 7 (111)
0			Set 6 (110)
0			Set 5 (101)
0			Set 4 (100)
1	0000	mem[0x000C]	Set 3 (011)
1	0000	mem[0x0008]	Set 2 (010)
1	0000	mem[0x0004]	Set 1 (001)
0			Set 0 (000)

Miss Rate = ?



STEMS

Direct Mapped Cache Performance



MIPS assembly code

addi \$t0, \$0, 5

loop: beq \$t0, \$0, done

lw \$t1, 0x4(\$0)

lw \$t2, 0xC(\$0)

lw \$t3, 0x8(\$0)

addi \$t0, \$t0, -1

j loop

done:

V	lag	Data	
0			Set 7 (111)
0			Set 6 (110)
0			Set 5 (101)
0			Set 4 (100)
1	0000	mem[0x000C]	Set 3 (011)
1	0000	mem[0x0008]	Set 2 (010)
1	0000	mem[0x0004]	Set 1 (001)
0			Set 0 (000)

Miss Rate = 3/15 = 20%

Temporal Locality Compulsory Misses



done:

Direct Mapped Cache: Conflict

Byte Set Offset Tag Memory 00...01 001 00 Address 3

MIPS assembly code

addi \$t0, \$0, 5 beq \$t0, \$0, done loop: lw \$t1, 0x4(\$0) 1w \$t2, 0x24(\$0)addi \$t0, \$t0, -1 loop

Tag 0 0 0 0 mem[0x00...04] mem[0x00...24] 00...00

Data

Set 7 (111) Set 6 (110) Set 5 (101) Set 4 (100) Set 3 (011) Set 2 (010) Set 1 (001) Set 0 (000)

Miss Rate = ?



O SYSTEMS

Direct Mapped Cache: Conflict

Memory Tag Set Offset Offset Offset 3

MIPS assembly code

addi \$t0, \$0, 5

loop: beq \$t0, \$0, done

lw \$t1, 0x4(\$0)

lw \$t2, 0x24(\$0)

addi \$t0, \$t0, -1

j loop

done:


V	Tag	Data	
0			Set 7 (111)
0			Set 6 (110)
0			Set 5 (101)
0			Set 4 (100)
0			Set 3 (011)
0			Set 2 (010)
1	0000	mem[0x0004] mem[0x00 24]	Set 1 (001)
0			Set 0 (000)

Miss Rate = 10/10 = 100%

Conflict Misses



N-Way Set Associative Cache



N-Way Set Associative Performance

MIPS assembly code

addi \$t0, \$0, 5

loop: beq \$t0, \$0, done

lw \$t1, 0x4(\$0)

lw \$t2, 0x24(\$0)

addi \$t0, \$t0, -1

j loop

Miss Rate = ?

done:

Way 1 Way 0

V	Tag	Data	V	Tag	Data	
0			0			Set 3 Set 2 Set 1 Set 0
0			0			Set 2
0			0			Set 1
0			0			Set 0



N-Way Set Associative Performance

MIPS assembly code

addi \$t0, \$0, 5

loop: beq \$t0, \$0, done

lw \$t1, 0x4(\$0)

lw \$t2, 0x24(\$0)

addi \$t0, \$t0, -1

j loop

Miss Rate = 2/10

=20%

Associativity reduces

conflict misses

done:

Way 1 Way 0

V	Tag	Data	V	Tag	Data	_
0			0			Set 3
0			0			Set 2
1	0010	mem[0x0024]	1	0000	mem[0x0004]	Set 1
0			0			Set 0



YSTEMS

Fully Associative Cache

V Tag Data V Tag Data




Reduces conflict misses

Expensive to build





Spatial Locality?

- Increase block size:
 - Block size, b = 4 words
 - -C = 8 words
 - Direct mapped (1 block per set)
 - Number of blocks, B = 2 (C/b = 8/4 = 2)



Cache with Larger Block Size





done:

Direct Mapped Cache Performance



Direct Mapped Cache Performance

```
addi $t0, $0, 5

loop: beq $t0, $0, done

lw $t1, 0x4($0)

lw $t2, 0xC($0)

lw $t3, 0x8($0)


addi $t0, $t0, -1

j loop
```

Miss Rate = 1/15 = 6.67%

Larger blocks reduce compulsory misses through spatial locality

done:



Cache Organization Recap

• Capacity: C

• Block size: b

• Number of blocks in cache: B = C/b

Number of blocks in a set: N

• Number of sets: S = B/N

Organization	Number of Ways (N)	Number of Sets $(S = B/N)$
Direct Mapped	1	В
N-Way Set Associative	1 < N < B	B/N
Fully Associative	В	1



Capacity Misses

- Cache is too small to hold all data of interest at once
- If cache full: program accesses data X & evicts data Y
- Capacity miss when access Y again
- How to choose Y to minimize chance of needing it again?
- Least recently used (LRU) replacement: the least recently used block in a set evicted



Types of Misses

- Compulsory: first time data accessed
- Capacity: cache too small to hold all data of interest
- Conflict: data of interest maps to same location in cache

Miss penalty: time it takes to retrieve a block from lower level of hierarchy



LRU Replacement

MIPS assembly

```
lw $t0, 0x04($0)
lw $t1, 0x24($0)
lw $t2, 0x54($0)
```

			Way 1	_		Way 0	_
٧	U	Tag	Data	V	Tag	Data	1
0	0			0			Set 3 (11)
0	0			0			Set 2 (10)
0	0			0			Set 1 (01)
0	0			0			Set 0 (00)



LRU Replacement

MIPS assembly

```
lw $t0, 0x04($0)
lw $t1, 0x24($0)
lw $t2, 0x54($0)
```

(a)

(b)

		Way 1			١	Nay 0	
٧	U	Tag	Data	٧	Tag	Data	ļ
0	0			0			Set 3 (11)
0	0			0			Set 2 (10)
1	0	00010	mem[0x0024]	1	00000	mem[0x0004]	Set 1 (01)
0	0			0			Set 0 (00)

		Way 1			١		
V	U	Tag	Data	V	Tag	Data	l
0	0			0			Set 3 (11)
0	0			0			Set 2 (10)
1	1	00010	mem[0x0024]	1	00101	mem[0x0054]	Set 1 (01)
0	0			0			Set 0 (00)




Cache Summary

- What data is held in the cache?
 - Recently used data (temporal locality)
 - Nearby data (spatial locality)
- How is data found?
 - Set is determined by address of data
 - Word within block also determined by address
 - In associative caches, data could be in one of several ways
- What data is replaced?
 - Least-recently used way in the set




Miss Rate Trends





Miss 10%

Miss Rate Trends



- Bigger blocks reduce compulsory misses
- Bigger blocks increase conflict misses




Multilevel Caches

- Larger caches have lower miss rates, longer access times
- Expand memory hierarchy to multiple levels of caches
- Level 1: small and fast (e.g. 16 KB, 1 cycle)
- Level 2: larger and slower (e.g. 256 KB, 2-6 cycles)
- Most modern PCs have L1, L2, and L3 cache



Intel Pentium III Die






Virtual Memory

- Gives the illusion of bigger memory
- Main memory (DRAM) acts as cache for hard disk




Memory Hierarchy



- Physical Memory: DRAM (Main Memory)
- Virtual Memory: Hard drive
 - Slow, Large, Cheap



Hard Disk



Takes milliseconds to seek correct location on disk



Virtual Memory

Virtual addresses

- Programs use virtual addresses
- Entire virtual address space stored on a hard drive
- Subset of virtual address data in DRAM
- CPU translates virtual addresses into *physical addresses* (DRAM addresses)
- Data not in DRAM fetched from hard drive

Memory Protection

- Each program has own virtual to physical mapping
- Two programs can use same virtual address for different data
- Programs don't need to be aware others are running
- One program (or virus) can't corrupt memory used by another



Cache/Virtual Memory Analogues

Cache	Virtual Memory
Block	Page
Block Size	Page Size
Block Offset	Page Offset
Miss	Page Fault
Tag	Virtual Page Number

Physical memory acts as cache for virtual memory




Virtual Memory Definitions

- Page size: amount of memory transferred from hard disk to DRAM at once
- Address translation: determining physical address from virtual address
- Page table: lookup table used to translate virtual addresses to physical addresses



Virtual & Physical Addresses




© 2007 Elsevier, Inc. All rights reserved

Most accesses hit in physical memory
But programs have the large capacity of virtual memory



Address Translation

Virtual Address



© 2007 Elsevier, Inc. All rights reserved



System:

- Virtual memory size: $2 \text{ GB} = 2^{31} \text{ bytes}$
- Physical memory size: $128 \text{ MB} = 2^{27} \text{ bytes}$
- Page size: $4 \text{ KB} = 2^{12} \text{ bytes}$



System:

- Virtual memory size: $2 GB = 2^{31}$ bytes
- Physical memory size: $128 \text{ MB} = 2^{27} \text{ bytes}$
- Page size: $4 \text{ KB} = 2^{12} \text{ bytes}$

Organization:

- Virtual address: 31 bits
- Physical address: 27 bits
- Page offset: 12 bits
- # Virtual pages = $2^{31}/2^{12} = 2^{19}$ (VPN = 19 bits)
- # Physical pages = $2^{27}/2^{12} = 2^{15}$ (PPN = 15 bits)



19-bit virtual page numbers

15-bit physical page numbers

Virtual Addresses

0x7FFFF000 - 0x7FFFFFFF 0x7FFFE000 - 0x7FFFFFFF 0x7FFFD000 - 0x7FFFDFFF

0x7FFFC000 - 0x7FFFCFFF 0x7FFFB000 - 0x7FFFBFFF

0x7FFFA000 - 0x7FFFAFFF

0x7FFF9000 - 0x7FFF9FFF

0x00006000 - 0x00006FFF

0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF

0x00003000 - 0x00003FFF

0x00002000 - 0x00002FFF

0x00001000 - 0x00001FFF

0x00000000 - 0x00000FFF


Virtual Memory

Physical Memory

Physical

Page Number

© 2007 Elsevier, Inc. All rights reserved



Virtual

Page

Number

7FFFF

7FFFE 7FFFD

7FFFC

7FFFB

7FFFA

7FFF9

00006

00005

00004

What is the physical address of virtual address **0x247C**?

Physical
Page
Number Physical Addresses

7FF 0x7FFF000 - 0x7FFFFF
7FF 0x7FFE000 - 0x7FFFFF

0001 0x0001000 - 0x0001FFF
0000 0x0000000 - 0x0000FFF

Physical Memory

Virtual Addresses

0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF 0x00003000 - 0x00003FFF 0x00002000 - 0x00002FFF 0x00001000 - 0x00001FFF 0x000000000 - 0x00000FFF

0x00006000 - 0x00006FFF

Virtual Memory

© 2007 Elsevier, Inc. All rights reserved



Virtual

Page Number

7FFFF

7FFFE

7FFFD

7FFFC

7FFFB 7FFFA

7FFF9

00006

00005

00004

00003

00002

00001

00000

What is the physical address of virtual address **0x247C?**

_	VPN =	0x2
---	-------	-----

Physical

- VPN 0x2 maps to PPN 0x7FFF
- 12-bit page offset: 0x47C
- Physical address = 0x7FFF47C

i ilyolodi		
Page		
Number	Physical Addresses	
7FFF [0x7FFF000 - 0x7FFFFFF	L
7FFE	0x7FFE000 - 0x7FFEFFF)
•	:	
	•	J
0001	0x0001000 - 0x0001FFF	1
0000	0x0000000 - 0x0000FFF	
	Physical Memory	

	Virtual Addresses	Number
	0x7FFFF000 - 0x7FFFFFFF	7FFFF
	0x7FFFE000 - 0x7FFFEFFF	7FFFE
1	0x7FFFD000 - 0x7FFFDFFF	7FFFD
//	0x7FFFC000 - 0x7FFFCFFF	7FFFC
7	0x7FFFB000 - 0x7FFFBFFF	7FFFB
	0x7FFFA000 - 0x7FFFAFFF	7FFFA
	0x7FFF9000 - 0x7FFF9FFF	7FFF9
		1
	•	
	0x00006000 - 0x00006FFF	00006
/	0x00006000 - 0x00006FFF 0x00005000 - 0x00005FFF	00006 00005
/		
/	0x00005000 - 0x00005FFF	00005
/	0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF	00005 00004
/	0x00005000 - 0x00005FFF 0x00004000 - 0x00004FFF 0x00003000 - 0x00003FFF	00005 00004 00003

Virtual

Page


© 2007 Elsevier, Inc. All rights reserved

Virtual Memory

How to perform translation?

- Page table
 - Entry for each virtual page
 - Entry fields:
 - Valid bit: 1 if page in physical memory
 - Physical page number: where the page is located









What is the physical address of virtual address **0x5F20**?

Pilysical	
Page Number	
0x0000	
0x7FFE	
	a)
	Page Table
•	
•	<u>e</u>
	ag
	-
0x0001	
0x7FFF	
	0x0000 0x7FFE

Physical




Virtual

Address

What is the physical address of virtual address **0x5F20**?

- -VPN = 5
- Entry 5 in page table
 VPN 5 => physical
 page 1
- Physical address:0x1F20






Virtual

Address

What is the physical address of virtual address **0x73E0**?




Virtual

Address

What is the physical address of virtual address **0x73E0**?

- -VPN = 7
- Entry 7 is invalid
- Virtual page must be paged into physical memory from disk



Page Table Challenges

- Page table is large
 - usually located in physical memory
- Load/store requires 2 main memory accesses:
 - one for translation (page table read)
 - one to access data (after translation)
- Cuts memory performance in half
 - Unless we get clever...



Translation Lookaside Buffer (TLB)

- Small cache of most recent translations
- Reduces # of memory accesses for most loads/stores from 2 to 1




TLB

- Page table accesses: high temporal locality
 - Large page size, so consecutive loads/stores likely to access same page
- TLB
 - Small: accessed in < 1 cycle</p>
 - Typically 16 512 entries
 - Fully associative
 - > 99 % hit rates typical
 - Reduces # of memory accesses for most loads/stores from 2 to 1



Example 2-Entry TLB





Memory Protection

- Multiple processes (programs) run at once
- Each process has its own page table
- Each process can use entire virtual address space
- A process can only access physical pages mapped in its own page table



Virtual Memory Summary

- Virtual memory increases capacity
- A subset of virtual pages in physical memory
- Page table maps virtual pages to physical pages – address translation
- A TLB speeds up address translation
- Different page tables for different programs provides memory protection



Memory-Mapped I/O

- Processor accesses I/O devices just like memory (like keyboards, monitors, printers)
- Each I/O device assigned one or more address
- When that address is detected, data read/written to I/O device instead of memory
- A portion of the address space dedicated to I/O devices



Memory-Mapped I/O Hardware

Address Decoder:

 Looks at address to determine which device/memory communicates with the processor

• I/O Registers:


Hold values written to the I/O devices

ReadData Multiplexer:

 Selects between memory and I/O devices as source of data sent to the processor




The Memory Interface





Memory-Mapped I/O Hardware






Memory-Mapped I/O Code

- Suppose I/O Device 1 is assigned the address 0xFFFFFFF4
 - Write the value 42 to I/O Device 1
 - Read value from I/O Device 1 and place in \$t3




Memory-Mapped I/O Code

Write the value 42 to I/O Device 1 (0xFFFFFFF4)



Memory-Mapped I/O Code

Read the value from I/O Device 1 and place in \$t3



Input/Output (I/O) Systems

- Embedded I/O Systems
 - Toasters, LEDs, etc.
- PC I/O Systems



Embedded I/O Systems

- Example microcontroller: PIC32
 - microcontroller
 - 32-bit MIPS processor
 - low-level peripherals include:
 - serial ports
 - timers
 - A/D converters



Digital I/O

```
3.3 V
// C Code
                                                  RD11 45
#include <p3xxxx.h>
                                                  RD1044
                                                                  R =
int main(void) {
                                                   RD9 43
  int switches;
                                                   RD8 42
  TRISD = 0xFF00;
                         // RD[7:0] outputs
                                                   RD7 55 ---
                         // RD[11:8] inputs
  while (1) {
                                                   RD6 54 ----
                                              PIC32
    // read & mask switches, RD[11:8]
                                                   RD5 53 → ✓ →
    switches = (PORTD >> 8) \& 0xF;
    PORTD = switches; // display on LEDs
                                                   RD4 52
                                                   RD351
                                                   RD2 50 -----
                                                   RD1 49 -----
                                                   RD0 46
                                                          LEDs
```

Switches




Serial I/O


- Example serial protocols
 - SPI: Serial Peripheral Interface
 - UART: Universal Asynchronous Receiver/Transmitter
 - Also: I²C, USB, Ethernet, etc.



SPI: Serial Peripheral Interface

- Master initiates communication to slave by sending pulses on SCK
- Master sends SDO (Serial Data Out) to slave, msb first
- Slave may send data (SDI) to master, msb first








UART: Universal Asynchronous Rx/Tx

- Configuration:
 - start bit (0), 7-8 data bits, parity bit (optional), 1+ stop bits (1)
 - data rate: 300, 1200, 2400, 9600, ...115200 baud
- Line idles HIGH (1)
- Common configuration:
 - 8 data bits, no parity, 1 stop bit, 9600 baud





Timers

```
// Create specified ms/us of delay using built-in timer
#include <P32xxxx.h>
void delaymicros(int micros) {
  if (micros > 1000) { // avoid timer overflow
   delaymicros(1000);
   delaymicros (micros-1000);
  else if (micros > 6) {
                          // reset timer to 0
   TMR1 = 0;
   T1CONbits.ON = 1;
                            // turn timer on
   PR1 = (micros-6) *20;
                            // 20 clocks per microsecond
                            // Function has overhead of ~6 us
   IFSObits.T1IF = 0;  // clear overflow flag
   while (!IFSObits.T1IF); // wait until overflow flag set
void delaymillis(int millis) {
  while (millis--) delaymicros(1000); // repeatedly delay 1 ms
                                    // until done
```




Analog I/O

- Needed to interface with outside world
- Analog input: Analog-to-digital (A/D) conversion
 - Often included in microcontroller
 - N-bit: converts analog input from $V_{ref-}V_{ref+}$ to 0-2^{N-1}
- Analog output:
 - Digital-to-analog (D/A) conversion
 - Typically need external chip (e.g., AD558 or LTC1257)
 - N-bit: converts digital signal from 0-2^{N-1} to V_{ref} - V_{ref} +
 - Pulse-width modulation




Pulse-Width Modulation (PWM)

Average value proportional to duty cycle



Add high-pass filter on output to deliver average value





Other Microcontroller Peripherals

- Examples
 - Character LCD
 - VGA monitor
 - Bluetooth wireless
 - Motors



Personal Computer (PC) I/O Systems

- USB: Universal Serial Bus
 - USB 1.0 released in 1996
 - standardized cables/software for peripherals
- PCI/PCIe: Peripheral Component Interconnect/PCI Express
 - developed by Intel, widespread around 1994
 - 32-bit parallel bus
 - used for expansion cards (i.e., sound cards, video cards, etc.)
- DDR: double-data rate memory



Personal Computer (PC) I/O Systems

- TCP/IP: Transmission Control Protocol and Internet Protocol
 - physical connection: Ethernet cable or Wi-Fi
- SATA: hard drive interface
- Input/Output (sensors, actuators, microcontrollers, etc.)
 - Data Acquisition Systems (DAQs)
 - USB Links

