Using the RV temperature monitor

The first time you use it, go to the app store and download the BerryLan app, it's free.

When you get to the RV park and have their WiFi information (SSID and password), plug in the Raspberry Pi and wait about a minute to let the computer boot up.

Open the BerryLan app on your phone (be sure BlueTooth is on). It will search for your Raspberry Pi which will appear with the name like BT wlan setup. Click on that entry and a screen should appear letting you pick the local SSID (click on it) and then enter the password. Enter those and you should be good to go.

To turn off the Raspberry Pi, just unplug it. If you plug it back in at the same RV park later, it will remember the SSID and password so you only need to do that once.

At the next RV park simply repeat the process.