







User Manual UM5118

**725-730 Families** 

**Waveform Recording Firmware Registers** 

Rev. 1 - December 6th, 2016

#### Purpose of this Manual

The User Manual contains the full description of the WaveForm Recording firmware registers for 725 and 730 digitizer families. The description is compliant with the firmware revision **4.8\_0.5**. For future release compatibility check in the firmware history files.

#### **Change Document Record**

Date	Revision	Changes
August 31st, 2016	00	First release grouping 730 and 725 digitizer families
December 6th, 2016	01	Corrected the Post Trigger formula

#### Symbols, abbreviated terms and notation

ADC Analog-to-Digital Converter
AMC ADC & Memory Controller
DAC Digital-to-Analog Converter

DC Direct Current

DPP Digital Pulse Processing LVDS Low-Voltage Differential Signal

ROC ReadOut Controller USB Universal Serial Bus

CAEN S.pA.

Via Vetraia, 11 55049 Viareggio (LU) - ITALY Tel. +39.0584.388.398 Fax +39.0584.388.959 info@caen.it www.caen.it

©CAEN SpA – 2016

#### Disclaimer

No part of this manual may be reproduced in any form or by any means, electronic, mechanical, recording, or otherwise, without the prior written permission of CAEN SpA.

The information contained herein has been carefully checked and is believed to be accurate; however, no responsibility is assumed for inaccuracies. CAEN SpA reserves the right to modify its products specifications without giving any notice; for up to date information please visit www.caen.it.

**MADE IN ITALY**: We stress the fact that all the boards are made in Italy because in this globalized world, where getting the lowest possible price for products sometimes translates into poor pay and working conditions for the people who make them, at least you know that who made your board was reasonably paid and worked in a safe environment. (this obviously applies only to the boards marked "MADE IN ITALY", we cannot attest to the manufacturing process of "third party" boards).





# Index

Pu	ose of this Manual	2
Ch	ge document record	2
Syı	ools, abbreviated terms and notation	2
1	egisters and Data Format	6
	Reset and Clear	6
	Register Address Map	7
	Event Readout Buffer	10
	Dummy32	11
	·	12
		13
		14
		- · 15
	1 65 6	16
		17
		18
		19
	·	19 20
		21
		22
		23
	•	24
	•	26
	65	28
		29
	,	30
		31
	·	32
	,	33
		36
	ROC FPGA Firmware Revision	37
	Event Stored	38
	Set Monitor DAC	39
	Software Clock Sync	40
	Board Info	41
	Monitor DAC Mode	12
	Event Size	43
	Fan Speed Control	14
	·	45
	,	16
		17
		48
		19
		50
		52
		53
		53 54
		55 55
	, ,	56
	•	57
	Max Number of Events per BLT	58

Scratch	59
Software Reset	60
Software Clear	61
Configuration Reload	62
Configuration ROM Checksum	63
Configuration ROM Checksum Length BYTE 2	64
Configuration ROM Checksum Length BYTE 1	65
Configuration ROM Checksum Length BYTE 0	66
Configuration ROM Constant BYTE 2	67
Configuration ROM Constant BYTE 1	68
Configuration ROM Constant BYTE 0	69
Configuration ROM C Code	70
Configuration ROM R Code	71
Configuration ROM IEEE OUI BYTE 2	72
Configuration ROM IEEE OUI BYTE 1	73
Configuration ROM IEEE OUI BYTE 0	74
Configuration ROM Board Version	75
Configuration ROM Board Form Factor	76
Configuration ROM Board ID BYTE 1	77
Configuration ROM Board ID BYTE 0	78
Configuration ROM PCB Revision BYTE 3	79
Configuration ROM PCB Revision BYTE 2	80
Configuration ROM PCB Revision BYTE 1	81
Configuration ROM PCB Revision BYTE 0	82
Configuration ROM FLASH Type	83
Configuration ROM Board Serial Number BYTE 1	84
Configuration ROM Board Serial Number BYTE 0	
Configuration ROM VCXO Type	

## 1 Registers and Data Format

All registers described in the User Manual are 32-bit wide. In case of VME access, **A24** and **A32** addressing mode can be used.

#### Reset and Clear

The module's registers can be set back to their default values on software reset command by writing in the Software Reset register or by system reset from backplane, in case of VME boards. In particular, the registers or buffers listed below

- Event Readout Buffer
- Buffer Occupancy
- Event Stored
- Event Size

are also be set back to their default values (registers) or emptied (buffers) by a clear issued:

- automatically by the firmware at the start of each run;
- on software command by writing in the Software Clear register
- by hardware (VME boards only), through the LVDS interface properly configured (see the section "Front Panel LVDS I/Os" of the digitizer User Manual).

#### Register Address Map

The table below reports the complete list of registers that can be accessed by the user. The register names in the first column can be clicked to be redirected to the relevant register description. The register address is reported on the second column as a hex value. The third column indicates the allowed register access mode, where:

- R **Read only.** The register can be accessed in read only mode.
- W Write only. The register can be accessed in write only mode.
- R/W **Read and write**. The register can be accessed both in read and write mode.

According to the attribute reported in the fourth column, the following choices are available:

Individual register. This kind of register has N instances, where N is the total number of channels in the board. Individual registers can be written either in single mode (individual setting) or broadcast (simultaneous write access to all channels). Read command must be individual

Single access can be performed at address 0x1nXY, where n is the channel number, while broadcast write can be performed at the address 0x80XY. For example:

- access to address 0x1570 to read/write register 0x1n70 for channel 5 of the board;
- to write the same value for all channels in the board, access to 0x8070 (broadcast write). To read the corresponding value, access to the individual address 0x1n70.
- Group register. In case of 725 and 730 digitizer family, some registers manages couples of channels. Group registers have N instances, where N is the total number of channels. Write access can be performed in single group mode (one couple at a time) or broadcast (simultaneous write access to all groups). Read command must be in single group mode. Single group access can be performed at address 0x1nXY, where n (even) identifies channel n and channel n+1, while broadcast write can be performed at the address 0x80XY. For example:
  - to read/write register 0x1n70 for couple 3 of the board (i.e. channel 6 and channel 7), access to address 0x1670. The same value is applied also to channel 7.
  - to write the same value for all couples in the board, access to 0x8070 (broadcast write). To read the corresponding value, access to the individual address 0x1n70.
- C Common register. Register with this attribute has a single instance, therefore read and write access can be performed at address 0x80XY only.

Register Name	Address	Mode	Attribute
Event Readout Buffer	0x0000 - 0x0FFC	R	С
Dummy32	0x1n24, 0x8024	R/W	I
Channel n Input Dynamic Range	0x1n28, 0x8028	R/W	I
Channel n Pulse Width	0x1n70, 0x8070	R/W	I
Channel n Trigger Threshold	0x1n80, 0x8080	R/W	I
Couple n Self-Trigger Logic	0x1n84, 0x8084	R/W	G
Channel n Status	0x1n88	R	I
AMC Firmware Revision	0x1n8C	R	I
Channel n DC Offset	0x1n98, 0x8098	R/W	I
Channel n ADC Temperature	0x1nA8	R	I
Board Configuration	0x8000, 0x8004 (BitSet), 0x8008 (BitClear)	R/W	С
Buffer Organization	0x800C	R/W	С
Custom Size	0x8020	R/W	С
Channel ADC Calibration	0x809C	W	С
Acquisition Control	0x8100	R/W	С
Acquisition Status	0x8104	R	С
Software Trigger	0x8108	W	С
Global Trigger Mask	0x810C	R/W	С
Front Panel TRG-OUT (GPO) Enable Mask	0x8110	R/W	С
Post Trigger	0x8110	R/W	С
LVDS I/O Data	0x8114 0x8118	R/W	С
Front Panel I/O Control	0x8116 0x811C	R/W	С
Channel Enable Mask	0x8120	R/W	С
ROC FPGA Firmware Revision	0x8124	R	С
Event Stored	0x812C	R	С
Set Monitor DAC	0x812C 0x8138	R/W	С
	0x813C	W	С
Software Clock Sync  Board Info	0x813C 0x8140	R	С
Monitor DAC Mode	0x8140 0x8144		С
Event Size		R/W	С
	0x814C	R/W	С
Fan Speed Control	0x8168	R/W	С
Memory Buffer Almost Full Level	0x816C		
Run/Start/Stop Delay  Board Failure Status	0x8170	R/W	С
	0x8178	R	С
Front Panel LVDS I/O New Features	0x81A0	R/W	С
Channels Shutdown	0x81C0	W D //A/	С
Readout Control	0xEF00	R/W	С
Readout Status	0xEF04	R	С
Board ID	0xEF08	R/W	С
MCST Base Address and Control	0xEF0C	R/W	С
Relocation Address	0xEF10	R/W	С
Interrupt Status/ID	0xEF14	R/W	С
Interrupt Event Number	0xEF18	R/W	С
Max Number of Events per BLT	0xEF1C	R/W	С
Scratch	0xEF20	R/W	С
Software Reset	0xEF24	W	С
Software Clear	0xEF28	W	С
Configuration Reload	0xEF34	W	С
Configuration ROM Checksum	0xF000	R	С
Configuration ROM Checksum Length BYTE 2	0xF004	R	С
Configuration ROM Checksum Length BYTE 1	0xF008	R	С
Configuration ROM Checksum Length BYTE 0	0xF00C	R	С
Configuration ROM Constant BYTE 2	0xF010	R	С
Configuration ROM Constant BYTE 1	0xF014	R	С
Configuration ROM Constant BYTE 0	0xF018	R	С

Configuration ROM C Code	0xF01C	R	С
Configuration ROM R Code	0xF020	R	С
Configuration ROM IEEE OUI BYTE 2	0xF024	R	С
Configuration ROM IEEE OUI BYTE 1	0xF028	R	С
Configuration ROM IEEE OUI BYTE 0	0xF02C	R	С
Configuration ROM Board Version	0xF030	R	С
Configuration ROM Board Form Factor	0xF034	R	С
Configuration ROM Board ID BYTE 1	0xF038	R	С
Configuration ROM Board ID BYTE 0	0xF03C	R	С
Configuration ROM PCB Revision BYTE 3	0xF040	R	С
Configuration ROM PCB Revision BYTE 2	0xF044	R	С
Configuration ROM PCB Revision BYTE 1	0xF048	R	С
Configuration ROM PCB Revision BYTE 0	0xF04C	R	С
Configuration ROM FLASH Type	0xF050	R	С
Configuration ROM Board Serial Number BYTE 1	0xF080	R	С
Configuration ROM Board Serial Number BYTE 0	0xF084	R	С
Configuration ROM VCXO Type	0xF088	R	С

#### **Event Readout Buffer**

This is the addressment space for the event readout. The event is a series of 32-bit words according to the event structure defined in the digitizer User Manual.

Address 0x0000 - 0x0FFC

Mode R Attribute C

Bit	Description
[31:0]	32-bit word of the event.

10

#### Dummy32

Writing and reading at this register can be used for debug purposes.

Address 0x1n24, 0x8024

Bit	Description
[31:0]	Dummy32 value (default value is 0).

### Channel n Input Dynamic Range

This register sets the input dynamic range of each channel individually.

Address 0x1n28, 0x8028

Bit	Description
[0]	Input Dynamic Range.
	Options are:
	0 = 2 Vpp (default);
	1 = 0.5 Vpp.
[31:1]	Reserved.

#### Channel n Pulse Width

This register sets the width of the pulse generated when the input signal on the channel crosses the threshold. The value of this register is given in units of trigger clock (i.e. 8 ns).

**NOTE**: this setting is meaninful if bit[2] = 0 in the Self-Trigger Logic register.

**NOTE**: this register is implemented only from AMC FPGA firmware revision 0.2 on.

Address 0x1n70, 0x8070

Bit	Description
[7:0]	Pulse Width (default value is 0x02).
[31:8]	Reserved.

#### Channel n Trigger Threshold

The channel is able to generate a self-trigger signal when the digitized input pulse exceeds a configurable threshold Vth. This register allows to set Vth individually for each channel.

Address 0x1n80, 0x8080

Bit	Description
	Vth = Trigger Threshold Value expressed in LSB (default value is 0).
[13:0]	1LSB = InputDynamicRange/2 <sup>14bit</sup>
[31:14]	Reserved.

#### Couple n Self-Trigger Logic

For a couple of channels of adjacent channels, this register sets the logic to generate the trigger request signal upon the self-triggers from the two channels of the couple. Please, refer to the digitizer User Manual (Self-Trigger section) for complete description.

In case of DT, NIM and 8-channel VME boards: n = 0 (CH0-CH1), 2 (CH2-CH3), 4 (CH4-CH5), 6 (CH6-Ch7). In case of 16-channel VME boards, also n = 8 (CH8-CH9), n = A (CH10-CH11), n = C (CH12-CH13), n = E (CH14-CH15) are admitted. NOTE: this register is implemented only from AMC FPGA firmware revision 0.2 on.

Address 0x1n84, 0x8084

Bit	Description
	Self-Trigger Logic.
	Options are:
[1:0]	00 = AND;
[1.0]	01 = ONLY CH(n);
	10 = ONLY CH(n+1);
	11 = OR (default).
	This bit sets the kind of signal to be generated when the input pulse crosses the programmed
	digital threshold.
	Options are:
	0 = a pulse of programmable width is generated (configured by the Channel n Pulse Width
[2]	register, 0x1n70);
	1 = an over/under-threshold signal is generated, that is active (i.e. 1) as long as the input
	pulse is over the threshold or under the threshold (set through the Board Configuration
	register, 0x8000).
	Default value is 0.
[31:3]	Reserved.

#### **Channel n Status**

This register contains the status information of channel n.

Address 0x1n88 Mode R Attribute I

Bit	Description
[0]	Memory Full.
[1]	Memory Empty.
	Channel n DAC Busy.
[2]	Options are:
[2]	0 = DC offset updated;
	1 = Busy.
	ADC Calibration Status.
[3]	Options are:
[2]	0 = Calibration not done;
	1 = Calibration done.
[7:4]	Reserved.
[8]	ADC Power Down.
	When set to 1, it means that the ADC of channel n has been shut down due to an
	over-temperature condition.
[31:9]	Reserved.

#### **AMC Firmware Revision**

This register contains the channel FPGA (AMC) revision information.

The complete format is:

Firmware Revision = X.Y (16 lower bits)

Firmware Revision Date = Y/M/DD (16 higher bits)

**EXAMPLE 1:** revision 1.03, November 12th, 2007 is 0x7B120103.

**EXAMPLE 2:** revision 2.09, March 7th, 2016 is 0x03070209.

Address 0x1n8C Mode R Attribute I

Bit	Description
[7:0]	AMC Firmware Minor Revision Number (Y).
[15:8]	AMC Firmware Major Revision Number (X).
[31:16]	AMC Firmware Revision Date (Y/M/DD).
	NOTE: the year (Y) code 0 is associated both to 2000 and 2016.

#### Channel n DC Offset

This register allows to set the DC Offset of channel n, that is to say to adjust the baseline position (i.e. the 0 Volt) of the input signal on the ADC scale. The ADC scale ranges from 0 to  $2^{\text{NBit}} - 1$ , where NBit is the number of bits of the on-board ADC. The DAC controlling the DC Offset has 16 bits, i.e. it goes from 0 to 65535 independently from the NBit value and the board type.

Typically, a DC Offset value of 32K (DAC mid-scale) corresponds to about the ADC mid-scale. Increasing values of DC Offset make the baseline decrease. The DAC range is about 5 (typ.) larger than the ADC range, hence DAC settings close to 0 and 64K correspond to ADC respectively over and under range.

**WARNING:** before writing at this register, it is necessary to check that the Channel n DAC Busy bit (i.e. SPI Bus Busy flag) in the Channels n Status register (0x1n88) is set to 0 (bit[2] = 0), otherwise the process of writing will not run properly! After writing, the user is recommended to wait for few seconds before a new RUN to let the DAC output (i.e. the new programmed DC offset) get stabilized.

Address 0x1n98, 0x8098

Bit	Description
[15:0]	DC offset Level (default value is 0x8000). Please, refer to the digitizer User Manual (Input Stage section) for details.
[31:16]	Reserved.

#### **Channel n ADC Temperature**

This register monitors the temperature of the ADC chips.

**NOTE:** if this temperature varies significantly during the digitizer operation, the user is recommended to perform a new channel calibration procedure (see register 0x809C) to restore the board performance.

Address 0x1nA8 Mode R Attribute I

Bit	Description
[7:0]	ADC Chip Temperature (expressed in °C).
[31:8]	Reserved.

### **Board Configuration**

This register contains general settings for the board configuration.

Address 0x8000, 0x8004 (BitSet), 0x8008 (BitClear)

Bit	Description
[0]	Reserved: must be 0.
[1]	Trigger Overlap Setting (default value is 0).  When two acquisition windows are overlapped, the second trigger can be either accepted or rejected.  Options are:  0 = Trigger Overlapping Not Allowed (no trigger is accepted until the current acquisition window is finished);  1 = Trigger Overlapping Allowed (the current acquisition window is prematurely closed by the arrival of a new trigger).  NOTE: it is suggested to keep this bit cleared in case of using a DPP firmware.
[2]	Reserved: must be 0.
[3]	Test Pattern Enable (default value is 0). This bit enables a triangular (0<>3FFF) test wave to be provided at the ADCs input for debug purposes. Options are: 0 = disabled; 1 = enabled.
[4]	Reserved: must be 1.
[5]	Reserved: must be 0.
[6]	Self-trigger Polarity (default value is 0).  Options are:  0 = Positive (the self-trigger is generated upon the input pulse overthreshold);  1 = Negative (the self-trigger is generated upon the input pulse underthreshold).
[8:7]	Reserved: must be 0.
[9]	Reserved.
[10]	Reserved: must be 0.
[22:11]	Reserved.
[23]	Rserved: must be 0.
[31:24]	Reserved.

#### **Buffer Organization**

Sets the number of buffers in which the channel memory can be divided. A write access to this register causes a software clear.

According to the BUFFER\_CODE value written in the register, the number of buffers Nb is given by 2<sup>BUFFER\_CODE</sup> - 10:

BUFFER_CODE	Nr.Buffers (Nb)	Buffer Size (Samples)
0x0	1	640k-10 (SRAM 640kS/ch), 5.12M-10 (SRAM 5.12MS/ch)
0x1	2	320k-10 (SRAM 640kS/ch), 2.56M-10 (SRAM 5.12MS/ch)
0x2	4	160k-10 (SRAM 640kS/ch), 1.28M-10 (SRAM 5.12MS/ch)
0x3	8	80k-10 (SRAM 640kS/ch), 640k-10 (SRAM 5.12MS/ch)
0x4	16	40k-10 (SRAM 640kS/ch), 320k-10 (SRAM 5.12MS/ch)
0x5	32	20k-10 (SRAM 640kS/ch), 160k-10 (SRAM 5.12MS/ch)
0x6	64	10k-10 (SRAM 640kS/ch), 80k-10 (SRAM 5.12MS/ch)
0x7	128	5k-10 (SRAM 640kS/ch), 40k-10 (SRAM 5.12MS/ch)
0x8	256	2560-10 (SRAM 640kS/ch), 20k-10 (SRAM 5.12MS/ch)
0x9	512	1280-10 (SRAM 640kS/ch), 10k-10 (SRAM 5.12MS/ch)
0xA	1024	640-10 (SRAM 640kS/ch), 5k-10 (SRAM 5.12MS/ch)

To obtain a number of samples per buffer (referring to one channel) different from the table above, it is necessary to use the Custom Size register, 0x8020. In this case, the BUFFER CODE must be set to have the closest buffer size with a number of samples per buffer larger than the one set by Custom Size.

**EXAMPLE:** to have a desired number of samples per buffer of 900 (set through the Custom Size register), the BUFFER\_CODE must be 0x09 in case of 640-kS/ch memory or 0x0A if 5.12-MS/ch one.

**IMPORTANT:** For AMC FPGA firmware release < 0.2, the buffer size must be intended as the number of the samples in the table above without decreasing by 10.

Address	0x800C
Mode	R/W
Attribute	С

Bit	Description
[3:0]	BUFFER_CODE.
[31:4]	Reserved.

#### **Custom Size**

Writing the number of memory locations per event ( $N_LOC$ ) in this register, the user can set the record length, which is the number of samples (Ns) of the digitized waveform in the acquisition window, according to the formula  $Ns = N_LOC*10$ .

**EXAMPLE:** to have 900 samples per buffer, the value to write is  $N_LOC = 0x05A$ .

WARNING: this register must not be written while acquisition is running.

Address 0x8020 Mode R/W Attribute C

Bit	Description
	Number of Memory Locations per Event (N_LOC).
[31:0]	Options are:  0 = Custom Size disabled (record length is given by the Buffer Organization register, 0x800C);  N_LOC = record length is this value multiplied by 10 (1 location = 10 samples).

#### **Channel ADC Calibration**

x725 and x730 digitizers require a channel calibration to achieve the best performance. A calibration of the ADCs is automatically performed by the firmware at the power-on, but the user is recommended to manually execute the calibration after the ADCs have stabilized their operating temperature (see the Channel n ADC Temperature register, 0x1nA8). The calibration will not need to be repeated at each acquisition run, unless the operating temperature varies significantly, or clock settings are modified (e.g. switching from internal to external clock).

WARNING: before writing this register, it is necessary to check that the Cannel n DAC Busy flag = 0 (i.e. bit[2] = 0) in the Channel Status register, 0x1n88, otherwise the writing process cannot run properly.

**WARNING:** it is normally not required to calibrate after a board reset but, if a Reset command is intentionally issued to the digitizer (write access at Software Reset register, 0xEF24) to be directly followed by a calibration procedure, it is recommended to wait for the board to reach stable conditions (indicatively 100 ms) before to start the calibration.

**WARNING:** at power-on, a Sync command is issued by the firmware to the ADCs to synchronize all of them to the board's clock. In the standard operating, this command is not required to be repeated by the user. If a Sync command is intentionally issued (see SW Clock Sync register), the user must consider that a new calibration procedure is needed for a correct board operating.

Address	0x809C
Mode	W
Attribute	С

Bit	Description
[31:0]	Write any value to start the automatic calibration of the ADC simultaneously for all channels of the board.  The ADC Calibration Status flag (bit[3] of the Channel Status register, 0x1n88) will be set to 0.  Poll the ADC Calibration Status flag until it returns to 1.

### **Acquisition Control**

This register configures the acquisition settings

Address 0x8100 Mode R/W Attribute C

Bit	Description
	Start/Stop Mode Selection (default value is 00).
	Options are:
	00 = SW CONTROLLED. Start/stop of the run takes place on software command by
	setting/resetting bit[2] of this register;
	01 = S-IN/GPI CONTROLLED (S-IN for VME, GPI for Desktop/NIM). If the acquisition is armed
	(i.e. bit[2] = 1), then the acquisition starts when S-IN/GPI is asserted and stops when S-IN/GPI
[4.0]	returns inactive. If bit[2] = 0, the acquisition is always off;
[1:0]	10 = FIRST TRIGGER CONTROLLED. If the acquisition is armed (i.e. bit[2] = 1), then the run
	starts on the first trigger pulse (rising edge on TRG-IN); this pulse is not used as input trigger,
	while actual triggers start from the second pulse. The stop of Run must be SW controlled (i.e.
	bit[2] = 0);
	11 = LVDS CONTROLLED (VME only). It is like option 01 but using LVDS (RUN) instead of S-IN.
	The LVDS can be set using Front Panel I/O Control register, 0x811C, and Front Panel LVDS I/O
	New Features register, 0x81A0.
	Acquisition Start/Arm (default value is 0).
	When bits[1:0] = 00, this bit acts as a Run Start/Stop. When bits[1:0] = 01, 10, 11, this bit
[2]	arms the acquisition and the actual Start/Stop is controlled by an external signal.
[2]	Options are:
	0 = Acquisition STOP (if bits[1:0]=00); Acquisition DISARMED (others);
	1 = Acquisition RUN (if bits[1:0]=00); Acquisition ARMED (others).
	Trigger Counting Mode Selection.
[3]	Options are:
[5]	0 = only accepted triggers are counted (default);
	1 = all triggers are counted.
[4]	Reserved.
	Memory Full Mode Selection (default value is 0).
	Options are:
[5]	0 = NORMAL. The board is full whenever all buffers are full;
	1 = ONE BUFFER FREE. The board is full whenever Nb-1 buffers are full, where Nb is the
	overall number of buffers in which the channel memory is divided.
	PLL Reference Clock Source (Desktop/NIM only). Default value is 0.
	Options are:
[6]	0 = internal oscillator (50 MHz);
	1 = external clock from front panel CLK-IN connector.
	NOTE: this bit is reserved in case of VME boards.
[7]	Reserved.
	LVDS I/O Busy Enable (VME only). Default value is 0.
	The LVDS I/Os can be programmed to accept a Busy signal as input, or to propagate it as
[8]	output.
	Options are:
	0 = disabled;
[0]	1 = enabled.
	<b>NOTE:</b> this bit is supported only by VME boards and meaningful only if the LVDS new features
	are enabled (Bit[8]=1 in the Front Panel I/O Control register, 0x811C). LVDS I/O New Features
	register, 0x81A0, should also be configured for nBusy/nVeto.
	register, onotho, should also be configured for fibusy/fiveto.

	LVDS I/O Veto Enable (VME only).
	The LVDS I/Os can be programmed to accept a Veto signal as input, or to transfer it as output.
	Options are:
	0 = disabled (default);
[9]	1 = enabled.
	<b>NOTE:</b> this bit is supported only by VME boards and meaningful only if the LVDS new features are enabled (Bit[8]=1 in the Front Panel I/O Control register, 0x811C). LVDS I/O New Features register, 0x81AO, should also be configured for nBusy/nVeto.
[10]	Reserved.
	LVDS I/O Runin Enable Mode (VME only).
	The LVDS I/Os can be programmed to accept a RunIn signal as input, or to transfer it as output.
	Options are:
	0 = starts on Runin level (default);
[11]	1 = starts on RunIn rising edge.
	NOTE: this bit is supported only by VME boards and meaningful only if the LVDS new features
	are enabled (Bit[8]=1 in the Front Panel I/O Control register, 0x811C). LVDS I/O New Features
	register, 0x81A0, should also be configured for nBusy/nVeto.
[31:12]	Reserved.

### **Acquisition Status**

This register monitors a set of conditions related to the acquisition status.

Address 0x8104 Mode R Attribute C

Bit	Description
[1:0]	Reserved.
[2]	Acquisition Status. It reflects the status of the acquisition and drivers the front panel 'RUN' LED.  Options are: 0 = acquisition is stopped ('RUN' is off); 1 = acquisition is running ('RUN' lits).
[3]	Event Ready. Indicates if any event are available for readout.  Options are:  0 = no event is available for readout;  1 = at least one event is available for readout.  NOTE: the status of this bit must be considered when managing the readout from the digitizer.
[4]	Event Full. Indicates if the board has reached the FULL condition.  Options are: 0 = the board is not FULL; 1 = the board is FULL.
[5]	Clock Source. Indicates the clock source status.  Options are:  0 = internal (PLL uses the internal 50 MHz oscillator as reference);  1 = external (PLL uses the external clock on CLK-IN connector as reference).
[6]	PLL Bypass Mode. This bit drives the front panel 'PLL BYPS' LED.  Options are:  0 = PLL bypass mode is not active ('PLL BYPS' is off);  1 = PLL bypass mode is active and the VCXO frequency directly drives the clock distribution chain ('PLL BYPS' lits).  WARNING: before operating in PLL Bypass Mode, it is recommended to contact CAEN for
[7]	feasibility.  PLL Unlock Detect. This bit flags a PLL unlock condition.  Options are:  0 = PLL has had an unlock condition since the last register read access;  1 = PLL hasn't had any unlock condition since the last register read access.  NOTE: flag can be restored to 1 via read access to the Readout Status register, 0xEF04.
[8]	Board Ready. This flag indicates if the board is ready for acquisition (PLL and ADCs are correctly synchronised).  Options are: 0 = board is not ready to start the acquisition; 1 = board is ready to start the acquisition.  NOTE: this bit should be checked after software reset to ensure that the board will enter immediately in run mode after the RUN mode setting; otherwise, a latency between RUN mode setting and Acquisition start might occur.
[14:9]	Reserved.
[15]	S-IN (VME boards) or GPI (DT/NIM boards) Status. Reads the current logical level on S-IN (GPI) front panel connector.
[16]	TRG-IN Status. Reads the current logical level on TRG-IN front panel connector.
[18:17]	Reserved.

[19]	Channels Shutdown Status. This bit monitors the shutdown of the channels according to bit[8] of 0x1n88 register address and the procedure described at 0x81C0 register address.  Options are: 0 = channels are ON; 1 = channels are in shutdown.
[23:20]	Bits[23:20] (bits[21:20] in case of DT, NIM and 8-channel VME versions) monitor the temperature status of the board channels. Each bit refers to a 4-channel mezzanine, i.e. bit[20] refers to channels 3-0, bit[21] to channels 7-4, and so on. When at least one of the channels in the mezzanine exceeds the 70°C limit, the relevant bit is set automatically to 1. As soon as at least one of these bits becomes 1, the board enters the temperature protection condition which causes the automatic channel turning off and the acquisition RUN stop (if it was on):  1. Bit[19] becomes 1. 2. Bit[2] of the Acquisition Control register, 0x8100, is automatically set to 0. Data possibly stored at the moment can be readout in any case.  When all the bits[23:20] (bits[21:20]) become 0, the board exits the temperature protection condition. This means that the channel temperature reached at least 61°C. The user has then to turn on the board channels and the acquisition RUN (if necessary):  1. Bit[0] of the Channels Shutdown regsiter, 0x8100, must be set to 0 (bit[19] of the Acquisition Status register, 0x8104, becomes 0).  2. Bit[2] of of the Acquisition Control register, 0x8100, must be set to 1.
[31:24]	Reserved.  NOTE: in case of DT, NIM and 8-channel VME boards, bits[31:22] are reserved.

#### **Software Trigger**

Writing this register causes a software trigger generation which is propagated to all the enabled channels of the board.

Address 0x8108 Mode W Attribute C

Bit	Description
[31:0]	Write whatever value to generate a software trigger.

### **Global Trigger Mask**

This register sets which signal can contribute to the global trigger generation.

Address 0x810C Mode R/W Attribute C

Bit	Description
[7:0]	Bit n corresponds to the trigger request from couple n that participates to the global trigger generation (n = 0,,3 for DT, NIM and 8-channel VME boards; n = 0,,7 for 16-channel VME boards).  Options are:  0 = trigger request is not sensed for global trigger generation;  1 = trigger request participates in the global trigger generation.  Couple n corresponds to the two consecutive channels 2n and 2n+1: couple 0 is channel 0 and channel 1, couple 1 is channel 2 and channel 3, and so on. The trigger request from the couple can be programmed through the Self-Trigger Logic register (0x1n84) to be the AND/OR/one of the channels.  NOTE: in case of DT, NIM and 8-channel VME boards, only bits[3:0] are meaningful, while bits[7:4] are reserved.
	Reserved.
[19:8]	
	NOTE: in case of DT, NIM and 8-channel VME Boards, bits[19:4] are reserved.
[23:20]	Majority Coincidence Window. Sets the time window (in units of the trigger clock) for the majority coincidence. Majority level must be set different from 0 through bits[26:24].
[26:24]	Majority Level. Sets the majority level for the global trigger generation. For a level m, the trigger fires when at least m+1 of the enabled trigger requests (bits[7:0] or [3:0]) are over-threshold inside the majority coincidence window (bits[23:20]).  NOTE: the majority level must be smaller than the number of channels enabled via bits[7:0] mask (or [3:0]).
[28:27]	Reserved.
[29]	LVDS Trigger (VME boards only). When enabled, the trigger from LVDS I/O participates to the global trigger generation (in logic OR).  Options are: 0 = disabled; 1 = enabled.
[30]	External Trigger. When enabled, the external trigger on TRG-IN participates to the global trigger generation in logic OR with the other enabled signals (bit[31] and bits[7:0] or [3:0]). Options are:  0 = disabled; 1 = enabled.
[31]	Software Trigger. When enabled, the software trigger participates to the global trigger signal generation in logic OR with the other enabled signals (bit[30] and bits[7:0] or [3:0]).  Options are: 0 = disabled; 1 = enabled.

### Front Panel TRG-OUT (GPO) Enable Mask

This register sets which signal can contribute to generate the signal on the front panel TRG-OUT LEMO connector (GPO in case of DT and NIM boards).

Address 0x8110 Mode R/W Attribute C

Bit	Description
[7:0]	This mask sets the trigger requests participating in the TRG-OUT (GPO) signal. Bit n corresponds to the trigger request from couple n (n=0,,3 in case of DT, NIM and 8-channel VME boards; n = 0,, 7 in case of 16-channel VME boards).  Options are:  0 = Trigger request does not participate to the TRG-OUT (GPO) signal;  1 = Trigger request participates to the TRG-OUT (GPO) signal.  Couple n corresponds to the two consecutive channels 2n and 2n+1: couple 0 is channel 0 and channel 1, couple 1 is channel 2 and channel 3, and so on. The trigger request from the couple can be programmed through the Self-Trigger Logic register (0x1n84) to be the AND/OR/one of the channels.  NOTE: in case of DT, NIM and 8-channels VME boards, only bits[3:0] are meaningful while
[9:8]	bis[7:4] are reserved.  TRG-OUT (GPO) Generation Logic. The enabled trigger requests (bits [7:0] or [3:0]) can be combined to generate the TRG-OUT (GPO) signal.  Options are:  00 = OR;  01 = AND;  10 = Majority;  11 = Reserved.
[12:10]	Majority Level. Sets the majority level for the TRG-OUT (GPO) signal generation. Allowed level values are between 0 and 7 for VME boards, while between 0 and 3 for DT, NIM and 8-channel VME boards. For a level m, the trigger fires when at least m+1 of the trigger requests are generated by the enabled couples of channels (bits [7:0] or [3:0]).
[28:13]	Reserved.
[29]	LVDS Trigger Enable (VME boards only). If the LVDS I/Os are programmed as outputs, they can participate in the TRG-OUT (GPO) signal generation. They are in logic OR with the other enabled signals (bits[31:30] and bits[7:0], or [3:0]).  Options are:  0 = disabled; 1 = enabled.
[30]	External Trigger. When enabled, the external trigger on TRG-IN can participate in the TRG-OUT (GPO) signal generation in logic OR with the other enabled signals (bit[31] and bits[7:0] or [3:0]).  Options are:  0 = disabled;  1 = enabled.
[31]	Software Trigger. When enabled, the software trigger can participate in the TRG-OUT (GPO) signal generation in logic OR with the other enabled signals (bit[30], bits[7:0] or [3:0]).  Options are:  0 = disabled;  1 = enabled.

#### Post Trigger

The value of this register is used to set the number of post-trigger samples, that is the number of further samples that are written by the FPGA in the channel memory, when a trigger occurs, before to freeze the buffer. The number of post trigger samples is:

Npost = PostTriggerValue \* N + ConstantLatency

#### where:

Npost = number of post trigger samples.

PostTriggerValue = content of this register.

N = coefficient to be multiplied by the PostTriggerValue (N = 8 for 730 and N = 4 for 725).

ConstantLatency = constant number of samples added due to the latency associated to the trigger processing logic in the ROC FPGA. This value is constant, but the exact value may change between different firmware revisions.

Address 0x8114 Mode R/W Attribute C

Bit	Description
[31:0]	PostTriggerValue.

### LVDS I/O Data

This register allows to readout the logic level of the LVDS I/Os if the LVDS pins are configured as outputs, and to set the logic level of the LVDS I/Os if the pins are configured as inputs (REGISTER mode).

NOTE: this register is supported only by VME boards.

Address 0x8118 Mode R/W Attribute C

Bit	Description
[15:0]	LVDS I/O Data (VME boards only). If the LVDS I/O new features are enabled (bit[8] of 0x811C) and REGISTER mode is set (through 0x81A0), this register allows to read/write from the corresponding nth LVDS I/O according to its configuration. A write operation sets the corresponding pin logic state if configured as output, while a read operation returns the logic state of the corresponding pin if configured as input.
[31:16]	Reserved.

## Front Panel I/O Control

This register manages the front panel I/O connectors.

Address 0x811C Mode R/W Attribute C

Bit	Description
[0]	LEMO I/Os Electrical Level. This bit sets the electrical level of the front panel LEMO connectors: TRG-IN, TRG-OUT (GPO in case of DT and NIM boards), S-IN (GPI in case of DT and NIM boards).  Options are:  0 = NIM I/O levels;  1 = TTL I/O levels.
[1]	LVDS I/O Enable (VME boards only). Enables the 16-pin LVDS I/O front panel connector.  Options are: 0 = enabled; 1 = high impedance.  NOTE: this bit is reserved in case of DT and NIM boards.
[2]	LVDS I/O [3:0] Direction (VME boards only). Sets the direction of the signals on the first 4-pin group of the LVDS I/O connector.  Options are:  0 = input;  1 = output.  NOTE: this bit is reserved in case of DT and NIM boards.
[3]	LVDS I/O [7:4] Direction (VME boards only). Sets the direction of the second 4-pin group of the LVDS I/O connector.  Options are: 0 = input; 1 = output.  NOTE: this bit is reserved in case of DT and NIM boards.
[4]	LVDS I/O [11:8] Direction (VME boards only). Sets the direction of the third 4-pin group of the LVDS I/O connector. Options are: 0 = input; 1 = output.  NOTE: this bit is reserved in case of DT and NIM boards.
[5]	LVDS I/O [15:12] Direction (VME boards only). Sets the direction of the fourth 4-pin group of the LVDS I/O connector.  Options are: 0 = input; 1 = output.  NOTE: this bit is reserved in case of DT and NIM boards.
[7:6]	LVDS I/O Signal Configuration (VME boards and LVDS I/O old features only). This configuration must be enabled through bit[8] set to 0.  Options are:  00 = general purpose I/O;  01 = programmed I/O;  10 = pattern mode: LVDS signals are input and their value is written into the header PATTERN field;  11 = reserved.  NOTE: these bits are reserved in case of DT and NIM boards.

	LVDS I/O New Features Selection (VME boards only).
	Options are:
	0 = LVDS old features;
	1 = LVDS new features.
[8]	The new features options can be configured through LVDS I/O New Features register
	(0x81A0). Please, refer to the User Manual for all details.
	NOTE: LVDS I/O New Features option is valid from motherboard firmware revision 3.8 on.
	NOTE: this bit is reserved in case of DT and NIM boards.
	LVDS I/Os Pattern Latch Mode (VME boards only).
	Options are:
	0 = Pattern (i.e. 16-pin LVDS status) is latched when the (internal) global trigger is sent to
	channels, in consequence of an external trigger. It accounts for post-trigger settings and input
[9]	latching delays;
	1 = Pattern (i.e. 16-pin LVDS status) is latched when an external trigger arrives.
	NOTE: this bit is reserved in case of DT and NIM boards.
	TRG-IN control. The board trigger logic can be synchronized either with the edge of the TRG-IN
	signal, or with its whole duration. Note: this bit must be used in conjunction with bit[11] = 0.
[10]	Options are:
	0 = trigger is synchronized with the edge of the TRG-IN signal;
	1 = trigger is synchronized with the whole duration of the TRG-IN signal.
	TRG-IN to Mezzanines (channels).
	Options are:
[11]	0 = the TRG-IN signal is processed by the motherboard and sent to mezzanine (default). The
[11]	trigger logic is then synchronized with TRG-IN;
	1 = TRG-IN is directly sent to the mezzanines with no mother board processing nor delay
	NOTE: if this bit is set to 1, then bit[10] is ignored.
[13:12]	Reserved.
	Force TRG-OUT (GPO). This bit can force TRG-OUT (GPO in case of DT and NIM boards) test
	logical level if bit[15] = 1.
[14]	Options are:
	0 = Force TRG-OUT (GPO) to 0;
	1 = Force TRG-OUT (GPO) to 1.
	TRG-OUT (GPO) Mode. Options are:
[15]	0 = TRG-OUT (GPO) is an internal signal (according to bits[17:16]);
	1= TRG-OUT (GPO) is a test logic level set via bit[14].
	TRG-OUT (GPO) Mode Selection.
	Options are:
	00 = Trigger: TRG-OUT/GPO propagates the internal trigger sources according to the Front
	Panel TRG-OUT Enable Mask register, 0x8110;
[17:16]	01 = Motherboard Probes: TRG-OUT/GPO is used to propagate signals of the motherboards
	according to bits[19:18];
	10 = Channel Probes: TRG-OUT/GPO is used to propagate signals of the mezzanines (Channel
1	,
	Signal Virtual Probe);
	Signal Virtual Probe); 11 = S-IN (GPI) propagation.
	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).
	Signal Virtual Probe); 11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO). Options are:
	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with
	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or
[10·1 <u>8</u> ]	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or TRG-OUT->S-IN daisy chain;
[19:18]	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or TRG-OUT->S-IN daisy chain;  01 = CLKOUT: this clock is synchronous with the sampling clock of the ADC and this option can
[19:18]	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or TRG-OUT->S-IN daisy chain;  01 = CLKOUT: this clock is synchronous with the sampling clock of the ADC and this option can be used to align the phase of the clocks in different boards;
[19:18]	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or TRG-OUT->S-IN daisy chain;  01 = CLKOUT: this clock is synchronous with the sampling clock of the ADC and this option can be used to align the phase of the clocks in different boards;  10 = CLK Phase;
[19:18]	Signal Virtual Probe);  11 = S-IN (GPI) propagation.  Motherboard Virtual Probe Selection (to be propagated on TRG- OUT/GPO).  Options are:  00 = RUN: the signal is active when the acquisition is running. This option can be used with VME boards to synchronize the start/stop of the acquisition through the TRG-OUT->TR-IN or TRG-OUT->S-IN daisy chain;  01 = CLKOUT: this clock is synchronous with the sampling clock of the ADC and this option can be used to align the phase of the clocks in different boards;

[20]	BUSY_UNLOCK Select. Selects the BUSY_UNLOCK signal type to be propagated on TRG-OUT (GPO) when bits[19:18] = 11.  Options are:  0 = Board BUSY;  1 = PLL Lock Loss.  NOTE: this bit is reserved in case of ROC FPGA firmware rel. 4.5 or lower.
[22:21]	Pattern Configuration. Configures the information given by the 16-bit PATTERN field in the header of the event format.  Option are:  00 = PATTERN: 16-bit pattern latched on the 16 LVDS signals as one trigger arrives (default);  01 = EVENT TRIGGER SOURCE: 16-bit PATTERN indicates the trigger source causing the event acquisition;  10 = EXTENDED TRIGGER TIME TAG: enables the Trigger Time Tag information over 48 bits.  The 16 most significant bits are given by the 16-bit PATTERN field, while the remaining 32 ones are given by the TRIGGER TIME TAG information in the header of the event format (roll-over bit is not managed).  11 = NOT USED: if configured, it acts like 00 setting.  NOTE: Refer to the Event Structure section of the digitizer User Manual for a complete information.
[31:23]	Reserved.

#### **Channel Enable Mask**

This register enables/disables selected channels to participate in the event readout. Disabled channels are not operative.

WARNING: this register must not be modified while the acquisition is running.

Address 0x8120 Mode R/W Attribute C

Bit	Description
[15:0]	Channel Enable Mask. Bit n can enable/disable channel n to participate in the event readout.  Options are: 0 = disabled; 1 = enabled.  NOTE: bits[15:8] are reserved in case of DT, NIM and 8-channel VME boards.
[31:16]	Reserved.

#### **ROC FPGA Firmware Revision**

This register contains information on the motherboard firmware revision (ROC FPGA) in the format X.Y, and the revision date in the format Y/M/DD.

Note that nibble code for the year makes this information to roll over each 16 years.

**EXAMPLE 1:** revision 3.08, November 12th, 2007 is 0x7B120308.

**EXAMPLE 2:** revision 4.09, March 7th, 2016 is 0x03070409.

Address 0x8124 Mode R Attribute C

Bit	Description
[7:0]	Firmware Minor Revision Number (Y).
[15:8]	Firmware Major Revision Number (X).
[31:16]	Revision Date.

#### **Event Stored**

This register contains the number of events currently stored in the Output Buffer.

**NOTE:** the value of this register cannot exceed the maximum number of available buffers according to the Buffer Organization register setting (0x800C).

Address 0x812C Mode R Attribute C

Bit	Description
[31:0]	Number of the current events stored in the Output Buffer.

#### **Set Monitor DAC**

When the Voltage Level Mode is enabled (through 0x8144), this register sets the DAC value to be provided on the front panel MON/Sigma output LEMO connector: 1 LSB = 0.244 mV, terminated on 50 Ohm.

**NOTE:** this register is supported only by VME boards.

Address 0x8138 Mode R/W Attribute C

Bit	Description
[11:0]	DAC Voltage Setting (VME boards only). The corresponding output value is multiplied by 0.244 mV.
[31:12]	Reserved

#### **Software Clock Sync**

At power-on, a Sync command is issued by the firmware to the ADCs to synchronize all of them to the clock of the board. In the standard operating, this command is not required to be repeated by the user.

A write access to this register (any value) forces the PLL to re-align all the clock outputs with the reference clock.

**EXAMPLE:** in case of Daisy chain clock distribution among VME boards, during the initialization and configuration, the reference clocks along the Daisy chain can be unstable and a temporary loss of lock may occur in the PLLs; although the lock is automatically recovered once the reference clocks return stable, it is not guaranteed that the phase shift returns to a known state. This command allows the board to restore the correct phase shift between the CLK-IN and the internal clocks.

NOTE: this register is supported by VME boards only.

**NOTE:** the command must be issued starting from the first to the last board in the clock chain.

**NOTE:** if a Sync command is intentionally issued, the user must consider that a new channels calibration procedure is needed for a correct board operating (see 0x809C).

Address 0x813C Mode W Attribute C

Bit	Description
[31:0]	Write whatever value to generate a Sync command.

#### **Board Info**

This register contains the specific information of the board, such as the digitizer family, the channel memory size and the channel density.

Address 0x8140 Mode R Attribute C

Bit	Description
[7:0]	Digitizer Family Code.
	Options are:
[7.0]	0x0E = 725 digitizer family;
	0x0B = 730 digitizer family.
	Channel Memory Size Code.
[15:8]	Options are:
[13.6]	0x01 = 640 kS acquisition memory per channel;
	0x08 = 5.12 MS acquisition memory per channel.
	Equipped Channels Number.
	Options are:
	0x10 = 16 channels (VME boards);
[23:16]	0x08 = 8 channels (DT, NIM and 8-channel VME boards).
	<b>NOTE:</b> if this number is lower than the physical channels number, there could be a
	communication problem with some of the mezzanines.
[31:24]	Reserved.

#### **Monitor DAC Mode**

This register sets the output DAC mode of the MON/Sigma front panel LEMO connector.

**NOTE:** this register is supported by VME boards only.

Address 0x8144 Mode R/W Attribute C

Bit	Description
	Monitor DAC Mode (VME boards only).
	Options are:
	000 = Trigger Majority mode;
	001 = Test mode;
[2:0]	010 = reserved;
	011 = Buffer Occupancy mode;
	100 = Voltage Level mode;
	Others = reserved.
	Please, refer to the digitizer User Manual for a detailed description.
[31:3]	Reserved.

#### **Event Size**

This register contains the current available event size in 32-bit words. The value is updated after a complete readout of each event.

Address 0x814C Mode R Attribute C

Bit	Description
[31:0]	Event Size (32-bit words).

#### **Fan Speed Control**

This register manages the fan speed control in order to guarantee an appropriate cooling according to the internal temperature variations (Desktop boards only).

**NOTE:** from revision 4 of the motherboard PCB (see register 0xF04C of the Configuration ROM), the automatic fan speed control has been implemented, and it is supported by ROC FPGA firmware revision greater than 4.4 (see register 0x8124).

Independently of the revision, the user can set the fan speed high by setting bit[3] = 1. Setting bit[3] = 0 will restore the automatic control for revision 4 or higher, or the low fan speed in case of revisions lower than 4.

NOTE: this register is supported by Desktop (DT) boards only.

Address 0x8168 Mode R/W Attribute C

Bit	Description
[2:0]	Reserved: Must be 0.
[3]	Fan Speed Mode.
	Options are:
	0 = slow speed or automatic speed tuning;
	1 = high speed.
[5:4]	Reserved: Must be 1.
[31:6]	Reserved: Must be 0.

#### Memory Buffer Almost Full Level

This regsiter allows to set the level for the Almost Full generation. The written value (ALMOST FULL LEVEL) represents the number of buffers that must be full of data before to assert the BUSY signal. This register takes part in the BUSY propagation among multiple boards.

**NOTE:** if this register is set to 0, the ALMOST FULL is a FULL.

For the Almost Full description, please refer to the Acquisition Synchronization section of the digitizer User Manual.

Address 0x816C Mode R/W Attribute C

Bit	Description
[10:0]	ALMOST FULL LEVEL.
[31:11]	Reserved.

#### Run/Start/Stop Delay

When the start of Run is given synchronously to several boards connected in Daisy chain, it is necessary to compensate for the delay in the propagation of the Start (or Stop) signal through the chain. This register sets the delay, expressed in trigger clock cycles between the arrival of the Start signal at the input of the board (either on S-IN/GPI or TRG-IN) and the actual start of Run. The delay is usually zero for the last board in the chain and rises going backwards along the chain.

Address 0x8170 Mode R/W Attribute C

Bit	Description
[31:0]	Delay (in units of 8 ns).

#### **Board Failure Status**

This register monitors a set of board errors. In case of a failure, bit[26] in the second word of the event format header is set to 1 during data readout (refer to the digitizer User Manual for event structure description). Reading at this register checks which kind of error occurred.

**NOTE:** in case of problems with the board, the user is recommended to contact CAEN for support.

Address 0x8178 Mode R Attribute C

Bit	Description
[3:0]	Internal Communication Timeout.
	Options are:
[5.0]	0000 = no error;
	Others = Timeout Error occurred.
	PLL Lock Loss.
[4]	Options are:
[4]	0 = no error;
	1 = PLL Lock Loss occurred.
	Temperature Failure.
[5]	Options are:
ادا	0 = no error;
	1 = Temperature Failure occurred (i.e. at least one channel is in over- temperature condition).
	ADC Power Down.
[6]	Options are:
	0 = no error;
	1 =ADC Power Down occurred (i.e. at least one channel is in power down mode due to an
	automatic over-temperature protection).
[31:7]	Reserved.

#### Front Panel LVDS I/O New Features

If the LVDS I/O new features are enabled (bit[8] = 1 of 0x811C), this register programs the functions of the front panel LVDS I/O 16-pin connector. It is possible to configure the LVDS I/O pins by group of four (4). Options are:

1) 0000 = REGISTER, where the four LVDS I/O pins act as register (read/write according to the configured input/output option);

2) 0001 = TRIGGER, where each group of four LVDS I/O pins can be configured to receive an input trigger for each channel (DPP Firmware only), or to propagate out the channel trigger request;

3) 0010 = nBUSY/nVETO, where each group of four LVDS I/O pins can be configured as inputs (0 = nBusyIn, 1 = nVetoIn, 2 = nTrigger In, 3 = nRun In) or as outputs (0 = nBusy, 1 = nVeto, 2 = nTrigger Out, 3 = nRun );

4) 0011 = LEGACY, that is to say according to the old LVDS I/O configuration (i.e. ROC FPGA firmware revisions lower than 3.8), where the LVDS can be configured as 0 = nclear TTT, and 1 = 2 = 3 = reserved in case of input LVDS setting, while they can be configured as 0 = Busy, 1 = Data ready, 2 = Trigger, 3 = Run in case of output LVDS setting). Please refer to the Front Panel LVDS I/Os section of the digitizer User Manual for detailed description.

NOTE: LVDS I/O new features are supported from ROC FPGA firmware revision 3.8 on.

NOTE: this register is supported by VME boards only.

Address 0x81A0 Mode R/W Attribute C

Bit	Description
[3:0]	LVDS I/O pins[3:0] Configuration.
[7:4]	LVDS I/O pins[7:4] Configuration.
[11:8]	LVDS I/O pins[11:8] Configuration
[15:12]	LVDS I/O pins[15:12] Configuration.
[31:16]	Reserved.

#### **Channels Shutdown**

This register allows to switch on all the channels of the board after they have been switched off by the automatic shutdown procedure. Channels must be switched on only once the board exits the temperature protection condition.

**NOTE:** bit[0] is forced to 1 while the board remains in the temperature protection condition.

**NOTE:** it is not recommended to use this register to shutdown the channels (bit[0] = 1) when the board is out of the temperature protection condition.

Address 0x81C0 Mode W Attribute C

Bit	Description
	Channels Shutdown.
[0]	Options are:
[0]	0 = no shutdown command is issued;
	1 = a shutdown command is issued.
[31:1]	Reserved.

#### **Readout Control**

This register is mainly intended for VME boards, anyway some bits are applicable also for DT and NIM boards.

Address 0xEF00 Mode R/W Attribute C

Bit	Description
	VME Interrupt Level (VME boards only). Options are:
[2:0]	0 = VME interrupts are disabled;
[=.0]	1,,7 = sets the VME interrupt level.
	NOTE: these bits are reserved in case of DT and NIM boards.
	Optical Link Interrupt Enable. Options are:
[3]	0 = Optikal Link interrupts are disabled;
	1 = Optical Link interrupts are enabled.
	VME Bus Error / Event Aligned Readout Enable (VME boards only). Options are:  0 = VME Bus Error / Event Aligned Readout disabled (the module sends a DTACK signal until
[4]	the CPU inquires the module);
[4]	1 = VME Bus Error / Event Aligned Readout enabled (the module is enabled either to generate a Bus Error to finish a block transfer or during the empty buffer readout in D32).
	NOTE: this bit is reserved (must be 1) in case of DT and NIM boards.  VME Align64 Mode (VME boards only).
	Options are:
[5]	0 = 64-bit aligned readout mode disabled; 1 = 64-bit aligned readout mode enabled.
	NOTE: this bit is reserved (must be 0) in case of DT and NIM boards.  VME Base Address Relocation (VME boards only).
	Options are:
[6]	0 = Address Relocation disabled (VME Base Address is set by the on-board rotary switches); 1 = Address Relocation enabled (VME Base Address is set by the Relocation Address register,
	0xEFOC).
	<b>NOTE:</b> this bit is reserved (must be 0) in case of DT and NIM boards.
	Interrupt Release mode (VME boards only).
	Options are: 0 = Release On Register Access (RORA): this is the default mode, where interrupts are
	removed by disabling them either by setting VME Interrupt Level to 0 (VME Interrupts) or by
[7]	setting Optical Link Interrupt Enable to 0;  1 = Release On Acknowledge (ROAK). Interrupts are automatically disabled at the end of a
[7]	VME interrupt acknowledge cycle (INTACK cycle).
	NOTE: ROAK mode is supported only for VME interrupts. ROAK mode is not supported on
	interrupts generated over Optical Link.
	NOTE: this bit is reserved (must be 0) in case of DT and NIM boards.
	Extended Block Transfer Enable (VME boarsd only). Selects the memory interval allocated for block transfers.
	Options are:
	0 = Extended Block Transfer Space is disabled, and the block transfer region is a 4kB in the
[8]	0x0000 - 0x0FFC interval; 1 = Extended Block Transfer Space is enabled, and the block transfer is a 16 MB in the
,	0x00000000 - 0xFFFFFFC interval.
	NOTE: in Extended mode, the board VME Base Address is only set via the on- board [31:28]
	rotary switches or the bits[31:28] of Relocation Address register (0xEF10).
	NOTE: this register is reserved in case of DT and NIM boards.



[31:9]	Reserved.				
--------	-----------	--	--	--	--

#### **Readout Status**

This register contains information related to the readout.

Address 0xEF04 Mode R Attribute C

Bit	Description
	Event Ready. Indicates if there are events stored ready for readout.
[0]	Options are:
[0]	0 = no data ready;
	1 = event ready.
	Output Buffer Status. Indicates if the Output Buffer is in Full condition.
[1]	Options are:
[1]	0 = the Output Buffer is not FULL;
	1 = the Output Buffer is FULL.
	Bus Error (VME boards) / Slave-Terminated (DT/NIM boards) Flag.
	Options are:
	0 = no Bus Error occurred (VME boards) or no terminated transfer (DT/NIM boards);
[2]	1 = a Bus Error occurred (VME boards) or one transfer has been terminated by the digitizer in
"-"	consequence of an unsupported register access or block transfer prematurely terminated in
	event aligned readout (DT/NIM).
	NOTE: this bit is reset after a Readout Status register readout (0xEF04).
[24.2]	· , ,
[31:3]	Reserved.

#### **Board ID**

The meaning of this register depends on which VME crate it is inserted in.

In case of VME64X crate versions, this register can be accessed in read mode only and it contains the GEO address of the module picked from the backplane connectors; when CBLT is performed, the GEO address will be contained in the Board ID field of the Event header (see the User Manual for further details).

In case of other crate versions, this register can be accessed both in read and write mode, and it allows to write the correct GEO address (default setting = 0) of the module before CBLT operation. GEO address will be contained in the Board ID field of the Event header (see the User Manual for further details).

NOTE: this register is supported by VME boards only.

Address 0xEF08 Mode R/W Attribute C

Bit	Description
[4:0]	GEO Address (VME boards only).
[31:5]	Reserved.

#### **MCST Base Address and Control**

This register configures the board for the VME Multicast Cycles.

**NOTE:** this register is supported by VME boards only.

Address OxEFOC Mode R/W Attribute C

Bit	Description
[7:0]	These bits contain the most significant bits of the MCST/CBLT address of the module set via
[7.0]	VME, that is the address used in MCST/CBLT operations.
	Board Position in Daisy chain.
	Options are:
[9:8]	00 = board disabled;
[5.6]	01 = last board;
	10 = first board;
	11 = intermediate board.
[31:10]	Reserved.

#### **Relocation Address**

If address relocation is enabled through register 0xEF00, this register sets the VME Base Address of the module.

**NOTE:** this register is supported by VME boards only.

Address 0xEF10 Mode R/W Attribute C

Bit	Description
[15:0]	These bits contain the A31A16 bits of the address of the module. If bit[6] = 1 of register 0xEF00, this register sets the VME Base Address of the module.
[31:16]	Reserved.

# Interrupt Status/ID

This register contains the STATUS/ID that the module places on the VME data bus during the Interrupt Acknowledge cycle.

**NOTE:** this register is supported by VME boards only.

Address 0xEF14 Mode R/W Attribute C

Bit	Description
[31:0]	STATUS/ID (VME boards only).

#### **Interrupt Event Number**

This register sets the number of events that causes an interrupt request. If interrupts are enabled, the module generates a request whenever it has stored in memory a Number of Events > INTERRUPT EVENT NUMBER.

Address 0xEF18 Mode R/W Attribute C

Bit	Description
[9:0]	INTERRUPT EVENT NUMBER.
[31:10]	Reserved.

#### Max Number of Events per BLT

This register sets the maximum number of complete events which has to be transferred for each block transfer (via VME BLT/CBLT cycles, or block readout through USB or Optical Link).

Address 0xEF1C Mode R/W Attribute C

Bit	Description
[15:0]	MAX NUM EVENT PER BLT.
[31:16]	Reserved.

#### **Scratch**

This register can be used to write/read words for test purposes.

Address 0xEF20 Mode R/W Attribute C

Bit	Description
[31:0]	SCRATCH.

#### **Software Reset**

All the digitizer registers can be set back to their default values on software reset command by writing any value at this register, or by system reset from backplane in case of VME boards.

Address 0xEF24 Mode W Attribute C

Bit	Description
[31:0]	Whatever value written at this location issues a software reset. All registers are set to their
[51.0]	default values (actual settings are lost).

#### **Software Clear**

All the digitizer internal memories are cleared:

- automatically by the firmware at the start of each run;
- on software command by writing at this register;
- by hardware (VME boards only) through the LVDS interface properly configured.

A clear command doesn't change the registers actual value, except for resetting the following registers:

- Event Stored;
- Event Size;
- Channel n Buffer Occupancy.

Address 0xEF28 Mode W Attribute C

Bit	Description
[31:0]	Whatever value written at this location generates a software clear.

#### **Configuration Reload**

A write access of any value at this location causes a software reset, a reload of Configuration ROM parameters and a PLL reconfiguration.

Address 0xEF34 Mode W Attribute C

Bit	Description
[31:0]	Write whatever value to perform a software reset, a reload of Configuration ROM parameters
[51.0]	and a PLL reconfiguration.

# **Configuration ROM Checksum**

Thi register contains information on 8-bit checksum of Configuration ROM space.

Address 0xF000 Mode R Attribute C

Bit	Description
[7:0]	Checksum.
[31:8]	Reserved.

#### Configuration ROM Checksum Length BYTE 2

This register contains information on the third byte of the 3-byte checksum length (i.e. the number of bytes in Configuration ROM to checksum).

Address 0xF004 Mode R Attribute C

Bit	Description
[7:0]	Checksum Length: bits[23:16].
[31:8]	Reserved.

#### Configuration ROM Checksum Length BYTE 1

This register contains information on the second byte of the 3-byte checksum length (i.e. the number of bytes in Configuration ROM to checksum).

Address 0xF008 Mode R Attribute C

Bit	Description
[7:0]	Checksum Length: bits[15:8].
[31:8]	Reserved.

#### Configuration ROM Checksum Length BYTE 0

This register contains information on the first byte of the 3-byte checksum length (i.e. the number of bytes in Configuration ROM to checksum).

Address 0xF00C Mode R Attribute C

Bit	Description
[7:0]	Checksum Length: bits[7:0].
[31:8]	Reserved.

# **Configuration ROM Constant BYTE 2**

This register contains the third byte of the 3-byte constant.

Address 0xF010 Mode R Attribute C

Bit	Description
[7:0]	Constant: bits[23:16] = 0x83.
[31:8]	Reserved.

# **Configuration ROM Constant BYTE 1**

This register contains the second byte of the 3-byte constant.

Address 0xF014 Mode R Attribute C

	Bit	Description
	[7:0]	Constant: bits[15:8] = 0x84.
Ī	[31:8]	Reserved.

# Configuration ROM Constant BYTE 0

This register contains the first byte of the 3-byte constant.

Address 0xF018 Mode R Attribute C

Bit	Description
[7:0]	Constant: bits[7:0] = 0x01.
[31:8]	Reserved.

# Configuration ROM C Code

This register contains the ASCII C character code (identifies this as CR space).

Address 0xF01C Mode R Attribute C

Bit	Description
[7:0]	ASCII 'C' Character Code.
[31:8]	Reserved.

# Configuration ROM R Code

This register contains the ASCII R character code (identifies this as CR space).

Address 0xF020 Mode R Attribute C

Bit	Description
[7:0]	ASCII 'R' Character Code.
[31:8]	Reserved.

# **Configuration ROM IEEE OUI BYTE 2**

This register contains information on the third byte of the 3-byte IEEE Organizationally Unique Identifier (OUI).

Address 0xF024 Mode R Attribute C

	Bit	Description
Γ	[7:0]	IEEE OUI: bits[23:16].
Γ	[31:8]	Reserved.

### **Configuration ROM IEEE OUI BYTE 1**

This register contains information on the second byte of the 3-byte IEEE Organizationally Unique Identifier (OUI).

Address 0xF028 Mode R Attribute C

Bit	Description
[7:0]	IEEE OUI: bits[15:8].
[31:8]	Reserved.

# Configuration ROM IEEE OUI BYTE 0

This register contains information on the first byte of the 3-byte IEEE Organizationally Unique Identifier (OUI).

Address 0xF02C Mode R Attribute C

Bit	Description
[7:0]	IEEE OUI: bits[7:0].
[31:8]	Reserved.

# **Configuration ROM Board Version**

This register contains the board version information.

Address 0xF030 Mode R Attribute C

Bit	Description
	Board Version Code.
	Options are:
	0xF0 = V1725/VX1725/DT5725/N6725;
	0xF1 = V1725B/VX1725B/DT5725B/N6725B;
[7:0]	0xF2 = V1725C/VX1725C;
[7.0]	0xF3 = V1725D/VX1725D;
	0xC0 = V1730/VX1730/DT5730/N6730;
	0xC1 = V1730B/VX1730B/DT5730B/N6730B;
	0xC2 = V1730C/VX1730C;
	0xC3 = V1730D/VX1730D.
[31:8]	Reserved.

## **Configuration ROM Board Form Factor**

This register contains the information of the board form factor.

Address 0xF034 Mode R Attribute C

Bit	Description
	Board Form Factor CAEN Code.
	Options are:
[7,0]	0x00 = VME64;
[7:0]	0x01 = VME64X;
	0x02 = Desktop;
	0x03 = NIM.
[31:8]	Reserved.

## **Configuration ROM Board ID BYTE 1**

This register contains the MSB of the 2-byte board identifier.

Address 0xF038 Mode R Attribute C

Bit	Description
[7:0]	Board Number ID: bits[15:8].
[31:8]	Reserved.

## Configuration ROM Board ID BYTE 0

This register contains the LSB information of the 2-byte board identifier.

Address 0xF03C Mode R Attribute C

Bit	Description
[7:0]	Board Number ID: bits[7:0].
[31:8]	Reserved.

### **Configuration ROM PCB Revision BYTE 3**

This register contains information on the fourth byte of the 4-byte hardware revision.

Address 0xF040 Mode R Attribute C

Bit	Description
[7:0]	PCB Revision: bits[31:24].
[31:8]	Reserved.

### **Configuration ROM PCB Revision BYTE 2**

This register contains information on the third byte of the 4-byte hardware revision.

Address 0xF044 Mode R Attribute C

Bit	Description
[7:0]	PCB Revision: bits[23:16].
[31:8]	Reserved.

### Configuration ROM PCB Revision BYTE 1

This register contains information on the second byte of the 4-byte hardware revision.

Address 0xF048 Mode R Attribute C

Bit	Description
[7:0]	PCB Revision: bits[15:8].
[31:8]	Reserved.

### Configuration ROM PCB Revision BYTE 0

This register contains information on the first byte of the 4-byte hardware revision.

Address 0xF04C Mode R Attribute C

Bit	Description
[7:0]	PCB Revision: bits[7:0].
[31:8]	Reserved.

# **Configuration ROM FLASH Type**

This register contains information on which FLASH type (storing the FPGA firmware) is present on-board.

Address 0xF050 Mode R Attribute C

Bit	Description
[7:0]	FLASH Type. Options are: 0x00 = 8 Mb FLASH; 0x01 = 32 Mb FLASH.
	NOTE: for 730 and 725 families, this byte must be 0x01.
[31:8]	Reserved.

## Configuration ROM Board Serial Number BYTE 1

This register contains information on the MSB of the board serial number.

Address 0xF080 Mode R Attribute C

Bit	Description
[7:0]	Board Serial Number: bits[15:8].
[31:8]	Reserved.

84

## Configuration ROM Board Serial Number BYTE 0

This register contains information on the LSB of the board serial number.

Address 0xF084 Mode R Attribute C

Bit	Description
[7:0]	Board Serial Number: bits[7:0].
[31:8]	Reserved.

# Configuration ROM VCXO Type

This register contains information on which type of VCXO is present on-board.

Address 0xF088 Mode R Attribute C

Bit	Description
	VCXO Type Code.
	Options for VME Digitizers are:
	0 = AD9510 with 1 GHz;
[31:0]	1 = AD9510 with 500 MHz (not programmable);
	2 = AD9510 with 500 MHz (programmable).
	Options for Desktop/NIM Digitizers are:
	0 = AD9520-3.



#### **Electronic Instrumentation**



CAEN SpA is acknowledged as the only company in the world providing a complete range of High/Low Voltage Power Supply systems and Front-End/Data Acquisition modules which meet IEEE Standards for Nuclear and Particle Physics. Extensive Research and Development capabilities have allowed CAEN SpA to play an important, long term role in this field. Our activities have always been at the forefront of technology, thanks to years of intensive collaborations with the most important Research Centres of the world. Our products appeal to a wide range of customers including engineers, scientists and technical professionals who all trust them to help achieve their goals faster and more effectively.



CAEN S.p.A.
Via Vetraia, 11
55049 Viareggio
Italy
Tel. +39.0584.388.398
Fax +39.0584.388.959
info@caen.it
www.caen.it

CAEN GmbH

Eckehardweg 10

42653 Solingen

Germany

Tel. +49.212.2544077

Mobile +49(0)15116548484

Fax +49.212.2544079

info@caen-de.com

www.caen-de.com

CAEN Technologies, Inc. 1140 Bay Street - Suite 2 C Staten Island, NY 10305 USA Tel. +1.718.981.0401 Fax +1.718.556.9185 info@caentechnologies.com www.caentechnologies.com





#### **Electronic Instrumentation**