

Making integrated circuits

2011-03-14

Carsten Wulff

Nomenclature

IC=Integrated circuit

MOS=Metal oxide semiconductor

FET=Field effect transistor

NMOS=n-type MOS enhancement MOS

PMOS=p-type MOS enhancement MOS

Outline

- Compulsory introduction: who am I, what have I done, and what do I do, where do I work, what to they do....
- Circuit elements
- Processing
- Layout
- Schematics
- Advice for electronics students

Who am I?

- Carsten Wulff
- Born Friday 13. August 1976
- R & D engineer wireless department at Nordic Semiconductor
- Married with three kids
- Graduated from NTNU 2002 (Programmable analog integrated circuit with TOC, 0.6um AMS)
- Ph.D from NTNU in 2008 (Efficient ADCs in nano-scale CMOS technology, 90nm ST)
- Fortunate to spend a year at University of Toronto (2006-2007) during my Ph.D
- <http://www.scribd.com/carstenwulff>
- <http://www.wulff.no/carsten>


About Nordic Semiconductor

- 151 employees in March 2011
- Revenue of 141.8 MUSD in 2010 (762 MNOK on 2011-03-12)
- Specialist on ultra-low power 2.4GHz radio circuits

wireless living ...




What Nordic Semiconductor does and where




Electronics research


Research takes time



The story



Taiwan



Norway


Outline

- Compulsory introduction to: who am I, what have I done, and what do I do, where do I work, what to they do....
- **Circuit elements**
- Processing
- Layout
- Schematics
- Advice for electronics students

Circuit elements

Transistor – The workhorse of ICs

- An extremely complicated device, but it's possible to make some assumptions



The accurate equation

$$I_D = f(W, L, \mu_n, C_{ox}, \dots, V_{GS}, V_{DS}, \dots) \text{ 284 parameters in BSIM 4.5}$$

The equation used for hand calculation in analog circuits

$$I_D \propto (V_{GS} - V_{th})^2$$

The equation sufficient for most digital designs

$$I_D \propto \begin{cases} \text{high, if } V_{GS} > V_{TH} \\ 0, \text{ if } V_{GS} < V_{TH} \end{cases}$$

Parameters for one transistor in BSIM 4.5

```

.MODEL N1 NMOS LEVEL=14 VERSION=4.5.0 BINUNIT=1 PARAMCHK=1 MOBMOD=0 CAPMOD=2 IGCMOD=1 IGBMOD=1 GEOMOD=1
DIOMOD=1 RDSMOD=0 RBODYMOD=0 RGATEMOD=3 PERMOD=1 ACNQSMOD=0 TRNQSMOD=0 TEMPMOD=0 TNOM=27 TOXE=1.8E-009
TOXP=10E-010 TOXM=1.8E-009 DTOX=8E-10 EPSROX=3.9 WINT=5E-009 LINT=1E-009 LL=0 WL=0 LLN=1 WLN=1 LW=0 WW=0 LWN=1
WWN=1 LWL=0 WWL=0 XPART=0 TOXREF=1.4E-009 SAREF=5E-6 SBREF=5E-6 WLOD=2E-6 KU0=-4E-6 KVSAT=0.2 KVTH0=-2E-8 TKU0=0.0
LLODKU0=1.1 WLODKU0=1.1 LLODVTH=1.0 WLODVTH=1.0 LKU0=1E-6 WKU0=1E-6 PKU0=0.0 LKVTH0=1.1E-6 WKVTH0=1.1E-6 PKVTH0=0.0
STK2=0.0 LODK2=1.0 STETA0=0.0 LODETA0=1.0 LAMBDA=4E-10 VSAT=1.1E 005 VTL=2.0E5 XN=6.0 LC=5E-9 RNOIA=0.577 RNOIB=0.37
LINTNOI=1E-009 WPEMOP=0 WEB=0.0 WEC=0.0 KVTH0WE=1.0 K2WE=1.0 KU0WE=1.0 SCREF=5.0E-6 TVOFF=0.0 TVFBSDOFF=0.0
VTH0=0.25 K1=0.35 K2=0.05 K3=0 K3B=0 W0=2.5E-006 DVT0=1.8 DVT1=0.52 DVT2=-0.032 DVT0W=0 DVT1W=0 DVT2W=0 DSUB=2
MINV=0.05 VOFFL=0 DVTP0=1E-007 DVTP1=0.05 LPE0=5.75E-008 LPEB=2.3E-010 XJ=2E-008 NGATE=5E 020 NDEP=2.8E 018 NSD=1E 020
PHIN=0 CDSC=0.0002 CDSCB=0 CDSCD=0 CIT=0 VOFF=-0.15 NFACTOR=1.2 ETA0=0.05 ETAB=0 UC=-3E-011 VFB=-0.55 U0=0.032 UA=5.0E-
011 UB=3.5E-018 A0=2 AGS=1E-020 A1=0 A2=1 B0=-1E-020 B1=0 KETA=0.04 DWG=0 DWB=0 PCLM=0.08 PDIBLC1=0.028 PDIBLC2=0.022
PDIBLCB=-0.005 DROUT=0.45 PVAG=1E-020 DELTA=0.01 PSCBE1=8.14E 008 PSCBE2=5E-008 RSH=0 RDSW=0 RSW=0 RDW=0 FPROUT=0.2
PDITS=0.2 PDITSD=0.23 PDITSL=2.3E 006 RSH=0 RDSW=50 RSW=150 RDW=150 RDSWMIN=0 RDWMIN=0 RSWMIN=0 PRWG=0
PRWB=6.8E-011 WR=1 ALPHA0=0.074 ALPHA1=0.005 BETA0=30 AGIDL=0.0002 BGIDL=2.1E 009 CGIDL=0.0002 EGIDL=0.8 AIGBACC=0.012
BIGBACC=0.0028 CIGBACC=0.002 NIGBACC=1 AIGBINV=0.014 BIGBINV=0.004 CIGBINV=0.004 EIGBINV=1.1 NIGBINV=3 AIGC=0.012
BIGC=0.0028 CIGC=0.002 AIGSD=0.012 BIGSD=0.0028 CIGSD=0.002 NIGC=1 POXEDGE=1 PIGCD=1 NTOX=1 VFBSDOFF=0.0 XRCRG1=12
XRCRG2=5 CGSO=6.238E-010 CGDO=6.238E-010 CGBO=2.56E-011 CGDL=2.495E-10 CGSL=2.495E-10 CKAPPAS=0.03 CKAPPAD=0.03
ACDE=1 MOIN=15 NOFF=0.9 VOFFCV=0.02 KT1=-0.37 KT1L=0.0 KT2=-0.042 UTE=-1.5 UA1=1E-009 UB1=-3.5E-019 UC1=0 PRT=0
AT=53000 FNOIMOD=1 TNOIMOD=0 JSS=0.0001 JSWS=1E-011 JSWGS=1E-010 NJS=1 IJTHSFWD=0.01 IJTHSREV=0.001 BVS=10 XJBVS=1
JSD=0.0001 JSWD=1E-011 JSWGD=1E-010 NJD=1 IJTHDFWD=0.01 IJTHDREV=0.001 BVD=10 XJBVD=1 PBS=1 CJS=0.0005 MJS=0.5 PBSWS=1
CJSWS=5E-010 MJSWS=0.33 PBSWGS=1 CJSWGS=3E-010 MJSWGS=0.33 PBD=1 CJD=0.0005 MJD=0.5 PBSWD=1 CJSWD=5E-010
MJSWD=0.33 PBSWGD=1 CJSWGD=5E-010 MJSWGD=0.33 TPB=0.005 TCJ=0.001 TPBSW=0.005 TCJSW=0.001 TPBSWG=0.005
TCJSWG=0.001 XTIS=3 XTIID=3 DMCG=0E-006 DMCI=0E-006 DMDG=0E-006 DMCGT=0E-007 DWJ=0.0E-008 XGW=0E-007 XGL=0E-008
RSHG=0.4 GBMIN=1E-010 RBPB=5 RBPD=15 RBPS=15 RBDB=15 RPBD=15 NGCON=1 JTSS=1E-4 JTSD=1E-4 JTSSWS=1E-10 JTSSWD=1E-10
JTSSWGS=1E-7 JTSSWGD=1E-7 NJTS=20.0 NJTSSW=20 NJTSSWG=6 VTSS=10 VTSD=10 VTSSWS=10 VTSSWD=10 VTSSWGS=2 VTSSWGD=2
XTSS=0.02 XTSD=0.02 XTSSWS=0.02 XTSSWD=0.02 XTSSWGS=0.02 XTSSWGD=0.02

```

$$I_D = \frac{1}{2} \mu_n C_{ox} \frac{W}{L} (V_{GS} - V_{th})^2$$


Integrated resistor – Master of ratios

- Most of the time a simple device



$$V = I R$$

- Very good matching between two resistors, so we can make very accurate voltage dividers




Integrated capacitor – Master of silence

- Not too hard either



$$i = C \frac{dv}{dt}$$

- Perfect for silencing a noisy power supply



Integrated inductor – Master of radio frequencies

- Principle is simple, not so easy to integrate on chip



$$V = L \frac{di}{dt}$$

- Used in sine wave generators, and radio frequency circuits

Outline

- Compulsory introduction to: who am I, what have I done, and what do I do, where do I work, what to they do....
- Circuit elements
- Processing
- Layout
- Schematics
- Advice for electronics students

Processing – Making an integrated circuit

The raw materials

hydrogen 1 H 1.0079	beryllium 4 Be 9.0122	carbon 6 C 12.011	nitrogen 7 N 14.007	oxygen 8 O 15.999	fluorine 9 F 18.998	helium 2 He 4.0026
lithium 3 Li 6.941	magnesium 12 Mg 24.305	aluminum 13 Al 26.982	silicon 14 Si 28.086	sulfur 16 S 32.065	chlorine 17 Cl 35.453	neon 10 Ne 20.180
sodium 11 Na 22.990	calcium 20 Ca 40.078	copper 29 Cu 63.546	zinc 30 Zn 65.39	arsenic 33 As 74.922	selenium 34 Se 78.96	bromine 35 Br 79.904
potassium 19 K 39.098	scandium 21 Sc 44.956	iron 26 Fe 56.938	cobalt 27 Co 58.933	silver 47 Pd 106.42	cadmium 48 Cd 112.41	iodine 53 I 79.904
rubidium 37 Rb 85.468	titanium 22 Ti 47.867	manganese 25 Mn 51.996	rhodium 45 Rh 102.91	gold 79 Au 196.97	thallium 81 Tl 204.38	xenon 54 Xe 131.29
caesium 55 Cs 132.91	yttrium 39 Y 88.906	chromium 24 Cr 51.996	technetium 43 Tc [98]	ruthenium 44 Ru 101.07	mercury 80 Hg 200.59	radon 86 Rn [222]
barium 56 Ba 137.33	lutetium 71 Lu 174.97	vanadium 23 V 50.942	niobium 41 Nb 92.906	tantalum 73 Ta 180.95	osmium 76 Os 186.21	lead 82 Pb 208.98
francium 87 Fr [223]	dubnium 103 Lr [262]	rutherfordium 104 Rf [261]	bohrium 105 Db [262]	seaborgium 106 Sg [266]	hassium 108 Bh [269]	bismuth 83 Bi [209]
radium 88 Ra [226]	lawrencium 89-102 * *	rutherfordium 104 Rf [261]	dubnium 105 Db [262]	seaborgium 106 Sg [266]	bohrium 107 Bh [269]	polonium 109 Mt [268]
actinium 89 Ac [227]	curium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]	americium 95 Am [243]
lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36	europerium 63 Eu 151.96
actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]	americium 95 Am [243]
lanthanide series	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
actinide series	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04	protactinium 91 Pa 231.04	uranium 92 U 238.03	neptunium 93 Np [237]	plutonium 94 Pu [244]
	lanthanum 57 La 138.91	cerium 58 Ce 140.12	praseodymium 59 Pr 140.91	neodymium 60 Nd 144.24	promethium 61 Pm [145]	samarium 62 Sm 150.36
	actinium 89 Ac [227]	thorium 90 Th 232.04</td				


The wafer – the fundamental building block



<http://www.tomshardware.com/reviews/semiconductor-production-101,1590-3.html>

- Ingot = An ultra pure, single crystal of silicon
- Wafer = A very thin slice of an ingot, used as the first layer in processing

Photolithography




Mask generation

Electron gun

Lens



Mask




- Extremely expensive
- Must have higher accuracy than what we want to develop
- Extensive calculations need to calculate how the mask should look to compensate for diffraction and processing inaccuracies

Minimum feature	Mask cost NOK
180nm	600 000
65nm	6 000 000
28nm	30 000 000

Photo resist and development



1) Expose photoresist




2) Remove photoresist and etch polysilicon


Toolbox

- Negative and positive photoresist
- Doping, etching, electroplating, vapor deposition

Doping and metal




3) Add doping



4) Add metal

- Dopants change electrical properties of the silicon substrate
- Metal is added to wire up the circuit. In most processes the metal is copper.
- Up to nine metal layers in advanced processes


Nanoscale transistor



New features in sub 100nm technologies:

- Stress is actively used to increase mobility
- Very thin oxide, reduced power supply to keep vertical field in check
- Halo implant that increases drain-source conductance at longer channel lengths
- Hot carrier effects
- Stress from the STI (shallow trench isolation)
- Proximity to well edge
- Lithography issues since the minimum dimensions are less than the wavelength used to expose the photoresist ($\lambda=193\text{nm}$)

We digress: Complex math



$$Y(t) = I(t) + jQ(t)$$

Our radio uses a complex receiver (one path for I and one for Q), so you need to understand complex mathematics


Outline

- Compulsory introduction to: who am I, what have I done, and what do I do, where do I work, what to they do....
- Circuit elements
- Processing
- Layout
- Schematics
- Advice for electronics students

Layout


Lets make a transistor

Diffusion




- Marks the boundary of the transistor
- Defines the width of the transistor

Polysilicon




- The intersection of diffusion and polysilicon defines the transistor
- Polysilicon is the gate of the transistor, and sets the length

Contacts




- Contacts are needed to connect between metal and diffusion

Metal




- Metal is used to connect one transistor to another

Transistor layout rules




Rule	Why
Always use two fingers	Transistor parameters change with current direction
Always run all gates in same direction	Stress in X and Y direction affect transistor differently
Always have dummy poly	Better poly control during processing
Always have larger than minimum length of diffusion	Less stress from shallow trench isolation
Always place transistors far from well edge	Reduce mismatch in threshold voltage
Be careful with metal routing across transistors	Metal changes the stress in the channel

Layout of an opamp



Layout of opamp



Layout of an ADC





Image of an ADC





Outline


- Compulsory introduction to: who am I, what have I done, and what do I do, where do I work, what to they do....
- The circuit elements
- Processing
- Layout
- **Schematics**
- Advice for electronics students

Schematics


Typical block diagram

Sampling (p_1)Charge transfer (p_2)

Opamp schematic in Visio



Opamp schematic in Cadence



Topics not covered

- Simulation, corner verification, monte-carlo simulation
- Digital design (Verilog)
- System level design (Matlab)
- Project management
- Lab testing
- Writing documentation

Outline

- Compulsory introduction to: who am I, what have I done, and what do I do, where do I work, what to they do....
- The circuit elements
- Processing
- Layout
- Schematics
- Advice for electronics students

Divide and conquer

- Break complex stuff down into smaller pieces
- Ignore the difficult stuff, and try to get an approximate understanding, then add in the difficult stuff
- Don't be afraid if something is difficult
- Don't think you're stupid and won't be able to understand
- Don't think that everybody else is smarter than you

When you don't understand

- Ask someone
- Don't be afraid to show that you don't know something, not knowing is OK (except on the exam, and in a job interview)
- Use wikipedia

Know your assumptions

- Assumption is your friend
- Assumption is worst enemy
- Assumption is the mother of all mistakes

What you need to teach yourself

- Ability to work hard (constant speed)
- Programming
- Report writing
- Explaining things to other people
- Convincing people that your right through persuasive arguments

Last comments

- Assumptions are important (but handle with care)
- Learn your courses, they are important
- The world is your playground, if you're good enough you can make a lot of money, and make the world a better place

Questions?

Things you should know about

Software:

Schematic (Mentor graphics, Cadence, Synopsys, Tanner tools)

Layout (Mentor graphics, Cadence, Synopsys, Tanner tools)

Simulation (Eldo, Spectre, Hspice, SMASH)

Scripting (Bash, Perl, Python, TCL, LISP)

Editors (Emacs)

Math software (Matlab, Maple, Octave)

Information sources:

<http://ieeexplore.ieee.org>

<http://webcast.berkeley.edu/>

EE240 spring 2007 to spring 2010