電物所 311651052 吳挺字

1. Differences between MAXI and Stream interface

數據傳輸模型:

MAXI 接口用於內存映射的數據傳輸,支持隨機訪問內存位置,並使用讀寫協議。

Stream 接口設計用於連續數據流處理,數據以連續、單向流動的方式進行。

數據流動:

MAXI接口支持讀和寫操作,有獨立的讀和寫通道,可以由主模塊和從模塊發起數據傳輸。

Stream 接口通常是單向的,可以是輸入流或輸出流,數據以連續、順序方式推送或拉取,不涉及單個內存位置的地址訪問。

用途:

MAXI接口常用於內存訪問和內存映射外設的接口,適用於需要隨機訪問內存位置的任務。

Stream 接口適用於數據密集型處理,如視頻和音頻處理、圖像過濾和信號 處理,以連續流方式處理數據。

突發與連續數據:

MAXI 接口支持突發數據傳輸,可以一次性讀取或寫入多個數據元素。 Stream 接口數據連續流動,一次傳輸一個元素,不支持突發數據傳輸。 協議複雜性:

MAXI接口通常遵循複雜的 AXI 協議,包括突發數據、寫入 strobe 和地址解碼等功能。

Stream 接口更簡單,不涉及複雜的地址和控制信號,因此更容易實現。 總之,MAXI 接口和 Stream 接口在用途、數據流動模式、數據處理方式和協 議複雜性等方面存在顯著不同,選擇取決於設計應用的具體需求。

2. Differences between csim and cosim


- 1. Csim:在 text,kernal 都是用 c 語言時,用來驗證演算法是否正確。
- 2. Co-sim:在 text 是 c 語言,kernal 是 verilog 時驗證,差異在於 co-sim 會 涉及到數據傳輸的問題。

MAXI


Performance:




Utilization:



Interface:



Co-simulation transcript/waveform:




Jupyter Notebook execution results:

```
71
72
73
74
75
        plt.show() # In Jupyter, press Tab + Shift keys to show plot then redo run
        print("Exit process")
76
```

Entry: /usr/local/share/pynq-venv/lib/python3.8/site-packages/ipykernel_launcher.py

System argument(s): 3
Start of "/usr/local/share/pynq-venv/lib/python3.8/site-packages/ipykernel_launcher.py"
Kernel execution time: 0.00026345252990722656 s




Exit process

Stream

Performance:




Utilization:



Interface:




Co-simulation transcript/waveform:



Jupyter Notebook execution results:

Entry: /usr/local/share/pynq-venv/lib/python3.8/site-packages/ipykernel_launcher.py

System argument(s): 3
Start of "/usr/local/share/pynq-venv/lib/python3.8/site-packages/ipykernel_launcher.py"
Kernel execution time: 0.0016443729400634766 s



Exit process