



BEND TABLE			
ID	DIRECTION	ANGLE	RADIU s
1	DOWN	90	1
2	DOWN	90	1
3	DOWN	90	1
4	DOWN	90	1
5	DOWN	90	1
6	DOWN	90	1
7	DOWN	90	1
8	DOWN	90	1
9	DOWN	90	1
10	DOWN	90	1
11	DOWN	90	1
12	DOWN	90	1
13	DOWN	90	1
14	DOWN	90	1
15	DOWN	90	1

