


BEND SEQUENCE					
ST	BEND	PUNCH	DIE	ANG	TON
	B1	AUTO	V6	90°	18kN
	B2	AUTO	V6	90°	18kN



BEND TABLE			
ID	DIRECTION	ANGLE	RADIUS
1	DOWN	90	1
2	DOWN	90	1
3	DOWN	90	1
4	DOWN	90	1
5	DOWN	90	1
6	DOWN	90	1
7	DOWN	90	1
8	DOWN	90	1
9	DOWN	90	1
10	DOWN	90	1
11	DOWN	90	1

