

Connection for LPD1 pin only

This is for those who want to use LPD1pin only. (The 1pin serial programing is also supported by this connection.)




Connection for both LPD 1pin and LPD 4pin

This is for those who want to use LPD1pin or LPD4pin. (All serial programing mode are also supported by this connection.)



Connection for both JTAG (3rd-party tool) and LPD 4pin

This is for those who want to use both 3rd party's JTAG tool and E1/E20 emulator.



Connection for JTAG (3rd-party tool) and LPD 1pin and LPD 4pin

This is for those who want to use both 3rd party's JTAG tool and E1/E20 emulator.

