EBV Workshop


Pre-requisites:

1. For Windows users, pre-install PuTTY and WinSCP/Filezilla or other serial console/scp client tools.

PuTTY (http://www.putty.org/) – serial console tool
WinSCP(https://winscp.net/eng/download.php) or Filezilla (https://filezilla-project.org/) or other scp client for Windows

2. Install ARTIK IDE and ARTIK 055s SDK on your laptop. Instruction is at: https://developer.artik.io/documentation/developer-guide/artik-ide/install-ide.html.

After you install ARTIK IDE, please go to Help-> ARTIK Package Manager, and install ARTIK 055s SDK v18.05.00



3. Register a developer account at http://developer.thingworx.com/.