VAYU.LIVE OUT- OUT+ ADDR

☐ R8 0X4A → SDA

☐ R7 0X4B → SCL

0X48 → GND

0X49 → 3V3