






Quick Start:

github.com/wyolum/ClockIOT/wiki/Quick-Start



- By default, ClockIOT expects to be in range of a WiFi hotspot.
 When it boots for the first time, it will create a temporary WiFi hotspot called "KLOK" & display "KLOK" using letters on the faceplate as pixels.
- Using a computer or phone, find & join "KLOK" network.
- This will bring you to the welcome screen (or enter 192.168.4.1 in a browser).
- Enter your WiFi credentials.
- · ClockIOT will store them and reset.
- Once on the internet, ClockIOT will look up the UTC (Zulu) time using NTP, and your timezone from wyolum.com courtesy of ipapi.co. And you are all set!!
- Visit http://www.wyolum.com/clockiot/UI/ to control ClockIOT.

