# VISION SDK Use-Case Auto-Generation Tool Overview

**July 2016** 



# **Agenda**

- Introduction
- Motivation
- Use-case Generation process
- Error Handling cases
- Extending the tool Ease for Developer




#### What is Vision SDK?

- VISION SDK is multi processor software development platform for TI family of ADAS SoCs.
- The software framework allows users to create different ADAS application data flows involving video capture, video pre-processing, video analytics algorithms, and video display.
- The SDK has sample ADAS data flows which exercises different CPUs and HW accelerators in the ADAS SoC and shows customers how to effectively use different SoC sub-systems.
- VISION SDK will be based on a framework named as the "Links and Chains" framework and user API to this framework is called "Link API"
- The SDK installer package includes all tools and components necessary to build such applications, including code gen tools, BIOS, IPC, starterware, BSP drivers, networking stacks, codecs, algorithm kernels




# Example ADAS data flow – LVDS surround view – system diagram



Logical design, not yet sure where to run different algorithm stages



# Example ADAS data flow – LVDS surround view in Vision SDK



INSTRUMENTS

#### **Normal Use-Case Generation Process**

- User has to determine the flow of connections
- C code has to be written for the use-case which
  - Set LinkID and Parameters
  - Insert IPC links when buffers are exchanged across CPUs
  - Connect Links
  - Create links in sequence of source to sink
  - Write functions for use-case Create, Start, Stop, Delete (PrintBufferStatistics, Print Link Statistics)



#### Normal Use-Case Generation Process: Drawbacks

- Typically usecase files have around 1000+ lines
- Writing a given usecase requires a lot of time
  - It took 1 week to write the surround view use-case file
- This method is more error prone
  - It took one week to make sure surround view use-case create, start, stop, delete passes
  - Common mistakes include this would take 1 week to resolve on HW board
    - Wrong connection of previous link ID to next link ID
    - Wrong link ID setting
    - Wrong insertion of IPC link



#### **Motivation**

- Help end user generate use-case in minimum time
- Give overall summary of use-case code using visual representation of data flow via images and logs
- Help user focus to main problem, i.e. determine flow of connections
- Detect and report errors during use-case generation stage itself and therefore reduce time required to debug on actual HW board
- Takes very less effort for changes in data flow. For e.g. change in Algorithm, or adding a new algorithm in a existing data flow




# **Example Results**

- Single Capture Display Use-case:
  - Generated 210 lines
  - Using 2 lines of configuration file
- Dense Optical Flow Use-Case
  - Generated 895 lines
  - Using 14 lines of configuration file
- Single Camera Frame copy to Single Camera Edge Detection
  - Required change of algorithm name in configuration file
  - Changing algorithm parameters in C code, which in this case 4 lines



# **Use-Case Coding Process using the tool**

- Process:
  - Write Configuration file
  - Code generation using the tool
  - Fill in missing code
    - Link parameters
    - Main control loop
- Ready for use





# Use-Case Coding Process: Config File

- A Link is named as [Link name] or [Link name] [user readable suffix].
  - For e.g Capture, Capture\_Ivds, Capture\_ov10640
- "-help" option displays all supported link names. All links in Vision SDK 2.3 are supported in the tool
  - Different suffix for different instances, i.e. Display\_Video, Display\_Grpx
  - Suffix can be any sequence of char's or number's readable to end user.
- Example: Single camera display

```
1 UseCase: chains_vipSingleCam_Display
2
3 Capture -> Display_Video
4 GrpxSrc -> Display_Grpx
```

- Use-case name should be mentioned
  - Files are generated with the use-case name and used for struct name and prefix of other function names
- IPC links, if required, are auto-detected and code for IPC links are autogenerated.
   So, no need to mention IPC IN/OUT links explicitly in config file
- Link Instance ID is auto-generated, Ex, in example shown above Display\_Video will be Display Instance 0 and Display\_Grpx will be Display Instance 1. No need to specify explicit instance number.



### **Configuration file: Grammar**

- Grammar:
  - Connection: ID (optional CPU name) | ID (optional CPU name) -> Connection;
  - When CPU name is not mentioned IPU1\_0 CPU is assumed
- Example: Dense optical flow view

```
1 UseCase: chains_vipSingleCameraDenseOpticalFlow
2 Capture -> Dup_capture
3
4 Dup_capture -> Alg_DenseOptFlow_1 (EVE1) -> Merge_Dof (DSP1)
5 Dup_capture -> Alg_DenseOptFlow_2 (EVE2) -> Merge_Dof
6 Dup_capture -> Alg_DenseOptFlow_3 (EVE3) -> Merge_Dof
7 Dup_capture -> Alg_DenseOptFlow_4 (EVE4) -> Merge_Dof
8
9 Merge_Dof -> Alg_VectorToImage (DSP1) -> Display_VideoDof
10 Dup_capture -> VPE_capture -> Display_VideoOriginal
11 GrpxSrc -> Display_Grpx
```



# **Code generation**

- Demo of how to generate code:
  - Options available:
    - -help Show help and supported basename and processors
    - -file Create .c and .h file
    - -img Create in .jpg image (or out.jpg)
    - -log Creates a .txt log file with debugging info
    - -debug Prints file name(in source code) and line no. in error statement
    - -path takes the next argument as output path
    - -v Verbose
- Examples:
  - ./vsdk\_win32 –file test
  - ./vsdk\_win32 –file –img test –path output



#### **Generated Code and Files**

#### Auto-Generated code includes

- Usecase object have link ID variables and create structure for all links used in the use case
- Assignment of link ID including instance number and CPU on which it runs
- Reseting of all link create parameters to default values
- Detecting and inserting IPC OUT/IN links as required
- Setting of all parameters of DUP, MERGE, IPC links
- Setting of inQueParams and outQueParams for all links this defines the usecase graph connection in C code
- Calling link create for all links in source to sink order
- Calling start / stop / delete / print statistics of all links in the use-case


#### Generated Files:

- [use case name]\_priv.h and [use case name]\_priv.c file
- Image file (optional) showing visual representation of the usecase graph
- log file (optional) for advanced debug




# **Example Generated Image**

Single Camera Capture Display





### **Example Generated Image: Dense Optical Flow**





# **Manually Written Code**

- Following code needs to manually written to complete the use-case and make it run on the HW board
  - Set Create Parameters of all links except inQueParams and outQueParams.
    - ▶ DUP, Merge, IPC IN, IPC OUT parameters are completely setup by the generated code
    - Algorithm Plugin baseClassCreate.size, baseClassCreate.algld are setup by the generated code
    - numOutQueue of Select, numInQueue of Null are setup by the generated code
  - Create DisplayCtrl link and configure it
  - Written main loop for use case and call generated API to create, start, stop, delete a use-case



#### **Define custom link**

- User can define a custom link which is not supported by the tool
- It is named as DefLink\_[Link name] in configuration file
- Here additionally edit DefLink\_CreateParams struct name in [use case]\_priv.h file and replace with actually parmaeter structure name of the custom link
- Set LinkID in [use case]\_priv.c file and call reset create params function in [use case]\_priv.c file



# **Define custom Algorithm**

- User can define a custom link which is not supported by the tool
- It is named as Alg\_[alg name] in configuration file
- Here additionally edit "[alg name]Link\_CreateParams" struct name in [use case]\_priv.h file and replace with actually parameter structure name of the custom link
- Set baseClassCreate.size, baseClassCreate.algld in [use case]\_priv.c file and call reset create params function in [use case]\_priv.c file



# **Error Handling cases**

- Wrong number of input or output to a link
  - Ex, previous link specified for capture link
- Invalid CPU name
- Same link instance is assigned two different CPUs
- Naming of Link does not follow the rules, i.e. Linkname, Linkname\_suffix
- Warnings for unsupported links and algorithm plugin's



# Extending the tool - Ease for developer

- In case extra link or alg plugin is added just include extra class in link.h
- Each class has it's separate functionalities which makes easier for user to determine where to change to include additional functionalities, etc.
  - UseCase class handles overall usecase information.
  - Link class handles information regarding a particular link
- In debug mode (-debug option) line number and file name is also given in case of errors
- See VisionSDK\_UsecaseGen\_UserGuide for step by steps details on extending the tool to support more link types and alg plugin types



### **Thank You**

