Product Version IC23.1 June 2023 © 2014-2023 Cadence Design Systems, Inc.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

**Trademarks:** Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522.

All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

- 1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
- 2. The publication may not be modified in any way.
- 3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
- 4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without enduser impact.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor

### **Contents**

Fluid Guard Ring Frequently Asked Questi	<u>ons</u>
Which technology rules are used for installing FGRs?	
Which technology rules are used for creating FGRs?	
Which technology rules are used while editing FGRs?	
How can geometry changes be avoided when existing FGRs Virtuoso release?	
Why do contacts at the corners of an FGR instance disappea ISR14?	
Why are the contacts inconsistently distributed in some areas are merged?	
Can an FGR device hidden from the Install Guard Ring form	<u>be re-installed?</u> 12
Can an FGR device hidden from the Create Guard Ring form Install Guard Ring form?	
Is it possible to install an FGR device with implant layer enclotechnology default?	
What should I do if a third party tool issues error and warning customized FGR?	
Can I make changes to the procedure for initializing customize	<u>xed FGR devices?</u> 13
Is it acceptable to call the procedure for initializing customize other than libInit.il?	
Do the fields displayed on the Create Guard Ring form have names?	
Can a newly created FGR for a FinFET device snap to the fir	arids?

This document contains the following frequently asked questions and answers related to fluid guard ring (FGR):

- Which technology rules are used for installing FGRs?
- Which technology rules are used for creating FGRs?
- Which technology rules are used while editing FGRs?
- How can geometry changes be avoided when existing FGRs are opened in a new Virtuoso release?
- Why do contacts at the corners of an FGR instance disappear in releases above IC6.1.5 ISR14?
- Why are the contacts inconsistently distributed in some areas when two or more FGRs are merged?
- Can an FGR device hidden from the Install Guard Ring form be re-installed?
- Can an FGR device hidden from the Create Guard Ring form be re-installed from the Install Guard Ring form?
- Is it possible to install an FGR device with implant layer enclosure value less than technology default?
- What should I do if a third party tool issues error and warning messages while using a customized FGR?
- Can I make changes to the procedure for initializing customized FGR devices?
- <u>Is it acceptable to call the procedure for initializing customized FGR devices from a file other than libInit.il?</u>
- <u>Do the fields displayed on the Create Guard Ring form have corresponding prompt</u> names?

Fluid Guard Ring Frequently Asked Questions

#### Advanced Nodes Only Features

Can a newly created FGR for a FinFET device snap to the fin grids?

### Which technology rules are used for installing FGRs?

The following table lists the technology rules that are applicable during FGR installation:

Install Guard Ring Form Field	Applicable Technology Rule(s)
Contact Dimension	minWidth and maxWidth of Cut layer
Contact Spacing	<pre>viaSpacing(4) viaSpacing(3) minSpacing(One layer)()</pre>
Diffusion Over Contact(W) (Diffusion, Cut)	Maximum of minOppExtension rule (a, b) minExtensionDistance
Diffusion Over Contact(L) (Diffusion, Cut)	Minimum of minOppExtension rule (a, b) minExtensionDistance
Metal Over Contact(W) (Metal, Cut)	Maximum of minOppExtension rule (a, b) minExtensionDistance
Metal Over Contact(L) (Metal, Cut)	Minimum of minOppExtension rule (a, b) minExtensionDistance
Implant/Well Over Diffusion (Implant, Diffusion)	Maximum of minOppExtension rule (a, b) minExtensionDistance

### Which technology rules are used for creating FGRs?

The following table lists the technology rules that are applicable during the creation of an FGR:

Create Guard Ring Form Field	Applicable Technology Rule(s)
Contact Spacing	<pre>viaSpacing(4) viaSpacing(3) minSpacing(One layer()</pre>
Contact Dimension	minWidth and maxWidth of Cut layer
Diffusion Over Contact (Diffusion, Cut)	<pre>minOppExtension rule (a, b) minExtensionDistance</pre>
Metal Over Contact (Metal, Cut)	minOppExtension rule (a, b) minExtensionDistance

Fluid Guard Ring Frequently Asked Questions

Implant/Well Over	Max of minOppExtension rule (a, b)
Diffusion (Implant, Diffusion)	minExtensionDistance

The other technology rules that are considered while creating a FGR include:

- minWidth of Diffusion layer
- minWidth of Metal layer
- minWidth of Implant/Well layer

For more details on the technology rules considered for creating the FGR instances, refer to the <u>Technology Rules Considered During Fluid Guard Ring Creation</u> section in the <u>Creating Fluid Guard Rings</u> chapter of the <u>Virtuoso Fluid Guard Ring User Guide</u>.

#### Which technology rules are used while editing FGRs?

While editing an FGR, the following technology rules, which are also applicable during FGR creation, are used:

viaSpacing of Cut layer
minSpacing(One layer) of Cut layer
minWidth of Cut layer
minWidth of Diffusion layer
minWidth of Metal layer
minWidth of Implant/Well layer
maxWidth of Cut layer
minOppExtension
minExtensionDistance

In addition, while using an *overlapping shape* to create a tunnel through an FGR, the following table rules are considered:

- One-dimensional minSpacing table rule
- Two-dimensional minSpacing table rule


Fluid Guard Ring Frequently Asked Questions

For detailed information, refer to the <u>Creating Tunnel By Using an Overlapping Shape</u> section in the <u>Editing Fluid Guard Rings</u> chapter of the <u>Virtuoso Fluid Guard Ring User Guide</u>.

### How can geometry changes be avoided when existing FGRs are opened in a new Virtuoso release?

Virtuoso evaluates FGRs, which are fluid pcells, dynamically. Opening a layout containing FGRs in a newer release of Virtuoso may result in geometry changes in the existing FGRs, due to bug fixes or enhancements implemented in the FGR code of the newer release of Virtuoso.

To avoid such geometry changes, you can use the <u>leFreezeInst</u> function to convert an FGR instance to a non-fluid pcell instance of a new master created on the disk. Alternatively, you can achieve this by choosing <u>Freeze PCell</u> from the context-sensitive menu displayed when you select an FGR instance and right-click on it.



### Why do contacts at the corners of an FGR instance disappear in releases above IC6.1.5 ISR14?


Until IC6.1.5 ISR14, you could see the contacts placed at the corners of all FGR instances in the design. This is because if rules similar to the following were found in the technology file,

Fluid Guard Ring Frequently Asked Questions

the FGR instance was not created using the smaller of the two <u>minOppExtension</u> values for its enclosure:

```
(minOppExtension "Metall" "Cont" (0.01 0.06))
```

However, from IC6.1.5 ISR15 onwards, you might not see the contacts at the corners of newly created FGR instances. The following image illustrates an FGR where the contacts from the corners were removed:




For detailed information, refer to the <u>Using minOppExtension for Placing Contacts in the Corners of a Fluid Guard Ring</u> section in the <u>Creating Fluid Guard Rings</u> chapter of the <u>Virtuoso Fluid Guard Ring User Guide</u>.

# Why are the contacts inconsistently distributed in some areas when two or more FGRs are merged?

Suppose, you have two identical FGRs with three rows of contacts each. When you superimpose these (as shown in the figure below), you can see some contacts that coincide partially or wholly.

Fluid Guard Ring Frequently Asked Questions


If you use the *Edit – Fluid Pcell – Merge* command on these superimposed FGRs, some sections of the resulting merged FGR have only two columns of contacts in some sections.



Inconsistent contact distribution; just two rows instead of three in some areas.

Fluid Guard Ring Frequently Asked Questions

In such scenarios, to get the correct contact distribution as shown below, it is recommended you use the *Edit – Fluid Pcell – Clean Overlapping Contacts* command instead.



#### Can an FGR device hidden from the Install Guard Ring form be reinstalled?

FGR devices can be hidden from the *Install Guard Ring* form using the device hiding techniques described in the *Hiding Fluid Guard Ring Devices* appendix of *Virtuoso Fluid Guard Ring User Guide*.

While trying to install a hidden FGR device, the following happens:

- A prompt message is displayed stating that the FGR device is already installed and is hidden.
- You are not allowed to re-install the hidden FGR device.

To re-install such FGR devices, first remove the associated <code>vfoGRHideDeviceInForms</code> property from the technology file and then reload the file in Virtuoso. Alternatively, you can use the <code>dbDeletePropByName</code> SKILL function in the CIW and then run the <code>dbSave</code> SKILL function to set the modified setting.

## Can an FGR device hidden from the Create Guard Ring form be re-installed from the Install Guard Ring form?

You can re-install an FGR device that was initially hidden from the *Create Guard Ring* form, but this makes it visible on the form once again. In addition, this might result in geometry changes to the existing instances of the FGR device in the layout. A question message is

Fluid Guard Ring Frequently Asked Questions

displayed seeking your confirmation to continue updating the FGR device. You can choose to click the *Yes* or *No* button on the message.

## Is it possible to install an FGR device with implant layer enclosure value less than technology default?

You can install an FGR with the implant layer enclosure value less than the default set in the technology file.

# What should I do if a third party tool issues error and warning messages while using a customized FGR?

A third party tool issues error and warning messages when it is unable to access SKILL and SKILL++ code files written for a customized FGR and thus fails to evaluate it. To allow use of customized FGRs in third party tools, you need to manually load the .il and context files that have the VFO infrastructure definitions as explained in the <u>Loading VFO Infrastructure in Third Party Tools</u> appendix of <u>Virtuoso Fluid Guard Ring User Guide</u>.

### Can I make changes to the procedure for initializing customized FGR devices?

The procedure for initializing customized FGR devices should not be changed. Use it exactly as given in the <u>Procedure for Initializing Customized FGR Devices</u> section of the <u>Loading VFO Infrastructure in Third Party Tools</u> appendix.

### Is it acceptable to call the procedure for initializing customized FGR devices from a file other than libInit.il?

Ensure the procedure for initializing customized FGR devices is called only from the libInit.il file.

# Do the fields displayed on the Create Guard Ring form have corresponding prompt names?

The fields displayed on the Create Guard Ring form have associated prompt names that can be used with the promptName argument of the vfoGRSetCreateFormFieldProp and vfoGRGetCreateFormFieldProp SKILL functions. For a list of valid prompt names, refer to the Create Guard Ring Form Field Names and Associated Prompt Names section

13

Fluid Guard Ring Frequently Asked Questions


of the <u>Customizing Create Guard Ring Form</u> application note available on the <u>Cadence Online Support</u> website.

### **Advanced Node Features (Advanced Nodes Only)**


#### Can a newly created FGR for a FinFET device snap to the fin grids?

Before creating an FGR for a FinFET device, if you select the *Snap Pattern Snapping* check box in the <u>Layout Editor Options</u> form and relevant snap patterns are available on the canvas (just like snapping is available for any other instance in Layout L), the FGR instance automatically snaps to the closest snap pattern fin grid. For detailed information about snap pattern grids in the layout canvas, refer to the <u>FinFET Support in Layout L</u> chapter of the *Virtuoso Layout Suite L User Guide*. The following images illustrate this difference in creating an FGR instance when automatic snapping is enabled or disabled in Layout L:


#### Automatic snapping to snap pattern grid is enabled



 When an FGR instance is created, it snaps to the closest snap pattern grid.




Drag the FGR instance to move it to a different snap pattern grid.




 The FGR instance again snaps to the underlying snap pattern grid that is closest to the new position on the layout.

Fluid Guard Ring Frequently Asked Questions


#### Automatic snapping to snap pattern grid is disabled



1. When an FGR instance is created, it does not snap to the closest snap pattern grid.



Drag the FGR instance to move it to a different snap pattern grid.



3. The FGR instance again does not snap to the underlying snap pattern grid that is closest to the new position on the layout.