Product Version IC23.1 June 2023 © 2023 Cadence Design Systems, Inc. All rights reserved. Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

**Trademarks**: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

**Restricted Permission:** This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

- 1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
- 2. The publication may not be modified in any way.
- 3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
- 4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

**Disclaimer:** Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

**Restricted Rights:** Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor

## **Contents**

<u>1</u>	
Relative Object Design Functions	5
Important Information related to Using ROD SKILL Functions	5
List of ROD SKILL Functions	
Editing ROD Objects with the Virtuoso Layout Editor	7
Using Variables in ROD Functions	
Maximum String Length for ROD Function Arguments	8
Using Special Characters in Names	
rodAddMPPChopHole	
rodAddPoints	13
rodAddSubPart	14
<u>rodAddToX</u>	25
<u>rodAddToY</u>	26
rodAlign	27
rodAssignHandleToParameter	34
rodCheck	57
rodCheckAllMPPsInCellView	58
rodCheckMPPs	60
rodCreateHandle	62
rodCreatePath	64
rodCreatePolygon	98
rodCreateRect	104
rodDeleteHandle	140
rodDeleteSubPart	141
rodFillBBoxWithRects	142
rodFillWithRects	149
rodGetBBox	156
rodForceUpdate	158
rodGetHandle	159
rodGetNamedShapes	160
rodGetObj	161

	rodGetSubPart	163
	rodlsFigNameUnused	164
	rodlsHandle	166
	rodlsMasterChoppable	167
	rodlsObj	168
	rodNameObject	170
	rodNameShape	172
	<u>rodPointX</u>	174
	<u>rodPointY</u>	175
	rodSetMasterChoppable	176
	rodSubPoints	178
	rodUnAlign	179
	rodUnNameShape	180
2		
	olative Object Decign Coordinate Functions	404
$\Box$	elative Object Design Coordinate Functions	
	<u>rodCoordBisect</u>	
	<u>rodCoordCreate</u>	
	rodCoordDefineGrid	
	<u>rodCoordFix</u>	
	rodCoordGetGrid	
	rodCoordIsOnGrid	188
	rodCoordParseString	189
	<u>rodCoordPartition</u>	190
	<u>rodCoordSnap</u>	
	<u>rodCoordToFloat</u>	192
	<u>rodCoordToInt</u>	194
	rodCoordToString	195

1

### **Relative Object Design Functions**

Virtuoso<sup>®</sup> relative object design (ROD) is a set of high-level functions for defining simple to complex layout objects and their relationships to each other, without the need to use low-level Cadence<sup>®</sup> SKILL language functions.

This user guide is aimed at CAD engineers and assumes that you are familiar with the development and design of integrated circuits, Virtuoso<sup>®</sup> Layout Suite L editor, and SKILL programming. This user guide also assumes that you are familiar with the creation of parametrized cells using SKILL or the graphical user interface.

This chapter contains information you need to know before using the Virtuoso<sup>®</sup> relative object design (ROD) functions and describes the ROD functions.

For more information on relative object design concepts, refer to the <u>Virtuoso Relative</u> <u>Object Design User Guide</u>.

#### Important Information related to Using ROD SKILL Functions

Editing ROD Objects with the Virtuoso Layout Editor

Using Variables in ROD Functions

Maximum String Length for ROD Function Arguments

#### List of ROD SKILL Functions

Functions are listed in alphabetical order

<u>rodAddMPPChopHole</u>

**rodAddPoints** 

rodAddSubPart

<u>rodAddToX</u>

## Virtuoso Relative Object Design SKILL Reference Relative Object Design Functions

Relative Object Design Functions

<u>rodNameShape</u>

<u>rodPointX</u>

<u>rodPointY</u>

**rodSubPoints** 

<u>rodUnAlign</u>

<u>rodUnNameShape</u>

#### **Editing ROD Objects with the Virtuoso Layout Editor**

For information about how the Virtuoso layout editor commands work with Virtuoso relative object design (ROD) objects, see <u>Appendix E, "How Virtuoso Layout Editor Works with ROD Objects"</u> in the *Virtuoso Relative Object Design User Guide*.

Using commands that are not fully supported for ROD objects could cause the objects to lose the ROD information associated with them, changing the objects into ordinary shapes.

#### **Using Variables in ROD Functions**

The following variables are useful in ROD functions:

■ pcCellView

An internal variable automatically created by the pcDefinePCell function. pcCellView contains the database ID of the cellview you are creating. Within the body of your Pcell code, use the pcCellView variable as the cellview identifier for which you create objects. In SKILL expressions (ILExpr) for ROD arguments, use the rodCellView variable rather than pcCellView.

■ tcCellView

An internal variable automatically created by the tcCreateCDSDeviceClass function. tcCellView contains the database ID of the cellview you are creating. Within the body of your Pcell code, use the tcCellView variable as the cellview identifier for which you create objects. In SKILL expressions (ILExpr) for ROD arguments, use the rodCellView variable rather than pcCellView.

■ rodCellView

When used in a SKILL expression (ILExpr) for a ROD argument, such as when specifying the  $n\_xSep$  and  $n\_ySep$  arguments for rodCreatePath, rodCellView

Relative Object Design Functions

contains the database ID of the current cellview. Using <code>rodCellView</code> allows you to reference rules in your technology file so that your code will work in different technologies. For example, you can create alignments at the zero-level in your hierarchy, and the system automatically updates the alignments when you make changes to technology file rules that affect them. You can use <code>rodCellView</code> inside or outside of Pcells.

#### **Maximum String Length for ROD Function Arguments**

The maximum number of characters you can specify for a ROD function argument that accepts a string is 1,024. If you specify a string having more than 1,024 characters, you get a syntax error. When you assign a string value to any of the following name arguments, use less than 1,024 characters:

- Paths, rectangles, or polygons when you create them
- Objects using the rodNameShape function
- User-defined handles

If you specify a name using a symbol, use no more than 255 characters in the symbol name. Any symbol name longer than 255 characters results in an error.

#### **Using Special Characters in Names**

When possible, avoid using special characters in the names of handles or ROD objects. Using a special character requires you to type a backslash as an escape character every time you type the name.

If you must use a special character in a string, type a backslash followed by the code for the special character, as shown in the following table:

8

Table 1-1 Using Special Characters in ROD Object Names

Special Character	Escape Sequence	
backspace	\b	
form feed	\f	
new line (line feed)	\n	
carriage return	\r	
horizontal tab	\t	
vertical tab	\v	

## Virtuoso Relative Object Design SKILL Reference Relative Object Design Functions

**Table 1-1 Using Special Characters in ROD Object Names** 

Special Character	Escape Sequence	
backslash	\\	
single quotation mark	\ '	
double quotation mark	\ "	

Relative Object Design Functions

#### rodAddMPPChopHole


```
rodAddMPPChopHole(
    R_rodObj
    l_pts
    );end rodAddMPPChopHole
    => t / nil
```


#### **Description**

Adds a chop hole to all choppable parts of a ROD multipart path. To define a chop hole, you specify a list of points on the centerline of the master path. The results depend on whether the master path is choppable or not.

Master path is not choppable, but subparts are choppable.

Master path is choppable; therefore all subparts are choppable.






Relative Object Design Functions

To add a chop hole to a segment of a multipart path, you must specify two points on the same segment. If you specify only one point on a segment, the system ignores the point.

Specify two points on a segment...


To get this result:



To add a chop hole that includes a vertex (the intersection of two segments), you must include the vertex point in your list.

Specify points including the vertex...

To get this result:



For more information about how chop holes affect multipart paths, see <u>Creating Paths with</u> rodCreatePath in the *Virtuoso Relative Object Design User Guide*.

#### **Arguments**

R\_rodObj

IROD object ID associated with the multipart path.

Default: none

Relative Object Design Functions

1\_pts

List of two or more points on the centerline of the master path specifying where to create a chop hole. The chop hole affects choppable parts only. You are required to specify at least two points. The system discards duplicate and collinear points but does not consider them an error.

Use one of the following formats:

```
list( x:y x:y ... )
or
list( list(x y) list(x y) ... )
Default: none
```

#### **Value Returned**

t

The multipart path was chopped successfully.

nil

An error occurred and the multipart path was not chopped.

Relative Object Design Functions

#### rodAddPoints

#### **Description**

Adds two points together and returns the resulting point as  $1\_point$ .

#### **Arguments**

1\_point1 A set of coordinates in one of the following formats:

x:y or list(xy)

Default: none

1\_point2 A set of points in one of the following formats:

x:y or list(xy)

Default: none

#### **Value Returned**

1\_point The point that results from adding 1\_point1 and

 $1\_point2.$ 

nil No points were added due to an error.

Relative Object Design Functions

#### rodAddSubPart

```
rodAddSubPart(
    R_rodObjId
    t_subpartType
    l_subpartParamList
    );end rodAddSubPart
    => R rodSubpartId / nil
```

#### Description

Creates a new subpart of the type specified by  $t\_subpartType$  with the given list of parameters  $(1\_subpartParamList)$  and adds it to an existing multipart path (MPP).

#### **Arguments**

R\_rodObjId ROD object ID associated with the multipart path (MPP).

*t\_subpartType* String specifying the subpart type. It can be an offset,

enclosure, or a rectangle subpart.

1\_subpartParamList A list of parameters.

list(1\_offsetSubpathArgs1 1\_encSubpathArgs
1\_subrectArgs)

#### where,

l\_offsetSubpathArgslis(txl\_layer n\_width g\_choppable n\_separation S\_justification n\_beginOffset n\_endOffset l\_prop)

#### where,

 $\Box$  txl\_layer

Text string, integer, or list specifying the layer or layerpurpose pair for the subpath, such as:

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Default purpose: drawing

Relative Object Design Functions

 $\square$   $n_{width}$ 

Positive integer or floating-point number specifying the width of the offset subpath.

Default: minWidth for the offset subpath layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreatePath reports an error.

 $\Box$   $g_choppable$ 

Boolean value indicating whether or not the subpath can be chopped. The value must be t or nil. When the master path is choppable, all subpaths must be choppable. When the master path is not choppable, each subpath can be choppable or not.

Default: t

□ n\_separation

Signed integer or floating-point number specifying the separation between the centerline or an edge of the subpath and the centerline or an edge of the master path, depending on the value of

S justification.

Default: 0

 $\square$   $S_{justification}$ 

Symbol or character string specifying from which part of the master path to separate the subpath, relative to the direction of the master path. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

Valid Values: center, left, right

Default: center

When left, the right edge of the subpath is separated from the left edge of the master path. When right, the left edge of the subpath is separated from the right edge of the master path. When center, the centerline of the subpath is separated from the centerline of the master path.

Relative Object Design Functions

□ n\_beginOffset

Signed integer or floating-point number specifying the starting edge of the subpath in relation to the starting edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default: n\_endOffset if specified; otherwise 0

 $\square$  n\_endOffset

Signed integer or floating-point number specifying the ending edge of the subpath in relation to the ending edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default: n\_beginOffset if specified; otherwise 0

□ 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <u>Add Property Form</u>. For Boolean properties, the value must be t or nil.

For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>. Default: nil

Relative Object Design Functions

1\_encSubpathArgsis(txl\_layer n\_enclosure
g\_choppable n\_beginOffset n\_endOffset)

where,

 $\Box$  txl\_layer

Text string, integer, or list specifying the layer or layerpurpose pair for the subpath, such as:

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
Default purpose: drawing
```

□ n enclosure

Signed integer or floating-point number specifying the enclosure of the subpath in relation to the master path. The system computes the width of an enclosure subpath as follows:

```
width = (n_width of master path) - (2 *
n_enclosure)
```

If you do not specify this argument, the system uses the minEnclosure rule from the technology file for master path layer to subpath layer; if the minEnclosure rule is not defined in the technology file, rodCreatePath reports an error.

Default: minEnclosure rule from the technology file for master path layer to subpath layer.

 $\Box$  g\_choppable

Boolean value indicating whether or not the subpath can be chopped. The value must be t or nil. When the master path is choppable, all subpaths must be choppable. When the master path is not choppable, each subpath can be choppable or not.

Default: t.

Relative Object Design Functions

□ n\_beginOffset

Signed integer or floating-point number specifying the starting edge of the subpath in relation to the starting edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default:  $n\_endOffset$  if specified; otherwise the negative of  $n\_enclosure$ 

 $\square$  n\_endOffset

Signed integer or floating-point number specifying the ending edge of the subpath in relation to the ending edge of the master path.

A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default:  $n\_beginOffset$  if specified; otherwise the negative of  $n\_enclosure$ 

1\_subrectArgs is list(txl\_layer n\_width
n\_length g\_choppable n\_sep
S\_justification n\_space n\_beginOffset
n\_endOffset n\_beginSegOffset
n\_endSegOffset S\_gap)

#### where,

□ txl layer

Text string, integer, or list specifying the layer or layerpurpose pair for the subpath, such as:

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
Default purpose: drawing
```

Relative Object Design Functions

 $\square$   $n_{width}$ 

Positive integer or floating-point number specifying the width of rectangles, where the width is parallel to the width of the master path.

If not specified, the system uses  $n\_length$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, nil is returned to indicate an error.

Default:  $n_1ength$  if specified; otherwise minWidth for the subrectangle layer from the technology file.

 $\square$  n\_length

Positive integer or floating-point number specifying the length of the subrectangle(s), where the length is parallel to the master path centerline.

If not specified, the system uses  $n\_width$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, returns nil to indicate an error.

Default:  $n\_width$  if specified; otherwise, minWidth for the subrectangle layer from the technology file.

□ g\_choppable

Boolean value indicating whether or not the subrectangles can be chopped. The value must be t or nil. When the master path is choppable, all subrectangles must be choppable. When the master path is not choppable, each set of subrectangles can be choppable or not.

Default: t.

 $\square$  n\_sep

Signed integer or floating-point number specifying the separation between the centerline or an edge of the subrectangles and the centerline or an edge of the master path, depending on the value of  $S\_justification$ . The system places subrectangles on grid, as close to the specified separation as possible.

Default: 0

Relative Object Design Functions

#### $\square$ $S_{justification}$

Symbol or character string specifying from which part of the master path to separate the subrectangles, in relation to the direction of the master path. When left, the right edge of the subrectangles is separated from the left edge of the master path. When right, the left edge of the subrectangles is separated from the right edge of the master path. When center, the centerline of the subrectangles is separated from the centerline of the master path.

Valid Values: center, left, right

Default: center

#### □ n\_space

Positive integer or floating-point number specifying the distance between the edges of adjoining rectangles. If not specified, the system uses the minSpacing rule for the subrectangle layer from the technology file. If the minSpacing rule is not defined in the technology file, rodCreatePath returns nil to indicate an error.

Default: minSpacing for the subrectangle layer from the technology file.

#### □ n\_beginOffset

Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the first subrectangle in a segment measured from the edge of the master path. Does not apply to the first segment; the position of the first subrectangle in the first segment is determined by the value of the  $n\_beginOffset$  argument.

Relative Object Design Functions

#### □ n\_endOffset

Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the last subrectangle in a segment from the edge of the master path. Does not apply to the last segment; the position of the last subrectangle in the last segment is determined by the value of the  $n\_endOffset$  argument.

#### □ n\_beginSegOffset

Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the first subrectangle in a segment measured from the edge of the master path. Does not apply to the first segment; the position of the first subrectangle in the first segment is determined by the value of the  $n\_beginOffset$  argument.

#### ☐ n endSegOffset


Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the last subrectangle in a segment from the edge of the master path. Does not apply to the last segment; the position of the last subrectangle in the last segment is determined by the value of the  $n\_endOffset$  argument.

Relative Object Design Functions

□ S\_gap

Symbol or character string specifying the method the system uses to place subrectangles within each segment. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.


The system always uses the value of  $n\_space$  for minimum space between subrectangles and calculates the maximum number of rectangles that fit in the segment, allowing for the space needed by  $n\_beginOffset$  and  $n\_endOffset$ . When the value of  $S\_gap$  is distribute, the system distributes the space around subrectangles as evenly as possible, in multiples of the grid space specified by mfgGridResolution. Any remaining space is left after the last subrectangle in the segment.



Relative Object Design Functions

When the value of  $S\_gap$  is distribute and there is only one subrectangle, the value of the distributeSingleSubRect environment variable determines where the single subrectangle is placed. When nil, which is the default, the subrectangle is offset as specified by  $n\_beginOffset$  and  $n\_endOffset$ . When t, the subrectangle is centered (but placed on grid), and  $n\_beginOffset$  and  $n\_endOffset$  are ignored.

When the value of  $S\_gap$  is minimum, the system places subrectangles  $n\_space$  apart until there is no space for another rectangle, then leaves the excess space after the last subrectangle in the segment.



Valid Values: distribute, minimum

Default: distribute

#### **Value Returned**

R\_rodSubpartId

Returns  $R\_rodSubpartId$  if the subpart was created and added successfully to the MPP.

nil

The subpart was not created or added to the MPP.

Relative Object Design Functions

#### Example

rodAddSubPart(mppId "offset" list(list("poly1" "drawing") 1.0 t 0.0 "center" 0.1
0.1))

#### **Related Topics**

<u>multipartPathTemplates</u>

<u>rodCreatePath</u>

Relative Object Design Functions

#### rodAddToX

#### **Description**

Adds a number to the X coordinate of  $1\_point$  and returns the resulting point as  $1\_point$ .

#### **Arguments**

1\_point A set of coordinates in one of the following formats:

x:y or list(xy)

Default: none

*n\_num* Signed integer or floating-point number.

Default: none

#### **Value Returned**

 $1\_point$  The point resulting from adding  $n\_num$  to the X coordinate of

1\_point.

nil No number was added due to an error.

Relative Object Design Functions

#### rodAddToY

#### **Description**

Adds a number to the Y coordinate of  $1\_point$  and returns the resulting point as  $1\_point$ .

#### **Arguments**

1\_point A set of coordinates in one of the following formats:

x:y or list(xy)

Default: none

*n\_num* Signed integer or floating-point number.

Default: none

#### **Value Returned**

 $1\_point$  The point resulting from adding  $n\_num$  to the Y coordinate of

1\_point.

nil No number was added due to an error.

Relative Object Design Functions

#### rodAlign

```
rodAlign(
    [ ?alignObj R_alignObj ]
    [ ?alignHandle S_alignHandle ]
    [ ?refObj R_refObj ]
    [ ?refHandle S_refHandle ]
    [ ?refPoint l_refPoint ]
    [ ?maintain g_maintain ]
    [ ?xSep txf_xSep ]
    [ ?ySep txf_ySep ]
    );end rodAlign
    => R rodObj / nil
```

#### Description

Aligns a named object by a point handle on that object to a specific point or to a point handle on a reference object. You can align objects that are at different levels of hierarchy as long as both objects are in the same top-level layout cellview. You can specify positive or negative separation between alignment points in the direction of both the X and Y axes, either as absolute distances or with Cadence SKILL language expressions. The system applies the offset from the reference point or reference object to the object to be aligned.

#### **Arguments**

```
?alignObj R_alignObj
```

ROD object ID associated with the object you want to align. Use with  $S_alignHandle$  to specify a point on  $R_alignObj$  to use for alignment. The object you want to align must exist in the same top-level cellview as the reference object or reference point.

Default: none

?alignHandle S\_alignHandle

Symbol or character string specifying the name of the handle to use as the alignment point on  $R\_alignObj$ . Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

Default: centerCenter

?refObj R\_refObj

Relative Object Design Functions

ROD object ID associated with the object to be used as a reference for the alignment. The reference object must exist in the same top-level cellview as the object specified by  $R_alignObj$ .

If you do not specify  $l\_refPoint$ , this argument is required. If you also specify  $l\_refPoint$ , the value of  $l\_refPoint$  overrides the values of  $R\_refObj$  and  $S\_refHandle$ . Default: none

?refHandle S\_refHandle

Symbol or character string specifying the name of the handle on the reference object to which you want to align  $R\_alignObj$ . If you also specify  $l\_refPoint$ , it overrides the value of  $R\_refObj$  and  $S\_refHandle$ . Default: centerCenter

?refPoint l\_refPoint

A list of two coordinates specifying the point to which you want to align  $R_alignObj$ . Use one of the following formats:

*x* : *y* or

list(xy)

If you do not specify  $S\_refHandle$ ,  $R\_refObj$ , or  $l\_refPoint$ , then  $l\_refPoint$  defaults to 0:0. If you specify  $l\_refPoint$  and also specify  $R\_refObj$  (with or without specifying  $S\_refHandle$ ), the value of  $l\_refPoint$  overrides the values of  $R\_refObj$  and  $S\_refHandle$ .

Default: 0:0

?maintain *g\_maintain* 

A Boolean value specifying whether or not to maintain an alignment after it is created. The value must be t or nil.

When set to t, moving one of two aligned objects moves the other with it. When set to nil, moving one of two aligned objects does not move the other object.

You can use the nil setting to create temporary alignments for the purpose of arranging objects in relation to each other. These alignments are no longer in effect after the rodAlign function completes execution.

Default: t

Relative Object Design Functions

?xSep txf\_xSep

An integer, floating-point number, or Cadence SKILL language expression specifying the vector distance in the direction of the X axis from either the reference point handle  $S\_refHandle$  on  $R\_refObj$  or the reference point  $l\_refPoint$  to the alignment point handle  $S\_alignHandle$  on  $R\_alignObj$ .

The value can be positive or negative or a SKILL expression that evaluates to a positive or negative number. SKILL expressions are reevaluated whenever the design is opened, the technology file is updated, or one of the aligned objects is moved or modified.

Default: 0

?ySep txf\_ySep

An integer, floating-point number, or Cadence SKILL language expression specifying the distance along the Y axis from either the reference point handle  $S\_refHandle$  on  $R\_refObj$  or the reference point  $1\_refPoint$  to the alignment point handle  $S\_alignHandle$  on  $R\_alignObj$ . The value can be positive or negative or a Cadence SKILL language expression that evaluates to a positive or negative number. SKILL expressions are reevaluated whenever the design is opened, the technology file is updated, or one of the aligned objects is moved or modified.

Default: 0

#### Value Returned

R\_rodObj ROD object ID for the ROD object information associated with

 $R_alignObj.$ 

nil An error occurred and no objects were aligned.

#### **Additional Information**

When you align an object to a point, the system creates a user-defined handle for the point with the system-assigned name  $\mathtt{handlen}$ , where n is a number that makes the handle name unique in the cellview. For information about user-defined handle, see "User-Defined Handles" in the *Virtuoso Relative Object Design User Guide*.

Relative Object Design Functions

You can also use the rodAlign function to quickly arrange objects in relation to each other by temporarily aligning them. When the  $g_{maintain}$  argument is set to nil, alignments are no longer maintained after the function is executed.

For an overview about aligning objects, see <u>"Aligning Objects"</u> in the *Virtuoso Relative Object Design User Guide*. The following examples illustrate aligning ROD objects.

Figure 1-1 on page 30 shows the object polyRect before and after it is aligned to the reference point 0:0.

Figure 1-1 Aligning a Rectangle to a Point




Figure 1-2 on page 31 shows the objects <code>polyRect</code> and <code>rect0</code> both before and after <code>polyRect</code> is aligned to <code>rect0</code>. After alignment, the <code>centerLeft</code> handle of <code>polyRect</code> is aligned to the <code>centerRight</code> handle of <code>rect0</code>, with a positive separation along the X axis. The object <code>polyRect</code> is on the right side of <code>rect0</code> because the system applies the offset from the reference object <code>rect0</code> to the aligned object <code>polyRect</code>.

Relative Object Design Functions

Figure 1-2 Aligning Two Rectangles with Positive Separation





Figure 1-3 on page 31 shows instance I1 and the rectangle rect0. Instance I1 contains instance I2, which contains the object polyRect.

Figure 1-3 Aligning an Instance and Rectangle Across Hierarchy



The hierarchical name for polyRect is I1/I2/polyRect.

Figure 1-4 on page 32 shows instance I1 and rect0 after alignment across hierarchy. rect0 is the reference object. The centerRight handle of


Relative Object Design Functions

I1/I2/polyRect is aligned to the centerLeft handle of rect0, with a -10 separation in the direction of the X axis.

Because the offset is negative along the X axis, the aligned object I1/I2/polyRect is on the left side of the reference object rect0. Subsequently, if you move rect0, instance I1 and everything in it moves with rect0, maintaining the correct alignment; also, if you move instance I1, rect0 moves with it.

Figure 1-4 Instance and Rectangle After Alignment

Negative offset from reference object.



**Note:** For information about how the Virtuoso layout editor *Maintain Connections* option works for aligned objects, see <u>"Maintaining Connections for ROD Objects"</u> in the *Virtuoso Relative Object Design User Guide*.

#### Querying an Object for Alignment

You can query any named object to see what the object is aligned to. When you query a hierarchical object, the system displays all top-level alignments for the object. To see the alignments for an object, you can use the Virtuoso layout editor Edit Properties command (the ROD section) or type commands in the CIW, as shown in the examples below.

As shown in the example, I1/I2/polyRect is aligned to rect0. To query rect0 in Figure 1-4 on page 32 for alignments, type the following in the CIW:

Relative Object Design Functions

```
cvId = deGetCellView()
rodGetObj( "rect0" cvId )~>align
```

The system displays text similar to the following in the CIW:

The text above states that the centerRight (cR) handle on I1/I2/polyRect (rodObj:2585108) is aligned to the centerLeft (cL) handle on rectO (rodObj:2585114), with a separation of -10.0 along the X axis and no separation along the Y axis.

#### **Moving Aligned Objects**

When you move a ROD object that is aligned to one or more ROD objects, the aligned objects also move. When you move a ROD object that is aligned to a reference point, the system changes the value of the reference point handle to keep the point in the same relationship with the object.

Relative Object Design Functions

#### rodAssignHandleToParameter

```
rodAssignHandleToParameter(
     [ ?parameter S_parameter ]
     [ ?rodObj R_rodObj ]
     [ ?handleName Sl handleName ]
     [ ?displayName S displayName ]
     [ ?displayExpression S_displayExpression ]
     [ ?stretchDir S_stretchDir ]
     [ ?stretchType S_stretchType ]
     [ ?moveOrigin g_moveOrigin ]
     [ ?updateIncrement f_updateIncrement ]
     [ ?userData g userData ]
     [ ?userFunction Sl_userFunction ]
     [ ?stretchKey S_stretchKey ]
     [ ?shape S_shape ]
    ); end rodAssignHandleToParameter
    => t / nil
```

#### **Description**

Assigns one or more user- or system-defined point handles on a ROD object within a SKILL-based parameterized cell (Pcell) to a single Pcell parameter, so you can change the value of the parameter by graphically stretching the handle(s). Stretching a handle has the same effect as changing the value of the associated parameter for the Pcell instance using the Edit Properties form. You cannot stretch handles on the Pcell master. All rodAssignHandleToParameter statements must occur within the body-of-code section of a SKILL-based Pcell.

For an overview of stretchable Pcells, see <u>"Stretchable Parameterized Cells"</u> in the *Virtuoso Relative Object Design User Guide*.

Relative Object Design Functions

#### **Arguments**

?parameter *S\_parameter* 

Symbol or character string specifying the name of the Pcell parameter to which you want to assign one or more point handles. The data type of the Pcell parameter must be an integer or floating-point number, unless you also specify the  $Sl\_userFunction$  argument.

This argument is required. If you do not specify this argument or the parameter does not exist in the parameter declaration section of the Pcell code, the function reports an error. Valid Values: any parameter associated with the Pcell Default: none

?rodObj R\_rodObj

ROD object ID identifying the object in a Pcell that has the point handles you want to assign to a parameter. This argument is required. If you do not specify this argument or the specified ROD object ID is not valid, the function reports an error.

Default: none

?handleName Sl\_handleName

Symbol or character string specifying the name of a single user- or system-defined point handle or a list of character strings or symbols specifying the names of one or more point handles. You can specify any point handles that are associated with the object specified by  $R_rodObj$ .

This argument is required. If you do not specify this argument or a specified handle is not a point handle for the specified object, the function reports an error.

Default: none

?displayName S\_displayName

Symbol or character string specifying any text that you want the system to display next to the Pcell while you stretch it, such as the name of a parameter or an expression. For example, the following are valid values: "length", 'length, "length + 2", and "My Handle".

Relative Object Design Functions

If you also specify  $S\_displayExpression$ , the system displays both its value "as is", without evaluating it, and the result of evaluating the  $S\_displayExpression$  argument, separated by the string " = ", in the following format:

```
displayName =
displayExpression_evaluation_result
```

The following examples show what the system displays when you specify both display arguments:

S_display Name	S_display Expr	displayExpr <b>Evals To</b>	What You See
"length"	"length * 2"	10	length = 10
"length"	"width + 3"	16	length = 16

If you do not specify  $S\_displayExpression$ , the system treats  $S\_displayName$  as an expression and evaluates it dynamically as you stretch the Pcell. The system displays both the string or symbol and the result of the evaluation, separated by the string " = ", in the following format:

```
displayName =
displayName_evaluation_result
```

If  $S\_displayName$  does not evaluate successfully, the system displays <code>Eval not successful</code> in the layout cellview instead of a value. If no value is specified for  $S\_display-Name$ , nothing is displayed for it.

For more information about specifying this argument, see <u>"Additional Information"</u> on page 44.

Default: none

?displayExpression S\_displayExpression

Relative Object Design Functions

Symbol or character string specifying an expression, such as a parameter name or equation. For example, the following are valid values: "width", 'width, and "width + 2".

The system evaluates the value of this argument dynamically as you stretch the Pcell and displays the result next to the Pcell. When you specify this argument but do not specify the  $S\_displayName$  argument, the system displays the result of the evaluation in the following format:

```
result_of_evaluation
```

For example, for the expression "width", where width equals 12, the system displays 12.0; for the expression "width + 2", the system displays 14.0.

If you also specify  $S\_displayName$ , the system displays both the value of  $S\_displayName$ , without evaluating it, and the result of evaluating the  $S\_displayExpression$  argument, separated by the string " = ", in the format:

For more information about specifying this argument, see <u>"Additional Information"</u> on page 44.

Default: none

?stretchDir S\_stretchDir

Symbol or character string specifying the axis along which you want the Pcell to stretch. Although you can stretch the Pcell in any direction, the system computes the change to  $S\_param-eter$  only in the direction of the axis specified by this argument; the system updates the associated Pcell parameter with a change in the direction of either the X or Y axis.

Valid Values: x, X, y, or Y

Default: x

Relative Object Design Functions

?stretchType S\_stretchType

Symbol or character string specifying whether the stretch is relative to the position of the handle or to the center of the Pcell. When the value is absolute, the stretch is relative to the handle; when the value is relative, the stretch is relative to the center of the Pcell.

For an absolute stretch, an upward stretch away from the position of the handle (in a positive direction along the axis) is an increment; a downward stretch away from the position of the handle (in a negative direction along the axis) is a decrement. For a relative stretch, a stretch is away from the center of the Pcell is an increment; a stretch towards the center of the Pcell is a decrement.

For examples showing relative vs. absolute, see <u>"Results of Stretching a Handle"</u> in the *Virtuoso Relative Object Design User Guide*.

Valid Values: relative or absolute


**Default**: relative


?moveOrigin g\_moveOrigin


Boolean value specifying whether the system can move the origin point of an instance during the stretch of a handle on the instance or on an object in the instance. When the value is t, the origin point can move during a stretch; when the value is nil, the origin point cannot move during a stretch. Specifying t is most useful when  $S\_stretchType$  is set to relative and the location of the stretch handle coincides with and affects the bounding box of the Pcell instance.


When the origin point can move, the edges of the instance adjacent to the origin point can move also, which allows handles on those edges to move in the direction of the stretch.

Relative Object Design Functions









When the origin cannot move, the edges of the instance adjacent to the origin point cannot move either, which prevents handles on those edges from moving in the direction of the stretch.

For more examples, see <u>"Results of Stretching a Handle"</u> in the *Virtuoso Relative Object Design User Guide*.

Valid Values: t, nil

Default: nil

Relative Object Design Functions

?updateIncrement f\_updateIncrement

Floating-point number specifying how often the system updates the Pcell parameter ( $S\_parameter$ ) and regenerates the Pcell during a stretch operation. If you specify a negative number, the system uses the default. The default is the value of the layout editor environment variable udpatePcel-lincrement. If you specify  $f\_updateIncrement$ , its value overrides the value of updatePcellIncrement. Default: value of the layout editor environment variable udpatePcellIncrement

?userData *g\_userData* 

User data of any data type. The system evaluates the data and includes the result as part of the  $r\_defstruct$  structure that is passed to  $Sl\_userFunction$  as input. This argument lets you pass the values of variables and constants defined in your Pcell code to a user-defined function. For example, you can pass the values of design rules, such as minSpacing and minWidth.

Relative Object Design Functions

?userFunction Sl\_userFunction

Symbol, string, or <u>lambda function</u> specifying a user-defined function. A lambda function lets you define a function without using a function name. The purpose of user-defined functions is to calculate new values for Pcell parameters. Do not use user-defined functions for other purposes, such as to create shapes. User-defined functions are executed interactively while the Pcell is stretched; therefore, a user-defined function cannot depend on Pcell arguments.

**Note:** It is recommended not to use lambda functions when using the Express Pcell feature. Instead, a normal function should be defined and passed as a function object to ROD for stretch handling. This is because in the Express Pcell feature, the Pcell code is evaluated and the submaster is stored in cache to avoid reevaluation. However, the lambda functions are temporary functions that need to be evaluated each time and therefore, cannot be stored in cache as a function object pointer. Therefore, any storage of the lambda functions as a function object becomes stale for the next session.

As input to the user-defined function, the system passes a defstruct that is predefined by the ROD software. A defstruct is a named SKILL structure containing a collection of one or more slots for variables.

In this syntax, the defstruct is referred to as  $r\_defstruct$ . Replace defstruct with your own name, for example, myDefstruct.

See defstruct.

Relative Object Design Functions

This destruct contains the following predefined variable slots:

t\_handleName
 Text specifying the name of the handle currently being stretched.

#### ■ n\_increment

An integer or floating-point number specifying the increment or decrement as a result of stretching  $t\_handle-Name$ .

d\_origInstIdDatabase ID of the original instance being stretched.

#### ■ g\_parameters

Lets you set the value of a Pcell parameter, using the following construct:

where  $parameter\_value$  must evaluate to the same data type as  $parameter\_name$ . The  $g\_parameters$  variable is write-only; it is not preloaded with parameter names and values. After the user-defined function completes, the system looks at  $g\_parameters$  within the predefined defstruct, and if any parameters were set, the system uses those values as the new parameter values.

#### **■** g\_paramVal

Current value of the Pcell parameter named S\_parameter; the value can have any data type.

#### ■ R\_rodObj

ROD object ID identifying the original object whose handle is being stretched.

#### ■ S\_stretchDir

String or symbol specifying the stretch direction for the current handle being stretched ( $t_handleName$ ).

#### ■ d\_stretchMaster

Interim database ID of the most recent Pcell submaster in virtual memory.

#### ■ g\_userData

Result of the evaluation of the  $g\_userData$  argument by the system, when user data is specified.

Relative Object Design Functions

The system replaces the value of  $S1\_parameter$  with the value returned. If the value for  $S1\_parameter$  is also set using the myDefstruct->parameters-> construct, the construct value overrides the value returned by the user-defined function.

User-defined functions **must** return a value with the same data type as  $S_parameter$ , and the value assigned by a myDef-struct->parameters-> construct must have the same data type as the parameter. If a value does not have the same data type as its parameter, the system issues a warning and assigns zero or a null value to the parameter; the evaluation of the Pcell could fail.

For more information about the ROD predefined destruct, see <u>"The r defstruct Structure"</u> on page 50. For more information about user-defined functions, see <u>"User-Defined Functions"</u> on page 48.

Default: none

?stretchKey S\_stretchKey

Symbol or character string that you can specify as per your requirement. The internal representation of this string is allocated dynamically. It is a null string, until a key is specified in the rodAssignHandleToParameter call.

Default: null

?shape  $S_shape$ 

Symbol or character string that you can use to control the default shape of the stretch handle.

Valid Values: diamond, square, dot

Relative Object Design Functions

#### **Value Returned**

t Handles were successfully assigned to the Pcell parameter.


nil An error occurred and no handle was assigned.

#### **Additional Information**

# Displaying Parameter Information

You can define information to be displayed for a Pcell parameter by specifying the  $S\_displayName$  and  $S\_displayExpression$  arguments. For  $S\_displayExpression$ , you can include any Pcell parameter in the expression. The system displays the information next to the upper-right corner of the Pcell when you select the assigned stretch handle and updates the information as you drag the handle.

For example, for a Pcell that contains only a rectangle and has one parameter, width, you might want to display the name of the parameter and its new value as you stretch the Pcell.



Depending on the information you want to display, specify the arguments as follows:

#### To display

displayName = displayName\_evaluation\_result

specify only the  $S\_displayName$  argument. The system displays its contents as an unevaluated text string on the left and the result of evaluating the  $S\_displayName$  argument on the right, separated by the string " = ".

The following examples show what the system displays when you specify only the  $S\_displayName$  argument:

S_displayName	Name Evals To	What You See
`length	10	length = 10

Relative Object Design Functions

S_displayName	Name Evals To	What You See
"length * 2"	20	length * 2 = 20
"onOffSwitch"	t	onOffSwitch = t
"M"	evaluation fails	M = Eval not successful

If no value is specified for  $S\_displayName$ , nothing is displayed for it.

# To display

displayExpression\_evaluation\_result

specify only the  $S\_displayExpression$  argument. You can use any Pcell parameter in the expression. The system evaluates the expression and displays the result.

For example, if  $S\_displayExpression$  contains the expression width + 3, and the variable width is currently equal to 5.0, the system displays the following: 8.0

## To display

displayName = displayExpression\_evaluation\_result

specify both the  $S\_displayName$  and  $S\_displayExpression$  arguments. The system displays the contents of  $S\_displayName$  as an unevaluated text string on the left and the result of evaluating  $S\_displayExpression$  on the right, separated by the string " = ".

The following examples show what the system displays when you specify both display arguments:

S_displayName	S_displayExpr	displayExpr Evals To	What You See
"length"	"length * 2"	10	length = 10
"length"	"width + 3"	16	length = 16

#### Examples of Display Information


In the following example, the Pcell contains only a rectangle, with handles assigned to the three Pcell parameters: capacitance, width, and length. The Pcell code contains three rodAssignHandleToParameter statements:

■ One rodAssignHandleToParameter statement assigns the upperRight handle to the capacitance parameter.

Relative Object Design Functions


- A second rodAssignHandleToParameter statement assigns the lowerRight handle to the width parameter.
- A third rodAssignHandleToParameter statement assigns the lowerRight handle to the length parameter.

In each statement, the information to be displayed is specified as follows:




- For the capacitance parameter, *S\_displayName* is cap and *S\_displayExpression* is the expression width\*length/capCoeff
- For the width parameter,  $S\_displayName$  is width and  $S\_displayExpression$  is not specified.
- For the length parameter, *S\_displayName* is length and *S\_displayExpression* is not specified.

When you select the upperRight handle, you see the following information displayed:



Relative Object Design Functions

When you select the lowerRight handle, you see the following information displayed:



For a table showing examples of how to specify the display arguments, see <u>Table 1-2</u> on page 47.

The following table shows the results of specifying one or both of the  $S\_display$  arguments.

Table 1-2 Examples of Specifying the Display Arguments

S_displayName	S_display Expression	Evaluates To	What You See
`length		10	length = 10
"length * 2"		20	length * 2 = 20
"onOffSwitch"		t	onOffSwitch = $t$
"My Handle"		evaluation fails	My Handle = Eval not successful
	"length"	10	10
	"length * 2"	20	20
	"onOffSwitch"	t	t
	"myHandle"	evaluation fails	Eval not successful
"length"	"length * 2"	20	length = 20
"length"	"width + 3"	16	length = 16
"On-Off Switch"	"onOffSwitch"	t	On-Off Switch = t
"My Handle"	"myHandle"	evaluation fails	My Handle = Eval not successful

Relative Object Design Functions

#### **User-Defined Functions**

When you assign a handle to a parameter, you can define your own function  $(S1\_userFunction)$  to calculate the value of the Pcell parameter  $(S\_parameter)$  to which you are assigning the handle. These functions are executed when the Pcell is stretched; they cannot depend on Pcell parameters.

**Note:** A user-defined function should be used only to calculate a new value for a Pcell parameter. Do not use user-defined functions for other purposes, such as creating objects.

#### Information Passed to a User-Defined Function

As input to user-defined functions, the ROD software passes a predefined, user-named defstruct ( $r\_defstruct$ ). For a description of the contents of the defstruct, see the  $Sl\_userFunction$  argument description.

## Specifying Values for Parameters Using the -> Operator

Within a user-defined function, you can use the following construct to set the value for any Pcell parameter:

```
myDefstruct->parameters->parameter_name = parameter_value
```

where myDefstruct is your name for the defstruct and parameter\_value must be the same data type or evaluate to the same data type as parameter\_name. For example,

```
myDefstruct->parameters->width = 6.0
```

The system stores all such constructs in the place-holder variable  $g_parameters$  within the  $r_defstruct$  structure.

**Note:** The  $g_parameters$  variable is not preloaded with parameters and their values.

#### What the System Does

The system executes the user-defined function, which calculates and returns a new value for  $S\_parameter$ . After the user-defined function completes, the system looks at the variable  $g\_parameters$  within the  $r\_defstruct$  structure and, if values were set for any parameters, uses those values as the new values for the parameters.

**Note:** If you set the value for  $S_parameter$  using the myDefstruct->parameters-> construct, the system uses the value assigned by the construct rather than the value returned by the user-defined function.

#### **Loading User-Defined Functions**

When there are user-defined functions specified, the system calls them at each drag increment during the stretch and when you complete the stretch operation. You need to make

Relative Object Design Functions

sure that user-defined functions are loaded into the system before the system needs them. User-defined functions must be loaded prior to dragging a stretch handle belonging to a Pcell.

The safest way to make sure that user-defined functions are always available when needed is to attach them to your library. Then the system automatically loads them when the library is opened.

Follow the steps below to attach a source file for a user-defined function to a library:

- **1.** Place the source file within the library directory.
- **2.** Create a file named libInit.il in the library directory.
- **3.** The system automatically loads the libInit.il file when the library is opened.
- **4.** Within the libInit.il file, write a load statement like this:

**Note:** Avoid using graphical SKILL functions such as hiSetBindKey in your libInit.il file; doing so will result in an error. For more information see <u>"What to Avoid in the libInit.il File"</u> in the *Virtuoso Parameterized Cell Reference*.

#### Lambda Functions

Using a *lambda function* lets you define a function without a name, in the form of a list. This is useful for writing temporary or local functions.

The syntax for a lambda function is:

```
lambda(
    (1_formalArguments)
    g_expr1 ...)
=> U_result)
); end lambda
```

#### **Arguments**

lambda Identifies the following arguments as belonging to an unnamed function.

1\_formalArguments List of one or more variable names.

Relative Object Design Functions

 $g_expr1...$ 

The remaining elements in the list are SKILL expressions that are evaluated when the lambda function is called.

For example, the following lambda function defines an unnamed function capable of computing the length of the diagonal side of a right-angled triangle:

```
lambda ( (x y) (sqrt (x*x + y*y))

When x = 3 and y = 4, the value returned is 5.0.
```

You do not need to precede a lambda function with a single quotation mark.

For more information about lambda functions, see <u>"Basic Concepts" in Chapter 3 of the SKILL Language User Guide</u> and <u>"lambda"</u> in the SKILL Language Reference.

#### The r\_defstruct Structure

 $r\_defstruct$  is a user-named structure that is predefined by the ROD software to contain a series of slots for specific variables. A defstruct behaves just like a disembodied property list. The system passes the defstruct as input to user-defined functions defined within the rodAssignHandleToParameter function. For more information, see <u>defstruct</u>.

You can access the value of the variables in the  $r\_defstruct$  structure by using the name you assigned to the defstruct, the structure access operator (->) and the name of the variable. For example, to access the value of the variable  $R\_rodObj$ , type the following:

```
myDefstruct->rodObj
```

#### **Examples**

The following examples use user-defined functions.

#### **Example 1**

The following user-defined function adds the value of  $n\_increment$  to  $g\_paramVa1$ , prints the current values of the myDefstruct variable slots, displays a warning message if the return value is less than zero, and returns the new value of  $g\_paramVa1$ .

Relative Object Design Functions

#### The user-defined function produces the following output:

```
myDefstruct->handleName = upperRight
myDefstruct->increment = 0.300000
myDefstruct->origInstId = db:67200100
myDefstruct->parameter = length
myDefstruct->paramVal = 1.0
myDefstruct->rodObj = rodObj:66969624
myDefstruct->stretchDir = y
myDefstruct->stretchMaster = db:67195948
```


#### **Example 2**

The following example shows how to specify the  $g\_userData$  argument and the  $g\_parameters$  element of the  $r\_defstruct$  structure for user-defined functions.

In the example, a capacitor has a fixed capacitance parameter (cap) and variable width and length parameters. As length is stretched, the system automatically adjusts width to maintain the fixed capacitance value; the converse is also true.

Relative Object Design Functions

The figure below shows what the capacitor looks like before and after stretching the leftCenter handle to increase width. The system decreases length to keep the capacitance constant.



To make the Pcell process independent, design rules such as minSpacing were retrieved from the technology file and passed to the user-defined function with the optional  $g\_userData$  argument.

In the code below, each section does the following:

- Section 1 is the part of the Pcell code that gets the technology file ID and uses it to retrieve the technology rules used in the input to the user-defined function in Section 3.
- Section 2 is the part of the Pcell code that assigns the leftCenter and rightCenter handles to the width parameter.
- Section 3 is a user-defined function that is called from within the Pcell, but which is not part of the Pcell code. The procedure updates length when width is stretched. The g\_userData argument passes technology rule values to the user-defined function.

As a SKILL Pcell author, you can write a process-independent Pcell by using design rules from your technology file, such as minSpacing and minEnclosure. The  $g\_userData$  parameter lets you pass values for constants and variables, such as the values of technology rules, directly to your user-defined function.

```
;; SECTION 1: Pcell code that gets minimum values from technology file
tfId = techGetTechFile( pcCellView )
capCoeff = techGetParam( tfId "capCoeff" )
;layer1 and layer2 are top and bottom layers for capacitor
lay10via = techGetOrderedSpacingRule( tfId "minEnclosure"
```

Relative Object Design Functions


```
layer1 "cont")
lay20via = techGetOrderedSpacingRule( tfId "minEnclosure"
                                    layer2 "cont" )
viaW = techGetSpacingRule( tfId "minWidth""cont"
grid = techGetMfgGridResolution( tfId )
minCap = techGetParam( tfId "minCap" )
;; SECTION 2: Pcell code that assigns handles to parameters
rodAssignHandleToParameter(
   ?parameter "width"
   ?rodObj cnt
   ?displayName "width"
   ?handleName list("leftCenter" "rightCenter")
    ?stretchType "absolute"
   ?stretchDir "x"
   ?userData list(list(capCoeff lay10via lay20via viaW grid
                minCap ))
   ?userFunction "myfunc"
) ; end rodAssignHandleToParameter
;; SECTION 3:User-defined function called from within pcell.
;; The procedure updates the length when width is changed by
;; the stretch operation.
procedure (myfunc (myDefstruct)
   let((returnVal mylist capCoeff lay10via lay20via viaW grid
           minCap)
       returnVal = myDefstruct->paramVal + myDefstruct->increment
       mylist = car(myDefstruct->userData)
       capCoeff = nth(0 mylist)
       lay10via = nth(1 mylist)
       lay20via = nth(2 mylist)
       viaW = nth(3 mylist)
       grid = nth(4 mylist)
       minCap = nth(5 mylist)
       cap = (myDefstruct->stretchMaster) ~>parameters~>cap
       if(lay10via > lay20via then
            minCapWidth = (2 * lay1Ovia + viaW)
       else
           minCapWidth = (2 * lay2Ovia + viaW)
        ); end if
       ;; Calculate the current length
       length = spcRound((cap/capCoeff/returnVal) grid)
       when (length < minCapWidth
           length = minCapWidth
           returnVal = spcRound((cap/capCoeff/length) grid)
       ); end when
       ;; Reset the length so the capacitance value remains fixed.
       myDefstruct->parameters->length = length
       returnVal
   ); end let
); end procedure
```

For more information about structures, see <u>Defstructs</u> in *SKILL Language User Guide* and the defstruct function *SKILL Language Reference*.

## Example 3

Relative Object Design Functions

The following example shows a MOS transistor Pcell with stretch handles on the source and drain contact arrays. The MOS transistor Pcell calls two user-defined functions.



The MOS transistor Pcell parameters are specified as follows:

Parameter Name	Default Value	Parameter Description
W	1.3	Width of gate
1	0.25	Length of gate
leftcov	1.0	Left contact coverage
rightcov	1.0	Right contact coverage
leftPos	"top"	Position of left contacts
rightPos	"top"	Position of right contacts


The contact arrays are aligned to the gate. For example, when leftPos equals top, the upperLeft point handle of the gate is aligned to the upperRight point handle of the left contact array, with an offset along both the X and Y axes.

The stretch handles are assigned as follows:

■ To make the source contacts stretchable, the upperCenter and lowerCenter point handles on the source contact array are assigned to the Pcell parameter leftcov with the stretch type relative and the stretch direction Y.

Relative Object Design Functions

■ To make the drain contacts stretchable, the upperCenter and lowerCenter point handles on the drain contact array are assigned to the Pcell parameter rightcov with the stretch type relative and the stretch direction Y.



Two user-defined functions control the number of contacts generated and whether they are aligned to the top or bottom of the diffusion:

- The user-defined function <u>contcov</u> sets a range for the contacts from a 100% coverage to the minimum contact width for the layer from the technology file.
- The user-defined function myStretch identifies the handle currently being stretched. It determines whether the contacts are aligned to the top or bottom of the diffusion.

To look at the code for the Pcell and the user-defined functions, see <u>"Stretchable MOS Transistor"</u> in the *Virtuoso Relative Object Design User Guide.* 

# **Example 4: Stretching the Sample MOS Transistor**

You can stretch the MOS transistor shown in <u>Example 3</u> in a negative direction towards the Y axis to reduce the number of contacts in the array to one, using the Virtuoso layout editor *Stretch* command.


- **1.** Choose *Edit Stretch*.
- 2. Select the upperCenter stretch handle on the left contact array using an area-selection box.
- **3.** To specify the reference point, click the upperCenter stretch handle on the left contact array.

Notice that the following information appears to the right of the Pcell:

leftcov = 1


Relative Object Design Functions

**4.** To specify the new location, click above the bottom transistor.



**Note:** If you have trouble selecting the stretch handle, try turning off the *Gravity On* option on the Layout Editor Options form.

The MOS transistor Pcell instance now looks like this:



Relative Object Design Functions

#### rodCheck

# Description

Searches the specified cellview for multipart paths (MPPs) for which the geometry does not match the definition information, and returns a list of the ROD object IDs. The MPPs found by this function include those that have lost their subshape definition information. By default, this function places warning markers over the potentially affected MPPs. (If you do not want to see warning markers, set the  $g\_createMarkers$  argument to nil.) Although subparts with missing definition information are still visible graphically, their definitions have been deleted from the database. Editing an affected MPP causes an immediate loss of the subpart graphics.

# **Arguments**

 $d_{CVID}$  Database ID for the cellview you want to search.

Default: none

g\_createMarkers Boolean value indicating whether or not to create warning

markers for the potentially affected MPPs found by the

rodCheck function.
Valid values: t, nil

Default: t

#### Value Returned

R1\_rodObj ROD object ID or list of ROD object IDs that identifies the

multipart paths for which the geometry does not match the

definition information.

Relative Object Design Functions

#### rodCheckAllMPPsInCellView

```
rodCheckAllMPPsInCellView(
    t_libName
    t_cellName
    t_viewName
    g_fix
    g_createMarkers
); end rodCheckAllMPPsInCellView
=> l_defectiveMPPIds / nil
```

#### **Description**

Finds and opens the design specified by  $t_libName$ ,  $t_cellName$ , and  $t_viewName$ , and checks if any MPP in the design contains defective internal data. If MPPs containing defective internal data are found, rodCheckAllMPPsInCellView fixes them and creates markers on them depending on the values of  $g_fix$  and  $g_createMarkers$  arguments.

# **Arguments**

t_libName	Character string representing the library name of the design
t_cellName	Character string representing the cell name of the design
t_viewName	Character string representing the view name of the design
$g\_fix$	Boolean value indicating whether or not to fix the potentially affected MPPs found by rodCheckAllMPPsInCellView. Valid values: t, nil
g_createMarkers	Boolean value indicating whether or not to create warning markers for the potentially affected MPPs found by the rodCheckAllMPPsInCellView function.  Valid values: t, nil

#### **Value Returned**

l_defectiveMPPIds	ROD object ID or list of ROD object IDs that identifies the multipart paths containing defective internal data.
nil	Returns nil if any of the arguments are invalid or the MPPs could not be fixed.

# Virtuoso Relative Object Design SKILL Reference Relative Object Design Functions

# Possible outputs

g_fix	g_createMarkers	Output
t	nil	Fix but do not create markers
t	t	Fix and create markers
nil	nil	Do not fix or create markers. Returns the list of defective MPP IDs.
nil	t	Do not fix, but create markers.

Relative Object Design Functions

#### rodCheckMPPs

```
rodCheckMPPs(
    d_cellViewId
    R_rodObj | list(R_rodObj ...)
    g_fix
    g_createMarkers
    );end rodCheckMPPs
=> l_defectiveMPPIds / nil
```

# **Description**

Checks if the given list of multipart paths (MPPs) contains corrupt internal data. If MPPs containing defective internal data are found, rodCheckMPPs fixes or creates markers to highlight them, or does both.

# **Arguments**

d_cellViewId	ID of the cellview that contains the MPP.		
R_rodObj / list(r_rodObj)			
	A single rodObjectId of an MPP or a list of rodObjectIds of MPPs.		
g_fix	Boolean value indicating whether or not to fix the potentially affected MPPs found by rodCheckMPPs.  Valid values: t, nil		
g_createMarkers	Boolean value indicating whether or not to create warning markers for the potentially affected MPPs found by the rodCheckMPPs function.  Valid values: t, nil		

#### **Value Returned**

l_defectiveMPPIds	Returns the list of rodObjectIds of MPPs containing defective internal data among the list provided.
nil	Returns nil if any of the arguments are invalid or the MPPs could not be fixed.

# Virtuoso Relative Object Design SKILL Reference Relative Object Design Functions

# Possible outputs

g_fix	g_createMarkers	Output
t	nil	Fix but do not create markers
t	t	Fix and create markers
nil	nil	Do not fix or create markers. Returns the list of defective MPPIds.
nil	t	Do not fix, but create markers.

Relative Object Design Functions

#### rodCreateHandle

```
rodCreateHandle(
    [?name S_name ]
    [?type S_type ]
    [?value g_value ]
    [?rodObj R_rodObj ]
    );end rodCreateHandle
=> t / nil
```

#### **Description**

Creates a user-defined handle for any ROD object (named shape, instance, or cellview); the object must be at level zero in the hierarchy. For example, you can create a handle for polyRect or for instance I1, but not for I1/polyRect.

To create a handle for a cellview, you must first get the ROD object ID for the cellview with the rodGetObj function.

After you create a handle, you can access it through hierarchy using the rodGetHandle function and the database access operator (~>). The rodGetHandle function automatically transforms (converts) the coordinates of the ROD object into the coordinate system of the topmost cellview.

#### **Arguments**

```
?name S_name
```

Symbol or character string specifying a unique name for the new handle. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

Do not use existing user- or system-defined handle names. For example, you can assign the name myPoint, but not centerCenter. If you do not assign a name, then the system assigns a name unique within the cellview, as follows: handle0, handle1, handle2, etc.

Valid Values: any symbol or character string except existing user- or system-defined handle names

Default: unique name assigned by the system

?type S\_type

Relative Object Design Functions

Symbol or character string specifying the type of data stored at the handle. The type can be Boolean, floating point, integer, point, string, or a Cadence SKILL language expression. This argument is required.

Valid Values: boolean, float, int, point, string,

ILExpr

Default: none

?value *g\_value* 

Value assigned to the handle. The value must evaluate to match the data type defined by  $S\_type$ . When  $S\_type$  is Boolean, the value must be t or nil. When  $S\_type$  is string, the value must be either a character string or a symbol. This argument is required.

Valid Values: a value that matches the data type specified by  $S_{type}$ ; when  $S_{type}$  is Boolean, t or nil.

Default: none

?rodObj R\_rodObj

ROD object ID associated with the object for which you want to create a user-defined handle. This argument is required.

Default: none

#### Value Returned

t Handle created successfully.

nil An error occurred and no handle was created.

#### **Example**

rodCreateHandle( ?name "myHandle1" ?type "point" ?value list(x y) ?rodObj rodId)

Relative Object Design Functions

#### rodCreatePath

```
rodCreatePath(
     [ ?name S name]
     [ ?layer txl_layer ]
     [ ?width n width ]
     [ ?pts 1 pts ]
     [ ?justification S_justification ]
     [ ?offset n_offset ]
     [ ?endType S_endType ]
     [ ?beginExt n_beginExt ]
     [ ?endExt n_endExt ]
     [ ?choppable g choppable ]
     [ ?cvId d_cvId ]
     [ ?fromObj R1_fromObj ]
     [ ?size txf_size ]
     [ ?startHandle | startHandle |
     [ ?endHandle 1 endHandle ]
     [ ?prop 1_prop ]
     [rodConnectivityArgs...]
          ; start ROD Connectivity Arguments (rodConnectivityArgs)
          [ ?netName S netName ]
          [ ?termName S termName ]
          [ ?termIOType S_termIOType ]
          [ ?pin g_pin ]
          [ ?pinAccessDir tl_pinAccessDir ]
          [ ?pinLabel g pinLabel ]
          [ ?pinLabelHeight n_pinLabelHeight ]
          [ ?pinLabelLayer txl_pinLabelLayer ]
          [ ?pinLabelFont S_pinLabelFont ]
          [ ?pinLabelDrafting g_pinLabelDrafting ]
          [ ?pinLabelOrient S_pinLabelOrient ]
          [ ?pinLabelOffsetPoint l_pinLabelOffsetPoint ]
          [ ?pinLabelJust S pinLabelJust ]
          [ ?pinLabelRefHandle S_pinLabelRefHandle ]
          ;end ROD Connectivity Arguments
     [ ?offsetSubPath
                                 1 offsetSubpathArgs... ]
     ; start Offset Subpath Arguments (I offset Subpath Args)
     list(
          list(
               [ ?layer tx1_layer ]
               [ ?width n_width ]
               [ ?choppable g_choppable ]
               [?sep n sep]
               [ ?justification S_justification ]
               [ ?beginOffset n_beginOffset ]
               [ ?endOffset n_endOffset ]
               [ ?prop 1 prop ]
               ; repeat ROD Connectivity Arguments here
```

Relative Object Design Functions

```
); end first offset subpath list
     ); end offset subpath lists
;end Offset Subpath Arguments
[ ?encSubPath
                     1 encSubpathArgs...
; start Enclosure Subpath Arguments (I encSubpathArgs)
list(
     list(
          [ ?layer tx1_layer ]
          [ ?enclosure n_enclosure ]
          [ ?choppable g_choppable ]
          [ ?beginOffset n beginOffset ]
          [ ?endOffset n_endOffset ]
          [ ?prop 1_prop ]
          ;repeat ROD Connectivity Arguments here
     ); end first enclosure subpath list
     ;end of enclosure subpath lists
;end Enclosure Subpath Arguments
[ ?subRect l_subrectArgs... ]
; start Subrectangle Arguments (I subrectArgs)
list(
     list(
          [ ?layer txl_layer ]
          [ ?width n_width ]
          [ ?length n length ]
          [ ?choppable g_choppable ]
          [ ?sep n_sep ]
          [ ?justification S_justification ]
          [ ?space n_space ]
          [ ?beginOffset n_beginOffset ]
          [ ?endOffset n_endOffset ]
          [ ?beginSegOffset n beginSegOffset ]
          [ ?endSegOffset n_endSegOffset ]
          [ ?prop 1_prop ]
          [ ?gap S_gap ]
          ; repeat ROD Connectivity Arguments here
          [ ?diagonal g_diagonalSubRect ]
     ); end first subrectangle list
     ;end subrectangle lists
  ); end Subrectangle Arguments
); end rodCreatePath
=> R_rodObj / nil
```

Relative Object Design Functions

#### **Description**

Creates a path consisting of one or more parts at level zero in the hierarchy on the same or on different layers from a list of points or from one or more existing objects. A path consisting of multiple parts is called a *multipart path*. You can use the rodCreatePath function to create one-part paths, simple multipart paths, or complex multipart paths such as guard rings, transistors, buses, and shielded paths. You can assign one or more property names and values to a multipart path.

**Note:** rodCreatePath is a core database SKILL function that checks only for even multiples of database units to create a path. As a result, the created path can be off grid. To create a path with required constraints and additional level of automation use an endapplication SKILL function, such as <a href="lectroatePath"><u>leCreatePath</u></a>.

A multipart path consists of a single *master path* and one or more *subparts*. The master path is an ordinary path; however, it is the defining part of a multipart path; all subparts are based on the master path. You can assign a property name and value, or a list of property names and values, to the master path and/or to each subpart. The subparts can be any or all of the following: offset subpaths, enclosure subpaths, and sets of subrectangles.

You can create any number of subparts. All subparts exist in relation to and depend on the master path. A subrectangle in a set of subrectangles is not an individual shape; it is part of that specific set of subrectangles. In the Virtuoso layout editor, you cannot select or edit an individual subrectangle. Subrectangles are created on grid.

**Note:** Although you cannot select an individual subrectangle, it is possible to obtain the database ID for an individual subrectangle. If you use the database ID to change connectivity information (such as terminal name) for one or more individual subrectangles, your change is applied to the individual subrectangles immediately, and propagated to all of the subrectangles in the set of subrectangles when the MPP is modified in any way (such as moved).

For a detailed overview of multipart paths, see "Multipart Paths".

You can also create MPPs and save them as templates in your technology file by using the graphical user interface or by editing the ASCII version of your technology file. For information about using the graphical user interface, see "Creating and Editing Multipart Paths" in the Virtuoso Layout Suite L User Guide. For information about editing your technology file, see "multiPartPathtcCreatreTemplates" in the Technology File and Display Resource File ASCII Syntax Reference Manual.

The following topics are discussed in this section, following the argument descriptions:

- Creating Self-Intersecting Paths
- Specifying Arguments as nil

Relative Object Design Functions

- Formatting List-of-Lists Arguments for Subparts
- How the System Follows to Create Subrectangles
- Disconnecting Shapes in a Multipart Path

#### **Arguments**

## **Master Path Arguments**

?name S\_name

Symbol or character string specifying the name for the master path. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The name must be unique for the cellview. If you do not specify a name, the system assigns a unique name, consisting of the prefix path, followed by a number. For example, for the first master path in a cellview for which you do not specify a name, the system assigns the name path0, if unique; for the second, path1, and so on.

Default: pathn

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the master path, such as

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. For lists, use the following format:

```
list( layer purpose )
```

## Examples of layer-purpose pairs:

```
?layer list("metal1" "drawing")
?layer list(45 252)
?layer list(45 "drawing")
?layer list("metal1" 252)
```

You are required to specify a layer.

Default Purpose: drawing

Relative Object Design Functions

?width n\_width

Positive integer or floating-point number specifying the width of the master path. If you do not specify the width, the system uses the minWidth rule for the master path layer from the technology file. If the minWidth rule is not defined in the technology file, the rodCreatePath function reports an error.

Default: the minWidth rule for the master path layer from the technology file

?pts l\_pts

List of points defining the centerline of the master path. Specify a point for the start and end of the first segment, and specify a point for the end of subsequent segments. You must specify at least two noncoincident points. You cannot create self-intersecting master paths. You are required to specify a list of points. The system discards duplicate and collinear points before creating the path but does not consider them an error.

Use one of the following formats:

```
list( x:y x:y \dots )
or
list( list(x y) list(x y) ... )
```

You must specify either  $1\_pts$  or  $R1\_fromObj$ . If you specify both, the system ignores the  $1\_pts$  argument. Default: none

?justification S\_justification

Symbol or character string specifying the part of the master path to offset from the point list: centerline, left edge, or right edge. Justification is relative to the direction of the path.

Valid Values: center, left, right

Default: center

?offset n\_offset

Signed integer or floating-point number specifying the distance by which the master path edge or centerline, depending on  $S\_justification$ , is offset from the point list specified by the  $1\_pts$  argument. A positive value creates the master path to the left of the point list; a negative value creates the master path to the right of the point list. For a detailed description about offsetting the master path, see "Master Paths" in the Virtuoso Relative Object Design User Guide.

Default: 0

?endType S\_endType

Relative Object Design Functions

Symbol or character string specifying the type of ends of the master path.

Valid Values: flush, offset, octagon, variable

Default: flush

?beginExt n\_beginExt

Zero or positive integer or floating-point number specifying the distance by which the starting end of the master path extends beyond its first point. This argument is ignored unless

 $S\_endType$  is set to variable.

Default: 0

?endExt n\_endExt

Zero or positive integer or floating-point number specifying the distance by which the ending end of the master path extends beyond its last point. This argument is ignored unless  $S\_endType$  is set to variable.

Default: 0

?choppable *g\_choppable* 

Boolean value indicating whether or not a ROD path can be chopped. The value must be t or nil. When a path has subparts and the master path is choppable, all subpaths and sets of subrectangles must be choppable also. When a path has subparts and the master path is not choppable, each subpath and/or set of subrectangles can be choppable or not. Default: t

?cdId d cvId

Database ID for the cellview in which you are creating a ROD path. If rodCreatePath occurs in the body of a pcDefinePCell function or tcCreateCDSDeviceClass function call, the default value is pcCellView or tcCellView, respectively; otherwise, this argument is required.

Default: none

?fromObj R1 fromObj

ROD object ID or list of ROD object IDs identifying a named object or list of named objects that you want to use as a source for creating a new ROD path. The source objects can be instances, rectangles, polygons, paths, lines, dots, labels, and/ or text-display objects. You must specify either the  $R1\_fromObj$  argument or the  $1\_pts$  argument. If you specify both, the system ignores the  $1\_pts$  argument. Default: none

June 2023 © 2023 Cadence Design Systems, Inc.

Relative Object Design Functions

?size txf\_size

A signed integer, floating-point number, or Cadence SKILL language expression specifying the distance between a bounding box around the source object  $(R1\_fromObj)$  and the centerline of the generated master path. When the source is more than one object,  $txf\_size$  specifies the distance between a bounding box around all of the objects and the centerline of the master path.

By default, the generated path has four segments and forms a ring. A positive number creates a path that is longer than the circumference of the bounding box; a negative number creates a path that is shorter than the circumference of the bounding box.

When you specify a SKILL expression, it must evaluate to a positive or negative integer or floating-point number. SKILL expressions are evaluated only when the new path is created.

If you specify a source object ( $R1\_fromObj$ ) but do not specify  $txf\_size$ , then  $txf\_size$  defaults to 0.0. If you specify  $txf\_size$ , you must also specify  $R1\_fromObj$ , or the system reports an error.

Default: 0.0

?startHandle S\_startHandle

Symbol or character string specifying the starting point for the generated path, such as startn, where n is the <u>segment number</u>.

Valid Values: startn, midn, endn, startLast, midLast,

endLast

Default: start0

?endHandle S endHandle

Symbol or character string specifying the ending point for the generated path, such as startn, where n is the <u>segment</u> number

Valid Values: startn, midn, endn, startLast, midLast,

endLast

Default: start0

Relative Object Design Functions

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the  $\underline{\mathsf{Add}}$  Property Form. For Boolean properties, the value must be  $\mathtt{t}$  or  $\mathtt{nil}$ . For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

rodConnectivityArgs...

A list containing rod connectivity arguments. For more details on these arguments, see <u>ROD Connectivity Arguments</u> (<u>rodConnectivityArgs</u>).

l\_offsetSubpathArgs...

A list containing one or more lists, each of which specifies the arguments for one offset subpath. The subpath is created in relationship to the master path. For information about how to specify lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

For more information on  $1\_encSubPathArgs$  arguments, see Enclosure Subpath Arguments (I\_encSubpathArgs).

1\_encSubPathArgs...

A list containing one or more lists, each of which specifies the arguments for one enclosure subpath. The enclosure subpath is created in relationship to the centerline of the master path. For information about how to specify lists of lists, see Formatting List-of-Lists Arguments for Subparts.

Relative Object Design Functions

For more information on *1\_offsetSubpathArgs*, see Enclosure Subpath Arguments (*l\_encSubpathArgs*).

*l\_subRectArgs...* 

A list containing one or more lists, each of which specifies the arguments for one set of unnamed subrectangles. The set of subrectangles is created in relationship to the centerline of the master path. For information about how to specify lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

For more information on  $1\_subRectArgs$ , see <u>Subrectangle Arguments (I\_subrectArgs)</u>.

## ROD Connectivity Arguments (rodConnectivityArgs)

?netname S\_netName

Symbol or character string specifying the name of the net with which you want to associate the shape. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark (').

ROD converts symbols to character strings. If the net does not exist, the system creates it, using the name specified by  $S\_netName$ . To associate the shape with a net, this argument is required. If you do not want to specify this argument, omit it or specify its value as nil.

Default: nil

?termName S\_termName

Symbol or character string specifying the name of the terminal and net with which you want to associate the shape. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark (').

ROD converts symbols to character strings. If the terminal and/ or net does not exist, the system creates it, using the name specified by  $S_termName$ .

Relative Object Design Functions

If you specify both  $S\_termName$  and  $S\_netName$ , their values must be the same. If a terminal with the specified name already exists, the net it belongs to must have the same name. If the net name does not match the terminal name, the function reports an error.

To associate the shape with a terminal and net, this argument is required. If you do not want to specify this argument, omit it or specify its value as nil.

Default: nil

?termIOType S\_termIOType

Symbol or character string specifying the direction type (I/O type) for the terminal. If  $S\_termName$  is not specified, the  $S\_termIOType$  argument is ignored. If a terminal with the name specified by  $S\_termName$  already exists, it must have the same direction type as specified by  $S\_termIOType$ ; if the direction type is not the same, the function reports an error. Valid Values: input, output, inputOutput, switch,

jumper

Default: inputOutput

Symbol or character string specifying the direction type (I/O type) for the terminal. If  $S\_termName$  is not specified, the  $S\_termIOType$  argument is ignored. If a terminal with the name specified by  $S\_termName$  already exists, it must have the same direction type as specified by  $S\_termIOType$ ; if the direction type is not the same, the function reports an error.

Valid Values: input, output, inputOutput, switch,

jumper

Default: inputOutput

?pin *g\_pin* 

Boolean value indicating whether or not to make the shape into a pin. The value must be t or nil. When you specify  $g\_pin$ , you must also specify a value other than nil for  $S\_netName$  and/or  $S\_termName$ ; if you do not, all connectivity arguments are ignored but no error is reported. If you do not want to specify this argument, omit it or specify its value as nil. When the value is nil, the shape created is not a pin and all other arguments containing the word pin are ignored.

Valid Values: t, nil

Default: nil

?pinAccessDir t1\_pinAccessDir

Relative Object Design Functions

Text string or list specifying the access direction(s) for the pin. Enclose string values in quotation marks. Do not use a symbol. An example of a list is

list( "top" "bottom" )

Valid Values: top, bottom, left, right, any, none, or a list containing any of these values

Default: any

?pinLabel  $g_pinLabel$ 

Boolean value indicating whether or not to add a text display object for the pin, where the text is the contents of the  $S\_termName$  argument. The value must be t or nil. When the value is t, the system creates a text display object as a ROD object and aligns it to the pin using the values you specify for the other pin label arguments. When the value is nil, no label is created and all other arguments containing the characters pinLabel are ignored.

Valid Values: t, nil

Default: nil

 $?pinLabelHeight n\_pinLabelHeight$ 

Positive integer or floating-point number specifying the vertical height of the pin text-display label in user units.

Default: 1

?pinLabelLayer txl\_pinLabelLayer

Text string, integer, or list specifying the layer or layer-purpose pair for the pin text-display label, such as

```
?pinLabelLayer "metal1"
?pinLabelLayer 45
?pinLabelLayer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. For lists, use the following format:

list(layer purpose)

Relative Object Design Functions

# Examples of layer-purpose pairs:

```
?pinLabelLayer list("metal1" "drawing")
?pinLabelLayer list(45 252)
?pinLabelLayer list(45 "drawing")
?pinLabelLayer list("metal1" 252)
```

When you specify only the layer, the purpose defaults to the purpose defined by  $1\_1ayer$ . When you specify neither layer nor purpose, both layer and purpose default to the values defined by  $1\_1ayer$ .

Default: layer specified by  $1\_layer$ ; purpose specified by  $1\_layer$ 

?pinLabelFont S\_pinLabelFont

Symbol or character string specifying the name of the font for the pin text-display label.

Valid Values: euroStyle, gothic, math, roman, script, stick, swedish

Default: stick

?pinLabelDrafting g\_pinLabelDrafting

Boolean value indicating wgetter configuration worth votation of the pin text-display label by more than 90 degrees. The value must be t or nil. You can set or change label rotation with the  $S\_pinLabelOrient$  argument or in the layout editor. When the value is t, the label can rotate less than or equal to 90 degrees. When the value is nil, the label can rotate more than 90 degrees.

Valid Values: t, nil

Default: t

?pinLabelpinLabelOrient S\_pinLabelOrient

Symbol or character string specifying the orientation of the pin text-display label.

Diagonal Configuration

Relative Object Design Functions

0	R0
90	R90
180	R180

270 R270

MY sideways

MYR90 sideways & 90

MX upsideDown


MXR90.... sideways & 270

Default: R0

Valid Values:

?pinLabelOffsetPoint l\_pinLabelOffsetPoint

Lists one set of coordinates specifying the X and Y offset of the origin of the pin text-display label from a point handle on the shape. The label origin is specified by  $S_pinLabelJust$ , and the shape point handle is specified by  $S_pinLabelRefHandle$ .



Relative Object Design Functions

Use one of the following formats:

x:y or list(x y)

or any expression that evaluates to a list of two numbers.

Default: 0:0

?pinLabelJust

Symbol or character string specifying the origin point for the text-display label.

#### Valid Values:

upperLeft	or	uL	lowerLeft	or	1L
upperCenter	or	uC	lowerCenter	or	1C
upperRight	or	uR	lowerRight	or	1R
centerLeft	or	cL			
centerCenter	or	сC			
centerRight	or	cR			
Default: centerCenter					

?pinLabelRefHandle S\_pinLabelRefHandle

Symbol or character string specifying the point handle on the shape from which you want to offset the origin point of the text-display label. You can specify the name of any bounding box or segment point handle.

For a detailed description of system-defined point handles, see <u>"System-Defined Handles"</u> in *Virtuoso Relative Object Design User Guide*.

#### Valid Values for bounding box point handles:

upperLeft	or	uL	lowerLeft	or	1L
upperCenter	or	uC	lowerCenter	or	1C
upperRight	or	uR	lowerRight	or	1R
centerLeft	or	$\mathtt{cL}$			
centerCenter	or	сC			
centerRight	or	cR			

#### Valid Values for segment point handles for all ROD shapes:

start0	mid0	end0
startLast	midLast	endLast
start <i>n</i>	mid <i>n</i>	end <i>n</i>

Relative Object Design Functions

mid0	end0
midLast	endLast
$\mathtt{mid} n$	end <i>n</i>
midLeft0	endLeft0
midLeftLast	endLeftLast
${\tt midLeft} n$	endLeft <i>n</i>
midRight0	endRight0
midRightLast	endRightLast
midRight <i>n</i>	${\tt endRight} n$
	midLast midn midLeft0 midLeftLast midLeftn midRight0 midRightLast

Default: the bounding box point handle centerCenter

# Offset Subpath Arguments (I\_offsetSubpathArgs)

For a detailed description of offset subpaths, see <u>"Offset Subpaths"</u> in *Virtuoso Relative Object Design User Guide*.

```
?layer txl_layer
```

Text string, integer, or list specifying the layer or layer-purpose pair for the subpath, such as:

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. Use the one of the formats defined for the master path argument <u>tx1 layer</u>. You are required to specify a layer.

Default Purpose: drawing

?width n\_width

Positive integer or floating-point number specifying the width of the offset subpath.

If you do not specify the width, the system uses the minWidth rule for the offset subpath layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreatePath reports an error.

Default: minWidth for the offset subpath layer from the technology file

Relative Object Design Functions

?sep n\_sep

Signed integer or floating-point number specifying the separation between the centerline or an edge of the subpath and the centerline or an edge of the master path, depending on the value of  $S_{justification}$ .

Default: 0

?justification S\_justification

Symbol or character string specifying from which part of the master path to separate the subpath, in relation to the direction of the master path. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

When left, the right edge of the subpath is separated from the left edge of the master path. When right, the left edge of the subpath is separated from the right edge of the master path. When center, the centerline of the subpath is separated from the centerline of the master path.

Valid Values: center, left, right

Default: center

?beginOffset n\_beginOffset

Signed integer or floating-point number specifying the starting edge of the subpath in relation to the starting edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path. Default:  $n\_endOffset$  if specified; otherwise 0

?endOffset n\_endOffset

Signed integer or floating-point number specifying the ending edge of the subpath in relation to the ending edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default: n\_beginOffset if specified; otherwise 0

Relative Object Design Functions

?choppable g\_choppable

Boolean value indicating whether or not the subpath can be chopped. The value must be t or nil. When the master path is choppable, all subpaths must be choppable. When the master path is not choppable, each subpath can be choppable or not.

Default: t

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <u>Add Property Form</u>. For Boolean properties, the value must be t or nil. For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

Relative Object Design Functions

## Enclosure Subpath Arguments (I\_encSubpathArgs)

For a detailed description of enclosure subpaths, see "Enclosure Subpaths".

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the subpath, such as

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. Use the one of the formats defined for the master path argument <u>txl\_layer</u>. You are required to specify a layer. Default Purpose: drawing

?enclosure n\_enclosure

Signed integer or floating-point number specifying the enclosure of the subpath in relation to the master path. The system computes the width of an enclosure subpath as follows:

```
width = (n_width of master path) - (2 * n_enclosure)
```

If you do not specify this argument, the system uses the minEnclosure rule from the technology file for master path layer to subpath layer; if the minEnclosure rule is not defined in the technology file, rodCreatePath reports an error. Default: minEnclosure rule from the technology file for master path layer to subpath layer

?beginOffset n\_beginOffset

Signed integer or floating-point number specifying the starting edge of the subpath in relation to the starting edge of the master path. A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path. Default:  $n\_endOffset$  if specified; otherwise the negative of  $n\_enclosure$ 

?endOffset n\_endOffset

Signed integer or floating-point number specifying the ending edge of the subpath in relation to the ending edge of the master path.

Relative Object Design Functions

A positive number extends the end of the subpath beyond the end of the master path; a negative number retracts the end of the subpath from the end of the master path.

Default: n\_beginOffset if specified; otherwise the negative of n\_enclosure

?choppable g\_choppable

Boolean value indicating whether or not the subpath can be chopped. The value must be t or nil. When the master path is choppable, all subpaths must be choppable. When the master path is not choppable, each subpath can be choppable or not.

Default: t

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <a href="Add Property Form">Add Property Form</a>. For Boolean properties, the value must be t or nil. For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>. Default: nil

June 2023 © 2023 Cadence Design Systems, Inc.

Relative Object Design Functions

## Subrectangle Arguments (I\_subrectArgs)

For a detailed description of sets of subrectangles for rodCreatePath, see <u>"Sets of Subrectangles"</u>.

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the subrectangle(s), such as

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```


Enclose string values in quotation marks. Do not use a symbol. Use the one of the formats defined for the master path argument <u>tx1\_layer</u>. You are required to specify a layer. Default Purpose: drawing

?width n\_width

Positive integer or floating-point number specifying the width of the rectangle(s), where the width is parallel to the width of the master path.

If not specified, the system uses  $n\_length$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreatePath returns nil to indicate an error.


Default:  $n_length$  if specified; otherwise minWidth for the subrectangle layer from the technology file.



Relative Object Design Functions

?length n\_length

Positive integer or floating-point number specifying the length of the subrectangle(s), where the length is parallel to the master path centerline.



If not specified, the system uses  $n\_width$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreatePath returns nil to indicate an error.


Default:  $n\_width$  if specified; otherwise, minWidth for the subrectangle layer from the technology file

?gap *S\_gap* 

Symbol or character string specifying the method the system uses to place subrectangles within each segment. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The system always uses the value of  $n\_space$  for minimum space between subrectangles and calculates the maximum number of rectangles that fit in the segment, allowing for the space needed by  $n\_beginOffset$  and  $n\_endOffset$ . When the value of  $s\_gap$  is distribute, the system distributes the space around subrectangles as evenly as possible, in multiples of the grid space specified by mfgGridResolution. Any remaining space is left after the last subrectangle in the segment.


Relative Object Design Functions



When the value of  $S_{gap}$  is distribute and there is only one subrectangle, the value of the distributeSingleSubRect environment variable determines where the single subrectangle is placed. When nil, which is the default, the subrectangle is offset as

nil, which is the default, the subrectangle is offset as specified by  $n\_beginOffset$  and  $n\_endOffset$ . When t, the subrectangle is centered (but placed on grid), and  $n\_beginOffset$  and  $n\_endOffset$  are ignored.

When the value of  $S\_gap$  is minimum, the system places subrectangles  $n\_space$  apart until there is no space for another rectangle, then leaves the excess space after the last subrectangle in the segment.



Relative Object Design Functions

Valid Values: distribute, minimum

Default: distribute

?sep n\_sep

Signed integer or floating-point number specifying the separation between the centerline or an edge of the subrectangles and the centerline or an edge of the master path, depending on the value of  $S_{justification}$ . The system places subrectangles on grid, as close to the specified separation as possible.

Default: 0

?justification S\_justification

Symbol or character string specifying from which part of the master path to separate the subrectangles, in relation to the direction of the master path. When left, the right edge of the subrectangles is separated from the left edge of the master path. When right, the left edge of the subrectangles is separated from the right edge of the master path. When center, the centerline of the subrectangles is separated from the centerline of the master path.

Valid Values: center, left, right

Default: center

?beginOffset n\_beginOffset

Signed integer or floating-point number specifying the offset of the edge of the first subrectangle from the starting edge of the master path. A positive number extends the beginning of the subrectangles beyond the beginning of the master path; a negative number retracts the beginning of the subrectangles from the beginning of the master path.

Default: n endOffset if specified; otherwise 0

?endOffset n\_endOffset


Signed integer or floating-point number specifying the offset of the edge of the last subrectangle from the ending edge of the master path. A positive number extends the end of the subrectangles beyond the end of the master path; a negative number retracts the end of the subrectangles from the end of the master path.


Default: n\_beginOffset if specified; otherwise 0

Relative Object Design Functions

?beginSegOffset n\_beginSegOffset

Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the first subrectangle in a segment measured from the edge of the master path. Does not apply to the first segment; the position of the first subrectangle in the first segment is determined by the value of the  $n\_beginOffset$  argument.






Relative Object Design Functions

If the segment begins before the full distance specified by  $n\_beginSegOffset$ , then  $n\_beginSegOffset$  is not applied, and a subrectangle could be placed at the corner of the subrectangle path. When applying offset specifications, the system will not create a spacing error; if the first subrectangle in a segment would be too close to the last subrectangle in the previous segment, the system discards the last subrectangle in the previous segment. This could result in more space at the corner than desired. Default: 0.0

?endSegOffset n endSegOffset

Positive, signed integer or floating-point number that, together with the other offset arguments, lets you control whether there is a subrectangle in the corner of a segment. Specifies the offset of the last subrectangle in a segment from the edge of the master path. Does not apply to the last segment; the position of the last subrectangle in the last segment is determined by the value of the  $n\_endOffset$  argument.



If the segment ends before the full distance specified by  $n\_endSegOffset$ , then  $n\_endSegOffset$  is not applied, and a subrectangle could be placed at the corner of the subrectangle path.

Default: 0.0

Relative Object Design Functions

?space n\_space

Positive integer or floating-point number specifying the distance between the edges of adjoining rectangles. If not specified, the system uses the minSpacing rule for the subrectangle layer from the technology file. If the minSpacing rule is not defined in the technology file, rodCreatePath returns nil to indicate an error.

Default: minSpacing for the subrectangle layer from the technology file

?choppable g\_choppable

Boolean value indicating whether or not the subrectangle(s) can be chopped. The value must be t or nil. When the master path is choppable, all subrectangles must be choppable. When the master path is not choppable, each set of subrectangles can be choppable or not. Default: t

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <u>Add Property Form</u>. For Boolean properties, the value must be t or nil. For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>. Default: nil

?diagonal g\_diagonalSubRect

Optional keyword-value pair argument specifying whether to create subrectangles on diagonal portions of the path.

Relative Object Design Functions

When defined, this argument must appear at the end of the subrectangle argument list, after any list specifying connectivity, immediately prior to the closing parentheses. Setting this argument to t works only when diagonal path segments are 45 degrees and all subrectangles on the path are square. When specified, you must type the keyword, followed by t or nil. For example, type: <code>?diagonal t Default: nil</code>

#### Value Returned

R\_rodObj The ROD object ID for the single layer or multipart ROD path

that was created.

nil No path was created due to an error.

#### **Additional Information**

# Creating Self-Intersecting Paths

You cannot create self-intersecting paths using rodCreatePath. If you specify the function arguments so that the master path and/or one or more subpaths would self-intersect, the system will not create the path.

For example, if you create a guard ring with abutted ends, and the ends of a subpath have a positive offset, the subpath will extend beyond the master path, which could cause intersection.

If your code tries to create a self-intersecting path, the path is not created, and the system displays a warning in the CIW.

# Specifying Arguments as nil

For the rodCreatePath function, a value of nil means the following, depending on the type of argument:

■ For Boolean arguments, nil is a valid value, and the system uses it. The rodCreatePath Boolean arguments are:

g\_choppable g\_pin

Relative Object Design Functions

- For non-Boolean arguments, specifying nil causes the system to use the default as it is defined in this document for that argument. Specifying nil is equivalent to not specifying a value for the argument.
- For the following Connectivity arguments, the default value is nil:

```
S_netName S_termName g_pin
```

When you specify any of the arguments listed above as nil, it is equivalent to not specifying a value for the argument.

# Specifying Pins

When you specify the  $g\_pin$  argument, you must also specify the  $S\_netName$  and/or  $S\_termName$  argument with a value other than nil. If you specify  $g\_pin$  but do not specify  $S\_netName$  and/or  $S\_termName$  with a value other than nil, the system ignores all connectivity arguments but does not report an error.

### Formatting List-of-Lists Arguments for Subparts

You must use a **list of lists** to specify arguments for an offset subpath, enclosure subpath, or set of subrectangles. The top-level list contains one or more sublists. Each sublist defines a unique subpath or set of subrectangles.

Each sublist consists of one or more keyword-value pairs, where the keyword identifies the argument. To specify the value as a character string, enclose it in quotation marks (""); to specify the value as a symbol, precede it with a single quotation mark (').

For any keyword that returns either a string or symbol, you can specify a Cadence SKILL language expression (constant, variable, or function call) as the value.

As an example, the syntax format for specifying an enclosure subpath as part of a rodCreatePath function is shown on the following page.

Relative Object Design Functions

```
) ;End of encSubPath list
```

An example showing values for an enclosure subpath within a rodCreatePath function specification might look like this:

```
poly1EndOffset = -0.4
tfId = = techGetTechFile(pcCellView)
?encSubPath list(
                    list( ?layer
                                          "metal2"
                           ?enclosure
                                 techGetParam( tfId "m1m2enc" )
                           ?beginOffset -.4
                                         nil
                           ?choppable
                         ); end of 1st enclosure subpath
                     list( ?layer
                                          "poly1"
                                          . 1
                           ?enclosure
                           ?beginOffset
                                         Ω
                           ?endOffset
                                       poly1EndOffset
                           ?choppable
                                         nil
                           ; end 2nd enclosure subpath
                ); end of 2nd enclosure subpath
```


where poly1EndOffset is a variable and techGetParam( tfId "m1m2enc" ) is a function call.


# How the System Follows to Create Subrectangles

The system follows these steps to create subrectangles:

**1.** Creates all subrectangles on the specified layer, with the subrectangle centerline separated from the master path centerline by  $n\_sep$ .


When  $n\_sep$  is zero, the master path centerline bisects the width of the subrectangles. When  $n\_sep$  is less than or greater than zero, the subrectangles are offset from the master path centerline.






Relative Object Design Functions

**2.** For the first path segment, offsets the edge of the first subrectangle from the starting edge of the master path by the distance specified in  $n\_beginOffset$ .




- **3.** Uses the value of  $n\_space$  to compute the maximum number of subrectangles that fit on grid in the segment, and the value of  $s\_gap$  to determine what to do with excess space, as follows:
  - When  $S_{gap}$  equals distribute (the default), distributes the space as evenly as possible, in multiples of the grid space specified by mfgGridResolution.




Relative Object Design Functions

When  $S_{gap}$  equals minimum, places subrectangles  $n_{space}$  apart until there is no space for another rectangle, then leaves the excess space after the last subrectangle in the segment.




- 4. For each subsequent path segment, the system
  - Positions the first subrectangle on the vertex of the subrectangle centerline with half its width towards the beginning of the segment.



□ Repeats step 3.


Relative Object Design Functions

**5.** For the last path segment, the system offsets the edge of the last subrectangle from the ending edge of the master path by the distance specified in  $n\_endOffset$ . For the remaining subrectangles in the last segment, the system repeats step 3.



### Subrectangles in the Corners of Segments

By default, the system creates a subrectangle in the corner formed by each segment of a subrectangle subpath, and then fills in the rest of the segment with subrectangles, following the spacing you specify with the rodCreatePath function.




There are several reasons that you might want to keep subrectangles out of the corners of your subrectangle subpaths. For example, when you specify multiple subrectangle subpaths, placing rectangles in the corners of segments might cause individual subrectangles to be out of alignment vertically or horizontally with the subrectangles in the other subrectangle subpaths.

If you do not want subrectangles in the corners of segments, you can keep them out by specifying the  $n\_beginSegOffset$  and  $n\_endSegOffset$  arguments. The system

Relative Object Design Functions

measures the  $n\_beginSegOffset$  and  $n\_endSegOffset$  values from the edge of the master path, as shown below.



When specifying the segment offset arguments, keep in mind:

- The n\_beginSegOffset value does not apply to the first segment; the position of the first subrectangle in the first segment is determined by the value of the n\_beginOffset argument.
- The  $n\_endSegOffset$  value does not apply to the last segment; the position of the last subrectangle in the last segment is determined by the value of the  $n\_endOffset$  argument.
- The segment offset arguments work in combination with the  $n\_beginOffset$  and  $n\_endOffset$  arguments.
- If the segment begins before the full distance specified by the  $n\_beginSegOffset$  argument, then  $n\_beginSegOffset$  is not applied, and a subrectangle could be placed at the corner of the subrectangle subpath.
- If the segment ends before the full distance specified by the  $n\_endOffset$  argument, then  $n\_endOffset$  is not applied, and a subrectangle could be placed at the corner of the subrectangle subpath.
- When applying the offset options, the system will not create a spacing error. If the first subrectangle in a subrectangle subpath segment would be too close to the last subrectangle in the previous segment, the system discards the last subrectangle in the previous segment.

When you specify the offset options, you need to check the results to make sure the corners are as desired. If they are not, you should change the values of the offset arguments and try again.

Relative Object Design Functions

# Disconnecting Shapes in a Multipart Path

You can change a multipart path into separate, unrelated shapes by removing the name of the multipart path. Once you do this, all relationships between the shapes are removed.

➤ To change all of the shapes in a multipart path into separate, unrelated shapes, remove the name of the multipart path using the rodUnNameShape function.

Now the master path is a separate, unnamed path; each subpath is a separate, unnamed path; and each rectangle is a separate, unnamed shape. None of them is a ROD object, and there is no relationship between them.

### Making a Former MPP Part into a ROD Object

You can make any shape that was formerly part of a multipart path (the master path, any subpath, or any individual subrectangle) into a ROD object by assigning it a unique name.

➤ To make a shape into a ROD object, assign a unique name to the shape using the rodNameShape function.

Each shape to which you assign a name is now a separate, unique ROD object.

Relative Object Design Functions

# rodCreatePolygon


```
rodCreatePolygon(
     [ ?name S_name ]
     [ ?layer tx1_layer ]
     [ ?pts 1 pts ]
     [ ?cvId d cvId ]
     [ ?fromObj R1_fromObj ]
     [ ?size txf_size ]
     [ ?prop 1_prop ]
     ; ROD Connectivity Arguments for Polygons
     [ ?netName S netName ]
     [ ?termName S termName ]
     [ ?termIOType S_termIOType ]
     [ ?pin q pin ]
     [ ?pinAccessDir t1_pinAccessDir ]
     [ ?pinLabel g pinLabel ]
     [ ?pinLabelHeight n pinLabelHeight ]
     [ ?pinLabelLayer txl_pinLabelLayer ]
     [ ?pinLabelFont S_pinLabelFont ]
     [ ?pinLabelDrafting g_pinLabelDrafting ]
     [ ?pinLabelOrient S_pinLabelOrient ]
     [ ?pinLabelOffsetPoint l_pinLabelOffsetPoint ]
     [ ?pinLabelJust S pinLabelJust ]
     [ ?pinLabelRefHandle S_pinLabelRefHandle ]
     ); end rodCreatePolygon
    => R_rodObj / nil
```


#### **Description**

Creates one polygon from a list of points or from one or more named objects. Also creates a ROD object containing information associated with the polygon, including its name and database ID. The associated ROD object is identified by a ROD object ID. The polygon is created at level zero in the hierarchy. You can assign a property name and value, or a list of property names and values, to the polygon. You can specify connectivity for the polygon by associating it with a specific terminal and net. You can also make the polygon into a pin.

Relative Object Design Functions


When you specify two or more existing named objects as the source for creating a polygon, as shown in the example below,





the system creates a four-sided, rectangular polygon based on a bounding box around all of the object(s).

The new rectangular polygon is larger or smaller than the bounding box, depending on whether you specify a positive or negative size.



**Note:** In the current release, no relationship exists between a generated polygon and its source object(s) after the new polygon is created.

For a detailed overview of creating polygons from other objects, see <u>"Creating a Polygon from Another Object"</u>.

Relative Object Design Functions

## **Arguments**

?name S\_name

Symbol or character string specifying the name for the polygon. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The name must be unique for the cellview. When you do not specify a name, the system assigns a unique name, consisting of the prefix polygon, followed by a number. For example, for the first unnamed polygon in a cellview, the system assigns the name polygon0, if unique; for the second, polygon1, and so on.

Default: polygonn

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the polygon, such as

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. For lists, use the following format:

```
list( layer purpose )
```

# Examples of layer-purpose pairs:

```
?layer list("metal1" "drawing")
?layer list(45 252)
?layer list(45 "drawing")
?layer list("metal1" 252)
```

You are required to specify a layer.

Default Purpose: drawing

```
?pts 1_pts
```

List of points defining the edges of the polygon. Specify a point for the beginning and end of the first edge and the end of subsequent edges. The system creates a closed shape by connecting the first and last points in the list. You cannot create a polygon with self-intersecting edges.

Relative Object Design Functions

The system discards duplicate points and excess collinear points without considering them errors. However, you must specify at least three noncoincident, noncollinear points. Coincident points have the same coordinate values. Collinear points are on the same line. If you specify more than two points on the same line, the system uses only the first and last points specified. An example of excess collinear points is 0:10, 0:20, and 0:30, where the system discards 0:20.Use one of the following formats:

```
list( x:y x:y \dots )
or
list( list(x y) list(x y) ... )
```

You must specify either  $1\_pts$  or  $R1\_fromObj$ . If you specify both, the system ignores the  $1\_pts$  argument. Default: none

?cvId d\_cvId

Database ID for the cellview in which you are creating a ROD path. If rodCreatePath occurs in the body of a pcDefinePCell function or tcCreateCDSDeviceClass function call, the default value is pcCellView or tcCellView, respectively; otherwise, this argument is required.

Default: none

?fromObj R1\_fromObj

ROD object ID or list of ROD object IDs identifying a named object or list of named objects that you want to use as a source for creating a new ROD polygon. The source objects can be instances, rectangles, polygons, paths, lines, dots, labels, and/ or text-display objects. You must specify either the

 $R1\_fromObj$  argument or the  $1\_pts$  argument. If you specify both, the system ignores the  $1\_pts$  argument. Default: none

Relative Object Design Functions

?size txf\_size

A signed integer, floating-point number, or Cadence SKILL language expression specifying the difference between the size of the source object  $(R1\_fromObj)$  and the size of the generated polygon. When the source is more than one object,  $txf\_size$  specifies the difference between a bounding box around all of the objects and the size of the generated polygon.

A positive number creates a polygon that is larger than the source object(s); a negative number creates a polygon that is smaller than the source object(s). When you specify a SKILL expression, it must evaluate to a positive or negative integer or floating-point number. SKILL expressions are evaluated only when the new polygon is created.

If you specify a source object ( $R1\_fromObj$ ) but do not specify  $txf\_size$ , then  $txf\_size$  defaults to 0.0. If you specify  $txf\_size$ , you must also specify  $R1\_fromObj$ , or the system issues a warning message and the function fails. Default: 0.0

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the  $\underline{\text{Add Property Form}}$ . For Boolean properties, the value must be  $\underline{\text{t or nil}}$ . For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

Relative Object Design Functions

# **ROD Connectivity Arguments for Polygons**

The connectivity arguments for polygons are the same as the connectivity arguments for rectangles. See <u>ROD Connectivity Arguments for Rectangles (rodRectConnectivityArgs)</u>.

#### **Value Returned**

R\_rodObj The ROD object ID for the polygon that was created.

nil No polygon was created due to an error.

Relative Object Design Functions

### rodCreateRect

```
rodCreateRect(
     [ ?name S name ]
     [ ?layer txl_layer ]
     [ ?width n width ]
     [ ?length n length ]
     [ ?origin l_origin ]
     [ ?bBox 1_bBox ]
     [ ?elementsX x\_elementsX ]
     [ ?elementsY x_elementsY ]
     [ ?spaceX n_spaceX ]
     [ ?spaceY n spaceY ]
     [ ?cvId d_cvId ]
     [ ?fillBBox 1 fillBBox ]
     [ ?fromObj Rl_fromObj ]
     [ ?size txf size ]
     [ ?prop 1 prop ]
     [ ?returnBoolean g_returnBoolean ]
     [rodRectConnectivityArgs...]
          ; start ROD Connectivity Arguments for Rectangles (rodRectConnectivityArgs)
          [ ?netName S netName ]
          [ ?termName S termName ]
          [ ?termIOType S_termIOType ]
          [ ?pin g_pin ]
          [ ?pinAccessDir tl_pinAccessDir ]
          [ ?pinLabel g pinLabel ]
          [ ?pinLabelHeight n_pinLabelHeight ]
          [ ?pinLabelLayer txl_pinLabelLayer ]
          [ ?pinLabelFont S_pinLabelFont ]
          [ ?pinLabelDrafting g_pinLabelDrafting ]
          [ ?pinLabelOrient S_pinLabelOrient ]
          [ ?pinLabelOffsetPoint l_pinLabelOffsetPoint ]
          [ ?pinLabelJust S pinLabelJust ]
          [ ?pinLabelRefHandle S_pinLabelRefHandle ]
          ;end ROD Connectivity Arguments for Rectangles
     [ ?subRectArray
                         l subrectArgs... ]
     ; start 1 subrectArgs Subrectangle Arguments (I subrectArgs)
     list(
          list(
               [ ?layer txl_layer ]
               [ ?width n_width ]
               [ ?length n_length ]
               [ ?qap S qap ]
               [ ?lowerLeftOffsetX n_lowerLeftOffsetX ]
               [ ?lowerLeftOffsetY n lowerLeftOffsetY ]
               [ ?upperRightOffsetX n_upperRightOffsetX ]
               [ ?upperRightOffsetY n upperRightOffsetY ]
               [ ?spaceX n_spaceX ]
```

Relative Object Design Functions

```
[ ?spaceY n_spaceY ]
        [ ?prop l_prop ]
    ;Repeat ROD Connectivity Arguments here
    );end first subrectangle list
    ...
    ) ;end all subrectangle lists
;end l_subrectArgs
);end rodCreateRect
=> R rodObj | t / nil
```

### Description

Creates a single named rectangle, one or more rows and/or columns of named rectangles, or fills a bounding box with named rectangles, where each rectangle has ROD attributes. You can create these named rectangles with the arguments  $S_name$  through  $g_returnBoolean$ . Each named rectangle is a separate object, created at level zero in the hierarchy. You can also create multipart rectangles by specifying one or more arrays of unnamed *subrectangles* for each named rectangle, where each unnamed subrectangle is an ordinary database shape, with no ROD attributes, created at level zero in the hierarchy. The named rectangles in a multipart rectangle are referred to as *master rectangles*.

You can assign a property name and value (or a list of property names and values) to named rectangles and/or to any set of unnamed subrectangles. You can specify connectivity to associate named rectangles with the same terminal and net and to turn named rectangles into pins on a specified terminal and net. You can also specify connectivity for each set of unnamed subrectangles to associate it with a terminal and net and turn each subrectangle into a pin.

Although a set of unnamed subrectangles is treated as a single shape, you can get a list of the database IDs for the individual subrectangles in the set by using the ROD object ID for the multipart path with the database access operator (~>) and the attribute name subShapes. For more information, see <u>"Accessing ROD Object Attributes"</u>.

**Note:** When you want to create a single unnamed rectangle that is a regular database shape and has no ROD attributes, use the <u>dbCreateRect</u> function. When you want to create a one-or two-dimensional array of unnamed rectangles that have no ROD attributes, use the <u>rodFillBBoxWithRects</u> function. Regular database shapes require less overhead, resulting in faster performance.

Relative Object Design Functions

## **Arguments**


?name S\_name

Symbol or character string specifying the name for the rectangle you want to create. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The name must be unique for the cellview. If you do not assign a name, the system assigns a unique name, consisting of the prefix rect, followed by a number. For example, for the first unnamed rectangle in the cellview, the system assigns the name rect0; for the second rect1, and so on.


Single row or column of rectangles: When you create a single row or column of rectangles, the system uses your specified name (or rectn if you did not specify a name) as a base and adds the suffix .n, where n starts at 1 and is increased by 1 for each rectangle in the row or column.

For example, if you create a row of three rectangles (rectangles in the direction of the X axis) and assign the name polyRect, the system names the three rectangles polyRect.1, polyRect.2, and polyRect.3.




If you create a column of three rectangles (rectangles in the direction of the Y axis) and you do not assign a name, the system names the three rectangles rect0.1, rect0.2, and rect0.3.

Relative Object Design Functions



Multiple rows and columns of rectangles: When you create multiple rows and columns of rectangles, the system uses your specified name as a base and adds the suffix .x.y, where .x.y is the number of the row and column.

For example, if you specify three rows and four columns, the system names the rectangles as follows:



Default: rectn, rectn.n, rectn.x.y

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the rectangle(s), such as

```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. For lists, use the following format:

```
list( layer purpose )
```

Relative Object Design Functions

# Examples of layer-purpose pairs are


?layer list("metal1" "drawing")
?layer list(45 252)
?layer list(45 "drawing")
?layer list("metal1" 252)

You are required to specify a layer.

Default Purpose: drawing

?width n\_width

Positive integer or floating-point number specifying the horizontal measurement of the rectangle, in user units.




The value of  $l\_bBox$  overrides the value of  $n\_width$  when you specify both. If you specify neither  $n\_width$  nor  $l\_bBox$ , the system uses the value of  $n\_length$ .

If you do not specify  $n\_length$ , the system uses the value for minWidth, the minimum width rule for the specified layer, from your technology file. If you specify none of these and minWidth is not available, the function reports an error. Default:  $n\_length$  if specified; otherwise the minimum width rule for the specified layer from your technology file

?length n\_length

Positive integer or floating-point number specifying the vertical measurement of the rectangle, in user units.



Relative Object Design Functions

The value of  $1\_bBox$  overrides the value of  $n\_length$  when you specify both. If you specify neither  $n\_length$  nor  $1\_bBox$ , the system uses the value of  $n\_width$ . If you do not specify  $n\_width$ , the system uses the value for minWidth, the minimum width rule for the specified layer, from your technology file. If you specify none of these and minWidth is not available, the function reports an error. Default:  $n\_width$  if specified; otherwise the minimum width rule for the specified layer from your technology file

?origin  $l_origin$ 

Single point or list of coordinates specifying the lower left corner of the first rectangle; use one of the following formats:

```
x:y
or
list(x y)
```

The value of  $1\_bBox$  overrides the value of  $1\_origin$  when you specify both.

Default: 0:0


?bBox *l\_bBox* 

List of two points specifying opposite corners of a bounding box for the size of the rectangle. You can start the box in any corner. The system determines the location of the first rectangle by using the difference between the coordinates for the specified opposite corners. Use one of the following formats:

```
list( x:y x:y )
or
list( list(x y) list(x y))
```


Example 1 starts in the bounding box in the lower-left corner.

```
list(3:3 30:15)
or
list( list(3 3) list(30 15))
or
list( list(3 3) list(30 15))
```



Example 2 starts the bounding box in the upper-left corner.

```
list(3:15 30:3)
or
list( list(3 15) list(30 3))
```



When you specify a rectangle size with  $l\_bBox$ , the value of  $l\_bBox$  overrides the values of  $n\_width$ ,  $n\_length$ , and  $l\_origin$ .

Default: none

?elements $X \times elementsX$ 

Positive integer specifying the number of rectangles to create in a row parallel to the X axis. If you also specify  $1\_fillBox$ ,  $x\_elementsX$  specifies the maximum number of rectangles to create in the direction of the X axis. Default: 1


?elementsY  $x_elementsY$ 

Relative Object Design Functions

Positive integer specifying the number of rectangles to create in a column parallel to the Y axis. If you also specify  $1\_fillBBox$ ,  $x\_elementsY$  specifies the maximum number of rectangles to create in the direction of the Y axis. Default: 1

?spaceX n\_spaceX

Positive integer or floating-point number specifying the distance between the edges of rectangles in the direction of the X axis. This argument is ignored when a row contains only one rectangle.




If you do not specify  $n\_spaceX$ , the system uses the value of  $n\_spaceY$ . If you specify neither, the system uses the value for minSpacing, the minimum spacing rule for the specified layer, from your technology file. If you specified neither of these and minSpacing is not available, the function reports an error.

Default:  $n\_spaceY$  if specified; otherwise the minimum spacing rule for the specified layer from your technology file

?spaceY n spaceY

Positive integer or floating-point number specifying the distance between the edges of rectangles in the direction of the Y axis. This argument is ignored when a row contains only one rectangle.



If you do not specify  $n\_spaceY$ , the system uses the value of  $n\_spaceX$ . If you specify neither, the system uses the value of minSpacing, the minimum spacing rule for the specified layer, from your technology file. If you specified neither of these and minSpacing is not available, the function reports an error.

Default:  $n\_spaceX$  if specified; otherwise the minimum spacing rule for the specified layer from your technology file

?cvId d\_cvId

Database ID for the cellview in which you are creating a rectangle.

Default: pcCellView or tcCellView when a rodCreateRect statement occurs in the body of a pcDefinePCell function or tcCreateCDSDeviceClass function call, respectively; nil if no cellview ID is specified or found

?fillBBox 1\_fillBBox

List of two points defining opposite corners of a bounding box to fill with rectangles, referred to as a *fill-bounding box*. The first point specifies any corner and the second point specifies the opposite corner. Use one of the following formats:

```
list( x:y x:y )
or
list( list(x y) list(x y))
```

You can specify the maximum number of rectangles the system creates in the fill-bounding box with  $x_elementsX$  and  $x_elementsY$ . If the number specified exceeds the space available in the fill-bounding box, the system creates only the number of rectangles that fit.

Relative Object Design Functions


You can specify the distance between rectangles in the fill-bounding box with  $n\_spaceX$  and  $n\_spaceY$ .

When you use  $1\_bBox$  argument with  $1\_fi11BBox$ , the system uses the  $1\_bBox$  coordinates only to compute the size of the rectangles. The system always places the first rectangle in the lower-left corner of the fill-bounding box. For example, the following argument values define a 14-by-10 fill-bounding box with its lower-left corner at 2:2:

```
?llBBox list( 2:2 16:12 )
?bBox list( 0:0 4:2 )
?spaceX 1.0
?spaceY 2.0
```

The coordinates of the first rectangle (0:0 4:2) are used to compute the size of the rectangles, not the location of the first rectangle.

The size of the rectangles is 4 units wide by 2 units long. The rectangles are spaced 1 unit apart in the direction of the X axis and 2 units apart in the direction of the Y axis.



The fill-bounding box is shown by a dashed line because no bounding box is created.

Default: nil

?fromObj Rl\_fromObj

Relative Object Design Functions

ROD object ID or list of ROD object IDs identifying a named object or list of named objects that you want to use as a source for creating a new named rectangle. The source objects can be instances, rectangles, polygons, paths, lines, dots, labels, and/ or text-display objects. When you specify  $R1\_fromObj$ , the value of the  $R1\_fromObj$  argument overrides other arguments that directly or indirectly specified coordinates for the generated rectangle:  $n\_width$ ,  $n\_length$ ,  $l\_origin$ , and  $l\_bBox$ .

Default: none

?size txf\_size

A signed integer, floating-point number, or Cadence SKILL language expression specifying the difference between the size of the source object  $(R1\_fromObj)$  and the size of the generated rectangle. When the source is more than one object,  $txf\_size$  specifies the difference between a bounding box around all of the objects and the size of the generated rectangle.

A positive number creates a rectangle that is larger than the source objects; a negative number creates a rectangle that is smaller than the source objects. When you specify a SKILL expression, it must evaluate to a positive or negative integer or floating-point number. SKILL expressions are evaluated only when the new rectangle is created.

If you specify a source object ( $R1\_fromObj$ ) but do not specify  $txf\_size$ , then  $txf\_size$  defaults to 0.0. If you specify  $txf\_size$ , you must also specify  $R1\_fromObj$ , or the system issues a warning message and the function fails. Default: 0.0

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <u>Add Property Form</u>. For Boolean properties, the value must be t or nil. For example, you would specify a single Boolean property as follows:

?prop list("myProp" t)

Relative Object Design Functions

And, a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

?returnBoolean g\_returnBoolean

Boolean value indicating whether or not the rodCreateRect function returns a Boolean value or ROD object IDs. The value must be t or nil. When  $g_returnBoolean$  is t, the function returns t or nil. When  $g_returnBoolean$  is nil, the function returns a single ROD object ID or a list of ROD object IDs. When you are creating multiple rectangles, the rodCreateRect function executes much more quickly if  $g_returnBoolean$  is set to t, so when you do not need a list of ROD object IDs, set this argument to t.

Default: nil

rodRectConnectivityArgs...

A list containing rod connectivity arguments for rectangles.

For more information on rod\_RectConnectivityArgs, see ROD Connectivity Arguments for Rectangles (rodRectConnectivityArgs)

?subRectArray  $l\_subrectArgs...$ 

A list containing one or more lists, each of which specifies the arguments for one set of unnamed subrectangles. Each list creates a set of unnamed subrectangles for each master rectangle in the multipart rectangle; each set of subrectangles is created in relationship to the lower-left corner of each master rectangle. For information about how to specify lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

For more information onf *1\_subrectArgs*, see <u>Subrectangle Arguments (I\_subrectArgs)</u>

Relative Object Design Functions

# ROD Connectivity Arguments for Rectangles (rodRectConnectivityArgs)

?netName S netName

Symbol or character string specifying the name of the net with which you want to associate the shape. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings. If the net does not exist, the system creates the net, naming it with S\_netName. To associate the shape with a net, this argument is required.

Default: none

?termName S\_termName

Symbol or character string specifying the name of the terminal and net with which you want to associate the shape. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings. If the terminal and net does not exist, the system creates them, naming them S termName.

If you specify both S\_termName and S\_netName, their names must be the same. If a terminal with the specified name already exists, the net it belongs to must have the same name. If the net name does not match the terminal name, the function reports an error. To associate the shape with a terminal and net, this argument is required.

Default: none

?termIOType S\_termIOType

Symbol or character string specifying the direction type (I/O type) for the terminal. If *S\_termName* is not specified, S termIOType is ignored. If a terminal with the name specified by S\_termName already exists, it must have the same direction type as specified by S termIOType; if the direction type is not the same, the function reports an error. Valid Values: input, output, inputOutput, switch,

jumper

Default: inputOutput

?pin g\_pin

Boolean value indicating whether or not to make the shape into a pin. The value must be t or nil.

Relative Object Design Functions

When you specify  $g_pin$ , you must also specify  $S_netName$  and  $S_termName$ ; if you do not, all connectivity arguments are ignored but no error is reported.

When the value is t, the shape created is a pin. When the value is nil, the shape created is not a pin, and all other arguments containing the word pin are ignored.

Valid Values: t, nil

Default: nil

?pinAccessDir t1\_pinAccessDir

Text string or list specifying the access directions for the pin. Enclose string values in quotation marks. Do not use a symbol. An example of a list is

list( "top" "bottom" )

Valid Values: top, bottom, left right, any, none, or a list containing any of these values

Default: any

?pinLabel g\_pinLabel

Boolean value indicating whether or not to add a text-display label for the pin. The value must be t or nil. When the value is t, the system creates a text-display label attached to the pin. The text is the contents the of the  $S\_termName$  argument.

Valid Values: t, nil

Default: nil

?pinLabelHeight n\_pinLabelHeight

Integer or floating-point number specifying the vertical height of the pin text-display label in user units.

Default:1

?pinLabelLayer txl\_pinLabelLayer

Text string, integer, or list specifying the layer or layer-purpose pair for the pin text-display label, such as

```
?pinLabelLayer "metal1"
?pinLabelLayer 45
?pinLabelLayer list("metal1" "drawing")
```

Relative Object Design Functions

Enclose string values in quotation marks. Do not use a symbol. For lists, use the following format:

list(layer purpose)

#### Examples of layer-purpose pairs are

```
?pinLabelLayer list("metal1" "drawing")
?pinLabelLayer list(45 252)
?pinLabelLayer list(45 "drawing")
?pinLabelLayer list("metal1" 252)
```

When only the layer is specified, the purpose defaults to the purpose defined by  $1\_1ayex$ . When neither layer nor purpose is specified, both layer and purpose default to the values defined by  $1\_1ayex$ .

Default: layer specified by  $1\_layer$ ; purpose specified by  $1\_layer$ 

?pinLabelFont S\_pinLabelFont

Symbol or character string specifying the name of the font for the pin text-display label.

Valid Values: euroStyle, gothic, math, roman, script,

stick, swedish

Default: stick

?pinLabelOrient g\_pinLabelDrafting

Boolean value indicating whether or not to rotate the pin text-display label more than 90 degrees. The value must be t or nil. When the value is t, the label can rotate 90 degrees or less. When the value is nil, the label can rotate 90 degrees or more.

Valid Values: t, nil

Default: t

?pinLabelOrient S\_pinLabelOrient

Symbol or character string specifying the orientation of the pin text-display label.

#### Valid Values:

0	R0	MY	sideways		
90	R90	MYR90	sideways&90		
180	R180	MX	upsideDown		
270	R270	MXR90	sideways&270		


Default: R0

?pinLabelOffsetPoint l\_pinLabelOffsetPoint

Relative Object Design Functions

Single set of coordinates specifying the X and Y offset of the origin of the pin text-display label from a point handle on the rectangle. The label origin is specified by  $S_pinLabelJust$ , and the rectangle point handle is specified by  $S_pinLabelRefHandle$ .

For example, to create a label on the rectangle polyRect, offset from the segment point handle mid2 by 2 units in the direction of the X axis and 0 units in the direction of the Y axis, specify 2:0.



Use one of the following formats:

X: Y

or

list(xy)

or any expression that evaluates to a list containing two numbers.

Default: 0:0

?pinLableJust S\_pinLabelJust

Symbol or character string specifying the origin point of the label. You must specify both words; do not abbreviate them.

Relative Object Design Functions

#### Valid Values:

upperLeft
upperCenter
upperRight lowerCenter
lowerRight

centerLeft centerCenter centerRight

Default: centerCenter

#### ?pinLabelRefHandle S\_pinLabelRefHandle

Symbol or character string specifying the point handle on the rectangle with which you want to associate the origin point of the text-display label. You can specify the name of any bounding box or segment point handle.

Bounding box point handle names: To specify a point handle on the bounding box of a rectangle, use either the two-word handle name or its two-character abbreviation, as shown in valid values. For example, you can use ul for upperleft. Valid Values for bounding box point handles:

upperLeft	or	uL	lowerLeft	or	1L
upperCenter	or	uC	lowerCenter	or	1C
upperRight	or	uR	lowerRight	or	1R
centerLeft	or	cL			
centerCenter	or	сC			
centerRight	or	cR			

Segment point handle names: To specify a point handle on a segment of a rectangle, use the system-defined name for the handle. Each segment has three system-defined point handles, named startn, midn, and endn, where n is the segment number, starting at zero.

The last segment also has the following point handles: startLast, midLast, and endLast. The system numbers segments clockwise, starting with the lower-left corner as zero, no matter how the rectangle was created.

For a complete description of system-defined point handles, see "System-Defined Handles".

Valid Values: start0, mid0, end0; start1, mid1, end1; start2, mid2, end2; startLast, midLast, endLast

Default: the bounding box point handle centerCenter

Relative Object Design Functions

# Subrectangle Arguments (I\_subrectArgs)

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose pair for the subrectangle(s), such as


```
?layer "metal1"
?layer 45
?layer list("metal1" "drawing")
```

Enclose string values in quotation marks. Do not use a symbol. Use one of the formats defined for the argument  $\underline{tx1} \underline{layex}$ . You are required to specify a layer.

Default Purpose: drawing

?width  $n_width$ 

Positive integer or floating-point number specifying the horizontal measurement of the subrectangle(s) in user units.



If not specified, the system uses  $n\_length$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreateRect returns nil to indicate an error.

Default:  $n\_length$  if specified; otherwise minWidth for the subrectangle layer from the technology file

?length n\_length

Positive integer or floating-point number specifying the vertical measurement of the subrectangle(s) in user units.

Relative Object Design Functions



If not specified, the system uses  $n\_width$ ; if neither is specified, the system uses the minWidth rule for the subrectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodCreateRect returns nil to indicate an error.

Default:  $n\_width$  if specified; otherwise, minWidth for the subrectangle layer from the technology file


?gap S\_gap

Symbol or character string specifying the method the system uses to place subrectangles within each master rectangle. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The system automatically calculates the maximum number of rectangles that fit in the master rectangle, allowing for the space needed by the offset arguments, and using the value of the  $n\_spaceX$  and  $n\_spaceY$  arguments to determine the minimum space between subrectangles.


When the value of  $S\_gap$  is distribute, which is the default, the system distributes the space around subrectangles as evenly as possible, in multiples of the grid space specified by mfgGridResolution. Any remaining space is divided evenly and placed to the right and/or above each subrectangle. The following example shows excess space along the X axis.

Relative Object Design Functions




When the value of  $S_{gap}$  is distribute and there is only one subrectangle, the system centers the subrectangle in the master rectangle, on grid.

When the value of  $S\_gap$  is minimum, the system places subrectangles  $n\_spaceX$  and  $n\_spaceY$  apart until there is no space for another subrectangle, then places all of the excess space to the right and/or above the rows/columns of subrectangles. The following example shows excess space along the X axis.



Relative Object Design Functions

When the value of  $S\_gap$  is minCenter, the system places subrectangles  $n\_spaceX$  and  $n\_spaceY$  apart until there is no space for another subrectangle. The subrectangles are then placed in the center by spreading the excess space evenly around these rows and columns of subrectangles. The following example shows excess space along the X axis.




Valid Values: distribute, minimum, minCenter

Default: distribute

?lowerLeftOffsetX n\_lowerLeftOffsetX

Signed integer or floating-point number specifying the offset along the X axis of the left edge of the lower-left subrectangle from the left edge of the master rectangle. A positive number starts the subrectangles to the right; a negative number starts the subrectangles outside the master rectangle.


Relative Object Design Functions



Default: 0

?lowerLeftOffseY n\_lowerLeftOffsetY


Signed integer or floating-point number specifying the offset along the Y axis of the bottom edge of the lower-left subrectangle from the bottom edge of the master rectangle. A positive number starts the subrectangles above the bottom edge of the master rectangle; a negative number starts the subrectangles outside the master rectangle.



?upperRightOffsetX n\_upperRightOffsetX


Relative Object Design Functions

Signed integer or floating-point number specifying the offset along the X axis of the right edge of the upper-right subrectangle from the right edge of the master rectangle. A positive number starts the subrectangles outside of the master rectangle; a negative number starts the subrectangles to the left of the right edge of the master rectangle.



?upperRightOffsetY n\_upperRightOffsetY

Signed integer or floating-point number specifying the offset along the Y axis of the top edge of the upper-right subrectangle from the top edge of the master rectangle. A positive number starts the subrectangles outside of the master rectangle; a negative number starts the subrectangles below the top edge of the master rectangle.



?spaceX n\_spaceX

Relative Object Design Functions

Positive integer or floating-point number specifying the distance between the edges of subrectangles in the direction of the X axis. If not specified, the system uses the minSpacing rule for the subrectangle layer from the technology file. If the minSpacing rule is not defined in the technology file, rodCreateRect returns nil to indicate an error.

Default:  $\min \text{Spacing}$  for the subrectangle layer from the technology file

?spaceY n spaceY

Positive integer or floating-point number specifying the distance between the edges of subrectangles in the direction of the Y axis. If not specified, the system uses the minSpacing rule for the subrectangle layer from the technology file. If the minSpacing rule is not defined in the technology file, rodCreateRect returns nil to indicate an error.

Default: minSpacing for the subrectangle layer from the technology file

?prop 1\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the Add Property Form. For Boolean properties, the value must be tornil. For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
```

and a list of properties as follows:

```
?prop list(
    list("myProp1" propValue1)
    list("myProp2" propValue2)
    ...
    list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

Relative Object Design Functions

#### Value Returned

The values returned by the rodCreateRect function is determined by how you specify the  $g_returnBoolean$  argument.

- When  $g_returnBoolean$  is set to t, the function returns t or nil.
- When *g\_returnBoolean* is set to nil, the function returns a ROD object ID or list of ROD object IDs.
- When g\_returnBoolean is set to nil and more than one rectangle is created, rodCreateRect returns a list of ROD object IDs with the upper right rectangle listed first and the lower left rectangle listed last. For example,

```
("xxx.6.6" "xxx.6.5" "xxx.6.4" "xxx.6.3" "xxx.6.2" "xxx.6.1"

"xxx.5.6" "xxx.5.5" "xxx.5.4" "xxx.5.3" "xxx.5.2" "xxx.5.1"

"xxx.4.6" "xxx.4.5" "xxx.4.4" "xxx.4.3" "xxx.4.2" "xxx.4.1"

"xxx.3.6" "xxx.3.5" "xxx.3.4" "xxx.3.3" "xxx.3.2" "xxx.3.1"

"xxx.2.6" "xxx.2.5" "xxx.2.4" "xxx.2.3" "xxx.2.2" "xxx.2.1"

"xxx.1.6" "xxx.1.5" "xxx.1.4" "xxx.1.3" "xxx.1.2" "xxx.1.1")

R_rodObj

ROD object ID or a list of ROD object IDs in descending sequence for ROD object information associated with the new rectangle or multiple new rectangles.

t Rectangles were created successfully.


An error occurred, and no rectangles were created.
```

# **Examples**

#### Example 1: Creating a Single Rectangle

**Note:** When you want to create a rectangle that is a regular, unnamed database shape, use the dbCreateRect function instead of the rodCreateRect function; using dbCreateRect produces less overhead, resulting in faster performance.

You can create a single named rectangle, with ROD attributes, as shown below:



Relative Object Design Functions

# with code similar to the following:


```
rodCreateRect(
    ?layer "metal2"
    ?width 4
    ?length 2
)
```

The return value is a single ROD object ID.

#### Example 2: Creating Rows and Columns of Named Rectangles

To create rows and columns of rectangles that are regular, unnamed database shapes, see <u>Filling a Bounding Box with Rectangles</u>.

You can create rows and columns of named rectangles that have ROD attributes, as shown below:



#### with code similar to the following.


The return value is a list of eight ROD object IDs.

Relative Object Design Functions

# Example 3: Filling a Bounding Box with Named Rectangles

To fill a bounding box with rectangles that are regular, unnamed database shapes, see <u>Filling a Bounding Box with Rectangles</u>.

You can fill a bounding box with named rectangles that have ROD attributes, as shown below:




with code similar to the following (the first rectangle is always in the lower-left corner of the bounding box):

The return value is t.

# Example 4: Creating a Multipart Rectangle

You can create a multipart rectangle consisting of a single master rectangle filled with unnamed subrectangles as shown below:



with code similar to the following. In this example,  $\underline{s}$   $\underline{gap}$  is not specified; it defaults to distribute, causing the excess space to be placed between the subrectangles.


```
cvId = deGetCellView()
rodCreateRect(
                    "metal1"
    ?layer
    ?width
                    24
                    17
    ?length
                    list( 0 0 )
    ?origin
    ?elementsX
    ?elementsY
    ?cvId
                    cvId
    ?subRectArray
    list(
           list(
                                          "metal2"
                   ?layer
                   ?width
                   ?length
                   ?lowerLeftOffsetX
                                          3.3
                   ?lowerLeftOffsetY
                                          3
                   ?upperRightOffsetX
                                          -6
                                          3.3
                   ?spaceX
                   ?spaceY
                                          3
        ); end first subrectangle list
```

Relative Object Design Functions

);end all subrectangle lists
) ;end rodCreateRect

# **Specifying the Gaps as Minimum**

To place excess space to the right or above the subrectangles, you can specify the  $S\_gap$  argument as minimum, as shown below.




cvId = deGetCellView()

Relative Object Design Functions

```
rodCreateRect(
        ?layer
                        "metal1"
                        24
        ?width
        ?length
                        17
                        list( 0 0 )
        ?origin
        ?elementsX
        ?elementsY
        ?cvId
                        cvId
         ?subRectArray
        list(
               list(
                       ?layer
                                          "metal2"
                                          3
                       ?width
                                          3
                       ?length
                                          "minimum"
                       ?gap
                       ?lowerLeftOffsetX
                                           3.3
                       ?lowerLeftOffsetY
                       ?upperRightOffsetX -6
                       ?spaceX
                       ?spaceY
                    ) ;End first subrectangle list
             ) ;end all subrectangle lists
        ) ; end rodCreateRect
```

#### Example 5: Creating a Multipart Rectangle with Overlapping Subrectangles

You can create a multipart rectangle with overlapping unnamed subrectangles, as shown below:




with code similar to the following;, where the lower-left offset arguments are less than zero and the upper-right offset arguments are greater than zero:

Relative Object Design Functions

```
?length
               12
?origin
               list(22)
?elementsX
?elementsY
               1
?cvId
               cvId
 ?subRectArray
      list(
         list(
                                      "metal2"
               ?layer
               ?width
                                      1
               ?lenath
                                      1
               ?lowerLeftOffsetX
                                      -2
               ?lowerLeftOffsetY
                                      -2
               ?upperRightOffsetX
                                      2
               ?upperRightOffsetY
                                      2
               ?spaceX
               ?spaceY
           ) ;end first subrectangle list
     ); end all subrectangle lists
); end rodCreateRect
```

### Example 6: Creating a Ground Rail and Contacts

You can create a ground rail with contacts, as shown below:



where with code similar to the following, you specify a named rectangle for the metal layer, a set of unnamed subrectangles on the p-diffusion layer, and a second set of unnamed subrectangles on the contact layer:

Relative Object Design Functions


```
list(
        list(
                                    "pdiff"
             ?layer
             ?width
                                    1
            ?length
                                    1
                                    "minimum"
             ?gap
             ?lowerLeftOffsetX
                                    0.5
                                     0.5
             ?lowerLeftOffsetY
        ) ; End of first subrectangle list
        list(
             ?layer
                                    "cont"
             ?width
                                    0.5
             ?length
                                    0.5
                                    "minimum"
             ?gap
             ?lowerLeftOffsetX
                                    0.75
             ?lowerLeftOffsetY
                                    0.75
                                    1.5
             ?spaceX
             ?spaceY
                                    1.5
        ) ;end second subrectangle list
    ) ; end all subrectangle lists
) ; end rodCreateRect
```

In this example, specifying the space arguments for the subrectangles is not necessary; the software uses the default values for the  $n\_spaceX$  and  $n\_spaceY$  arguments to create the number of contacts that fit. However, if you want to an amount of space between contacts that is different than the default when the power rail is stretched, you do need to specify the space arguments.

# Example 7: Stretching a Multipart Rectangle


The following examples include stretching the master rectangle of a multipart rectangle in the direction of the Y axis. To make the subrectangles regenerate correctly, specifying  $n\_spaceY$  is necessary. The space arguments default to the minimum spacing (minSpacing) defined for the subrectangle layers in the technology file, which, in this case, does not produce the desired result.

When you stretch a master rectangle using the Virtuoso<sup>®</sup> Layout Editor *Edit – Stretch* command, the system regenerates all sets of unnamed subrectangles. For example, stretching the master rectangle specified in the last example to the right, as shown below:




Relative Object Design Functions

makes the power rail longer, adding more contacts horizontally, like this:




Stretching the master rectangle upward, as shown below:



Relative Object Design Functions


makes the power rail wider, adding more rows of contacts vertically, like this:



Relative Object Design Functions

# Example 8: Creating Multiple Master Rectangles Filled with Subrectangles

For a multipart rectangle, you can create rows and columns of master rectangles and fill them with unnamed subrectangles, as shown below:





#### with code similar to the following:

```
cvId = deGetCellView()
rodCreateRect(
                   "metal1"
    ?layer
    ?width
                   3.5
    ?length
                   list( 0.75 0.75 )
    ?origin
                   3
    ?elementsX
    ?elementsY
                   2
    ?spaceX
                   0.75
    ?spaceY
                   0.75
    ?cvId
                   cvId
    ?subRectArray
    list(
           list(
                                         "metal2"
                   ?layer
                   ?width
                                         1
                  ?length
                                         0.75
                   ?lowerLeftOffsetX
                                         0.5
                   ?lowerLeftOffsetY
                                         0.5
                                         -0.5
                   ?upperRightOffsetX
                                        -0.5
                   ?upperRightOffsetY
                   ?spaceX
                                         0.5
                   ?spaceY
           ); end first subrectangle list
        ) ;end all subrectangle lists
   ) ;end rodCreateRect
```


#### Example 9: Creating a Rectangle from Other Objects

You can specify the coordinates of a named rectangle with the  $n\_width$ ,  $n\_length$ , and  $l\_origin$  arguments or with the  $l\_bBox$  argument. Optionally, you can use the  $Rl\_fromObj$  argument to specify one or more named objects from which to generate a named rectangle. When you specify two or more named objects as the source for creating a rectangle, as shown in the example below:





the system creates the rectangle based on a bounding box around the objects. The new rectangle is larger or smaller than the bounding box, depending on whether you specify a positive or negative size.



**Note:** After a new rectangle is generated, no relationship exists between the generated rectangle and its source objects.

For a detailed overview of creating rectangles from other objects, see <u>Creating a Rectangle from Another Object</u>.

Relative Object Design Functions

#### rodDeleteHandle

```
rodDeleteHandle(
    R_rodObj
    S_name
    );end rodDeleteHandle
    => t / nil
```

# **Description**

Deletes a user-defined handle. You provide the ROD object ID and handle name.

#### **Arguments**

R\_rodObj ROD object ID of the named object for which you want to

delete a handle. This argument is required.

S\_name Symbol or character string specifying the name of the handle

to delete. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD

converts symbols to character strings.

You cannot delete a system-defined handle. This argument is

required.

Valid Values: the name of any existing user-defined handle

Default: none

#### Value Returned

t The handle was deleted successfully.

nil An error occurred and no handle is deleted.

Relative Object Design Functions

#### rodDeleteSubPart

```
rodDeleteSubPart(
    R_rodObjId
    t_subpartName
    );end rodDeleteSubPart
    => t / nil
```

# **Description**

Deletes the named subpart from the given multipart path (MPP).

#### **Arguments**

R_rodObjId	ROD object ID associated with the multipart path (MPP).
t_subpartName	String specifying the name of the subpart to be deleted.

#### Value Returned

t The subpart was deleted successfully.

nil An error occurred and the subpart was not deleted.

#### **Example**

```
rodDeleteSubPart(mppId, "subpart0")
```

Deletes the subpart named subpart 0 from the MPP corresponding to mppId.

Relative Object Design Functions

#### rodFillBBoxWithRects

```
rodFillBBoxWithRects(
    [?cvId d_cvId]
    [?layer txl_layer]
    [?fillBBox l_fillBBox]
    [?width n_width]
    [?length n_length]
    [?gap S_gap]
    [?spaceX n_spaceX]
    [?spaceY n_spaceY]
    [?prop l_prop]
    [?returnBoolean g_returnBoolean]
    );end rodFillBBoxWithRects
    => d dbId / t / nil
```

#### Description

Fills a bounding box with rectangles, as many as fit within the bounding box you specify. The rectangles are ordinary unnamed shapes, identified by database IDs; the rectangles have no ROD attributes. You can assign a property name and value, or a list of property names and values, to the set of rectangles. The property or list of properties apply to every rectangle in the bounding box. You specify the return value of the function to be Boolean or a list of the database IDs for the rectangles. When you want to create a one- or two-dimensional array of rectangles, and the rectangles do not need to be ROD objects, use this function instead of rodCreateRect because regular database shapes require less overhead, contributing to faster performance.

#### **Arguments**

?cvId d\_cvId

Database ID for the cellview in which you are creating

rectangles.

Valid Values: valid cellview ID

Default: nil

?layer txl\_layer

Text string, integer, or list specifying the layer or layer-purpose

pair for the rectangle(s), such as:

Relative Object Design Functions

?layer "metal1"
?layer 45
?layer list("metal1" "drawing")

Enclose string values in quotation marks. Use one of the formats defined for the argument  $\underline{tx1\_layer}$ . You are required to specify a layer.

Default Purpose: drawing

?fillBBox *1\_fillBBox* 

List of two points defining opposite corners of a bounding box to fill with rectangles.

Valid Values: list of two points

Default: nil

?width n\_width

Positive integer or floating-point number specifying the horizontal measurement of the rectangle(s) in user units.

If not specified, the system uses  $n\_length$ ; if neither is specified, the system uses the minWidth rule for the rectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodFillBBoxWithRects returns nil to indicate an error.

Default:  $n_length$  if specified; otherwise minWidth for the rectangle layer from the technology file

?length n\_length

Positive integer or floating-point number specifying the vertical measurement of the rectangle(s) in user units.

If not specified, the system uses  $n\_width$ ; if neither is specified, the system uses the minWidth rule for the rectangle layer from the technology file. If the minWidth rule is not defined in the technology file, rodFillBBoxWithRects returns nil to indicate an error.

Default:  $n\_width$  if specified; otherwise, minWidth for the rectangle layer from the technology file

?gap S\_gap

Relative Object Design Functions

Symbol or character string specifying the method the system uses to place rectangles within the bounding box. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings.

The system always uses the value of  $n\_spaceX$  and  $n\_spaceY$  for minimum space between rectangles and calculates the maximum number of rectangles that fit in the bounding box.

When the value of  $S\_gap$  is distribute, the system distributes the space around rectangles as evenly as possible, in multiples of the grid space specified by mfgGridResolution. Any remaining space is placed to the right of the rows of rectangles and/or above the columns of rectangles.

**Note:** When the value of  $S_{gap}$  is distribute and there is only room for one rectangle, the system centers the rectangle in the bounding box, on grid.

When the value of  $S\_gap$  is minimum, the system places rectangles  $n\_spaceX$  and  $n\_spaceY$  apart until there is no space for another rectangle, and then places remaining space to the right of the rows of rectangles and/or above the columns of rectangles.

When the value of  $S\_gap$  is minCenter, the system places rectangles  $n\_spaceX$  and  $n\_spaceY$  apart until there is no space for another rectangle. The rectangles are then placed in the center by spreading the excess space evenly around these rows and columns of rectangles.

Valid Values: distribute, minimum, minCenter

Default: distribute

?spaceX n\_spaceX

Positive integer or floating-point number specifying the distance between the edges of rectangles in the direction of the X axis. If not specified, the system uses the minSpacing rule for the rectangle layer from the technology file.

Relative Object Design Functions

If the minSpacing rule is not defined in the technology file, rodFillBBoxWithRects returns nil to indicate an error. Default: minSpacing for the rectangle layer from the technology file

?spaceY n\_spaceY

Positive integer or floating-point number specifying the distance between the edges of rectangles in the direction of the Y axis. If not specified, the system uses the minSpacing rule for the rectangle layer from the technology file. If the minSpacing rule is not defined in the technology file, rodFillBBoxWithRects returns nil to indicate an error. Default: minSpacing for the rectangle layer from the technology file

?prop l\_prop

A list or lists of lists, where each list contains the name of a property and its value. When the property name is a string, enclose it in quotes. For a description of the valid data types, see the <u>Add Property Form</u>. For Boolean properties, the value must be t or nil. For example, you would specify a single Boolean property as follows:

```
?prop list("myProp" t)
and a list of properties as follows:
?prop list(
   list("myProp1" propValue1)
   list("myProp2" propValue2)
   ...
   list("myPropN" propValueN)
)
```

For a more detailed description about specifying lists of lists, see <u>Formatting List-of-Lists Arguments for Subparts</u>.

Default: nil

?returnBoolean g\_returnBoolean

Boolean value indicating whether or not the rodFillBBoxWithRects function returns a Boolean value or list of database object IDs. (This functions does not return a ROD object ID).

Relative Object Design Functions

The value of the  $g\_returnBoolean$  argument must be t or nil. When  $g\_returnBoolean$  is t, the function returns t or nil. When  $g\_returnBoolean$  is nil, the function returns a list of database object IDs. When you are creating multiple rectangles, this function executes much more quickly if  $g\_returnBoolean$  is set to t, so when you do not need the database object IDs, set this argument to t.


Default: nil

#### **Value Returned**

The value returned by the rodFillBBoxWithRects function is determined by how you specify the  $g_returnBoolean$  argument.

- ☐ When *g\_returnBoolean* is set to t, the function returns t or nil.
- □ When *g\_returnBoolean* is set to nil, the function returns a database ID or list of database IDs. (This function does not return ROD object IDs.)
- □ When *g\_returnBoolean* is set to nil and more than one rectangle is created, rodFillBBoxWithRects returns a list of database IDs with the upper right rectangle listed first and the lower left rectangle listed last.

The numbers in the illustration below show the sequence in which the database IDs of the rectangles would be returned.



d dbId

Database object ID or list of database object IDs (**not** the ROD object ID) for the rectangles created to fill the bounding box, in descending sequence.

t

Rectangles were created successfully.

nil


An error occurred, and no rectangles were created.

Relative Object Design Functions

#### **Additional Information**

You can fill a bounding box with rectangles as shown below by defining the lower-left and upper-right points of the bounding box. Notice where the system places any excess space.

Figure 1-5 Filling a Bounding Box with Rectangles




```
cvId = deGetCellView()
dbIdList = rodFillBBoxWithRects(
    ?cvId
                         cvId
                         "metal1"
    ?layer
    ?fillBBox
                         list( 1:1 12:6 )
    ?width
                         2.0
    ?length
                         1.0
                         0.7
    ?spaceX
    ?spaceY
                         0.7
    ?returnBoolean
                         nil
    ) ; end rodFillBBoxWithRects
```

In the example above, the  $\underline{s}$   $\underline{gap}$  argument is not specified, so it defaults to distribute, causing excess space to be placed between the subrectangles. Therefore, the space between rectangles along the Y axis is 0.3 more than the minimum of 0.7 specified by the  $n\_spaceY$  argument. The example code returns the variable dbIdList, which contains a list of 12 database IDs.

You can fill the same bounding box specified above, but with the  $S\_gap$  argument set to minimum, to create the rectangles shown below.

Relative Object Design Functions

Figure 1-6 Filling a Bounding Box with Rectangles with Minimum Gaps



```
cvId = deGetCellView()
rc = rodFillBBoxWithRects(
        ?cvId
                              cvId
                              "metal1"
        ?layer
                              list( 1:1 12:6 )
        ?fillBBox
        ?width
                              2.0
        ?length
                              1.0
        ?gap
                              "minimum"
        ?spaceX
                              0.7
        ?spaceY
                              0.7
        ?returnBoolean
                              t
    ) ; end rodFillBBoxWithRects
```

The  $S\_gap$  argument was set to minimum, so the system spaced the rectangles apart using the values of  $n\_spaceX$  and  $n\_spaceY$ , and placed the remaining space above and to the right of the rectangles. The example code returns the variable rc, which is set to t.

Relative Object Design Functions

#### rodFillWithRects

```
rodFillWithRects(
     [ ?shapeId d_shapeID ]
     [ ?fillShapeLPP 1pp ]
     [ ?fillShapeWidth n width ]
     [ ?fillShapeLength n_length ]
     [ ?gap S_gap ]
     [ ?justification S_justification ]
     [ ?keepOut l_ptList ]
     [ ?spaceX n_spaceX ]
     [ ?spaceY n_spaceY ]
     [ ?enclosureX n_encX ]
     [ ?enclosureY n_encY ]
     [ ?grid n_grid ]
     [ ?outputFillShape l_dbId ]
    ); end rodFillWithRects
    => t / nil
```

### **Description**

Fills a base shape with rectangles. The base shape can be a rectangle, polygon or a path type.

Figure 1-7 Symmetric Shape Filling




Figure 1-8 Asymmetric Shape Filling





Figure 1-9 Diagonal Filling



## **Arguments**

?shapeId *d\_shapeID* 

Database ID of an unnamed base shape or database ID of a ROD object. This shape can be a rectangle, polygon or path type. Other shapes like ellipse or donut are not supported.

?fillShapeLPP 1pp

Specifies the layer-purpose pair of the shape that is used for filling the base shape, such as, "Cont" or "drawing". It is mandatory to specify the value of layer and purpose as a list. For example:

?fillShapeLPP list("Cont" "drawing")

Relative Object Design Functions

?fillShapeWidth n\_width

Positive integer or floating-point number specifying the horizontal measurement or width of the fill shape in user units.

**Note:** The only valid shape that can be used for filling is rectangles.

?fillShapeLength n\_length

An optional argument that is a positive integer or floating-point number specifying the vertical measurement of the fill shape in user units. When it is not specified, it is considered equal to the value of  $n_width$ .

?gap S\_gap

This optional argument is a character string that specifies the method used to fill the base shape. The only value supported is minimum.

?justification S\_justification

This optional argument is a character string or symbol that specifies the origin of the first fill shape. It supports nine types of justification modes. These are: lowerLeft, lowerCenter, lowerRight, centerLeft, centerCenter, centerRight, upperLeft, upperCenter, and upperRight.

For the center configurations of the *S\_justification* parameter, such as lowerCenter, centerLeft, centerCenter, centerRight and upperCenter, extra grid handling is done as follows:

For ring and c-type shapes, extra grid is adjusted inside the shape.

For shapes other than ring and c-type, extra grid is adjusted as below:

At right for lowerCenter and upperCenter configurations.

At the top for centerLeft and centerRight configurations.

At top right for centerCenter configuration.

Default Value: lowerLeft

?keepOut *l\_ptList* 

Relative Object Design Functions

Defines the list of polygon points that need to be excluded while filling. For example, (((x1, y1)(x2, y2) (x3, y3) (x4, y4))...)

?spaceX n\_spaceX

Positive integer or floating-point number specifying the distance between the edges of fill shape in the direction of the X-axis.

?spaceY n\_spaceY

An optional positive integer or floating-point number argument specifying the distance between the edges of fill shape in the direction of the Y axis. When it is not specified, it is considered equal to  $n\_spaceX$ .

?enclosureX n\_encX

Sets the minimum enclosure value for base shape and fill shape in the X-direction.

?enclosureY n\_encY

This is an optional argument that sets the minimum enclosure value for base shape and fill shape in the Y-direction. When it is not specified, it is considered equal to  $n_{enc}X$ .

?grid n\_grid

This optional argument specifies the minimum grid resolution value. If not present, this value defaults to fill layer grid. If layer grid is not present, it defaults to manufacturing grid.

Relative Object Design Functions

?outputFillShape *l\_dbId* 

This is an optional argument that can be either a valid list or valid database object  $group\_id$ .

If the value is specified as 'list()', it is considered as nil or not specified but if the value is specified as 'list(nil)', it is not nil and is a valid value.

If the value is nil or is not specified, the SKILL function returns whether it was run successfully.

When a valid list is specified, nil is returned if there are no shapes to fill or the SKILL function did not run successfully. Otherwise, the database IDs of the rectangles it has been filled with is returned. The argument <code>?outputFillShape</code> contains the same database IDs as the database IDs of the rectangles being filled.

#### Value Returned

If value for outputFillShape is not specified, or if the value specified is nil, the value returned is:

t Base shape is filled successfully

nil Base shape could not be filled

If value of outputFillShape is a groupid (valid group ID in database), the value returned is:

d\_group Base shape is filled successfully with the shapes associated

with the given group ID and the group of the filled IDs is

returned.

nil Base shape could not be filled

If value of outputFillShape is a listShapes(valid list(nil) object), the value returned is:

1\_shapes Base shape is filled successfully with the given list and the list

of filled IDs is returned.

nil Base shape could not be filled

Relative Object Design Functions

### **Examples**

The following examples show the results of using rodFillWithRects in different circumstances:

#### Example 1: outputFilShape is speciafied as a valid list object

#### Here:

- returnList contains list of filled shape IDs
- myList is the list of filled shape dblds
- The return value returnList is same as myList, which is filled with shape IDs.

### Example 2: outputFilShape is specidfied as a valid group object

Here.

Relative Object Design Functions

- myGroup is a valid database object of group ID. This group includes a list of filled shape dblds
- The value returned is returnGroup, which is same as myGroup that associates all filled shape IDs as members of this group.

### Example 3: outputFilShape not given or given as nil

```
returnValue = rodFillWithRects(
    ?shapeId shapeId
    ?fillShapeLPP list("Cont" "drawing")
    ?fillShapeWidth 0.1
    ?fillShapeLength 0.1
    ?gap "minimum"
    ?justification "centerCenter"
    ?keepOut nil
    ?spaceX 0.1
    ?spaceY 0.1
    ?enclosureX 0.1
    ?enclosureY 0.1
    ?grid 0.005
)
```

The value returned is t if the function is successful in filling the base shape. The value returned is nil if the function fails in filling the base shape.

Relative Object Design Functions

### rodGetBBox

```
rodGetBBox(
    [ ?figId d_figId ]
    [ ?layer t_layer ]
    [ ?purpose t_purpose ]
    [ ?stopLevel x_stopLevel ]
    [ ?filterText g_filterText ]
    );end rodGetBBox
    => l_bBox / nil
```

#### Description

Returns the coordinates of the rectangular bounding box enclosing all the elements of a specified figure on a specified layer. You can optionally limit the calculation to include only elements on a specified layer purpose and down to a specified level of design hierarchy. You can also exclude labels and text displays from the calculation.

#### **Arguments**

```
?figId d_figId
```

Database ID of the figure for which the bounding box is required. A figure can be a shape, instance, via, or any type of figGroup (which can, in turn, contain shapes, instances, vias, and other figGroups).

**Note:** Blockages and halos are not supported.

```
?layer t_layer
```

Name of the layer on which the function is to run; for example: ?layer "Poly"

```
?purpose t_purpose
```

Name of the layer purpose on which the function is to run; for example:

```
?purpose "drawing"
```

If you do not specify a purpose, the function runs on all the purposes of the specified layer.

Default: nil (all purposes)

```
?stoplevel x_stopLevel
```

Specifies how far down the hierarchy to search for elements to include in the calculation; for example:

```
?stopLevel 1
```

Relative Object Design Functions

The top level is level 0. If you do not specify a stop level, the function traverses the entire hierarchy for the specified figure and layer.

Default: 32 (all levels)

?filterText  $g_filterText$ 

Specifies whether labels and text displays are filtered out of the bounding box calculation. When set to t, labels and text displays are filtered out; when set to nil, labels and text displays are included.

Default: nil

#### **Value Returned**

1 bBox

List of coordinates defining the bounding box enclosing all the elements of the specified figure on the specified layer (with layer purpose, stop level, and text filters applied if specified). The bounding box is always defined by two sets of X and Y coordinates, the first specifying the lower left corner of the bounding box rectangle, the second specifying the upper right corner.

nil

No elements were found from which a bounding box could be calculated.

#### Example

The following example returns the bounding box of all the elements of the specified figure, taking into account shapes, instances, vias, and figGroups drawn on layer-purpose pair (Poly drawing) at the current level of hierarchy, but excluding labels and text displays.

```
rodGetBBox(?figId css() ?layer "Poly" ?purpose "drawing" ?stopLevel 1 ?filterText
t)
=> ((0.935 4.75) (6.28 7.43))
```

Relative Object Design Functions

# rodForceUpdate

```
rodForceUpdate(
    )
=> nil
```

# **Description**

Applies all ROD update requests in the queue.

## **Arguments**

None

#### **Value Returned**

nil

The function has no specified return value but the requested updates were made.

### **Example**

```
rodForceUpdate()
```

All ROD update requests are applied.

Relative Object Design Functions

#### rodGetHandle

```
rodGetHandle(
    R_rodObj
    S_name
    );end rodGetHandle
    => g handleValue / nil
```

### **Description**

Returns the value of a system- or user-defined handle. You specify the handle name and the ROD object ID for the object with which the handle is associated.

For Boolean handles, the value can be either t or nil. When the value is nil, rodGetHandle returns an ambiguous result: nil could mean that the handle was not found or that the value of the handle is nil. To avoid ambiguity for Boolean handles, verify that the handle exists with the rodIsHandle function before you try to access it.

#### **Arguments**

R_rodObj	ROD object ID for the object with which the handle is
----------	---

associated.

Symbol or character string specifying the name of the handle

whose value is returned. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark (').

ROD converts symbols to character strings.

#### Value Returned

g\_handleValue The value of the handle. The values of point handles are fully

transformed into the coordinate system of the top-level

cellview.

nil No handle was found, or, if the handle is Boolean, the handle

value is equal to nil.

Relative Object Design Functions

# rodGetNamedShapes

### **Description**

Returns a list of the ROD object IDs for all named shapes (rectangles, polygons, and paths) at level zero in the hierarchy within the specified cellview that are ROD objects. This function looks only at the top level of hierarchy and does not return the ROD object ID for instances or cellviews.

#### **Arguments**

d\_cvId

Database ID for the cellview in which you want to identify named shapes that are ROD objects. If the rodGetNamedShapes statement occurs in the body of a pcDefinePCell function or tcCreateCDSDeviceClass function call, the default value is pcCellView or tcCellView, respectively; otherwise, this argument is

required. Default: none

#### Value Returned

1R\_rodObjID A list of the ROD object IDs for all named shapes in the

specified cellview that are ROD objects.

nil No ROD objects or other named shapes exist in the cellview, or

an error occurred.

Relative Object Design Functions

# rodGetObj

```
rodGetObj(
     S hierarchicalName | d dbId
     [d_cellViewId]
    ); end rodGetObj
     => R rodObj / nil
```

### **Description**

Lets you find a named object at any level of hierarchy in your cellview. You must specify either the database ID for the object or its hierarchical name. If you specify the hierarchical name, you must also specify the cellview ID. When you specify a cellview ID, it is not necessary to also specify the database ID; however, if you specify both, the cellview ID must be correct for the database ID you specify. If your rodGetObj statement occurs in the code for a Pcell (in the body of a pcDefinePCell function or tcCreateCDSDeviceClass function call), specifying the cellview ID is optional; if you do not specify it, the cellview ID defaults to pcCellView or tcCellView, respectively.

Note: Some dbCreate\* functions, such as dbCreateInst and dbCreateParamInst create named objects and as a result, have a ROD ID associated with them. You can use the rodGetObj SKILL function to fetch the ROD ID of these objects.

#### **Arguments**


S\_hierarchicalName Symbol or character string specifying an object name, preceded by the names of the instances in the path to the object, separated by the slash character ( / ). If you specify this argument, you must specify the cellview ID as well, unless the statement is in the code for a Pcell or device. When you specify a cellview ID, it is not necessary to also specify the database ID; however, if you specify both, the cellview ID must be correct for the database ID you specify.

> Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings. For this argument, an empty character string (null) is a valid value.

For example, the hierarchical name for the shape polyRect shown below is mem/pTran/polyRect.

Relative Object Design Functions

The hierarchical name for polyRect is mem/pTran/polyRect.



An empty string ("") means that there is no named object; the function returns the ROD object ID for the cellview specified by d cellviewId.

Default: none.

d dbId

Database ID for the object. If you specify this argument, you do not need to specify a cellview ID. However, if you specify both a database ID and a cellview ID, the cellview ID must be correct for the database ID you specify.

d\_cellViewId

ID for the top-level cellview that contains the object specified by the  $S\_hierarchicalName$  or  $d\_dbId$  argument. When  $S\_hierarchicalName$  is specified as an empty string (""), specify the cellview for which you want the ROD object ID.

This argument is required when you do not specify  $d\_dbId$ , unless the rodGetObj statement is in the code for a Pcell or device. If you specify this argument, you do not need to specify the database ID. However, if you specify both a database ID and a cellview ID, the cellview ID must be correct for the database ID you specify.

Default: pcCellView or tcCellView when the rodGetObj statement occurs in the body of a pcDefinePCell function or tcCreateDeviceClass function call, respectively

#### **Value Returned**

R\_rodObj

ROD object ID for the object.

nil

An error occurred and no object was found.

Relative Object Design Functions

#### rodGetSubPart

```
rodGetSubPart(
    R_rodObjId
    t_subpartName
    );end rodGetSubPart
    => R rodSubpartId / nil
```

### **Description**

Returns the subpart ID corresponding to the specified subpart name for the multipart path (MPP) specified as rodObjectId.

#### **Arguments**

R\_rodObjId ROD object ID associated with the multipart path (MPP).ROD

object ID associated with the multipart path (MPP).

t\_subpartName String specifying the subpart name for which the subpart ID is

to be retrieved.

#### Value Returned

R\_rodSubpartId The subpart ID corresponding to the subpart name for the

specified MPP.

### **Example**

subId = rodGetSubPart(mppId "subpart0")

Relative Object Design Functions

## rodlsFigNameUnused

```
rodIsFigNameUnused(
    S_name
    [d_cvId]
    ); rodIsFigNameUnused
    => t / nil
```

### **Description**

Determines whether the name specified by  $S_name$  is a valid name and whether it is already assigned to a ROD object, instance, or mosaic in the cellview specified by  $d_cvId$ . A valid name cannot contain <u>hierarchy</u> (indicated by one or more slashes) and cannot be an empty string.

You might want to verify whether a name is already assigned before you attempt to assign it to a shape with the <u>rodNameShape</u> function.

### **Arguments**

S	n	а	m	e

Symbol or character string specifying the name you want to verify as valid and not assigned to a ROD object, instance, or mosaic in the specified cellview. Enclose character strings in quotation marks (""); precede symbols with a single quotation mark ('). ROD converts symbols to character strings. This argument is required

For example, you can type the characters testName as "testName" or as 'testName.

Valid Values: any non-empty character string or symbol that does not contain a slash (/)

Default: none

 $d_cvId$ 

Database ID for the cellview in which you want to verify  $S\_name$ . If the <code>rodIsFigNameUnused</code> statement occurs in the body of a <code>pcDefinePCell</code> function or <code>tcCreateDeviceClass</code> function call, the default value is <code>pcCellView</code> or <code>tcCellView</code>, respectively; otherwise, this argument is required.

Default: none

Relative Object Design Functions

#### **Value Returned**

t The name is a valid name and is **not** assigned to a ROD

object, instance, or mosaic in the cellview identified by

 $d_cvId.$ 

nil The name is either already assigned to a ROD object,

instance, or mosaic in the cellview identified by  $d_{CVId}$  or is

not a valid name.

Relative Object Design Functions

### rodlsHandle

```
rodIsHandle(
    R_rodObj
    S_name
    );end rodIsHandle
    => t / nil
```

### **Description**

Determines whether the name specified for  $S_name$  identifies a valid system- or user-defined handle associated with the object specified by  $R_rodObj$ . Use this function prior to the rodGetHandle function when you want to verify that the handle exists before you try to access it.

#### **Arguments**

R rodObj	ROD object ID for the named object about which you are
----------	--

inquiring. This argument is required.

Default: none

S\_name Symbol or character string specifying the name you want to

verify as the name of a valid system- or user-defined handle for the object identified by  $R_{rodObj}$ . Enclose character strings

in quotation marks (""); precede symbols with a single

quotation mark ('). ROD converts symbols to character strings.

This argument is required.

Valid Values: any text string, enclosed in quotation marks

Default: none

#### Value Returned

t The name is a valid system- or user-defined handle for the

object identified by R rodObj.

nil The name is not a valid system- or user-defined handle for the

object identified by *R\_rodObj*.

Relative Object Design Functions

# rodlsMasterChoppable

```
rodIsMasterChoppable(
    R_rodObjId
)
=> t / nil
```

### **Description**

Returns the value of the MPP master path choppability attribute.

#### **Arguments**

R\_rodObjId

Specifies the master path of an MPP.

#### **Value Returned**

t Indicates that the master path is choppable.

nil Indicates that the master path is not choppable.

### **Example**

In the following example, when the <code>choppable</code> attribute of master path is set to nil, the first subpart of the given MPP is made non-choppable. In this MPP, the mppid variable contains the rodObjld value.

Relative Object Design Functions

## rodlsObj

```
rodIsObj(
    g_object
    ;end rodIsObj
    => t / nil
```

### **Description**

Determines whether the object specified for  $g\_object$  identifies a valid ROD object. This function is useful for testing variables and parameters to see if they contain a ROD object ID.

For information about what happens to ROD object IDs when you do an *Undo* in a cellview, see <u>ROD object ID changes after Undo</u>.

#### **Arguments**

*g\_object* Value of any data type. This argument is required.

Default: none

#### Value Returned

t The object is a valid ROD object.

nil The object is not a valid ROD object.

#### **Examples**

The following examples show the results of using rodIsObj in several circumstances.

### Example 1

Using rodCreateRect to create a rectangle results in a ROD object, and the function returns the ROD object ID. Assigning the result to the variable rect sets rect equal to the ROD object ID.

```
rect = rodCreateRect( ?cvId geGetEditCellView() ?layer "metal1" )
=> rodObj:19984408
```

Using rodIsObj to test rect returns t, as the object is a ROD object:

```
rodIsObj( rect )
t
```

Relative Object Design Functions

#### Example 2

Testing anything other than a valid ROD object ID, such as a number, returns nil:

```
rodIsObj( 42 )
nil
```

### Example 3

As in Example 1, above, the variable rect contains the ROD object ID for the new rectangle:

Testing rect returns a ROD object ID:

```
rect
rodObj:23494680
```

Using rodIsObj to test rect returns t, as the object is a ROD object:

```
rodIsObj( rect )
t
```

However, if you select the ROD rectangle, move it, and then do an *Undo*, the variable rect no longer contains a ROD object ID.

```
rect
rod:invalid
rodIsObj(rect)
nil
```

For more information about what happens when you do an *Undo* in a cellview that contains ROD objects, see <u>ROD object ID changes after Undo</u>.

Relative Object Design Functions

## rodNameObject

```
rodNameObject(
    [?name S_name]
    [?shapeId d_shapeId]
    [?permitRename g_permitRename]
    );end rodNameObject
    => R rodObj / nil
```

#### Description

Assigns a name to an unnamed database shape or renames a ROD shape. Once the object is named, it can identified by a ROD object ID. This is an alias to an existing public function, rodNameShape.

#### **Arguments**

?name S name

Symbol or character string specifying the name you want to assign to the shape. Enclose a character string in quotation marks (""); precede a symbol with a single quotation mark ('). ROD converts symbols to character strings. For example, to name an object polyrect, you can type the name as "polyrect" or as 'polyrect. The name must be unique for the cellview.

The name cannot contain hierarchy, where hierarchy is indicated by one or more slashes. For example, at the lowest level in the hierarchy (zero-level), you can assign the name polyRect. You cannot assign a name with implied hierarchy, such as

```
I1/I2/polyRect.
```

When you do not specify a name, the system determines whether the shape is a rectangle, polygon, path, line, ellipse, donut, dot, label, and/or text-display object and assigns a name indicating the shape.

For rectangles, the system assigns rect0 to the first rectangle you name in the cellview, rect1 to the second, and so on.

Relative Object Design Functions

For polygons, the system assigns polygon0, polygon1, and so on; for paths, pathn.

For an ellipse, donut, dot, line, label, and/or text-display object, the system assigns ellipsen, donutn, dotn, linen, labeln, or textn, respectively.

For a shape other than these, the system issues a warning message and the function fails.

Default: rectn, polygonn, pathn, ellipsen, vian, blockagen, boundaryn, pathsegn, donutn, dotn, linen, labeln, or textn, as determined by the system.

?shapeId d\_shapeId

Database ID of unnamed shape or database ID of a ROD object (not the ROD object ID; instances and mosaics are not shapes.) This argument is required.

?permitRename g\_permitRename

A Boolean value specifying whether or not to rename the shape if it already has a name. The value must be t or nil. Default: nil

#### **Value Returned**

R_rodObj	ROD object ID for ROD object information associated with the
	newly named shape.

nil An error occurred and no shape was named.

### **Example**

This will name the object selected as myObj1 and return the newly created ROD objectId for the object.

Relative Object Design Functions

## rodNameShape

```
rodNameShape(
    [?name S_name]
    [?shapeId d_shapeId]
    [?permitRename g_permitRename]
    );end rodNameShape
    => R rodObj / nil
```

#### Description

Assigns a name to an unnamed database shape or renames a ROD shape. Creates (or updates) a ROD object containing information associated with the shape, including its name and database ID. The associated ROD object is identified by a ROD object ID. Optionally, you can specify whether to rename an existing ROD object.

**Note:** Instances and mosaics are not shapes. You cannot rename an instance or a mosaic with this function.

You can refer to a named shape through hierarchy using its hierarchical name. You can also access system-defined handles associated with a named shape and create user-defined handles for a named shape.

To assign a name to an unnamed shape, you must identify the shape by its database ID. You can specify a name that is unique within the cellview or let the system generate a name. If you attempt to assign a name to an object that already has a name, and the  $g\_permitRename$  argument is set to nil, the system displays an error message.

You can assign a property name and value, or list of property names and values, to the shape you are naming. For example, you could assign a Boolean property named myProp and a value of t or nil to the shape you are renaming.

Before assigning a name, you might want to verify that the string is a valid name and that it has not already been used in the cellview. To do this, use the <u>rodlsFigNameUnused</u> function.

## **Arguments**

```
?name S_name
```

Symbol or character string specifying the name you want to assign to the shape. Enclose a character string in quotation marks (""); precede a symbol with a single quotation mark ('). ROD converts symbols to character strings.

Relative Object Design Functions

For example, to name an object polyrect, you can type the name as "polyrect" or as 'polyrect. The name must be unique for the cellview.

The name cannot contain hierarchy, where hierarchy is indicated by one or more slashes. For example, at the lowest level in the hierarchy (zero-level), you can assign the name polyRect. You cannot assign a name with implied hierarchy, such as

I1/I2/polyRect.

When you do not specify a name, the system determines whether the shape is a rectangle, polygon, path, line, ellipse, donut, dot, label, and/or text-display object and assigns a name indicating the shape. For rectangles, the system assigns rect0 to the first rectangle you name in the cellview, rect1 to the second, and so on. For polygons, the system assigns polygon0, polygon1, and so on; for paths, pathn. For an ellipse, donut, dot, line, label, and/or text-display object, the system assigns ellipsen, donutn, dotn, linen, labeln, or textn, respectively. For a shape other than these, the system issues a warning message and the function fails. Default: rectn, polygonn, pathn, ellipsen, donutn, dotn, linen, labeln, or textn, as determined by the system.

?shapeId  $d\_shapeId$ 

Database ID of unnamed shape or database ID of a ROD object (not the ROD object ID; instances and mosaics are not shapes.) This argument is required.

?permitRename g\_permitRename

A Boolean value specifying whether or not to rename the shape if it already has a name. The value must be t or nil. Default: nil

#### Value Returned

R\_rodObj

ROD object ID for ROD object information associated with the newly named shape.

nil

An error occurred and no shape was named.

Relative Object Design Functions

### rodPointX

## **Description**

Returns the X coordinate of the point specified by *1\_point*.

#### **Arguments**

1\_point A set of coordinates in one of the following formats:

x:y or list(xy).

Default: none

#### **Value Returned**

n\_num A signed integer or floating-point number that is the X

coordinate of the point specified by <code>l\_point</code>.

nil No coordinate was returned due to an error.

Relative Object Design Functions

#### rodPointY

### **Description**

Returns the Y coordinate of the point specified by *1\_point*.

## **Arguments**

1\_point A set of coordinates in one of the following formats:

x:y or list(xy).

Default: none

#### **Value Returned**

n\_num A signed integer or floating-point number that is the Y

coordinate of the point specified by 1\_point.

nil No coordinate was returned due to an error.

Relative Object Design Functions

# rodSetMasterChoppable

```
rodSetMasterChoppable(
    R_rodObjId
    g_setting { t | nil }
)
    => t / nil
```

## **Description**

Sets the choppability attribute of an MPP master path to the specified value.

### **Arguments**

R_rodObjI	Specifies the master path of an MPP.
g_setting	The new setting for the choppability of the specified master path.

#### **Value Returned**

t	Indicates that the master path choppability attribute has been set to the given value.
nil	Indicates that either the given $rodObjId$ is not a valid master path of an MPP or the master path choppability attribute could not be set to the given value (in this case, a warning message will be displayed).

#### **Example**

In the following example, the first subpart of an MPP created in the edited cellview, is made non-choppable.

Relative Object Design Functions

```
?offsetSubPath
           list(
               list(
                   ?layer "vapox"
                   ?justification "left"
                   ?sep
                                    1
                                    . 4
                   ?width
               ) ;end of offset sublist1
               list(
                   ?layer
                                   "vapox"
                   ?justification "right"
                   ?sep
                   ?width
                                   . 4
               ) ;end of offset sublist2
           ) ;end of offset list of lists
       ) ;end of rodCreatePath
when(rodSetMasterChoppable(mppId nil)
    car(mppId~>subParts)~>choppable = nil
   )
```

Relative Object Design Functions

#### rodSubPoints

## **Description**

Subtracts 1\_point2 from 1\_point1 and returns the resulting point as 1\_point.

### **Arguments**

1\_point1 A set of coordinates in one of the following formats:

x:y or list(xy)

Default: none

1\_point2 A set of points in one of the following formats:

x:y or list(xy)

Default: none

#### **Value Returned**

1\_point The point resulting from subtracting 1\_point2 from

 $1\_point1.$ 

nil No point was subtracted due to an error.

Relative Object Design Functions

# rodUnAlign

```
rodUnAlign(
    R_rodObj1
    [R_rodObj2]
    );end rodUnAlign
=> t / nil
```

## **Description**

When you specify only one ROD object ID, removes all alignments for the object specified. When you specify two ROD object IDs, removes only the alignment between the two objects.

## **Arguments**

R_alignObj1	ROD object ID for the first or only object for which you want to remove alignments. When $R_alignObj2$ is specified, only the alignments between the two objects are removed. When $R_alignObj2$ is not specified, all alignments for $R_alignObj1$ are removed. This argument is required. Default: none
R_alignObj2	ROD object ID for the second object for which you want to remove alignments. When specified, only the alignment between $R_alignObj2$ and $R_alignObj1$ are removed. Default: none

#### **Value Returned**

t	The alignment constraints were removed successfully.
nil	An error occurred and no alignment constraints were removed.

**Relative Object Design Functions** 

## rodUnNameShape

```
rodUnNameShape(
    R1_rodObj
    );end rodUnNameShape
=> t / nil
```

### **Description**

Removes the name from a named shape or list of named shapes. The ROD object ID for the shape and all user-defined handles associated with it are deleted. If the object is an instance, the instance keeps its name but all user-defined handles associated with the instance are deleted. Also removes all alignment constraints that reference the shape.

#### **Arguments**

R1\_rod0bj ROD object ID or list of ROD object IDs that identifies the

named shape for which you want to remove the name.

Default: none

#### Value Returned

t The name(s) of the shape(s) was removed and all alignment

constraints that reference the shape(s) were deleted.

nil An error occurred and no changes were made to the shape(s).

# Relative Object Design Coordinate Functions

This chapter contains information on the Virtuoso relative object design (ROD) coordinate functions.

For more information on relative object design coordinate objects, refer to the *Virtuoso Relative Object Design User Guide*.

The functions in this chapter are listed in the alphabetical order.

<u>rodCoordBisect</u>

<u>rodCoordCreate</u>

<u>rodCoordDefineGrid</u>

<u>rodCoordFix</u>

<u>rodCoordGetGrid</u>

rodCoordIsOnGrid

rodCoordParseString

<u>rodCoordPartition</u>

<u>rodCoordSnap</u>

<u>rodCoordToFloat</u>

<u>rodCoordToInt</u>

<u>rodCoordToString</u>

Relative Object Design Coordinate Functions

# rodCoordBisect

```
rodCoordBisect(
    o_rodCoord [ S_snapType ]
    );end rodCoordBisect
    => o rodCoord
```

# **Description**

Divides the input value by two (bisect). You can optionally set the argument that rounds off the calculated value, truncates it, or converts it based on the defined maximum ceiling.

# **Arguments**

o\_rodCoord A rodCoord object.

S\_snapType A symbol representing snap type (ROUND, TRUNCATE,

CEILING)

ROUND— Converts the value to the nearest arithmetic unit with the mid-point value rounding away from the zero grid point. TRUNCATE — Converts the value to the next arithmetic unit

towards the zero grid point.

CEILING – Converts the value to the next larger arithmetic unit

towards positive infinity.

Default value: TRUNCATE.

#### Value Returned

o\_rodCoord Returns a new rodCoord object. A SKILL error is returned if

the input value is invalid.

#### **Example**

```
rodCoordBisect(coord1)
=> rodCoord@0x016036
```

In this example, a new rodCoord object is returned.

Relative Object Design Coordinate Functions

# rodCoordCreate

```
rodCoordCreate(
    g_inputValue [ S_unitType [ S_snapType ] ]
    [ x_resolution ]
    );end rodCoordCreate
    => o_rodCoordObj
```

# **Description**

Creates a rodCoord object from the given value, that is, g\_inputValue.

Relative Object Design Coordinate Functions

# **Arguments**

g\_inputValue The input value for the constructor. It could be a float or integer

number, or a string representing a float or integer number, or a

rodCoord object.

The unitType and snapType arguments are ignored when

the input is a rodCoord object.

S\_unitType An optional argument that specifies a symbol representing the

unit type of the input value, such as ARITHMETIC\_UNIT or

USER\_UNIT.

Default value: USER\_UNIT.

S\_snapType A symbol representing the snap type (ROUND, TRUNCATE,

CEILING). This argument is only applicable when the unit type

is USER\_UNIT.

ROUND – Converts the value to the nearest arithmetic unit with the mid-point value rounding away from the zero grid

point.

TRUNCATE - Converts the value to the next arithmetic unit

towards the zero grid point.

CEILING - Converts the value to the next larger arithmetic unit

towards positive infinity.

Default value: ROUND.

x resolution An integer value that defines the number of arithmetic units in

one user unit value.

#### Value Returned

o\_rodCoord Returns a new instance of the rodCoord user type. A SKILL

error is returned if the input value is invalid.

#### **Example**

rodCoordCreate(1.25 'USER\_UNIT 'ROUND)
=> rodCoord@0x018ex64

In this example, a new instance of the rodCoord object is returned.

Relative Object Design Coordinate Functions

# rodCoordDefineGrid

```
rodCoordDefineGrid(
    n_gridValue
    x_resolutionValue
    );end rodCoordDefineGrid
    => t
```

# **Description**

Defines the grid and the arithmetic resolution factor values, which are used by the rodCoord\* API.

## **Arguments**

n_gridValue	A fixed or floating	ກumber in the ເ	user unit that defines the gr	ʻid

value.

x\_resolutionValue An integer value that defines the number of arithmetic units in

one user unit value.

#### Value Returned

t The function is executed successfully.

#### **Example**

```
rodCoordDefineGrid(10.2 1000000)
=> +
```

In this example, the grid and arithmetic resolution factor values are defined.

Relative Object Design Coordinate Functions

# rodCoordFix

rodCoordFix(
 o\_rodCoord
 );rodCoordFix
 => o\_newRodCoord

# **Description**

Fixes the rodCoord object and returns a new rodCoord object using the fix() SKILL function.

# **Arguments**

o\_rodCoord Specifies the rodCoord object.

#### **Value Returned**

o\_newRodCoord A new rodCoord object is returned. A SKILL error is returned

if the input value is invalid.

## **Example**

rodCoordFix(coord2)
=> rodCoord0x01604206

In this example, the rodCoord object, coord2 is truncated and a new rodCoord object is returned.

Relative Object Design Coordinate Functions

# rodCoordGetGrid

rodCoordGetGrid()
 ;end rodCoordGetGrid
 => o\_gridValue

## **Description**

Returns the grid value (defined by rodCoordDefineGrid) as a rodCoord object.

# **Arguments**

None.

#### Value Returned

o\_gridValue

A grid value defined by the <u>rodCoordDefineGrid</u> function as a <u>rodCoord</u> object is returned. A SKILL error is returned if the input value is invalid.

# **Example**

rodCoordGetGrid()
=> rodCoord@0x018ef24

In this example, a grid value is returned as a rodCoord object.

Relative Object Design Coordinate Functions

# rodCoordIsOnGrid

```
rodCoordIsOnGrid(
    o_rodCoord
    [ n_gridValue ]
    );end rodCoordIsOnGrid
    => t / nil
```

# **Description**

Checks if the data in the given rodCoord object is on the grid or not.

# **Arguments**

o\_rodCoord Specifies a valid rodCoord object.

 $n\_gridValue$  Specifies a fixed or floating number in user units that defines

the grid value. If  $n\_gridValue$  is not specified, the grid value (global) is set using the rodCoordDefineGrid

function.

However, if the global grid value is not set and the

rodCoordIsOnGrid function is called without the second

argument, the SKILL error is returned.

#### Value Returned

t The data in the given rodCoord object is on the grid.

nil The data in the given rodCoord object is not on the grid.

#### Example

```
rodCoordIsOnGrid(coord1)
=> t
```

In this example, the data in the specified rodCoord object is on the grid.

Relative Object Design Coordinate Functions

# rodCoordParseString

```
rodCoordParseString(
    t_rodStringCoord
)
=> o rodCoord
```

# **Description**

Creates a rodCoord object out of t\_rodString generated by the rodCoordToString function.

#### **Arguments**

t\_rodStringCoord

The string representation of the rodCoord object that is generated by the <u>rodCoordToString</u> SKILL function.

#### Value Returned

o\_rodCoord

Returns a new rodCoord object. The error message is returned if the input value is invalid.

## **Example**

```
; Call rodCoordToString with second argument t to generate a string in the needed
format:
rodCoordToString(coord t)
=> "1.22502@100000"
; Then pass this string to rodCoordParseString:
```

=> rodCoord@0x1b211400 ; rodCoord created (equal to the original rodcoord object).

rodCoordParseString("1.22502@100000")

Relative Object Design Coordinate Functions

# rodCoordPartition

```
rodCoordPartition(
    o_dividend
    g_divisor
    );end rodCoordPartition
    => l_result
```

# **Description**

Performs a division on the given arguments – dividend and divisor.

# **Arguments**

0	dividend S	Specifies a rodCoord object used as the dividend (numera	ator)

for division.

 $g\_divisor$  Specifies a rodCoord object or a fixed number value used as

the divisor (denominator) for division. If the divisor value is a fixed number it is used as a fixed number and not converted to rodCoord before applying the division. A zero value is not

accepted.

#### Value Returned

1\_result A list containing two rodCoord objects – integer quotient and

remainder.

# **Example**

```
rodCoordPartition(coord1 coord2)
=> (rodCoord@0x018ef28 rodCoord@0x018ef68)
```

In this example, a division on the given arguments dividend and divisor is performed.

Relative Object Design Coordinate Functions

# rod Coord Snap

```
rodCoordSnap(
    o_rodCoord
    [[ S_snapType ]
        [ n_gridValue ]]
    );end rodCoordSnap
    => o_rodCoord
```

# **Description**

Snaps a rodCoord object so that its value is on the grid.

Relative Object Design Coordinate Functions

#### **Arguments**

o\_rodCoord A rodCoord object.

S\_snapType A symbol representing the snap type (ROUND, TRUNCATE,

CEILING)

ROUND – Converts the value to the nearest arithmetic unit with the mid-point value rounding away from the zero grid

point.

TRUNCATE - Converts the value to the next arithmetic unit

towards the zero grid point.

CEILING – Converts the value to the next larger arithmetic unit

towards positive infinity.

Default value: TRUNCATE.

 $n\_gridValue$  Specifies a fixed or floating number in user units that defines

the grid value. If  $n\_gridValue$  is not specified, the grid value (global) is set using the rodCoordDefineGrid

function.

However, if the global grid value is not set and the

rodCoordSnap function is called without the third argument,

the SKILL error is returned.

#### **Value Returned**

o\_rodCoord A new rodCoord object is returned. A SKILL error is returned

if the input value is invalid.

#### **Example**

rodCoordSnap(coord1)
=> rodCoord@0x016036

In this example, a specified o\_rodCoord object is snapped.

#### rodCoordToFloat

rodCoordToFloat(
 o\_rodCoordObj
 );end rodCoordToFloat
 => f\_value

Relative Object Design Coordinate Functions

# **Description**

Returns the rodCoord data in user unit as floating point number.

# **Arguments**

o\_rodCoordObj Specifies a valid rodCoord object.

#### **Value Returned**

f\_value A floating point number is returned. A SKILL error is returned if

the input value is invalid.

# **Example**

rodCoordToFloat(coord1)
=> 1.25

In this example, a floating point number is returned.

Relative Object Design Coordinate Functions

## rodCoordToInt

```
rodCoordToInt(
    o_rodCoordObj
    );end rodCoordToInt
    => x value
```

# **Description**

Returns the rodCoord data in user unit as a fixed number.

# **Arguments**

o\_rodCoordObj Specifies a valid rodCoord object.

#### **Value Returned**

 $f_{value}$  A fixed number is returned. A SKILL error is returned if the

input value is invalid.

# **Example**

```
rodCoordToFloat(coord1)
=> 1
```

In this example, a fixed number is returned.

Relative Object Design Coordinate Functions

# rodCoordToString

```
rodCoordToString(
    o_rodCoordObj
    [ g_dumpAR ]
    );end rodCoordToString
    => t_value
```

# **Description**

Returns a string containing the rodCoord data in user unit as floating number.

# **Arguments**

o\_rodCoordObj Specifies a valid rodCoord object.

 $g\_dumpAR$  If set to t, the string is dumped in the arithmetic resolution,

<number>@<ar> format. You can then pass this string to the
rodCoordParseString function to restore the rodCoord

object.

#### Value Returned

f\_value A string value returned. A SKILL error is returned if the input

value is invalid.

#### Example

```
rodCoordToFloat(coord1)
=> "1.25"
```

In this example, a string containing the rodCoord data in user unit as floating number is returned.

```
rodCoordToFloat(coord1 t)
=> "1.25@1000"
```

In this example, a string containing the rodCoord data is dumped as 1.25@1000.