```
u-boot-2009.11
```

make smdk2410_config

\$ diff -r u-boot-2009.11 u-boot-2009-build

只在 u-boot-2009-build/include 存在: asm

只在 u-boot-2009-build/include/asm-arm 存在: arch

只在 u-boot-2009-build/include/asm-arm 存在: proc

只在 u-boot-2009-build/include 存在: config.h

只在 u-boot-2009-build/include 存在: config.mk

1. in u-boot-2009-build/include directory

In -s asm-arm asm

asm -> asm-arm/

2. in u-boot-2009-build/include/asm-arm directory

In -s arch-s3c24x0 arch

arch -> arch-s3c24x0

3. in u-boot-2009-build/include/asm-arm directory

In -s proc-armv proc

```
proc -> proc-armv
```

4. generate u-boot-2009-build/include/conig.h

```
1. /* Automatically generated - do not edit */
2. #include <configs/smdk2410.h>
3. #include <asm/config.h>
```

5. generate u-boot-2009-build/include/conig.mk

```
    ARCH = arm
    CPU = arm920t
    BOARD = smdk2410
    VENDOR = samsung
    SOC = s3c24x0
```

in Makefile

```
unconfig:
    @rm -f $(obj)include/config.h $(obj)include/config.mk \
    $(obj)board/*/config.tmp $(obj)board/*/*/config.tmp \
    $(obj)include/autoconf.mk $(obj)include/autoconf.mk.dep

smdk2410_config : unconfig

mk \
    @$(MKCONFIG) $(@:_config=) arm arm920t smdk2410 samsung s3c24x0
```

即在执行command前先delete include/config.h and include/config.mk

@\$(MKCONFIG) \$(@:_config=) arm arm920t smdk2410 samsung s3c24x0

\$@ 即 smdk2410_config , \$(@:_config=) 把_config去掉。

mkconfig's Parameters: Target Architecture CPU Board [VENDOR] [SOC]

即Target = smdk2410

Architecture = arm

CPU = arm920t

Board = smdk2410

VENDOR = samsung

SOC = s3c24x0

create asm -> asm-arm/

arch -> arch-s3c24x0

proc -> proc-armv

include/conig.h

include/conig.mk

都在mkconfig shell script中。

关键是include/config.h中的

#include <configs/smdk2410.h>

echo "#include <configs/\$1.h>" >>config.h

生成。这里\$1 = smdk2410 (Target)

其实include/configs/smdk2410.h就在那里了。该文件中就是与该target相关的config。