open "devshell" for yocto development environment setting

bitbake -c devshell linux-granite-upstream

you have already in kernel source directory

```
    root@walterzh-Precision-T1650:~/work/2016-05-LSP/64-bit/tmp/work-shared/gran ite2v8/kernel-source# pwd
    /home/walterzh/work/2016-05-LSP/64-bit/tmp/work-shared/granite2v8/kernel-source
```

generate default .config
if you have default .config, you need not do it.

make ARCH=arm64 pegmatite_defconfig

```
1.
     root@walterzh-Precision-T1650:~/work/2016-05-LSP/64-bit/tmp/work-shared/gran
     ite2v8/kernel-source# make ARCH=arm64 pegmatite_defconfig
2.
     make[1]: Entering directory `/home/walterzh/work/2016-05-LSP/64-bit/tmp/work
     /granite2v8-poky-linux/linux-granite-upstream/4.2.8+gitAUTOINC+ceb442947a-r0
     /linux-granite2v8-standard-build'
3.
       HOSTCC scripts/basic/fixdep
       HOSTCC scripts/kconfig/conf.o
4.
       HOSTCC scripts/kconfig/zconf.tab.o
5.
       HOSTLD scripts/kconfig/conf
6.
7.
     # configuration written to .config
8.
9.
```

pegmatite_defconfig file in in arch/arm64/configs directory

- merge pegmatite64.cfg file into the default .config pegmatite64.cfg is in ccsgit/meta-granite/recipes-kernel/linux/files
- custimize configuration by hand

```
make ARCH=arm64 menuconfig
```

• if you don't know where could find the setting, please press "/" key, enter search dialog box as follow



in the dialog box, I search "regulator" setting

Note:

If you could not find the setting that you want to add or modify, please add the them into the specific Kconfig files. The menuconfig show the settings according to the Kconfig

