u-boot中的marvell pxa i2c的i2c read / write operation慢动作化了整个过程,对理解i2c协议很有帮助。

in u-boot/drivers/i2c/mv_i2c.c

```
1.
      int i2c_transfer(struct i2c_msg *msg)
 2.
 3.
              int ret;
4.
5.
              if (!msg)
6.
                       goto transfer error msg empty;
7.
8.
              switch (msg->direction) {
9.
              case I2C WRITE:
                      /* check if bus is not busy */
10.
11.
                       if (!i2c_isr_set_cleared(0, ISR_IBB))
12.
                               goto transfer_error_bus_busy;
13.
14.
                      /* start transmission */
                      writel(readl(&base->icr) & ~ICR START, &base->icr);
15.
16.
                      writel(readl(&base->icr) & ~ICR STOP, &base->icr);
                      writel(msg->data, &base->idbr);
17.
18.
                      if (msg->condition == I2C_COND_START)
19.
                               writel(readl(&base->icr) | ICR START, &base->icr);
20.
                       if (msg->condition == I2C COND STOP)
21.
                               writel(readl(&base->icr) | ICR_STOP, &base->icr);
22.
                       if (msg->acknack == I2C ACKNAK SENDNAK)
23.
                               writel(readl(&base->icr) | ICR ACKNAK, &base->icr);
24.
                       if (msg->acknack == I2C_ACKNAK_SENDACK)
25.
                               writel(readl(&base->icr) & ~ICR ACKNAK, &base->icr);
26.
                      writel(readl(&base->icr) & ~ICR_ALDIE, &base->icr);
27.
                      writel(readl(&base->icr) | ICR_TB, &base->icr);
28.
29.
                       /* transmit register empty? */
30.
                       if (!i2c_isr_set_cleared(ISR_ITE, 0))
31.
                               goto transfer_error_transmit_timeout;
32.
33.
                      /* clear 'transmit empty' state */
34.
                      writel(readl(&base->isr) | ISR ITE, &base->isr);
35.
                       /* wait for ACK from slave */
36.
37.
                       if (msg->acknack == I2C ACKNAK WAITACK)
38.
                               if (!i2c isr set cleared(0, ISR ACKNAK))
39.
                                       goto transfer_error_ack_missing;
40.
                       break;
41.
42.
              case I2C READ:
43.
44.
                       /* check if bus is not busy */
45.
                       if (!i2c isr set cleared(0, ISR IBB))
46.
                               goto transfer_error_bus_busy;
47.
48.
                       /* start receive */
49.
                      writel(readl(&base->icr) & ~ICR_START, &base->icr);
                      writel(readl(&base->icr) & ~ICR STOP, &base->icr);
50.
51.
                       if (msg->condition == I2C COND START)
                               writel(readl(&base->icr) | ICR_START, &base->icr);
52.
53.
                       if (msg->condition == I2C_COND_STOP)
```

```
54.
                                writel(readl(&base->icr) | ICR STOP, &base->icr);
                        if (msg->acknack == I2C ACKNAK SENDNAK)
 55.
 56.
                                writel(readl(&base->icr) | ICR_ACKNAK, &base->icr);
 57.
                        if (msg->acknack == I2C_ACKNAK_SENDACK)
 58.
                                writel(readl(&base->icr) & ~ICR ACKNAK, &base->icr);
 59.
                        writel(readl(&base->icr) & ~ICR ALDIE, &base->icr);
                        writel(readl(&base->icr) | ICR_TB, &base->icr);
 60.
 61.
                        /* receive register full? */
 62.
 63.
                        if (!i2c_isr_set_cleared(ISR_IRF, 0))
 64.
                                goto transfer_error_receive_timeout;
 65.
 66.
                       msg->data = readl(&base->idbr);
 67.
                        /* clear 'receive empty' state */
 68.
                        writel(readl(&base->isr) | ISR_IRF, &base->isr);
 69.
 70.
                        break;
 71.
               default:
 72.
                        goto transfer_error_illegal_param;
 73.
 74.
 75.
               return 0;
 76.
 77.
       transfer_error_msg_empty:
                        PRINTD(("i2c_transfer: error: 'msg' is empty\n"));
 78.
 79.
                        ret = -1; goto i2c_transfer_finish;
80.
 81.
       transfer_error_transmit_timeout:
 82.
                        PRINTD(("i2c_transfer: error: transmit timeout\n"));
 83.
                        ret = -2; goto i2c_transfer_finish;
 84.
 85.
       transfer_error_ack_missing:
 86.
                        PRINTD(("i2c_transfer: error: ACK missing\n"));
87.
                        ret = -3; goto i2c_transfer_finish;
 88.
 89.
       transfer_error_receive_timeout:
 90.
                        PRINTD(("i2c transfer: error: receive timeout\n"));
91.
                        ret = -4; goto i2c_transfer_finish;
 92.
 93.
       transfer_error_illegal_param:
 94.
                        PRINTD(("i2c_transfer: error: illegal parameters\n"));
95.
                        ret = -5; goto i2c_transfer_finish;
96.
97.
       transfer_error_bus_busy:
98.
                        PRINTD(("i2c transfer: error: bus is busy\n"));
99.
                        ret = -6; goto i2c_transfer_finish;
100.
101.
       i2c_transfer_finish:
102.
                        PRINTD(("i2c transfer: ISR: 0x%04x\n", readl(&base->isr)));
103.
                        i2c reset();
104.
                        return ret;
105.
       }
```

```
1. struct i2c_msg {
2.          u8 condition;
3.          u8 acknack;
4.          u8 direction;
5.          u8 data;
6. };
```

data field就是要传输的byte direction field决定是read or write acknack决定是发送ACK还是NACK condition field:

即transer的该byte需要附带START / STOP 信号还是没有(normal)

write one byte

```
1.
                      writel(readl(&base->icr) & ~ICR START, &base->icr);
                      writel(readl(&base->icr) & ~ICR_STOP, &base->icr);
 2.
                      writel(msg->data, &base->idbr);
 3.
                                                                               (2)
                      if (msg->condition == I2C_COND_START)
 4.
 5.
                               writel(readl(&base->icr) | ICR_START, &base->icr);
                      if (msg->condition == I2C COND STOP)
 6.
                               writel(readl(&base->icr) | ICR_STOP, &base->icr);
 8.
                      if (msg->acknack == I2C_ACKNAK_SENDNAK)
 9.
                               writel(readl(&base->icr) | ICR_ACKNAK, &base->icr);
                       if (msg->acknack == I2C_ACKNAK_SENDACK)
10.
11.
                               writel(readl(&base->icr) & ~ICR_ACKNAK, &base->icr);
                      writel(readl(&base->icr) & ~ICR_ALDIE, &base->icr);
12.
13.
                      writel(readl(&base->icr) | ICR_TB, &base->icr);
14.
                      /* transmit register empty? */
15.
16.
      if (!i2c_isr_set_cleared(ISR_ITE, 0))
17.
                               goto transfer_error_transmit_timeout;
18.
19.
                      /* clear 'transmit empty' state */
20.
                      writel(readl(&base->isr) | ISR_ITE, &base->isr);
21.
                      /* wait for ACK from slave */
22.
23.
                      if (msg->acknack == I2C_ACKNAK_WAITACK)
                                                                               8
24.
                               if (!i2c_isr_set_cleared(0, ISR_ACKNAK))
25.
                                       goto transfer_error_ack_missing;
```

1

清除control register中的start and stop signal产生条件

把要传输的byte放入data register

3

根据调用函数的要求来产生start / stop / ack /nack signal

4

清除ALD (Arbitration Loss Detected)

(5)

设置TB bit, 也就是启动传输

6

等待data register中的data被传输出去(ITE - IDBR Transmit Empty bit会告诉我们)

7

把ITE置位,这一步好像有点多余,因为上一不如果不是timeout则退出的条件就是ITE已被硬件置位。

8

在传输完一个bute后,查看是否要等待ACK signal

read one byte大同小异,就是查看IRF bit.

```
1.
 2.
       * i2c read: - Read multiple bytes from an i2c device
 3.
       * The higher level routines take into account that this function is only
4.
       * called with len < page length of the device (see configuration file)
5.
6.
 7.
       * @chip:
                      address of the chip which is to be read
8.
       * @addr:
                     i2c data address within the chip
9.
      * @alen:
                     length of the i2c data address (1..2 bytes)
                    where to write the data
10.
       * @buffer:
11.
       * @len:
                     how much byte do we want to read
       * @return: 0 in case of success
12.
13.
       */
14.
      int i2c_read(uchar chip, uint addr, int alen, uchar *buffer, int len)
15.
16.
              struct i2c_msg msg;
17.
              u8 addr_bytes[3]; /* lowest...highest byte of data address */
18.
19.
              PRINTD(("i2c read(chip=0x%02x, addr=0x%02x, alen=0x%02x, "
20.
                      "len=0x%02x)\n", chip, addr, alen, len));
21.
22.
              i2c_reset();
23.
24.
              /* dummy chip address write */
              PRINTD(("i2c_read: dummy chip address write\n"));
25.
26.
              msg.condition = I2C_COND_START;
              msg.acknack = I2C_ACKNAK_WAITACK;
27.
28.
              msg.direction = I2C WRITE;
29.
              msg.data = (chip << 1);
30.
              msg.data &= 0xFE;
31.
              if (i2c_transfer(&msg))
32.
                      return -1;
33.
34.
              /*
35.
               * send memory address bytes;
               * alen defines how much bytes we have to send.
36.
37.
               */
38.
              /*addr &= ((1 << CONFIG_SYS_EEPROM_PAGE_WRITE_BITS)-1); */</pre>
              addr_bytes[0] = (u8)((addr >> 0) & 0x000000FF);
39.
40.
              addr_bytes[1] = (u8)((addr >> 8) & 0x000000FF);
41.
              addr_bytes[2] = (u8)((addr >> 16) & 0x000000FF);
42.
43.
              while (--alen >= 0) {
44.
                      PRINTD(("i2c read: send memory word address byte %1d\n", alen));
45.
                      msg.condition = I2C COND NORMAL;
46.
                      msg.acknack = I2C_ACKNAK_WAITACK;
47.
                      msg.direction = I2C_WRITE;
48.
                      msg.data = addr_bytes[alen];
49.
                      if (i2c_transfer(&msg))
50.
                              return -1;
51.
              }
52.
53.
              /* start read sequence */
```

```
54.
              PRINTD(("i2c read: start read sequence\n"));
55.
              msg.condition = I2C_COND_START;
56.
              msg.acknack = I2C_ACKNAK_WAITACK;
57.
              msg.direction = I2C_WRITE;
58.
              msg.data
                         = (chip << 1);
59.
                          = 0x01;
              msg.data
60.
              if (i2c_transfer(&msg))
61.
                      return -1;
62.
              /* read bytes; send NACK at last byte */
63.
64.
              while (len--) {
                      if (len == 0) {
65.
66.
                              msg.condition = I2C_COND_STOP;
67.
                              msg.acknack = I2C_ACKNAK_SENDNAK;
68.
                      } else {
69.
                              msg.condition = I2C_COND_NORMAL;
70.
                              msg.acknack = I2C_ACKNAK_SENDACK;
71.
                      }
72.
73.
                      msg.direction = I2C_READ;
74.
                                = 0x00;
                      msg.data
75.
                      if (i2c transfer(&msg))
76.
                              return -1;
77.
78.
                      *buffer = msg.data;
79.
                      PRINTD(("i2c_read: reading byte (0x%08x)=0x%02x\n",
80.
                               (unsigned int)buffer, *buffer));
81.
                      buffer++;
82.
              }
83.
84.
              i2c reset();
85.
86.
              return 0;
87.
      }
```

这里的addr就是访问的i2c device内部的register的offset,其长度为alen。比如对256 bytes容量的 eeprom,一个byte的addr就够了,但对于几十K的则addr显然要2 bytes。

1

首先发送START signal,然后写写该i2c device的address

2(3)

这两步是发送i2c device内部的register地址,这是normal write,不要发送START signal

(4)

开始真正的读取了。

发送START signal, 然后还是写i2c device的address

(5)

如果读取的是最后一个byte,则需要发送STOP signal和NAK signal


ക്ര

如果读取的是不是最后一个byte,那么只发送ACK signal

(7)

读取收到的byte

比如要读取0x53 i2c device的从0x10 offset开始的10个bytes,那么整个时序大致是这样的



T2C davise for address 为 0x13
从 0x10 offset 处读取 10个 bytess
每岁卷/接心-个byte,客P要有 ACK/NAK对应

```
1.
 2.
       * i2c write: - Write multiple bytes to an i2c device
 3.
       * The higher level routines take into account that this function is only
4.
       * called with len < page length of the device (see configuration file)
5.
6.
7.
       * @chip:
                      address of the chip which is to be written
8.
       * @addr:
                      i2c data address within the chip
9.
      * @alen:
                     length of the i2c data address (1..2 bytes)
                    where to find the data to be written
10.
       * @buffer:
11.
       * @len:
                     how much byte do we want to read
       * @return: 0 in case of success
12.
13.
       */
14.
      int i2c_write(uchar chip, uint addr, int alen, uchar *buffer, int len)
15.
16.
              struct i2c_msg msg;
              u8 addr_bytes[3]; /* lowest...highest byte of data address */
17.
18.
19.
              PRINTD(("i2c write(chip=0x%02x, addr=0x%02x, alen=0x%02x, "
20.
                      "len=0x%02x)\n", chip, addr, alen, len));
21.
22.
              i2c_reset();
23.
24.
              /* chip address write */
              PRINTD(("i2c_write: chip address write\n"));
25.
26.
              msg.condition = I2C_COND_START;
              msg.acknack = I2C_ACKNAK_WAITACK;
27.
28.
              msg.direction = I2C WRITE;
29.
              msg.data = (chip << 1);
30.
              msg.data &= 0xFE;
31.
              if (i2c_transfer(&msg))
32.
                      return -1;
33.
34.
              /*
               * send memory address bytes;
35.
               * alen defines how much bytes we have to send.
36.
               */
37.
38.
              addr_bytes[0] = (u8)((addr >> 0) & 0x000000FF);
              addr_bytes[1] = (u8)((addr >> 8) & 0x000000FF);
39.
40.
              addr bytes[2] = (u8)((addr >> 16) \& 0x0000000FF);
41.
42.
              while (--alen >= 0) {
43.
                      PRINTD(("i2c_write: send memory word address\n"));
44.
                      msg.condition = I2C_COND_NORMAL;
                      msg.acknack = I2C_ACKNAK_WAITACK;
45.
46.
                      msg.direction = I2C_WRITE;
47.
                      msg.data
                                 = addr_bytes[alen];
48.
                      if (i2c_transfer(&msg))
49.
                              return -1;
              }
50.
51.
52.
              /* write bytes; send NACK at last byte */
              while (len--) {
53.
```

```
54.
                       PRINTD(("i2c_write: writing byte (0x%08x)=0x%02x\n",
                               (unsigned int)buffer, *buffer));
55.
56.
57.
                       if (len == 0)
58.
                               msg.condition = I2C_COND_STOP;
59.
                       else
60.
                               msg.condition = I2C_COND_NORMAL;
61.
62.
                       msg.acknack = I2C_ACKNAK_WAITACK;
63.
                       msg.direction = I2C_WRITE;
64.
                       msg.data
                                  = *(buffer++);
65.
66.
                       if (i2c_transfer(&msg))
                               return -1;
67.
              }
68.
69.
70.
              i2c_reset();
71.
72.
              return 0;
73.
```

1

首先发送START, 然后是i2c device address

23

发送offset


(4)

由于还是write,不像read一样,operation有所改变,所以这里在write data前无需再次发送i2c device address

如果是最后一个发送的data,则要发送STOP signal

(5)

不是最后一个byte,无需其他signal



No Start or Stop Condition

Data byte	ACK/
	NAK

Start Condition

START	Target Slave Address	R/nW	ACK/ NAK
-------	----------------------	------	-------------

Stop Condition

Data Byte	ACK/ NAK	STOP
-----------	-------------	------

i2c_read() / i2c_write()中首先write i2c device adress就是上面的Start Condition。 发送和接受data(非最后一个)则是NO Start or Stop Condition 而发送或接收最后一个byte data则是Stop Condition。