u-boot code是SMP-aware吗?

应该不是,但???

in arch/arm/cpu/armv7/pegmatite/smp\_init.S

```
.ltorg
 2.
        .globl lowlevel_init
                  .type lowlevel_init, %function
       lowlevel_init:
 6.
                  @ Save link register in r3
                  mov r3, lr
 8.
                  mrrc p15, 1, r0, r1, c15 @ Read CPUECTRL register orr r0, r0, \#(1<<6) @ Turn on SMP mcrr p15, 1, r0, r1, c15 @ Write CPUECTRL register
 9.
10.
11.
12.
13.
                  mov
                           pc, r3
                                                             @ return
```

读出CP15 coprocessor的c15 register,对第6位置位。从comment看是"Turn on SMP"。

in "arm\_architecture\_reference\_v7A\_v7R\_manual",

## G.7.22 c15, IMPLEMENTATION DEFINED

As in ARMv7, CP15 c15 is reserved for IMPLEMENTATION DEFINED use. Typically, it is used for processor-specific runtime and test features.

在Marvell自己的6270 / 6220 Programmer Guide上没有找到任何关于CP15 c15 register的描述。本来这应该是Marvell的责任。