



The logo for the xStation Installation Guide. It features the word "xStation" in a large, bold, dark gray sans-serif font. A blue "X" character is positioned to the left of the "x". To the right of "Station", there is a horizontal ellipsis (...). Below "xStation", the words "Installation Guide" are written in a smaller, dark gray sans-serif font. On either side of the text are three circular icons: a black circle with a white dot at the top-left, a black circle with a green dot in the center, and a black circle with a blue dot at the top-right.

xStation

Installation Guide

LATE PU-8

xStation ODE installation guide for LATE PU-8 Playstation 1 motherboards

The LATE PU-8 mainboards can be found in:


Most SCPH-1001 and SCPH-1002
Most SCPH-3000
Most SCPH-3500
All SCPH-5000

Why the mainboard called “LATE”, and is there an “EARLY”?

Literally, yes! The PU-8 came in two major flavors (EARLY and LATE). You can check which mainboard you have by looking for these marks:

1. Mainboard labels

- EARLY mainboards are labeled PU-8-**11**
- LATE mainboards are labeled PU-8-**21/22/23** or **41**



EARLY PU-8

labeled as: X-XXX-XXX-11




LATE PU-8

labeled as: X-XXX-XXX-23

2. The GPU and especially the VRAM area on the top side of the mainboard is different, see picture below




EARLY PU-8
2 VRAM blocks near the GPU




LATE PU-8
1 big VRAM block near the GPU

3. The Mechacon controller chip has different sizes, see picture below



EARLY PU-8
big Mechacon controller chip
(on the right)




LATE PU-8
smaller Mechacon controller chip
(on the right)

When you are sure that you have a LATE PU-8 you can follow this guide.

1. You have to disassemble the Playstation 1 completely to get to the mainboard. **PLEASE REMOVE ALL CABLES FROM THE POWER SUPPLY. MAKE SURE THAT THE POWER CORD IS DISCONNECTED!**

2. Search for IC309

- IC309 is labeled CXD2510Q. You will find it in the upper left corner. See picture below




(Remember the purple area as well. We will get to it later in this guide. For now we'll focus on the red area.)

3. IC309 (CXD2510Q) needs to have the following pins lifted:

44, 63, 66 and 69.


Please make sure that only the shown pins are lifted.




4. Please be careful not to damage the mainboard when lifting pins. Use a needle or x-acto knife and a fine soldering tip to simply touch the pin and apply some heat, then gently lift it from underneath using the needle or blade.




5. Please make sure that you have lifted the pins completely. They should not have contact with the motherboard, nor with each other.




6. Now we'll get to the purple area on the mainboard top side. In this area you can see the 67mhz oscillator. You need to desolder/remove the small resistor and the filter. They are marked in the picture below.



We are now finished with the top side of the mainboard; turn it bottom side up. Here, 3 resistors have to be desoldered and then the Quick Solder Board (QSB) installed.




7. First we need to desolder the 3 resistors as shown




desoldered resistors

8. Place the QSB on the mainboard as shown, the yellow markings help with the alignment.




9. Connect the IO16 pad from the QSB to the marked location. Please ensure that the cable does not run over the metal areas where the shield could crush it.




It should look like this:




10. The difficult part is now finished, but the lower part of the console shell still needs to be prepared. Clip off the small plastic pin marked below in red. This is necessary to prevent the flex cable from pinching and taking damage during installation.



11. Connect the flex cable to the cable holder on the QSB (blue side up) and close the cable holder. When this is done you can fold the flex cable to the right, as shown.




12. To ensure that the cable sits correctly route it through the slot on the top shield.




13. Prepare the PCB and push all 3 spacers into the xStation board. If you look at it from above they can be found in:

- the lower middle (right next to the ESP32)
- the upper right corner
- the upper left corner.


(The spacers are a bit too long for installation in a PU-8. We recommend that you shorten them a bit, so that the xStation pcb rests securely.)



14. Now grab the other side from the flex cable and carefully connect it to the cable holder on the xStation. When it is done you have to fold the flexcable a bit. Folding it like this is best:




16. Mount the xStation on the posts of the original Disc Drive. It should look like this:




When everything is ready, you have to reassemble the Playstation 1 in reverse order.

A freshly installed xStation:



Initial Software Steps

17. Format a microSD card to either exFAT or FAT32.
18. Create a folder on your microSD card named “00xstation” (without quotation marks), then download the latest update files and copy the files **update.bin** and **loader.bin** to the 00xstation folder.
<https://github.com/x-station/xstation-releases>



From now on, your Playstation will boot right into the xStation loader!