

Compilation and programming system

compile the whole system

Check the build environment

Specify the configuration file

```
./setup_config.sh ./configs/nvr/i2m/8.2.1/spinand.glibc.011a.128
```

production system

Release kernel related resources (not necessary, only need to perform this step when changing to the kernel part config) Nand Flash:

```
./release.sh -k ${kernel_path} -b 011A -p nvr -f spinand -c i2m -l glibc -v 8.2.1;
```

Execute: make image (project project does not support multi-threaded compilation)

Generate image, directory: project/image/output/images After getting the generated image, refer to the burning document/master making document and burn it to the board.

Flash image

programming in uboot

