

Hdmi Q&A

Q1: How to output the sensor to HDMI for display?

You can refer to the panel in the mi_demo directory, and use the screen parameters according to the README configuration in the directory.

Q2: [ST_ResetHdmiDispFlow 1790]exec function failed, error: a0222007 is reported when using HDMI?

Check whether the input HDMI data format is correct, such as SCL->HDMI, then stSclOutputParam.ePixelFormat should set the correct format.

Q3: For HDMI display, the GetSinkInfo function obtains the physical resolution of the display screen. For a 4K display, the NativeTimingType value given is 48, but the MI_HDMI_TimingType_e provided in the SDK is only up to 42?

It seems that the header file has not been updated. The linked library and header file must be unified. Then check the sdk update status to see if the link library and header file are not correct after the update.

Q4: When switching HDMI display, different resolutions are indeed detected in the printing information, and the configuration is also issued. There is no error prompt in each printing information. The callback function is all passed, but the display is not activated?

You can print the debugging information under /proc to see if the data flow is normal, for example, see if there is data in the recvbuff of disp. For detailed debug information, see the relevant documents on sigdoc.

Q5: When the HDMI module switches the resolution (for example, from 4K to 1080P), the function prompts after SetAttr are all successful. Why is the display not activated?

The correct switching resolution process is: stop getattr setattr start, if the picture does not switch according to this process, you can check the debug information of the corresponding disp device under cat /proc

 Q6: How to debug HDMI drive capability?

Set Bank 145A_22/23 = 0x1414 to Bank 145A_22/23 = 0x0000 and try again. PS: After HDMI is up, read the register again. HDMI Default Bank 145A_22/23 = 0x1414 Bank 145A_22 6bit 【5:0】 Data0 Bank 145A_22 6bit 【13:8】 Data1 Bank 145A_23 6bit 【5:0】 Data2 Bank 145A_23 6bit 【13:8】 CLK driver current 0.5mA(1 [0]+2[1]+4[2]+8[3]+16[4]+32*[5]).