

System

Q1: After compiling the kernel, how to upgrade the kernel of the board?

Copy the ulmage.xz file generated after compiling the kernel to the image, rename the kernel, replace the original kernel file, and then upgrade it through tftp or ISP tools.

Q2: How to determine the config and dts used by the kernel through the defconfig of the currently compiled project?

All current config files are stored in the project/configs/defconfigs/ directory. Open the used config file and you can see that the configuration specified by the CONFIG_KERNEL_CONFIG parameter is the configuration used by the current kernel, such as:

```
tianhui.he@xm10bc6401:~/codes/sourcecode/project$ cat configs/defconfigs/
dispcam_m6_spinand.glibc-9.1.0-squashfs.016a.512x512.bga2.demo_defconfig
| grep "CONFIG_KERNEL_CONFIG"
```

```
CONFIG_KERNEL_CONFIG="mercury6-ssc016a-s01a-spinand-dispcam_defconfig"
```

Or you can also see a line of log when making image: linux-config:"mercury6-ssc016a-s01a-spinand-dispcam_defconfig" Open the defconfig used in the kernel directory, search for the value corresponding to CONFIG_SS_DTB_NAME is the dts file name (suffix ".dts") used, Such as:

```
tianhui.he@xm10bc6401:~/codes/sourcecode/kernel$ cat arch/arm/configs/mer
cury6-ssc016a-s01a-spinand-dispcam_defconfig | grep "CONFIG_SS_DTB_NAME"
```

```
CONFIG_SS_DTB_NAME="mercury6-ssc016a-s01a-dispcam"
```