

Miyoo Mini

[Jump to bottom](#)

TriForce edited this page Apr 22, 2022 · 62 revisions



Current Version

v1.6 2022-04-19

Note: Firmware is not open-source, the updates came directly from the manufacturer. Other stuff like front-end, themes, emus and apps still can be modified by the community.

Stock Firmware

- Miyoo Official Updates ([ENG](#) | [CN](#))
- Miyoo Firmware Updates Backup ([Download](#))
- Update Guide ([View](#))
- Miyoo Mini SDK ([Download](#))

Custom Packages

Download	Guides	Dev / Port by
Onion OS	Wiki	jimgraygit

Download	Guides	Dev / Port by
Better SD Card	Wiki	nicosensei
Taki SD Card	Wiki	Takiiaiiiiii

Apps and Homebrew

Download	Dev / Port by
RTC Emulator	lucamadd
GMU Music Player	TechDevangelist
DinguxCommander	shauninman
SDL 2048	miyoo
SDL Pal	miyoo

Others

Download	Description
Language Pack	Community updates for firmware translation files

Firmware Update Guide

Important Note: Check the official site before update, sometimes there are extra steps or additional notes.

MIYOO MINI FIRMWARE UPGRADE GUIDE

Part 1 - Preparation


1- DOWNLOAD THE LATEST FIRMWARE FROM [HTTPS://LEMIYOO.CN/UPGRADE/](https://lemiyoo.cn/upgrade/)

*Always check that you are downloading the latest firmware.



2- COPY THE MIYOO283_FW.IMG FILE TO THE ROOT OF YOUR MICRO SD CARD.

*Backup any important games/saves/bios from this micro sd card onto your computer.



Part 2 - Installation

- 1- TURN OFF THE MIYOO MINI.
- 2- TAKE OUT THE BATTERY OF THE DEVICE.
- 3- PUT THE MICRO SD CARD INTO THE MIYOO MINI.
- 4- PLUG THE MIYOO MINI INTO A CHARGER WITH A USB-C TO USB-A CABLE.

*Make sure the power plug is no more than 5V to avoid voltage problems.
 *Do not use a USB-C cable with USB-C heads on both sides of the charging cable.
 *Be careful not to lose power during the upgrade process or it may brick.
 *Do not turn on the device or unplug it during the upgrade process.



KEEP YOUR EYES ON THE DEVICE



WAIT



Part 3 - Clean Up

- 1- PLUG THE MICRO SD CARD BACK INTO THE COMPUTER AND PLUG THE BATTERY BACK INTO THE MIYOO MINI.**
- 2- DELETE THE MIYOO283_FW.IMG FROM THE MICRO SD CARD.**
- 3- GO TO THE ORIGINAL FIRMWARE DOWNLOAD AND COPY THE FILES FROM THE TF CARD FOLDER TO THE ROOT OF YOUR MICRO SD CARD.**



*It will take some time to load after a new firmware upgrade.

AFTER UPGRADING PLEASE CONSIDER COMMUNITY UPDATES SUCH AS ONION OS AND OTHERS TO COME.

BY: PIXELSHIFT
SP THANKS: TNGLIKER

► Show Alternative Guide (Written)

► Change log

Console Specs

- Sigmastar SSD202D Dual Core Cortex-A7 1.2GHz ([Data Sheet](#))
- 128MB DDR3 RAM
- 16MB ROM (SPI)
- 32GB TF Card storage (up to 128GB)
- 2.8 inch IPS screen 640x480
- Weight 110g
- 3.7V 1900mAh 5V/1A Battery
- USB-C Charge only

Developer Resources

The next stuff is some developer logs and useful info. To access the required tools to build apps click [here](#)

- ▶ GPIO Log
- ▶ Boot Log
- ▶ U-Boot Env
- ▶ PCB Pictures

This wiki was made for **stock & custom firmware** usage and tools. If we missed something or if you have a question/suggestion, please send us a message in our *Discord* server [here](#)

▶ Pages 27

Miyoo Mini

- [Overview](#)
- [Stock Firmware](#)
- [Firmware Update Guide](#)
- [Custom Packages and Apps](#)
- [Developer Resources](#)

Miyoo CFW

- [Overview](#)
- [Custom Firmware Setup](#)
- [Build Source](#)
- [Making Games](#)
- [Bug Reporting](#)
- [Discussions Forums](#)

Applications

- [Emulator Info](#)
- [Homebrew Info](#)
- [DosBox Setup](#)
- [RetroArch Setup](#)
- GameBoy
 - [GamBatte](#)
 - [OhBoy](#)
 - [GPSP](#)
- Arcade
 - [MAME4All](#)
 - [GnGeo](#)
 - [FBA-A320](#)

- PlayStation
 - [PCSX-ReARMed](#)

Themes

- [Fontixel](#)
- [NewComicBook](#)
- [CoverFlow](#)

Modding

- [Sound Noise Fix](#)
- [Light Bleed Fix](#)
- [Ghost Key Fix](#)
- [Shoulder Buttons](#)
- [Improve Directional Pad](#)

Clone this wiki locally

<https://github.com/TriForceX/MiyooCFW.wiki.git>

