

MODULE: 1756-OB32 CHASSIS: C2 SLOT: 6 TYPE: DO TERMINAL STRIP: C2S06-X1 POINTS: 32														RATING: 24V DC SINK/SOURCE PANEL: CA1 / MOTOR CONTROL													
PT	PLC ADDR	TB PIN		INTERNAL / BARRIER	FIELD DEST	TAG NUMBER	SERVICE / INSTRUMENT DESCRIPTION							PT	PLC ADDR	TB PIN		INTERNAL / BARRIER	FIELD DEST	TAG NUMBER	SERVICE / INSTRUMENT DESCRIPTION						
01	C2S06,01	X1:02		RELAY 700-HL (24VDC)	JB-402	XV-40204B	Jet Cooker P&ID: 325-01-402-PD-01							17	C2S06,17	X1:18		RELAY 700-HL (24VDC)	JB-602	XV-60214	Steam feed to Spray dryer P&ID: 325-01-600-PD-03						
02	C2S06,02	X1:03		RELAY 700-HL (24VDC)	JB-402	XV-40204C	Jet Cooker P&ID: 325-01-402-PD-01							18	C2S06,18	X1:19		RELAY 700-HL (24VDC)	JB-602	XV-60241	Gas On/Off Valve for Bag House Isolation.. P&ID: 325-01-600-PD-05						
03	C2S06,03	X1:04		RELAY 700-HL (24VDC)	JB-402	XV-40205A	Jet Cooker P&ID: 325-01-402-PD-02							19	C2S06,19	X1:20		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
04	C2S06,04	X1:05		RELAY 700-HL (24VDC)	JB-402	XV-40205B	Jet Cooker P&ID: 325-01-402-PD-02							20	C2S06,20	X1:21		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
05	C2S06,05	X1:06		RELAY 700-HL (24VDC)	JB-402	XV-40205C	Jet Cooker P&ID: 325-01-402-PD-02							21	C2S06,21	X1:22		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
06	C2S06,06	X1:07		RELAY 700-HL (24VDC)	JB-402	XV-40205D	Jet Cooker P&ID: 325-01-402-PD-02							22	C2S06,22	X1:23		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
07	C2S06,07	X1:08		RELAY 700-HL (24VDC)	JB-402	XV-40205F	Jet Cooker P&ID: 325-01-402-PD-02							23	C2S06,23	X1:24		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
08	C2S06,08	X1:09		RELAY 700-HL (24VDC)	JB-402	XV-40222	Jet Cooker P&ID: 325-01-402-PD-02							24	C2S06,24	X1:25		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
09	C2S06,09	X1:10		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							25	C2S06,25	X1:26		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
10	C2S06,10	X1:11		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							26	C2S06,26	X1:27		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
11	C2S06,11	X1:12		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							27	C2S06,27	X1:28		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
12	C2S06,12	X1:13		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							28	C2S06,28	X1:29		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
13	C2S06,13	X1:14		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							29	C2S06,29	X1:30		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
14	C2S06,14	X1:15		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							30	C2S06,30	X1:31		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
15	C2S06,15	X1:16		RELAY 700-HL (24VDC)	JB-402	SPARE	Spare I/O Channel							31	C2S06,31	X1:32		RELAY 700-HL (24VDC)	JB-602	SPARE	Spare I/O Channel						
16	C2S06,16	X1:17		RELAY 700-HL (24VDC)	JB-602	XS-60240B	Fan Command for BGHS-21 (Bag House Air P.. P&ID: 325-01-600-PD-05								C2S06,00	X1:--		RELAY 700-HL (24VDC)	JB-402	XV-40203F	Jet Cooker P&ID: 325-01-402-PD-02						
														</													