






0 · Base (Enthium)





1 · Numbers & Symbols



2 · Navigation & Editing



3 · System & Function



Navigation modes

The EXTEND layer cursor cluster, with Select / Delete / Tabs sub-modes layered on top.

Navigation Engage Hold the EXTEND key Exit Release (or Layer Lock) <i>base</i>	Select Engage Hold Exit Release (hold-only) <i>Sel</i>	Delete Engage Hold Exit Release (hold-only) <i>DI</i> ☹	Tabs Engage Hold Exit Release (hold-only) <i>hold</i>
--	--	---	---

Key	Navigation	Select	Delete	Tabs
◀	Char left	Select char left	Backspace	Previous tab
▶	Char right	Select char right	Forward-delete	Next tab
▲	Line up	Select line up	·	New tab
▼	Line down	Select line down	·	Close tab
◀◀	Word back	Select word back	Delete word back	Page back
▶▶	Word forward	Select word forward	Delete word forward	Page forward
⏮	Line start	Select to line start	Delete to line start	·
⏭	Line end	Select to line end	Delete to line end	·
PgUp	Page up	Select page up	·	·
PgDn	Page down	Select page down	·	·
●	·	·	·	Reopen tab

· no special role in that mode — the key keeps its Navigation behaviour. Tab actions are OS-aware (Firefox & Chrome, macOS & Linux).
Select and Delete are mutually exclusive — while Delete is held the Select key is inert.

Compose & diacritics

Press Shift + Space on the base layer to arm Compose, then press one key.

Arm

Shift + Space from the base layer

Cancel

Esc any other key types as usual

Key	Produces	Example
	DEAD KEYS — press, then type the base letter	
e	´ acute	Shift + Space e e → é
a	` grave	Shift + Space a e → è
u	¨ diaeresis	Shift + Space u e → ë
o	^ circumflex	Shift + Space o e → ê
	DIRECT — prints the character immediately	
c	ç	Shift + Space c → ç
n	ñ	Shift + Space n → ñ
w	€ euro	Shift + Space w → €

Dead keys wait for a base letter, so the same accent works on any vowel (é á í ó ú · è à ì ò ù ...). Accents are OS-aware (macOS & Linux).