
Lecture 11: Feedforward Control Zero Phase Error Tracking

Big picture
Stable pole-zero cancellation
Phase error
Zero phase error tracking

Big picture

why are we learning this:




- two basic control problems: tracking (the reference) and regulation (against disturbances)
- feedback control has performance limitations
- For tracking r(k), ideally we want

$$G_{\text{closed}}\left(z^{-1}\right) = 1$$

which is **not attainable** by feedback. We thus need **feedforward** control.

Big picture



notation:

$$G_{\mathrm{closed}}\left(z^{-1}\right) = \frac{z^{-d}B_{c}\left(z^{-1}\right)}{A_{c}\left(z^{-1}\right)}$$

where

$$B_c(z^{-1}) = b_{c0} + b_{c1}z^{-1} + \dots + b_{cm}z^{-m}, \ b_{co} \neq 0$$


 $A_c(z^{-1}) = 1 + a_{c1}z^{-1} + \dots + a_{cn}z^{-n}$

 $ightharpoonup z^{-1}$: one-step delay operator. $z^{-1}r(k) = r(k-1)$

Lecture 11: Feedforward Control, Zero Phase Error Tracking

ME233 11-2

Big picture



one naive approach: to let y(k) track $y_d(k)$, we can do

$$r(k) = G_{\text{closed}}^{-1}(z^{-1}) y_d(k) = \frac{z^d A_c(z^{-1})}{B_c(z^{-1})} y_d(k) = \frac{A_c(z^{-1})}{B_c(z^{-1})} y_d(k+d) \quad (1)$$

- **causality**: (1) requires knowledge of $y_d(k)$ for at least d steps ahead (usually not an issue)
- **stability**: poles of $G_{\text{closed}}^{-1}(z^{-1})$, i.e., zeros of $G_{\text{closed}}(z^{-1})$, must be all stable (usually an issue)
- **robustness**: the model $G_{\text{closed}}\left(z^{-1}\right)$ needs to be accurate

The cancellable parts in $G_{\text{closed}}\left(z^{-1}\right)$

$$y_d(k) \longrightarrow \overline{\text{Feedforward}} \longrightarrow \overline{G_{\text{closed}}(z^{-1})} = \frac{z^{-d}B_c(z^{-1})}{A_c(z^{-1})} \longrightarrow y(k)$$

- $G_{
 m closed}(z^{-1})$ is always stable \Rightarrow $A_c(z^{-1})$ can be fully canceled
- ▶ $B_c(z^{-1})$ may contain *uncancellable parts* (zeros on or outside the unit circle)
- partition $G_{\text{closed}}(z^{-1})$ as

$$G_{\text{closed}}(z^{-1}) = \frac{z^{-d}B_c(z^{-1})}{A_c(z^{-1})} = \frac{z^{-d}B_c^+(z^{-1})}{A_c(z^{-1})} \underbrace{B_c^-(z^{-1})}_{\text{Cancellable uncancellable}}$$
(2)

Lecture 11: Feedforward Control, Zero Phase Error Tracking

ME233 11-4

Stable pole-zero cancellation

$$y_d(k) \longrightarrow Feedforward \longrightarrow G_{closed}(z^{-1}) = \frac{z^{-d}B_c(z^{-1})}{A_c(z^{-1})} \longrightarrow y(k)$$

feedforward via stable pole-zero cancellation:

$$G_{\text{spz}}(z^{-1}) = \frac{z^d A_c(z^{-1})}{B_c^+(z^{-1})} \frac{1}{B_c^-(1)}$$
(3)

where $B_c^-\left(1
ight)=\left.B_c^-\left(z^{-1}
ight)
ight|_{z^{-1}=1}$

▶ $B_c^-(1)$ makes the overall DC gain from $y_d(k)$ to y(k) to be one:


$$G_{y_d o y}\left(z^{-1}\right) = G_{\text{spz}}\left(z^{-1}\right) G_{\text{closed}}\left(z^{-1}\right) = \frac{B_c^-(z^{-1})}{B_c^-(1)}$$

• example: $B_c^-(z^{-1}) = 1 + z^{-1}$, $B_c^-(1) = 2$, then

$$G_{y_d \to y}(z^{-1}) = \frac{1+z^{-1}}{2}$$
: a moving-average low-pass filter

Stable pole-zero cancellation

properties of $G_{y_d \to y}(z^{-1}) = \frac{1+z^{-1}}{2}$:



- there is always a phase error in tracking
- example: if $y_d(k) = \alpha k$ (a ramp signal)

$$y(k) = G_{y_d \to y}(z^{-1}) y_d(k) = \alpha k - \frac{\alpha}{2}$$

which is always delayed by a factor of $\alpha/2$

Lecture 11: Feedforward Control, Zero Phase Error Tracking

ME233 11-6

Zero Phase Error Tracking (ZPET)

Feedforward
$$G_{closed}(z^{-1}) = \frac{z^{-d}B_c^+(z^{-1})B_c^-(z^{-1})}{A_c(z^{-1})}$$

Zero Phase Error Tracking (ZPET): extend (3) by adding a $B_c^-(z)$ part

$$G_{\text{ZPET}}(z^{-1}) = \frac{z^d A_c(z^{-1})}{B_c^+(z^{-1})} \frac{B_c^-(z)}{B_c^-(1)^2}$$
(4)

where
$$B_c^-(z) = b_{c0}^- + b_{c1}^- z + \dots + b_{cs}^- z^s$$
 if $B_c^-(z^{-1}) = b_{c0}^- + b_{c1}^- z^{-1} + \dots + b_{cs}^- z^{-s}$

• overall dynamics between y(k) and $y_d(k)$:

$$G_{y_d \to y}(z^{-1}) = G_{\text{closed}}(z^{-1}) G_{\text{ZPET}}(z^{-1}) = \frac{B_c^-(z)B_c^-(z^{-1})}{\left[B_c^-(1)\right]^2}$$
 (5)

Zero Phase Error Tracking (ZPET)

understanding (5):

the frequency response always has zero phase error:

$$B_c^-\left(e^{j\omega}\right)=\overline{B_c^-\left(e^{-j\omega}\right)}$$
 (a complex conjugate pair)

▶ $B_c^-(1)^2$ normalizes $Gy_d \to y$ to have unity DC gain:

$$G_{y_d \to y}\left(e^{-j\omega}\right)\big|_{\omega=0} = \frac{B_c^-(e^{j\omega})\big|_{\omega=0} B_c^-(e^{-j\omega})\big|_{\omega=0}}{\left[B_c^-(1)\right]^2} = \frac{\left[B_c^-(1)\right]^2}{\left[B_c^-(1)\right]^2}$$

• example: $B_c^-(z^{-1}) = 1 + z^{-1}$, then

$$G_{y_d \to y}(z^{-1}) = \frac{(1+z)(1+z^{-1})}{4}$$

- if $y_d(k) = \alpha k$, then $y(k) = \alpha k!$
- fact: ZPET provides perfect tracking to step and ramp signals at steady state (see ME 233 course reader)

Lecture 11: Feedforward Control, Zero Phase Error Tracking

ME233 11-8

Zero Phase Error Tracking (ZPET)

Example: $B_c^-(z^{-1}) = 1 + 2z^{-1}$

$$G_{y_d \to y}(z^{-1}) = \frac{(1+2z)(1+2z^{-1})}{9} = \frac{2z+5+2z^{-1}}{9}$$




Figure: Bode Plot of $\frac{2z+5+2z^{-1}}{9}$

Implementation

 $ightharpoonup z^d$ is not causal \Rightarrow do instead

$$r(k) = \left[\frac{A_c(z^{-1})}{B_c^+(z^{-1})} \frac{B_c^-(z)}{B_c^-(1)^2}\right] y_d(k+d)$$

▶ $B_c^-(z) = b_{c0}^- + b_{c1}^- z + \cdots + b_{cs}^- z^s$ is also not causal \Rightarrow do instead

$$r(k) = \left[\frac{A_c(z^{-1})}{B_c^+(z^{-1})} \frac{z^{-s} B_c^-(z)}{B_c^-(1)^2} \right] y_d(k+d+s)$$

▶ at time k, requires $y_d(k+d+s)$: d+s steps preview of the desired output

Lecture 11: Feedforward Control, Zero Phase Error Tracking


ME233 11-10

Implementation

Example:

$$G_{\text{closed}}(z^{-1}) = \frac{z^{-1}(1+2z^{-1})}{3}$$

without feedforward control:




Implementation

Example:

$$G_{\text{closed}}(z^{-1}) = \frac{z^{-1}(1+2z^{-1})}{3}$$

with ZPET feedforward:



Lecture 11: Feedforward Control, Zero Phase Error Tracking

ME233 11-12

Implementation

ZPET extensions:

standard form:

$$G_{\text{ZPET}}(z^{-1}) = \frac{z^d A_c(z^{-1})}{B_c^+(z^{-1})} \frac{B_c^-(z)}{B_c^-(1)^2}$$

extended bandwidth (ref: B. Haack and M. Tomizuka, "The effect of adding zeros to feedforward controllers," ASME J. Dyn. Syst. Meas. Control, vol. 113, pp. 6-10, 1991):

$$G_{\mathsf{ZPET}}(z^{-1}) = \frac{z^d A_c(z^{-1})}{B_c^+(z^{-1})} \frac{B_c^-(z)}{B_c^-(1)^2} \frac{\left(z^{-1} - b\right)(z - b)}{\left(1 - b\right)^2}, \ 0 < b < 1$$

remark: $(z^{-1} - b)(z - b)/(1 - b)^2$, 0 < b < 1 is a high-pass filter with unity DC gain