Lecture 14: Disturbance Observer

Big picture

Disturbance and uncertainties in mechanical systems:

- system models are important in design: e.g., in ZPET, observer, and preview controls
- inevitable to have uncertainty in actual mechanical systems
- system is also subjected to disturbances

Related control design:

- robust control
- adaptive control

Disturbance observer is one example of robust control.


Disturbance observer (DOB)

 introduced by Ohnishi (1987) and refined by Umeno and Hori (1991)

System:

$$V(s) = G_{uv}(s)[U(s) + D(s)]$$


Assumptions: u(t)-input; d(t)-disturbance; v(t)-output; $G_{uv}(s)$ -actual plant dynamics between u and v; $G_{nv}^n(s)$ -nominal model



Lecture 14: Disturbance Observer

ME233 14-2

DOB intuition



if Q(s) = 1, then

$$U(s) = U^{*}(s) - \left[\frac{G_{uv}(s)}{G_{uv}^{n}(s)}(U(s) + D(s)) + \frac{1}{G_{uv}^{n}(s)}\Xi(s) - U(s)\right]$$


$$\Rightarrow U(s) = \frac{G_{uv}^{n}(s)}{G_{uv}(s)}U^{*}(s) - D(s) - \frac{1}{G_{uv}(s)}\Xi(s)$$

$$V(s) = G_{uv}^{n}(s)U^{*}(s) - \Xi(s)$$

i.e., dynamics between $U^*(s)$ and V(s) follows the nominal model; and disturbance is rejected

Lecture 14: Disturbance Observer

DOB intuition



if Q(s) = 1, then


$$\hat{D}(s) = \left(\frac{G_{uv}(s)}{G_{uv}^n(s)} - 1\right)U(s) + \frac{1}{G_{uv}^n(s)}\Xi(s) + \frac{G_{uv}(s)}{G_{uv}^n(s)}D(s)$$
 $pprox \frac{1}{G_{uv}(s)}\Xi(s) + D(s) \text{ if } G_{uv}(s) = G_{uv}^n(s)$

i.e., disturbance D(s) is estimated by $\hat{D}(s)$.

Lecture 14: Disturbance Observer

ME233 14-4

DOB details: causality



It is impractical to have Q(s) = 1.


e.g., if $G_{uv}(s) = 1/s^2$, then $1/G_{uv}^n(s) = s^2$ (not realizable) Q(s) should be designed such that $Q(s)/G_{nv}^n(s)$ is causal. e.g. (low-pass filter)

$$Q(s) = \frac{1 + \sum_{k=1}^{N-r} a_k (\tau s)^k}{1 + \sum_{k=1}^{N} a_k (\tau s)^k}, \ Q(s) = \frac{3\tau s + 1}{(\tau s + 1)^3}, \ Q(s) = \frac{6(\tau s)^2 + 4\tau s + 1}{(\tau s + 1)^4}$$

where au determines the filter bandwidth

Lecture 14: Disturbance Observer

DOB details: nominal model following



Block diagram analysis gives

$$V(s) = G_{uv}^{o}(s) U^{*}(s) + G_{dv}^{o}(s) D(s) + G_{\xi_{V}}^{o}(s) \Xi(s)$$


where

$$G_{uv}^{o} = rac{G_{uv}G_{uv}^{n}}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}, \ G_{dv}^{o} = rac{G_{uv}G_{uv}^{n}(1 - Q)}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}$$
 $G_{\xi v}^{o} = -rac{G_{uv}Q}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}$

Lecture 14: Disturbance Observer

ME233 14-6

DOB details: nominal model following



if $Q(s) \approx 1$, we have disturbance rejection and nominal model following:


$$G_{uv}^o pprox G_{uv}^n, \ G_{dv}^o pprox 0, \ G_{\xi_v}^o = -1$$

if $Q(s) \approx 0$, DOB is cut off:

$$G_{uv}^o pprox G_{uv}, \ G_{dv}^o pprox G_{uv}, \ G_{\xi_v}^o pprox 0$$

Lecture 14: Disturbance Observer

DOB details: stability robustness



$$G_{uv}^{o} = \frac{G_{uv}G_{uv}^{n}}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}, \ G_{dv}^{o} = \frac{G_{uv}G_{uv}^{n}(1 - Q)}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}, \ G_{\xi v}^{o} = -\frac{G_{uv}Q}{G_{uv}^{n} + (G_{uv} - G_{uv}^{n})Q}$$

closed-loop characteristic equation:

$$G_{uv}^{n}(s) + (G_{uv}(s) - G_{uv}^{n}(s)) Q(s) = 0$$

 $\Leftrightarrow G_{uv}^{n}(s) (1 + \Delta(s) Q(s)) = 0$, if $G_{uv}(s) = G_{uv}^{n}(s) (1 + \Delta(s))$


robust stability condition: stable zeros for $G_{nv}^{n}(s)$, plus

$$||\Delta(j\omega)Q(j\omega)|| < 1, \ \forall \omega$$

Lecture 14: Disturbance Observer ME233 14-8

Application example

Discrete-time case



where $P(z^{-1}) \approx z^{-m} P_n(z^{-1})$

see more details in, e.g., X. Chen and M. Tomizuka, "Optimal Plant Shaping for High Bandwidth Disturbance Rejection in Discrete Disturbance Observers," in Proceedings of the 2010 American Control Conference, Baltimore, MD, Jun.

30-Jul. 02, 2010, pp. 2641-2646

Lecture 14: Disturbance Observer

ME233 14-10