Manualslib.com - The Global Manuals Library

VORTEX CORE USER MANUAL

Quick Links

Key Code Programming Instruction
Restore to Factory Default

Table of Contents

main features
package content
Key code Programming Instruction
Restore to factory default
keyboard layout
Switching layer description
Other description
Other ManualsLib Projects

CORE User manual

Main Features:

1. Tiny & compact size, easy to portable
2. Cherry MX switches inside
3. Arbitrary programming key code and LED colors (Backlit only)
4. PBT DSA profile keycaps with Dye-Sublimated technology
5. Anodized CNC-machined aluminum case (Narrow bezel)
6. Build in 4 layers
7. Detachable Micro USB cable

Package Content

1. Keyboard x 1
2. Micro USB Cable x 1

Downloaded from www.Manualslib.com manuals search engine

Key code Programming Instruction

The default layer (L0) can not be programmed. Only layer 1(L1) ~ layer 3(L3) can be.

Step 1. Choose the layer (L1~L3) ***note** which you want to programmed.

Step 2. Press Fn + R_Ctrl to enter the programming mode

(R_Spacebar LED steadily lit in Blue color)

Step 3. Select a key you want to program (R_Spacebar LED flashing in Red Color)

Step 4. Key in the contents and then press Pn (R_Spacebar LED back to Blue color again)

Step 5. Repeat step 2 ~ step 4 to program other keys.

Step 6. Press Fn + R_Ctrl to exit programming mode (Spacebar right LED off)

Note:

R_ctrl, M, < , > and L_ Shift keys are fixed can not be programmed.

More:

Support Fn layer (e.g., Fn + A) to program.

Support time delay, press 15ms key (Fn + T) each time to delay 15ms, press 0.1s key (Fn + G) each time to delay 0.1s, press 0.5s key (Fn + B) each time to delay 0.5s.

Consecutive delay will add up but will only be counted as 1 key stroke.

Every key can program up to 32 key strokes.

If there is no key pressed for 15 sec. in programming mode, it will back to normal mode.

Restore to factory default

1. Press and hold Fn + R, L_spacebar LED will be flashing in white color for 5 seconds, then the layer will restore to default.

2. Press and hold both Alt, L_spacebar LED will be flashing in white color for 5 seconds it will clean all layers' key codes if you had programmed.

(return to default layer.)

Downloaded from www.Manualslib.com manuals search engine

Keyboard layout



= Green legit icon

ex: To type " ? " (question mark) you need to **PRESS** Fn1 + Shift + N

Switching layer description

Fn+M = Default layer (Spacebar left LED off)
Fn+<, = Layer 2 (Spacebar left LED showing **Red** color)
FN+>. = Layer 3 (Spacebar left LED showing **Green** color)
Fn+Shift = Layer 4 (Spacebar left LED showing **Blue** color)

Other description:

1. L_Win + L_Alt + R_Spacebar = R_Shift, R_win , Menu(Pn) and R_Ctrl as arrow keys

2. Switch Fn / Pn position***note**

Hit Fn and L_Shift for 3 seconds, then select new Fn key location directly

Change Pn: With the above step

3. Fn1+Z as symbol key between L-shift and Z for ISO version

Note: Fn or Pn key only can swap to **L_Ctrl**, **L_Win**, **L_Alt**, **L_Spacebar, R_Alt**

Downloaded from www.Manualslib.com manuals search engine

Other ManualsLib Projects

www.manualslib.com

www.manualslib.de

www.manualslib.es

www.manualslib.fr

www.manualslib.nl

www.manualslib.mx

www.manualslib.tech 30+ Languages