Computer Organization and Architecture

THIRD EDITION

Linda Null Julia Lobur

Chapter 7

Input/Output and Storage Systems

Chapter 7 Objectives

- Understand how I/O systems work, including I/O methods and architectures.
- Become familiar with storage media, and the differences in their respective formats.
- Understand how RAID improves disk performance and reliability, and which RAID systems are most useful today.
- Be familiar with emerging data storage technologies and the barriers that remain to be overcome.

7.1 Introduction

- Data storage and retrieval is one of the primary functions of computer systems.
 - One could easily make the argument that computers are more useful to us as data storage and retrieval devices than they are as computational machines.
- All computers have I/O devices connected to them, and to achieve good performance I/O should be kept to a minimum!
- In studying I/O, we seek to understand the different types of I/O devices as well as how they work.

7.2 I/O and Performance

- Sluggish I/O throughput can have a ripple effect, dragging down overall system performance.
 - This is especially true when virtual memory is involved.
- The fastest processor in the world is of little use if it spends most of its time waiting for data.
- If we really understand what's happening in a computer system we can make the best possible use of its resources.

7.3 Amdahl's Law

- The overall performance of a system is a result of the interaction of all of its components.
- System performance is most effectively improved when the performance of the most heavily used components is improved.
- This idea is quantified by Amdahl's Law:

$$S = \frac{1}{(1-f) + \frac{f}{k}}$$

where *S* is the overall speedup; *f* is the fraction of work performed by a faster component; and *k* is the speedup of the faster component.

7.3 Amdahl's Law

- Amdahl's Law gives us a handy way to estimate the performance improvement we can expect when we upgrade a system component.
- On a large system, suppose we can upgrade a CPU to make it 50% faster for \$10,000 or upgrade its disk drives for \$7,000 to make them 150% faster.
- Processes spend 70% of their time running in the CPU and 30% of their time waiting for disk service.
- An upgrade of which component would offer the greater benefit for the lesser cost?

7.3 Amdahl's Law

The processor option offers a 30% speedup:

$$f = 0.70,$$
 $S = \frac{1}{(1 - 0.7) + 0.7/1.5}$

And the disk drive option gives a 22% speedup:

$$f = 0.30, S = 1$$


 $k = 2.5$ $(1 - 0.3) + 0.3/2.5$

• Each 1% of improvement for the processor costs \$333, and for the disk a 1% improvement costs \$318.

Should price/performance be your only concern?

- We define input/output as a subsystem of components that moves coded data between external devices and a host system.
- I/O subsystems include:
 - Blocks of main memory that are devoted to I/O functions.
 - Buses that move data into and out of the system.
 - Control modules in the host and in peripheral devices
 - Interfaces to external components such as keyboards and disks.
 - Cabling or communications links between the host system and its peripherals.


This is a model I/O configuration.



- I/O can be controlled in five general ways.
 - Programmed I/O reserves a register for each I/O device. Each register is continually polled to detect data arrival.
 - Interrupt-Driven I/O allows the CPU to do other things □ until I/O is requested.
 - Memory-Mapped I/O shares memory address space Detween I/O devices and program memory.
 - Direct Memory Access (DMA) offloads I/O processing to
 a special-purpose chip that takes care of the details.
 - Channel I/O uses dedicated I/O processors.


This is an idealized I/O subsystem that uses interrupts.

Each device connects its interrupt line to the interrupt controller.



- Recall from Chapter 4 that in a system that uses interrupts, the status of the interrupt signal is checked at the top of the fetch-decode-execute cycle.
- The particular code that is executed whenever an interrupt occurs is determined by a set of addresses called *interrupt vectors* that are stored in low memory.
- The system state is saved before the interrupt service routine is executed and is restored afterward.

We provide a flowchart on the next slide.




- In memory-mapped I/O devices and main memory share the same address space.
 - Each I/O device has its own reserved block of memory.
 - Memory-mapped I/O therefore looks just like a memory access from the point of view of the CPU.
 - Thus the same instructions to move data to and from both
 I/O and memory, greatly simplifying system design.
- In small systems the low-level details of the data transfers are offloaded to the I/O controllers built into the I/O devices.

This is a DMA configuration.

Notice that the DMA and the CPU share the bus.


The DMA runs at a higher priority and steals memory cycles from the CPU.



- Very large systems employ channel I/O.
- Channel I/O consists of one or more I/O processors (IOPs) that control various channel paths.
- Slower devices such as terminals and printers are combined (multiplexed) into a single faster channel.
- On IBM mainframes, multiplexed channels are called *multiplexor channels*, the faster ones are called *selector channels*.

- Channel I/O is distinguished from DMA by the intelligence of the IOPs.
- The IOP negotiates protocols, issues device commands, translates storage coding to memory coding, and can transfer entire files or groups of files independent of the host CPU.
- The host has only to create the program instructions for the I/O operation and tell the IOP where to find them.


This is a channel I/O configuration.




- Character I/O devices process one byte (or character) at a time.
 - Examples include modems, keyboards, and mice.
 - Keyboards are usually connected through an interruptdriven I/O system.
- Block I/O devices handle bytes in groups.
 - Most mass storage devices (disk and tape) are block I/O devices.
 - Block I/O systems are most efficiently connected through DMA or channel I/O.

- I/O buses, unlike memory buses, operate asynchronously. Requests for bus access must be arbitrated among the devices involved.
- Bus control lines activate the devices when they are needed, raise signals when errors have occurred, and reset devices when necessary.
- The number of data lines is the width of the bus.
- A bus clock coordinates activities and provides bit cell boundaries.


This is a generic DMA configuration showing how the DMA circuit connects to a data bus.



This is how a bus connects to a disk drive.




Timing diagrams, such as this one, define bus operation in detail.



Time	Salient Bus Signal	Meaning
to	Assert Write	Bus is needed for writing (not reading)
t ₁	Assert Address	Indicates where bytes will be written
t ₂	Assert Request	Request write to address on address lines
t ₃	Assert Ready	Acknowledges write request, bytes placed on data lines
t ₄ t ₇	Data Lines	Write data (requires several cycles)
t ₈	Lower Ready	Release bus

7.5 Data Transmission Modes

- Bytes can be conveyed from one point to another by sending their encoding signals simultaneously using *parallel data transmission* or by sending them one bit at a time in *serial data transmission*.
 - Parallel data
 transmission
 for a printer
 resembles the
 signal protocol
 of a memory
 bus:




7.5 Data Transmission Modes

- In parallel data transmission, the interface requires one conductor for each bit.
- Parallel cables are fatter than serial cables.
- Compared with parallel data interfaces, serial communications interfaces:
 - Require fewer conductors.
 - Are less susceptible to attenuation.
 - Can transmit data farther and faster.


Serial communications interfaces are **suitable** for timesensitive (*isochronous*) data **such as voice and video**.

- Magnetic disks offer large amounts of durable storage that can be accessed quickly.
- Disk drives are called *random* (or *direct*) *access* storage devices, because blocks of data can be accessed according to their location on the disk.
 - This term was coined when all other durable storage (e.g., tape) was sequential.
- Magnetic disk organization is shown on the following slide.


Disk tracks are numbered from the outside edge, starting with zero.



- Hard disk platters are mounted on spindles.
- Read/write heads are mounted on a comb that swings radially to read the disk.



- The rotating disk forms a logical cylinder beneath the read/write heads.
- Data blocks are addressed by their cylinder, surface, and sector.



- There are a <u>number of electromechanical</u> properties of hard disk drives that <u>determine how fast</u> its data can be accessed.
- Seek time is the time that it takes for a disk arm to move into position over the desired cylinder.
- Rotational delay is the time that it takes for the desired sector to move into position beneath the read/write head.
- Seek time + rotational delay = access time.

- Transfer rate gives us the rate at which data can be read from the disk.
- Average latency is a function of the rotational speed:

disk rotation speed × 1000 ms second

2

- Mean Time To Failure (MTTF) is a statisticallydetermined value often calculated experimentally.
 - It usually doesn't tell us much about the actual expected life of the disk. Design life is usually more realistic.

Figure 7.15 in the text shows a sample disk specification.

- Low cost is the major advantage of hard disks.
- But their limitations include:
 - Very slow compared to main memory
 - Fragility
 - Moving parts wear out
- Reductions in memory cost enable the widespread adoption of solid state drives, SSDs.
 - Computers "see" SSDs as jut another disk drive, but they store data in non-volatile *flash* memory circuits.
 - Flash memory is also found in memory sticks and MP3 players.

- SSD access time and transfer rates are *typically* 100 times faster than magnetic disk, but slower than onboard RAM by a factor of 100,000.
 - There numbers vary widely among manufacturers and interface methods.
- Unlike RAM, flash is block-addressable (like disk drives).
 - The duty cycle of flash is between 30,000 and 1,000,000 updates to a block.
 - Updates are spread over the entire medium through wear
 leveling to prolong the life of the SSD.

7.7 Optical Disks

- Optical disks provide large storage capacities very inexpensively.
- They come in a <u>number of varieties</u> including CD-ROM, DVD, and WORM.
- Many large computer installations produce document output on optical disk rather than on paper. This idea is called COLD-- Computer Output Laser Disk.
- It is estimated that optical disks can endure for a hundred years. Other media are good for only a decade-- at best.

7.7 Optical Disks

- CD-ROMs were designed by the music industry in the 1980s, and later adapted to data.
- This history is reflected by the fact that data is recorded in a single spiral track, starting from the center of the disk and spanning outward.
- Binary ones and zeros are delineated by bumps in the polycarbonate disk substrate. The transitions between pits and lands define binary ones.
- If you could unravel a full CD-ROM track, it would be nearly five miles long!

7.7 Optical Disks

- The logical data format for a CD-ROM is much more complex than that of a magnetic disk. (See the text for details.)
- Different formats are provided for data and music.
- Two levels of error correction are provided for the data format.
- Because of this, a CD holds at most 650MB of data, but can contain as much as 742MB of music.

- DVDs can be thought of as quad-density CDs.
 - Varieties include single sided, single layer, single sided
 double layer, double sided double layer, and double sided
 double layer.
- Where a CD-ROM can hold at most 650MB of data,
 DVDs can hold as much as 17GB.
- One of the reasons for this is that DVD employs a laser that has a shorter wavelength than the CD's laser.
- This allows pits and lands to be closer together and the spiral track to be wound tighter.


- A shorter wavelength light can read and write bytes in greater densities than can be done by a longer wavelength laser.
- This is one reason that DVD's density is greater than that of CD.
- The 405 nm wavelength of blue-violet light is much shorter than either red (750 nm) or orange (650 nm).
- The manufacture of blue-violet lasers can now be done economically, bringing about the next generation of laser disks.

- The Blu-Ray disc format won market dominance over HD-CD owing mainly to the influence of Sony.
 - HD-CDs are backward compatible with DVD, but hold less data.
- Blu-Ray was developed by a consortium of nine companies that includes Sony, Samsung, and Pioneer.
 - Maximum capacity of a single layer Blu-Ray disk is 25GB.
 - Multiple layers can be "stacked" up to six deep.
 - Only double-layer disks are available for home use.

- Blue-violet laser disks are also used in the data center.
- The intention is to provide a means for long term data storage and retrieval.
- Two types are now dominant:
 - Sony's Professional Disk for Data (PDD) that can store
 23GB on one disk and
 - Plasmon's Ultra Density Optical (UDO) that can hold up to 30GB.
- It is too soon to tell which of these technologies will emerge as the winner.


- First-generation magnetic tape was not much more than wide analog recording tape, having capacities under 11MB.
- Data was usually written in nine vertical tracks:





- Today's tapes are digital, and provide multiple gigabytes of data storage.
- Two dominant recording methods are serpentine and helical scan, which are distinguished by how the read-write head passes over the recording medium.
- Serpentine recording is used in digital linear tape
 (DLT) and Quarter inch cartridge (QIC) tape
 systems.
- *Digital audio tape* (DAT) systems employ helical scan recording.

These two recording methods are shown on the next slide.




- Numerous incompatible tape formats emerged over the years.
 - Sometimes even different models of the same manufacturer's tape drives were incompatible!
- Finally, in 1997, HP, IBM, and Seagate collaboratively invented a best-of-breed tape standard.
- They called this new tape format Linear Tape Open
 (LTO) because the specification is openly available.

- LTO, as the name implies, is a linear digital tape format.
- The specification allowed for the refinement of the technology through four "generations."
- Generation 5 was released in 2010.
 - Without compression, the tapes support a transfer rate of 208MB per second and each tape can hold up to 1.4TB.
- LTO supports several levels of error correction, providing superb reliability.
 - Tape has a reputation for being an error-prone medium.


- RAID, an acronym for Redundant Array of Independent Disks was invented to address problems of disk reliability, cost, and performance.
- In RAID, data is stored across many disks, with extra disks added to the array to provide error correction (redundancy).
- The inventors of RAID, David Patterson, Garth Gibson, and Randy Katz, provided a RAID taxonomy that has persisted for a quarter of a century, despite many efforts to redefine it.

- RAID Level 0, also known as drive spanning, provides improved performance, but no redundancy.
 - Data is written in blocks across the entire array




- The disadvantage of RAID 0 is in its low reliability.

- RAID Level 1, also known as disk mirroring, provides 100% redundancy, and good performance.
 - Two matched sets of disks contain the same data.




The disadvantage of RAID 1 is cost.

- A RAID Level 2 configuration consists of a set of data drives, and a set of Hamming code drives.
 - Hamming code drives provide error correction for the data drives.




RAID 2 performance is poor and the cost is relatively high.

- RAID Level 3 stripes bits across a set of data drives and provides a separate disk for parity.
 - Parity is the XOR of the data bits.




 RAID 3 is not suitable for commercial applications, but is good for personal systems.

- RAID Level 4 is like adding parity disks to RAID 0.
 - Data is written in blocks across the data disks, and a parity block is written to the redundant drive.




 RAID 4 would be feasible if all record blocks were the same size.

- RAID Level 5 is RAID 4 with distributed parity.
 - With distributed parity, some accesses can be serviced concurrently, giving good performance and high reliability.




RAID 5 is used in many commercial systems.

- RAID Level 6 carries two levels of error protection over striped data: Reed-Soloman and parity.
 - It can tolerate the loss of two disks.



- RAID 6 is write-intensive, but highly fault-tolerant.

 Double parity RAID (RAID DP) employs pairs of overlapping parity blocks that provide linearly independent parity functions.



- Like RAID 6, RAID DP can tolerate the loss of two disks.
- The use of simple parity functions provides RAID
 DP with better performance than RAID 6.
- Of course, because two parity functions are involved, RAID DP's performance is somewhat degraded from that of RAID 5.
 - RAID DP is also known as EVENODD, diagonal parity
 RAID, RAID 5DP, advanced data guarding RAID (RAID ADG) and-- erroneously-- RAID 6.

- Large systems consisting of many drive arrays may employ various RAID levels, depending on the criticality of the data on the drives.
 - A disk array that provides program workspace (say for file sorting) does not require high fault tolerance.
- Critical, high-throughput files can benefit from combining RAID 0 with RAID 1, called RAID 10.
- Keep in mind that a higher RAID level does not necessarily mean a "better" RAID level. It all depends upon the needs of the applications that use the disks.


- Advances in technology have defied all efforts to define the ultimate upper limit for magnetic disk storage.
 - In the 1970s, the upper limit was thought to be around 2Mb/in².
 - Today's disks commonly support 20Gb/in².
- Improvements have occurred in several different technologies including:
 - Materials science
 - Magneto-optical recording heads.
 - Error correcting codes.

- As data densities increase, bit cells consist of proportionately fewer magnetic grains.
- There is a point at which there are too few grains to hold a value, and a 1 might spontaneously change to a 0, or vice versa.
- This point is called the superparamagnetic limit.
 - In 2006, the superparamagnetic limit is thought to lie between 150Gb/in² and 200Gb/in².
- Even if this limit is wrong by a few orders of magnitude, the greatest gains in magnetic storage have probably already been realized.


- Future exponential gains in data storage most likely will occur through the use of totally new technologies.
- Research into finding suitable replacements for magnetic disks is taking place on several fronts.
- Some of the more interesting technologies include:
 - Biological materials
 - Holographic systems and
 - Micro-electro-mechanical devices.

- Present day biological data storage systems combine organic compounds such as proteins or oils with inorganic (magentizable) substances.
- Early prototypes have encouraged the expectation that densities of 1Tb/in² are attainable.
- Of course, the ultimate biological data storage medium is DNA.
 - Trillions of messages can be stored in a tiny strand of DNA.
- Practical DNA-based data storage is most likely decades away.

 Holographic storage uses a pair of laser beams to etch a three-dimensional hologram onto a polymer medium.



 Data is retrieved by passing the reference beam through the hologram, thereby reproducing the original coded object beam.




- Because holograms are three-dimensional, tremendous data densities are possible.
- Experimental systems have achieved over 30Gb/in², with transfer rates of around 1GBps.
- In addition, holographic storage is content addressable.
 - This means that there is no need for a file directory on the disk. Accordingly, access time is reduced.
- The major challenge is in finding an inexpensive, stable, rewriteable holographic medium.

- Micro-electro-mechanical storage (MEMS) devices offer another promising approach to mass storage.
- IBM's Millipede is one such device.
- Prototypes have achieved densities of 100Gb/in² with 1Tb/in² expected as the technology is refined.

A photomicrograph of Millipede is shown on the next slide.

- Millipede consists of thousands of cantilevers that record a binary 1 by pressing a heated tip into a polymer substrate.
- The tip reads a binary 1 when it dips into the imprint in the polymer

Photomicrograph courtesy of the IBM Corporation.
© 2005 IBM Corporation



⊢ 10 µm

Chapter 7 Conclusion

- I/O systems are critical to the overall performance of a computer system.
- Amdahl's Law quantifies this assertion.
- I/O systems consist of memory blocks, cabling, control circuitry, interfaces, and media.
- I/O control methods include programmed I/O, interrupt-based I/O, DMA, and channel I/O.
- Buses require control lines, a clock, and data lines. Timing diagrams specify operational details.

Chapter 7 Conclusion

- Magnetic disk is the principal form of durable storage.
- Disk performance metrics include seek time, rotational delay, and reliability estimates.
- Optical disks provide long-term storage for large amounts of data, although access is slow.
- Magnetic tape is also an archival medium.
 Recording methods are track-based, serpentine, and helical scan.

Chapter 7 Conclusion

- RAID gives disk systems improved performance and reliability. RAID 3 and RAID 5 are the most common.
- RAID 6 and RAID DP protect against dual disk failure, but RAID DP offers better performance.
- Any one of several new technologies including biological, holographic, or mechanical may someday replace magnetic disks.
- The hardest part of data storage may be end up be in locating the data after it's stored.

End of Chapter 7