

Model Advisor Report – SimpleConveyorSystem.slx

Simulink version: 25.2

Model version: 1.3

System: SimpleConveyorSystem/ConveyorLogic

Current run: 17-Dec-2025 10:59:53

Treat as Referenced Model: off

Configuration File:

Justifications File:

Run Summary

Incomplete		0
Failed		0
Warning		3
Justified		0
Information		0
Passed		18
Not Run		3
Total		24

Simulink PLC Coder

 Model configuration checks 0 0 0 0 7 0 1

Check Data Store Memory blocks

Lists the Data Store Memory blocks which do not resolve to Simulink signal

Passed

Check model for Stateflow messages

Checks if model uses any Stateflow messages

Passed

✔ Check if signal lines are configured properly
Lists the signal lines that are not compatible with Simulink PLC Coder
Passed

✔ Check if model uses row major algorithms
Checks if model uses row major algorithms
Passed

✔ Check model mask parameters
Lists the mask parameters which have Inf elements
Passed

✔ Check if model uses machine parented data
Lists the blocks/events that use machine parented data
Passed

✔ Check if model uses custom code
Checks if model uses custom code
Passed

📁 Check model tunable parameters
Not Run

📁 Checks for blocks and block settings 0 0 0 0 8 0 1

✔ Check if model uses event based blocks
Lists the event based blocks that are not compatible with Simulink PLC Coder
Passed

✔ Check if model uses probe blocks
Lists the probe blocks that are not compatible with Simulink PLC Coder
Passed

✔ Check if model uses environment controller blocks
Lists the environment controller blocks that are not compatible with Simulink PLC Coder
Passed

✔ Check Stateflow chart update
Lists the Stateflow charts that are not compatible with Simulink PLC Coder
Passed

✔ Check issues with integrator blocks
Lists the discrete integrator blocks that have incompatible initial conditions
Passed

✔ Check if model uses blocks that are not supported
Lists the blocks that are not compatible with Simulink PLC Coder
Passed

✔ Check if model can generate testbench
Checks if top level subsystem has inputs and outputs when testbench generation is enabled
Passed

✔ Check function packaging configuration
Checks if subsystems are set to generate reusable functions
Passed

 Check trigonometric blocks
Not Run

 Industry standard checks  0  0  3  0  3  0  1

 Define the names to avoid

Names defined as keywords must not be used

Passed

Input Parameters Selection

Name	Value
Open Keywords File	N/A

 Define the use of case (capitals)

The use of capital letters in object names must be clear and consistent across the project

Warning

The names across the model are not consistent

Non consistent names in the model

Type	Name
SF Object	IDLE
SF Object	MOVING
SF Object	ROBOT_WORKING
SF Object	conveyor_on

SF Object	robot_done
SF Object	robot_trigger
Signal	conveyor_on
Signal	robot_trigger

Input Parameters Selection

Name	Value
Case condition	alllowercase
Ignore prefix	false

✔ Define the maximum variable name length

Names that exceed the defined maximum name length must be avoided

Passed

Input Parameters Selection

Name	Value
Maximum acceptable length	32

⚠ Comments must describe the intention of the code

Check if function blocks have comments

Warning

The function block has no comment

Recommended Action

Add description to the subsystem block

 Avoid nested comments

Nesting of multiline comments must be avoided

Warning

The function block has no comment

Recommended Action

Add description to the subsystem block

 Define maximum number of input/output/in-out variables of a POU

The number of input variables, output variables, and in-out variables of a POU must be within a limited set

Passed

Input Parameters Selection

Name	Value
Maximum number of I/O variables	20

 Define type prefixes for variables (if used)

Not Run