

Real-Time Embedded Multithreading With Azure RTOS ThreadX

Fourth Edition

Edward L. Lamie

Published: March 23, 2022

Table of Contents

List of Figures	x
Preface	xvi
Chapter 1 Embedded and Real-time Systems Introduction What is an Embedded System? Characteristics of Embedded Systems Real-time Systems Real-time Operating Systems and Real-time Kernels Processes, Tasks, and Threads Architecture of Real-time Systems Embedded Systems Development Key Terms and Phrases	1 2 3 4 5
Chapter 2 First Look at a System Using an RTOS Operating Environment	9 9 .12 .16 .16
Chapter 3 RTOS Concepts and Definitions	. 23 . 23 . 24 . 25
NUUIIU-NUUIII JUIIEUUIIIIU	. 20

Determinism	28
Kernel	28
RTOS	28
Context Switch	28
Time-Slice	29
Interrupt Handling	29
Thread Starvation	29
Priority Inversion	30
Priority Inheritance	31
Preemption-Threshold	31
Key Terms and Phrases	32
Problems	32
Chapter 4 RTOS Building Blocks for System Developme	nt 24
Introduction	24
Defining Public Resources	
Azure RTOS ThreadX Data Types	
Thread	
Memory Pools	
Application Timer	
Mutex	
Counting Semaphore	
Event Flags Group	
Message Queue	
Summary of Thread Synchronization and Communication	
Components	
Key Terms and Phrases	
Problems	
	_
Chapter 5 The Thread—The Essential Component	
Introduction	
Thread Control Block	
Summary of Thread Services	
Thread Creation	
Thread Deletion	
Identify Thread	
Get Thread Information	56

Preemption-Threshold Change	57
Priority Change	
Relinquish Control	59
Resume Thread Execution	59
Thread Sleep	
Suspend Thread Execution	
Terminate Application Thread	
Time-Slice Change	
Abort Thread Suspension	
Thread Notification Services	
Execution Overview	62
Thread States	64
Thread Design	66
Minimize the Number of Threads	66
Choose Priorities Carefully	66
Minimize the Number of Priorities	67
Consider Preemption-Threshold	68
Consider Priority Inheritance	68
Consider Round-Robin Scheduling	69
Consider Time-Slicing	69
Thread Internals	69
Overview	71
Key Terms and Phrases	71
Problems	72
hapter 6 Mutual Exclusion Challenges and Considerations	74
Introduction	74
Protecting a Critical Section	
Providing Exclusive Access to Shared Resources	
Mutex Control Block	
Summary of Mutex Services	
Creating a Mutex	
Deleting a Mutex	
Obtaining Ownership of a Mutex	
Retrieving Mutex Information	
Prioritizing the Mutex Suspension List	

Releasing Ownership of a Mutex	
Avoiding the Deadly Embrace	
Sample System Using a Mutex to Protect Critical Sections	84
Output Produced by Sample System	
Listing for 06_sample_system.c	
Mutex Internals	
Overview	
Key Terms and Phrases	99
Problems	99
Chapter 7 Memory Management: Byte Pools and Block Pools	101
Introduction	
Summary of Memory Byte Pools	102
Memory Byte Pool Control Block	104
Pitfalls of Memory Byte Pools	104
Summary of Memory Byte Pool Services	104
Creating a Memory Byte Pool	105
Allocating from a Memory Byte Pool	106
Deleting a Memory Byte Pool	107
Retrieving Memory Byte Pool Information	107
Prioritizing a Memory Byte Pool Suspension List	108
Releasing Memory to a Byte Pool	109
Memory Byte Pool Example—Allocating Thread Stacks	110
Memory Byte Pool Internals	111
Summary of Memory Block Pools	112
Memory Block Pool Control Block	115
Summary of Memory Block Pool Services	116
Creating a Memory Block Pool	116
Allocating a Memory Block Pool	118
Deleting a Memory Block Pool	118
Retrieving Memory Block Pool Information	119
Prioritizing a Memory Block Pool Suspension List	120
Releasing a Memory Block	121
Memory Block Pool Example—Allocating Thread Stacks	121
Memory Block Pool Internals	122
Overview and Comparison	

Key Terms and Phrases	123
Problems	124
Chapter 8 Internal System Clock and Application Timers	125
Introduction	125
Internal System Clock Services	127
Application Timer Control Block	128
Summary of Application Timer Services	
Creating an Application Timer	129
Activating an Application Timer	
Changing an Application Timer	
Deactivating an Application Timer	
Deleting an Application Timer	132
Retrieving Application Timer Information	
Sample System Using Timers to Measure Thread Performance	ce134
Listing for 08_sample_system.c	
Application Timer Internals	
Overview	
Key Terms and Phrases	
Problems	146
Chapter 9 Event Notification and Synchronization with Countin	ng
Semaphores	
Introduction	148
Counting Semaphore Control Block	150
Avoiding Deadly Embrace	
Avoiding Priority Inversion	
Summary of Counting Semaphore Services	
Creating a Counting Semaphore	
Deleting a Counting Semaphore	
Getting an Instance of a Counting Semaphore	
Retrieving Information about Counting Semaphores	
Prioritizing a Counting Semaphore Suspension List	
Placing an Instance in a Counting Semaphore	
Placing an Instance in a Semaphore Using a Ceiling	
Semaphore Notification and Event-Chaining	
Comparing a Counting Semaphore with a Mutex	157

Sample System Using a Binary Semaphore in Place of a Mut	
Listing for 09a_sample_system.c	161
Sample System Using a Counting Semaphore in a Producer-	-
Consumer Application	167
Listing for 09b_sample_system.c	170
Counting Semaphore Internals	175
Overview	176
Key Terms and Phrases	177
Problems	177
Chapter 10 Synchronization of Threads Using Event Flags Gro	oups
	179
Introduction	179
Event Flags Group Control Block	181
Summary of Event Flags Group Control Services	
Creating an Event Flags Group	
Deleting an Event Flags Group	
Getting Event Flags from an Event Flags Group	183
Sample System Using an Event Flags Group to Synchronize	
Threads	
Retrieving Information about an Event Flags Group	189
Setting Event Flags in an Event Flags Group	
Event Flags Group Notification and Event-Chaining	
Listing for 10_sample_system.c	
Event Flags Group Internals	
Overview	
Key Terms and Phrases	
Problems	
Chapter 11 Thread Communication with Message Queues	202
Introduction	
Message Queue Control Block	
Summary of Message Queue Services	
Creating a Message Queue	205
Sending a Message to a Message Queue	
Receiving a Message from a Message Queue	
Deleting a Message Queue	

Flushing the Contents of a Message Queue	208
Sending a Message to the Front of a Message Queue	
Retrieving Message Queue Information	
Prioritizing a Message Queue Suspension List	210
Message Queue Notification and Event-Chaining	211
Sample System Using a Message Queue for Interthread	
Communication	211
Listing for 11_sample_system.c	214
Message Queue Internals	220
Overview	221
Key Terms and Phrases	223
Problems	223
Chapter 12 Advanced Topics	225
Introduction	
Event-Chaining	
Queue Event-Chaining	
Semaphore Event-Chaining	
Event Flags Group Event-Chaining	
Sample System Using Event-Chaining	
Listing for 12_sample_system.c	
Run-Time Performance Metrics	
Block Pool Performance Information	
Byte Pool Performance Information	
Event Flags Performance Information	
Mutex Performance Information	246
Queue Performance Information	247
Semaphore Performance Information	247
Thread Performance Information	
Timer Performance Information	251
Key Terms and Phrases	253
Chapter 13 Case Study: Designing a Multithreaded System	25/
Introduction	
Statement of Problem	
Analysis of the Problem	
Design of the System	

Thread Design	262
Public Resources Design	
Implementation	
Listing of VAM System	
Overview	
Appendices	297
Appendix A Memory Block Pool Services	
Appendix B Memory Byte Pool Services	
Appendix C Event Flags Group Services	
Appendix D Interrupt Control Service	
Appendix E Mutex Services	
Appendix F Message Queue Services	356
Appendix G Counting Semaphore Services	376
Appendix H Thread Services	391
Appendix I Internal System Clock Services	423
Appendix J Application Timer Services	426
Appendix K Azure RTOS ThreadX API	440
Index	449

List of Figures

Figure 1. RTOS kernel	3
Figure 2. Comparison of processes and threads	4
Figure 3. Control loop with polling approach	5
Figure 4. Preemptive scheduling method	
Figure 5. Components of the sample system	10
Figure 6. Activities of the <i>speedy_thread</i> (priority = 5)	12
Figure 7. Activities of the slow_thread (priority = 15)	12
Figure 8. Basic structure of sample system	12
Figure 9. Entry function definition for the speedy_thread	15
Figure 10. Output produced by sample system	16
Figure 11. Priority Values	23
Figure 12. Ready Thread State	
Figure 13. Suspended Thread List	25
Figure 14. Thread preemption	26
Figure 15. Round-robin processing	
Figure 16. Example of cooperative multithreading	
Figure 17. Example of priority inversion	
Figure 18. Example of preemption-threshold	32
Figure 19. Azure RTOS ThreadX components	34
Figure 20. Azure RTOS ThreadX primitive data types	
Figure 21. Azure RTOS ThreadX system data types	
Figure 22. Attributes of a thread	
Figure 23. Memory byte pool	
Figure 24. Attributes of a memory byte pool	
Figure 25. Memory block pool	38
Figure 26. Attributes of a memory block pool	
Figure 27. Attributes of an application timer	
Figure 28. Attributes of a mutex	
Figure 29. Attributes of a counting semaphore	
Figure 30. Attributes of an event flags group	42
Figure 31. An event flags group	42
Figure 32. Attributes of a message queue	42
Figure 33. A message queue	
Figure 34. Comparison of a mutex with a counting semaphore	
Figure 35. Recommended uses of resources	
Figure 36. Thread Control Block	
Figure 37. Two useful members of the Thread Control Block	48

Figure 38.	Thread services	49
Figure 39.	Typical thread stack	.50
Figure 40.	Attributes of a thread	.51
Figure 41.	Creating a thread with priority 15	.52
	Thread create parameters used in previous figure	
	Creating a thread with priority = 20 and preemption-threshold = 14	
	Creating a thread with priority 18 and no preemption-threshold	
	Deletion of thread my_thread	
	Example showing how to retrieve thread information	
Figure 47.	Change preemption-threshold of thread my_thread	.58
	Change priority of thread <i>my_thread</i>	
Figure 49.	Example showing the resumption of thread <i>my_thread</i>	.59
Figure 50.	Example showing a time-slice change for thread my_thread	61
	Types of program execution	
Figure 52.	Thread state transition	64
Figure 53.	Created thread list	69
Figure 54.	Map showing ready thread priorities	.70
Figure 55.	Example of array of ready thread head pointers indexed by priority	.70
Figure 56.	Mutex protecting a critical section	.75
Figure 57.	Mutexes providing exclusive access to multiple shared resources	.75
	Mutex Control Block	
Figure 59.	Mutex services	.77
Figure 60.	Attributes of a mutex	.77
Figure 61.	Creating a mutex with priority inheritance	.78
	Deleting a mutex	
	Actions taken when mutex is already owned by another thread	
	Obtain ownership of a mutex	
	Example showing how to retrieve mutex information	
	Prioritizing the mutex suspension list	
	Releasing ownership of a mutex	
	Sequence of actions leading to a deadly embrace	
Figure 69.	Activities of the Speedy_Thread (priority = 5)	.84
	Activities of the Slow_Thread (priority = 15)	
	Basic system structure	
	Definitions, declarations, and prototypes	
	The main entry point	
	Application definitions	
Figure 75.	Speedy_Thread entry function	.89
Figure 76.	Slow_Thread entry function	.90
	Some output produced by sample system	
Figure 78.	Partial activity trace of sample system	.92
Figure 79.	Created mutex list	.97
Figure 80.	Example showing effect of priority inheritance on thread priority	.97

Figure 81. Memory Byte Pool Control Block	103
Figure 82. Services of the memory byte pool	
Figure 83. Attributes of a memory byte pool	105
Figure 84. Creating a memory byte pool	106
Figure 85. Allocating bytes from a memory byte pool	106
Figure 86. Deleting a memory byte pool	107
Figure 87. Retrieving information about a memory byte pool	108
Figure 88. Prioritizing the memory byte pool suspension list	109
Figure 89. Releasing bytes back to the memory byte pool	110
Figure 90. Created memory byte pool list	111
Figure 91. Organization of a memory byte pool upon creation	
Figure 92. Memory byte pool after the first allocation	
Figure 93. Memory Block Pool Control Block	
Figure 94. Services of the memory block pool	
Figure 95. Memory block pool attributes	
Figure 96. Creating a memory block pool	
Figure 97. Allocation of a fixed-size block of memory	
Figure 98. Deleting a memory block pool	119
Figure 99. Retrieving information about a memory block pool	119
Figure 100. Prioritizing the memory block pool suspension list	
Figure 101. Release one block to the memory block pool	
Figure 102. Created memory block pool list	122
Figure 103. Get current time from the internal system clock	127
Figure 104. Set current time of the internal system clock	
Figure 105. Application Timer Control Block	
Figure 106. Services of the application timer	
Figure 107. Attributes of an application timer	
Figure 108. Activation of an application timer	
Figure 109. Change characteristics of an application timer	
Figure 110. Deactivate an application timer	
Figure 111. Deleting an application timer	
Figure 112. Retrieve Information about an application timer	
Figure 113. Additions to the declarations and definitions section	135
Figure 114. Additions to the application definitions section	
Figure 115. Additions to the Speedy_Thread entry function	
Figure 116. Expiration function to display summary information	
Figure 117. Created application timer list	
Figure 118. Example of array of active timer head pointers	
Figure 119. Counting Semaphore Control Block	
Figure 120. Services of the counting semaphore	
Figure 121. Counting semaphore attributes	
Figure 122. Creating a counting semaphore	
Figure 123. Deleting a counting semaphore	103

		Get an instance from a counting semaphore	
		Get Information about a counting semaphore	
Figure	126.	Prioritize the counting semaphore suspension list	155
Figure	127.	Place an instance on a counting semaphore	156
		Place an instance on a semaphore using a ceiling	
Figure	129.	Comparison of a mutex with a counting semaphore	158
		Activities of the <i>Speedy_Thread</i> (priority = 5)	
		Activities of the <i>Slow_Thread</i> (priority = 15)	
		Changes to Activity 2	
Figure	133.	Changes to Activity 4	161
		Producer-consumer system	
		Activities of the producer (<i>Speedy_Thread</i>) where priority = 5	
		Activities of the consumer (<i>Slow_Thread</i>) where priority = 15	
		Creating Counting semaphore for producer-consumer system	
		Activity 2 of the producer	
		Created counting semaphore list	
Figure	140.	An event flags group	179
		Event Flags Group Control Block	
		Services of the event flags group	
Figure	143.	Attributes of an event flags group	182
		Creating an event flags group	
		Deleting an event flags group	
		Options to satisfy a get request	
		Example of an event flags group where flags 0, 4, and 8 are set	
		Getting event flags from an event flags group	
		Event flags group with a value of 0x537	
Figure	150.	Event flags group with a value of 0x426	185
		Event Flags group with flags 0, 5, and 10 set	
		Getting event flags from an event flags group	
Figure	153.	Event flags group with value 0xFF0C	186
Figure	154.	Event Flags group with value 0xFB0C	187
		Retrieving information about an event flags group	
		Set options	
		Clearing flags with the TX_AND option	
		Setting flags with the TX_OR option	
Figure	159.	Set event flags in an event flags group	192
		Created event flags group list	
		A message queue	
		Message Queue Control Block	
		Services of the message queue	
		Attributes of a message queue	
		Creating a message queue	
Figure	166.	Send a message to a queue	207

Figure 167	'. Receive a message from a queue	207
	Deleting a message queue	
). Flushing a message queue	
Figure 170). Sending a message to the front of a queue	209
	. Retrieving information about a message queue	
	2. Effect of prioritizing a message queue suspension list	
Figure 173	Prioritizing a message queue suspension list	211
Figure 174	Activities of the Speedy_Thread where priority = 5	212
Figure 175	i. Activities of the Slow_Thread where priority = 15	212
	i. Changes to Activity 2	
	'. Changes to Activity 4	
Figure 178	S. Created message queue list	221
Figure 179	. Recommended uses of public resources	223
Figure 180	. Template for event-chaining with a message queue	226
Figure 181	. Template for event-chaining with a counting semaphore	228
	!. Template for event-chaining with an event flags group	
	Multiple object suspension problem	
	. speedy_thread activities	
	i. slow_thread activities	
	Comments about sample system listing	
	'. Performance information services	
	Block pool performance information parameters	
	Block pool performance information retrieval	
	Byte pool performance information parameters	
Figure 191	. Byte pool performance information retrieval	244
	L. Event flags group performance information parameters	
	Event flags group performance information retrieval	
	. Mutex performance information parameters	
	. Mutex performance information retrieval	
	Queue performance information parameters	
	. Queue performance information retrieval	
Figure 198	Semaphore performance information parameters	249
	Semaphore performance information retrieval	
	Thread performance information retrieval	
	. Results of speedy_thread performance information	
	Timer performance information parameters	
	Thread performance information parameters	
	. Timer performance information retrieval	
	Directions of G-forces	
	Events and corresponding priorities	
	7. Graphical classification of events by G-forces	
	B. G-Forces and event classifications	
Figure 209	Temporary memory (Circular list)	260

Figure 210. Protected memory	260
Figure 211. Event overwrite rules	261
Figure 212. Initialization of the VAM system	262
Figure 213. Capturing data from the VAM unit	262
Figure 214. Overview of event interrupts and data recording	263
Figure 215. Event processing	265
Figure 216. Summary of public resources used for the VAM system	266
Figure 217. Definitions, arrays, and counters used in the VAM system	267
Figure 218. Entry and expiration functions used in the VAM system	268
Figure 219 . Sample output produced by VAM system	268
Figure 220. Basic structure for the VAM system	269
Figure 221. Declarations and definitions — Part 1	270
Figure 222. Declarations, definitions, and prototypes—Part 2	271
Figure 223. Organization of temporary memory	271
Figure 224. The main entry point	
Figure 225. Application definitions—Part 1	274
Figure 226. Application definitions—Part 2	275
Figure 227. Message queue event_notice	277
Figure 228. Function definitions Part 1—initializer entry function	279
Figure 229. Function definitions Part 2—data_capture_process entry function	
Figure 230. Function definitions Part 3—crash_ISR and crash_copy_scheduler expir	ation
functions	281
Figure 231. Function definitions Part 4—event_recorder entry function	283
Figure 232. Function definitions Part 5—print stats expiration function	283

Preface

Embedded systems are ubiquitous. These systems are found in most consumer electronics, automotive, government, military, communications, and medical equipment. Most individuals in developed countries have many such systems and use them daily, but relatively few people realize that these systems actually contain embedded computer systems. Although the field of embedded systems is young, the use and importance of these systems is increasing, and the field is rapidly growing and maturing.

This book is intended for persons who develop embedded systems, or for those who would like to know more about the process of developing such systems. Although embedded systems developers are typically software engineers or electrical engineers, many people from other disciplines have made significant contributions to this field. This book is specifically targeted toward embedded applications that must be small, fast, reliable, and deterministic.¹

This book comprises 13 chapters that cover embedded and real-time concepts, all the services provided by the Azure RTOS ThreadX® real-time operating system (RTOS), solutions to classical problem areas, and a case study. I assume the reader has a programming background in C or C++, so we won't devote any time on programming fundamentals. Depending on the background of the reader, the chapters of the book may be read independently.

There are several excellent books written about embedded systems. However, most of these books are written from a generalist point of view. This book is unique because it is based on embedded systems development using a typical commercial RTOS. This approach has the advantage of providing specific knowledge and techniques, rather than generic concepts that must be converted to your specific system. Thus, you can immediately apply the topics in this book to your development efforts.

Because an actual RTOS is used as the primary tool for embedded application development, there is no discussion about the merits of building your own RTOS or

-

¹ Such systems are sometimes called deeply embedded systems.

forgoing an RTOS altogether. I believe that the relatively modest cost of a commercial RTOS provides a number of significant advantages over attempts to "build your own." For example, most commercial RTOS companies have spent years refining and optimizing their systems. Their expertise and product support may play an important role in the successful development of your system.

The RTOS chosen for use in this book is Azure RTOS Thread X^2 . This RTOS was selected for a variety of reasons, including reliability, ease of use, low cost, widespread use, and the maturity of the product due to the extensive experience of its developers. This RTOS contains most of the features found in contemporary RTOSes, as well as several advanced features that are not. Another notable feature of this RTOS is the consistent and readable coding convention used within its application programming interface (API). Developing applications is highly intuitive because of the logical approach of the API.

Although I chose the C programming language for this book, you could use C++ instead for any of the applications described in this book.

Please download a limited Azure RTOS ThreadX³ system and source code for all the project listings in this book, located at https://aka.ms/azrtos-simulator-win32. You may use this system to perform your own experiments, run the included demonstration system, and experiment with the projects described throughout the book.

Ed Lamie

² Azure RTOS ThreadX is a registered trademark of Microsoft. The Azure RTOS ThreadX API, associated data structures, and data types are copyrights of Microsoft.

³ Microsoft has granted permission to use this demonstration system for the sample systems and the case study in this book.

Chapter 1

Embedded and Real-time Systems

Introduction

Although the history of embedded systems is relatively short,⁴ the advances and successes of this field have been profound. Embedded systems are found in a vast array of applications such as consumer electronics, "smart" devices, communication equipment, automobiles, desktop computers, and medical equipment.⁵

What is an Embedded System?

In recent years, the line between embedded and non-embedded systems has blurred, largely because embedded systems have expanded to a vast array of applications. However, for practical purposes, an embedded system is defined here as one dedicated to a specific purpose and consisting of a compact, fast, and extremely reliable operating system that controls the microprocessor located inside a device. Included in the embedded system is a collection of programs that run under that operating system, and of course, the microprocessor.⁶

Because an embedded system is part of a larger system or device, it is typically housed on a single microprocessor board, and the associated programs are stored in ROM.⁷ Because most embedded systems must respond to inputs within a small period of time,

⁴ The first embedded system was developed in 1971 by the Intel Corporation, which produced the 4004 microprocessor chip for a variety of business calculators. The same chip was used for all the calculators, but software in ROM provided unique functionality for each calculator. Source: The Intel 4004 website at http://www.intel4004.com/

⁵ Approximately 98% of all microprocessors are used in embedded systems. Turley, Jim, The Two Percent Solution, Embedded Systems Programming, Vol. 16, No. 1, January 2003.

⁶ The microprocessor is often called a microcontroller, embedded microcontroller, network processor, or digital signal processor; it consists of a CPU, RAM, ROM, I/O ports, and timers.

⁷ We often say that embedded systems are ROMable or scalable.

these systems are frequently classified as real-time systems. For simple applications, it might be possible for a single program (without an RTOS) to control an embedded system, but typically an RTOS or kernel is used as the engine to control the embedded system.

Characteristics of Embedded Systems

Another important feature of embedded systems is *determinism*. There are several aspects to this concept, but each is built on the assumption that for each possible state and each set of inputs, a unique set of outputs and next state of the system can be, in principle, predicted. This kind of determinism is not unique to embedded systems; it is the basis for virtually all kinds of computing systems. When we say that an embedded system is deterministic, we are usually referring to *temporal determinism*. A system exhibits temporal determinism if the time required to process any task is finite and predictable. In particular, we are less concerned with average response time than we are with worst-case response time. In the latter case, we must have a guarantee on the upper time limit, which is an example of temporal determinism.

An embedded system is typically encapsulated by the hardware it controls, so end-users are usually unaware of its presence. Thus, an embedded system is actually a computer system that does not have the outward appearances of a computer system. An embedded system typically interacts with the external world, but it usually has a primitive or nonexistent user interface.

The embedded systems field is a hybrid that draws extensively from disciplines such as software engineering, operating systems, and electrical engineering. Embedded systems have borrowed liberally from other disciplines and have adapted, refined, and enhanced those concepts and techniques for use in this relatively young field.

Real-time Systems

As noted above, an embedded system typically must operate within specified time constraints. When such constraints exist, we call the embedded system a *real-time system*. This means that the system must respond to inputs or events within prescribed time limits, and the system as a whole must operate within specified time constraints. Thus, a real-time system must not only produce correct results but also it must produce

them in a timely fashion. The timing of the results is sometimes as important as their correctness.

There are two important subclasses of real-time constraints: hard real-time and soft real-time. Hard real-time refers to highly critical time constraints in which missing even one time deadline is unacceptable, possibly because it would result in catastrophic system failure. Examples of hard real-time systems include air traffic control systems, medical monitoring systems, and missile guidance systems. Soft real-time refers to situations in which meeting the time constraints is desirable, but not critical to the operation of the system.




Figure 1. RTOS kernel

Real-time Operating Systems and Real-time Kernels

Relatively few embedded applications can be developed effectively as a single control program, so we consider only commercially available real-time operating systems (RTOSes) and real-time kernels here. A real-time kernel is generally much smaller than a complete RTOS. In contemporary operating system terminology, a *kernel* is the part of the operating system that is loaded into memory first and remains in memory while the application is active. Likewise, a real-time kernel is memory-resident and provides all the

necessary services for the embedded application. Because it is memory-resident, a real-time kernel must be as small as possible. Figure 1 contains an illustration of a typical kernel and other RTOS services.

The operation of an embedded system entails the execution of processes, and tasks or threads, either in response to external or internal inputs, or in the normal processing required for that system. The processing of these entities must produce correct results within specified time constraints.

Processes, Tasks, and Threads

The term *process* is an operating system concept that refers to an independent executable program that has its own memory space. The terms "process" and "program" are often used synonymously, but technically a process is more than a program: it includes the execution environment for the program and handles program bookkeeping details for the operating system. A process can be launched as a separately loadable program, or it can be a memory-resident program that is launched by another process. Operating systems are often capable of running many processes concurrently. Typically, when an operating system executes a program, it creates a new process for it and maintains within that process all the bookkeeping information needed. This implies that there is a one-to-one relationship between the program and the process, i.e., one program, one process.




Figure 2. Comparison of processes and threads

When a program is divided into several segments that can execute concurrently, we refer to these segments as threads. A *thread* is a semi-independent program segment; threads share the same memory space within a program. The terms "task" and "thread" are frequently used interchangeably. However, we will use the term "thread" in this book

because it is more descriptive and more accurately reflects the processing that occurs. Figure 2 contains an illustration of the distinction between processes and threads.

Architecture of Real-time Systems

The architecture of a real-time system determines how and when threads are processed. Two common architectures are the *control loop with polling*⁸ approach and the *preemptive scheduling* model. In the control loop with polling approach, the kernel executes an infinite loop, which polls the threads in a predetermined pattern. If a thread needs service, then it is processed. There are several variants to this approach, including *time-slicing*⁹ to ensure that each thread is guaranteed access to the processor. Figure 3 contains an illustration of the control loop with a polling approach.




Figure 3. Control loop with polling approach

⁸ The control loop with polling approach is sometimes called the super loop approach.

⁹ Each thread is allocated a predetermined slice of time in which to execute.

Although the control loop with polling approach is relatively easy to implement, it has several serious limitations. For example, it wastes much time because the processor polls threads that do not need servicing, and a thread that needs attention has to wait its turn until the processor finishes polling other threads. Furthermore, this approach makes no distinction between the relative importance of the threads, so it is difficult to give threads with critical requirements fast access to the processor.




Figure 4. Preemptive scheduling method

Another approach that real-time kernels frequently use is *preemptive scheduling*. In this approach, threads are assigned priorities and the kernel schedules processor access for the thread with the highest priority. There are several variants to this approach including techniques to ensure that threads with lower priorities get some access to the processor. Figure 4 illustrates one possible implementation of this approach. In this example, each

thread is assigned a priority from zero (0) to some upper limit. ¹⁰ Assume that priority zero is the highest priority.

An essential feature in preemptive scheduling schemes is the ability to suspend the processing of a thread when a thread that has a higher priority is ready for processing. The process of saving the current information of the suspended thread so that another thread can execute is called *context switching*. This process must be fast and reliable because the suspended thread must be able to resume execution exactly at the point where it was suspended when it ultimately regains control of the processor.

Embedded systems need to respond to inputs or events accurately and within specified deadlines. This is accomplished in part by means of an *interrupt*, which is a signal to the processor that an event has occurred and that immediate attention may be required. An interrupt is handled with an *interrupt service routine (ISR)*, which may activate a thread with a higher priority than the currently executing thread. In this case, the ISR would suspend the currently executing thread and permit the higher priority thread to proceed. Interrupts can be generated from software¹¹ or by a variety of hardware devices.

Embedded Systems Development

Embedded applications should be designed and developed using sound software engineering principles. Because most embedded applications are real-time systems, one major difference from traditional computer applications is the requirement to adhere strictly to prescribed time constraints. ¹² The requirements and design phases are performed with the same rigor as any other software application.

Another major consideration in embedded systems development is that the modules (that is, the threads) are not designed to be executed in a procedural manner, as is the case with traditional software systems. The threads of an embedded application are designed to be executed independently of each other or in parallel¹³ so this type of system is called

 $^{^{10}}$ Azure RTOS ThreadX provides 1024 distinct priority values, where 0 represents the highest priority.

¹¹ Software interrupts are also called traps or exceptions.

¹² Some writers liken the study of real-time systems to the science of performance guarantees.

¹³ In cases where there is only one processor, threads are executed in pseudo-parallel.

multithreaded.¹⁴ Because of this apparent parallelism, the traditional software-control structures are not always applicable to embedded systems.

A real-time kernel is used as the engine to drive the embedded application, and the software design consists of threads to perform specific operations, using inter-thread communication facilities provided by the kernel. Although most embedded systems development is done in the C (or C++) programming language, some highly critical portions of the application are often developed in assembly language.

Key Terms and Phrases

control loop with polling priority

determinism real-time kernel embedded system real-time system

interrupt ROMable microprocessor RTOS multithreading scalable preemptive scheduling thread

_

¹⁴ Multithreading is sometimes called multitasking.

Chapter 2

First Look at a System

Using an RTOS

Operating Environment

We will use the Win32 version of Azure RTOS ThreadX because it permits developers to develop prototypes of their applications in the easy-to-use and prevalent Windows programming environment. We achieve complete Azure RTOS ThreadX simulation by using Win32 calls. The Azure RTOS ThreadX-specific application code developed in this environment will execute in an identical fashion on the eventual target hardware. Thus, Azure RTOS ThreadX simulation allows real software development to start well before the actual target hardware is available. We will use Microsoft Visual C/C++ Tools to compile all the embedded systems in this book.

Installation of the Azure RTOS ThreadX Demonstration System

Download a demonstration version of Azure RTOS ThreadX for use with this book. View the Readme file for information about installing and using this demonstration system.

Sample System with Two Threads

The first step in mastering the use of Azure RTOS ThreadX is to understand the nature and behavior of threads. We will achieve this purpose by performing the following operations in this sample system: create several threads, assign several activities to each thread, and compel the threads to cooperate in the execution of their activities. A *mutex*

will be used to coordinate the thread activities, and a memory byte pool will be used to create *stacks* for the threads. (Mutexes and stacks are described in more detail later.)

The first two components that we create are two threads named <code>speedy_thread</code> and <code>slow_thread</code>. <code>speedy_thread</code> will have a higher priority than <code>slow_thread</code> and will generally finish its activities more quickly. Azure RTOS ThreadX uses a preemptive scheduling algorithm, which means that threads with higher priorities generally have the ability to preempt the execution of threads with lower priorities. This feature may help <code>speedy_thread</code> to complete its activities more quickly than <code>slow_thread</code>. Figure 5 contains an illustration of the components that we will use in the sample system.




Figure 5. Components of the sample system

In order to create the threads, you need to assign each of them a *stack*: a place where the thread can store information, such as return addresses and local variables, when it is preempted. Each stack requires a block of contiguous bytes. You will allocate these bytes from a memory byte pool, which you will also create. The memory byte pool could also be used for other Azure RTOS ThreadX objects, but we will restrict its usage to the two threads in this system. There are other methods by which we could assign memory space for a stack, including use of an array and a memory block pool (to be discussed later). We

choose to use the memory byte pool in this sample system only because of its inherent simplicity.

We will use a Azure RTOS ThreadX object called a mutex in this sample system to illustrate the concept of mutual exclusion. Each of the two threads has two sections of code known as *critical sections*. Very generally, a critical section is one that imposes certain constraints on thread execution. In the context of this example, the constraint is that when a thread is executing a critical section, it must not be preempted by any other thread executing a critical section—no two threads can be in their respective critical sections at the same time. A critical section typically contains shared resources, ¹⁵ so there is the potential for system failure or unpredictable behavior when more than one thread is in a critical section.

A *mutex* is an object that acts like a token or gatekeeper. To gain access to a critical section, a thread must acquire "ownership" of the mutex, and only one thread can own a given mutex at the same time. We will use this property to provide inter-thread mutual exclusion protection. For example, if *slow_thread* owns the mutex, then *speedy_thread* must wait to enter a critical section until *slow_thread* gives up ownership of the mutex, even though *speedy_thread* has a higher priority. Once a thread acquires ownership of a mutex, it will retain ownership until it voluntarily gives up that mutex. In other words, no thread can preempt a mutex owned by another thread regardless of either thread's priority. This is an important feature that provides inter-thread mutual exclusion.

Each of the two threads in the sample system has four activities that will be executed repeatedly. Figure 6 contains an illustration of the activities for the *speedy_thread*. Activities 2 and 4 appear in shaded boxes that represent critical sections for that thread. Similarly, Figure 7 contains an illustration of the activities for the *slow_thread*. Note that *speedy_thread* has a priority of 5, which is higher than the priority of 15 that is assigned to the *slow_thread*.

Microsoft

¹⁵ Or, it contains code that accesses shared resources.




Figure 6. Activities of the *speedy_thread* (priority = 5)




Figure 7. Activities of the *slow_thread* (priority = 15)

Creating the Azure RTOS ThreadX Objects

Program listing 02_sample_system.c is located at the end of this chapter. It contains the complete source code for our sample system. Detailed discussion of the specifics of this listing is included in later chapters to provide a highlight of the essential portions of the system. Figure 8 contains a summary of the main features of the source code listing.




Figure 8. Basic structure of sample system

The main () portion of the basic structure contains exactly one executable statement, as follows:

```
tx kernel enter();
```

The above entry function turns over control to Azure RTOS ThreadX (and does not return!). Azure RTOS ThreadX performs initialization of various internal data structures and then processes the application definitions and the thread entry definitions. Azure RTOS ThreadX then begins scheduling and executing application threads. The purpose of the tx_application_define function in our sample system is to define all the Azure RTOS ThreadX components that will be used. For example, we need to define a memory byte pool, two threads, and one mutex. We also need to allocate memory from the byte pool for use as thread stacks. The purpose of the thread entry functions section is to prescribe the behavior of the two threads in the system. We will consider only one of the thread entry functions in this discussion because both entry functions are similar.

```
void Speedy Thread entry(ULONG thread input)
UINT status:
ULONG current_time;
 while (1)
   /* Activity 1: 2 timer-ticks */
   tx_thread_sleep(2);
   /* Get the mutex with suspension */
   tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
   /* Activity 2: 5 timer-ticks */ ** critical section ** */
   tx_thread_sleep(5);
   /* Release the mutex */
   tx_mutex_put(&my_mutex);
   /* Activity 3: 4 timer-ticks */
   tx_thread_sleep(4);
   /* Get the mutex with suspension */
   tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
```

```
/* Activity 4: 3 timer-ticks *** critical section *** */
tx_thread_sleep(3);

/* Release the mutex */
tx_mutex_put(&my_mutex);

current_time = tx_time_get();
printf("Current Time: %5lu Speedy_Thread finished
cycle...\n", current_time);
}

}
```

Figure 9 contains a listing of the entry function for the speedy_thread.

Recall that activities 2 and 4 are the critical sections of *speedy_thread*. Note that *speedy_thread* seeks to obtain ownership of the mutex with the following statement:

```
tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
```

If slow_thread already owns the mutex, then speedy_thread will "wait forever" for its turn to obtain ownership. When speedy_thread completes a critical section, it gives up ownership of the mutex with the following statement:

```
tx mutex put(&my mutex);
```

When this statement is executed, *speedy_thread* relinquishes ownership of the mutex, so it is once again available. If *slow_thread* is waiting for the mutex, it will then have the opportunity to acquire it.

```
void Speedy_Thread_entry(ULONG thread_input)
UINT status:
ULONG current_time;
 while (1)
   /* Activity 1: 2 timer-ticks */
   tx_thread_sleep(2);
   /* Get the mutex with suspension */
   tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
   /* Activity 2: 5 timer-ticks */ ** critical section ** */
   tx_thread_sleep(5);
   /* Release the mutex */
   tx_mutex_put(&my_mutex);
   /* Activity 3: 4 timer-ticks */
   tx_thread_sleep(4);
   /* Get the mutex with suspension */
   tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
   /* Activity 4: 3 timer-ticks *** critical section *** */
   tx_thread_sleep(3);
   /* Release the mutex */
   tx_mutex_put(&my_mutex);
   current time = tx time get();
   printf("Current Time: %5lu Speedy_Thread finished
   cycle...\n", current time);
```

Figure 9. Entry function definition for the speedy_thread

The entry function for *speedy_thread* concludes by getting the current system time and displaying that time, along with a message that *speedy_thread* has finished its current cycle of activities.

Building and Debugging the Sample System

Build and debug the sample system contained in 02_sample_system.c. A complete listing appears in a section at the end of this chapter.

Analysis of the System and the Resulting Output

Figure 10 contains output produced by executing the sample system. Your output should be similar, but not necessarily identical.

The minimum amount of time in which *speedy_thread* can complete its cycle of activities is 14 timer-ticks. By contrast, the *slow_thread* requires at least 40 timer-ticks to complete one cycle of its activities. However, the critical sections of the *slow_thread* will cause delays for the *speedy_thread*. Consider the sample output in Figure 10 where the *speedy_thread* finishes its first cycle at time 34, meaning that it encountered a delay of 20 timer-ticks because of the *slow_thread*. The *speedy_thread* completes subsequent cycles in a more timely fashion but it will always spend a lot of time waiting for the *slow_thread* to complete its critical section.

```
Current Time: 34
                      Speedy Thread finished cycle...
Current Time: 56
Current Time: 77
Current Time: 83
                      Slow Thread finished cycle...
                      Speedy Thread finished cycle...
                      Speedy Thread finished cycle...
                      Slow Thread finished cycle...
Current Time: 99
                      Speedy Thread finished cycle...
Current Time: 120
                      Speedy Thread finished cycle...
Current Time: 126
                      Slow Thread finished cycle...
Current Time: 142
                      Speedy Thread finished cycle...
Current Time: 163
                      Speedy Thread finished cycle...
```

Figure 10. Output produced by sample system

Listing of 02_sample_system.c

The complete listing for $02_sample_system.c$ appears below; line numbers have been added for easy reference.

```
001 /* 02 sample system.c
002
003 Create two threads, one byte pool, and one mutex.
004
   The threads cooperate with each other via the mutex. */
005
006
008 /*
          Declarations, Definitions, and Prototypes */
009 /*****************************
010
011 #include "tx api.h"
012 #include stdio.h.
013
014 #define DEMO STACK SIZE 1024
015 #define DEMO BYTE POOL SIZE 9120
016
017
018 /* Define the Azure RTOS ThreadX object control blocks... */
019
020 TX_THREAD Speedy_Thread;
021 TX_THREAD Slow_Thread;
022
023 TX MUTEX
            my mutex;
024
025 TX BYTE POOL my byte pool;
026
027
028 /* Define thread prototypes. */
029
030 void Speedy Thread entry (ULONG thread input);
031 void Slow Thread entry (ULONG thread input);
032
033
034 /*******************************
035 /*
                  Main Entry Point
036 /*******************************
037
038 /* Define main entry point. */
039
040 int main()
041 {
```

```
042
           /* Enter the Azure RTOS ThreadX kernel. */
043
044
           tx kernel enter();
045 }
046
047
048
    /**********************************
049
050 /*
                                                         * /
                     Application Definitions
    /***********************************
051
052
053
054 /* Define what the initial system looks like. */
055
056 void tx application define (void *first unused memory)
057
058
059 CHAR *pool pointer;
060
061
062
    /* Create a byte memory pool from which to allocate
       the thread stacks. */
063
064
    tx byte pool create (&my byte pool, "my byte pool",
065
                        first unused memory,
066
                        DEMO BYTE POOL SIZE);
067
    /* Put system definition stuff in here, e.g., thread
068
069
       creates and other assorted create information. */
070
071 /* Allocate the stack for the Speedy Thread. */
072
    tx byte allocate(&my byte pool, (VOID **) &pool pointer,
073
                     DEMO STACK SIZE, TX NO WAIT);
074
075
    /* Create the Speedy Thread. */
076 tx thread create (&Speedy Thread, "Speedy Thread",
077
                     Speedy Thread entry, 0,
078
                     pool pointer, DEMO STACK SIZE, 5, 5,
079
                     TX NO TIME SLICE, TX AUTO START);
080
081 /* Allocate the stack for the Slow Thread. */
082 tx byte allocate(&my byte pool, (VOID **) &pool pointer,
```

```
083
                   DEMO STACK SIZE, TX NO WAIT);
084
085 /* Create the Slow Thread. */
    tx thread create (&Slow Thread, "Slow Thread",
086
087
                   Slow Thread entry, 1, pool pointer,
088
                   DEMO STACK SIZE, 15, 15,
089
                   TX NO TIME SLICE, TX AUTO START);
090
091
    /* Create the mutex used by both threads */
    tx mutex create (&my mutex, "my mutex", TX NO INHERIT);
092
093
094
095 }
096
097
099 /*
                      Function Definitions
101
102
103 /* Entry function definition of the "Speedy Thread"
104
      it has a higher priority than the "Slow Thread" */
105
106 void Speedy Thread entry (ULONG thread input)
107 {
108
109 ULONG current time;
110
111
    while (1)
112
113
        /* Activity 1: 2 timer-ticks */
114
        tx thread sleep(2);
115
        /* Get the mutex with suspension */
116
117
        tx mutex get(&my mutex, TX WAIT FOREVER);
118
        /* Activity 2: 5 timer-ticks *** critical section *** */
119
120
       tx thread sleep(5);
121
122
        /* Release the mutex */
123
        tx mutex put(&my_mutex);
```

```
124
125
          /* Activity 3: 4 timer-ticks */
126
          tx thread sleep(4);
127
128
          /* Get the mutex with suspension */
129
          tx mutex get(&my mutex, TX WAIT FOREVER);
130
131
          /* Activity 4: 3 timer-ticks *** critical section ***
* /
132
          tx thread sleep(3);
133
134
          /* Release the mutex */
135
          tx mutex put(&my mutex);
136
137
          current time = tx time get();
          printf("Current Time: %5lu Speedy Thread finished a
138
cycle...\n",
139
                  current time);
140
141
     }
142 }
143
    /****************
144
145
146 /* Entry function definition of the "Slow Thread"
147
       it has a lower priority than the "Speedy Thread" */
148
149 void Slow Thread entry (ULONG thread input)
150 {
151
152
153 ULONG current time;
154
155
     while (1)
156
157
         /* Activity 5 - 12 timer-ticks *** critical section ***
* /
158
159
         /* Get the mutex with suspension */
160
         tx mutex get(&my mutex, TX WAIT FOREVER);
161
```

```
162
          tx thread sleep(12);
163
          /* Release the mutex */
164
165
          tx mutex put(&my mutex);
166
167
          /* Activity 6 - 8 timer-ticks */
168
          tx thread sleep(8);
169
170
          /* Activity 7 - 11 timer-ticks *** critical section *** */
171
          /* Get the mutex with suspension */
172
173
          tx mutex get(&my mutex, TX WAIT FOREVER);
174
175
          tx thread sleep(11);
176
          /* Release the mutex */
177
178
          tx mutex put(&my mutex);
179
180
          /* Activity 8 - 9 timer-ticks */
181
          tx thread sleep(9);
182
183
          current time = tx time get();
          printf("Current Time: %5lu Slow Thread finished a
184
cycle...\n",
185
                  current time);
187
    }
188 }
```

Key Terms and Phrases

application define function preemption critical section priority current time scheduling threads initialization sleep time inter-thread mutual exclusion stack kernel entry suspension memory byte pool template thread mutex

mutual exclusion thread entry function ownership of mutex timer-tick

Problems

22

1. Modify the sample system to compute the average cycle time for the *speedy_thread* and the *slow_thread*. You will need to add several variables and perform several computations in each of the two thread entry functions. You will also need to get the current time at the beginning of each thread cycle.

2. Modify the sample system to bias it in favor of the *speedy_thread*. For example, ensure that *slow_thread* will not enter a critical section if the *speedy_thread* is within two timer-ticks of entering its critical section. In that case, the *slow_thread* would sleep two more timer-ticks and then attempt to enter its critical section.

Chapter 3

RTOS Concepts and Definitions

Introduction

The purpose of this chapter is to review some of the essential concepts and definitions used in embedded systems. You have already encountered several of these terms in previous chapters, and you will read about several new concepts here.

Priorities

Most embedded real-time systems use a priority system as a means of establishing the relative importance of threads in the system. There are two classes of priorities: static and dynamic. A *static priority* is one that is assigned when a thread is created and remains constant throughout execution. A *dynamic priority* is one that is assigned when a thread is created, but can be changed at any time during execution. Furthermore, there is no limit on the number of priority changes that can occur.

Priority Value	Meaning
0	Highest Priority
1	
:	
31	Lowest Priority

Figure 11. Priority Values

Azure RTOS ThreadX provides a flexible method of dynamic priority assignment. Although each thread must have a priority, Azure RTOS ThreadX places no restrictions on how priorities may be used. As an extreme case, all threads could be assigned the same priority that would never change. However, in most cases, priority values are carefully assigned and modified only to reflect the change of importance in the processing of threads. Azure RTOS ThreadX provides priority values from 0 to 1023, in multiples of 32. Figure 11 shows the default priority range of 0 to 31, where the value 0 represents the highest priority and the value 31 represents the lowest priority.

Ready Threads and Suspended Threads

Azure RTOS ThreadX maintains several internal data structures to manage threads in their various states of execution. These data structures represent the Suspended Thread State and the Ready Thread State, or more simply, the suspended state and the ready state. As implied by the nomenclature, threads in the suspended state have been *suspended*—temporarily stopped executing—for some reason. Threads in the ready state are not currently executing but are ready to run.

When a thread is placed in the suspended state, it is because of some event or circumstance, such as being forced to wait for an unavailable resource. Such a thread remains in that state until the event or circumstance has been resolved. When a thread is removed from the suspended state, one of two possible actions occurs: it is placed in the ready state, or it is terminated.




Figure 12. Ready Thread State—Threads ready to be executed are organized by priority, then by FIFO

When a thread is ready for execution, it is placed in the ready state. When Azure RTOS ThreadX schedules a thread for execution, it selects the ready thread that has the highest priority. If all the ready threads have equal priority, Azure RTOS ThreadX selects the thread that has been waiting the longest.² Figure 12 contains an illustration of how threads in the ready state appear.

If for any reason a thread is not ready for execution, it is placed in the suspended state. For example, if a thread is waiting for a resource, if it is in "sleep" mode, if it was created with a TX_DONT_START option, or if it was explicitly suspended, then it will remain in the suspended state until that situation has cleared. Figure 13 contains a depiction of several suspension lists where each list contains threads that are suspended for the same reason. Thus, there may be as many suspension lists as there are causes for suspended threads.




Figure 13. Suspended Thread List—Threads are placed in suspension lists according to the causes of the suspensions

Preemptive, Priority-Based Scheduling

The term *preemptive*, *priority-based scheduling* refers to the type of scheduling in which a higher priority thread can interrupt and suspend a currently executing thread that has a lower priority. Figure 14 contains an example of how this scheduling might occur.




Figure 14. Thread preemption

In this example, Thread 1 has control of the processor. However, Thread 2 has a higher priority and becomes ready for execution. Azure RTOS ThreadX then interrupts Thread 1 and gives Thread 2 control of the processor. When Thread 2 completes its work, Azure RTOS ThreadX returns control to Thread 1 at the point where it was interrupted. The developer does not have to be concerned about the details of the scheduling process. Thus, the developer is able to develop the threads in isolation from one another because the scheduler determines when to execute (or interrupt) each thread.

Round-Robin Scheduling

The term *round-robin scheduling* refers to a scheduling algorithm designed to provide processor sharing in the case in which multiple threads have the same priority. There are two primary ways to achieve this purpose, both of which are supported by Azure RTOS ThreadX.

Figure 15 illustrates the first method of round-robin scheduling, in which Thread 1 is executed for a specified period of time, then Thread 2, then Thread 3, and so on to Thread n, after which the process repeats. See the section titled Time-Slice for more information about this method. The second method of round-robin scheduling is achieved by the use of a cooperative call made by the currently executing thread that temporarily relinquishes control of the processor, thus permitting the execution of other threads of the same or

higher priority. This second method is sometimes called *cooperative multithreading*. Figure 16 illustrates this second method of round-robin scheduling.




Figure 15. Round-robin processing

With cooperative multithreading, when an executing thread relinquishes control of the processor, so that other ready threads at the same priority have an opportunity to access the processor. When those threads have finished processing, the thread that relinquished the processor resumes. For convenience, Figure 16 shows only ready threads with the same priority, but ready threads can have several different priorities.




Figure 16. Example of cooperative multithreading —the currently executing thread (shaded) voluntarily relinquishes the processor and allows other ready threads to access the processor

In summary, the cooperative multithreading feature permits the currently executing thread to voluntarily give up control of the processor. That thread remains in a ready state and it will not gain access to the processor until after all other ready threads that have the same (or higher) priority have been processed.

Determinism

As noted in Chapter 1, an important feature of real-time embedded systems is the concept of determinism. The traditional definition of this term is based on the assumption that for each system state and each set of inputs, a unique set of outputs and next state of the system can be determined. However, we strengthen the definition of determinism for real-time embedded systems by requiring that the time necessary to process any task be predictable. In particular, we are less concerned with average response time than we are with worst-case response time. For example, we must be able to guarantee the worst-case response time for each system call in order for a real-time embedded system to be deterministic. In other words, simply obtaining the correct answer is not adequate. We must get the right answer within a specified time frame.

Many RTOS vendors claim their systems are deterministic and justify that assertion by publishing tables of minimum, average, and maximum number of clock cycles required for each system call. Thus, for a given application in a deterministic system, it is possible to calculate the timing for a given number of threads, and determine whether real-time performance is actually possible for that application.

Kernel

A *kernel* is a minimal implementation of an RTOS. It normally consists of at least a scheduler and a context switch handler. Most modern commercial RTOSes are actually kernels, rather than full-blown operating systems.

RTOS

An RTOS is an operating system that is dedicated to the control of hardware, and must operate within specified time constraints. Most RTOSes are used in embedded systems.

Context Switch

A *context* is the current execution state of a thread. Typically, it consists of such items as the program counter, registers, and stack pointer. The term *context switch* refers to the saving of one thread's context and restoring a different thread's context so that it can be executed. This normally occurs as a result of preemption, interrupt handling, time-slicing (see below), cooperative round-robin scheduling (see below), or suspension of a thread

because it needs an unavailable resource. When a thread's context is restored, then the thread resumes execution at the point where it was stopped. The kernel performs the context switch operation. The actual code required to perform context switches is necessarily processor-specific.

Time-Slice

The length of time (i.e., number of timer-ticks) for which a thread executes before relinquishing the processor is called its *time-slice*. When a thread's (optional) time-slice expires in Azure RTOS ThreadX, all other threads of the same or higher priority levels are given a chance to execute before the time-sliced thread executes again. Time-slicing provides another form of round-robin scheduling. Azure RTOS ThreadX provides optional time-slicing on a per-thread basis. The thread's time-slice is assigned during creation and can be modified during execution. If the time-slice is too short, then the scheduler will waste too much processing time performing context switches. However, if the time-slice is too long, then threads might not receive the attention they need.

Interrupt Handling

An essential requirement of real-time embedded applications is the ability to provide fast responses to asynchronous events, such as hardware or software interrupts. When an interrupt occurs, the context of the executing thread is saved and control is transferred to the appropriate interrupt vector. An *interrupt vector* is an address for an *interrupt service routine (ISR)*, which is user-written software designed to handle or service the needs of a particular interrupt. There may be many ISRs, depending on the number of interrupts that needs to be handled. The actual code required to service interrupts is necessarily processor-specific.

Thread Starvation

One danger of preemptive, priority-based scheduling is *thread starvation*. This is a situation in which threads that have lower priorities rarely get to execute because the processor spends most of its time on higher-priority threads. One method to alleviate this problem is to make certain that higher-priority threads do not monopolize the processor. Another solution would be to gradually raise the priority of starved threads so that they do get an opportunity to execute.

Priority Inversion

Undesirable situations can occur when two threads with different priorities share a common resource. *Priority inversion* is one such situation; it arises when a higher-priority thread is suspended because a lower-priority thread has acquired a resource needed by the higher-priority thread. The problem is compounded when the shared resource is not in use while the higher-priority thread is waiting because a medium-priority thread has preempted the lower-priority thread and is running. This phenomenon may cause the time of the priority inversion to become nondeterministic and may lead to application failure. Consider Figure 17, which shows an example of the priority inversion problem.




Figure 17. Example of priority inversion

In this example, Thread 3 (with the lowest priority) becomes ready. It obtains mutex M and begins its execution. Sometime later, Thread 2 (which has a higher priority) becomes ready, preempts Thread 3, and begins its execution. Then Thread 1 (which has the highest priority of all) becomes ready. However, it needs mutex M, which is owned by Thread 3, so it is suspended until mutex M becomes available. Thus, the higher-priority thread (i.e., Thread 1) must wait for the lower-priority thread (i.e., Thread 2) before it can continue.

During this wait, the resource protected by mutex M is not being used because Thread 3 has been preempted by Thread 2. The concept of priority inversion is discussed more thoroughly in Chapters 6 and 9.

Priority Inheritance

Priority inheritance is an optional feature that is available with Azure RTOS ThreadX for use only with the mutex services. (Mutexes are discussed in more detail in the next chapter.) Priority inheritance allows a lower-priority thread to temporarily assume the priority of a higher-priority thread that is waiting for a mutex owned by the lower-priority thread. This capability helps the application to avoid nondeterministic priority inversion by eliminating preemption of intermediate thread priorities. This concept is discussed more thoroughly in Chapters 5 and 6.

Preemption-Threshold

Preemption-threshold¹⁶ is a feature that is unique to Azure RTOS ThreadX. When a thread is created, the developer has the option of specifying a priority ceiling for disabling preemption. This means that threads with priorities greater than the specified ceiling are still allowed to preempt, but those with priorities equal to or less than the ceiling are not allowed to preempt that thread. The preemption-threshold value may be modified at any time during thread execution. Consider Figure 18, which illustrates the impact of preemption-threshold. In this example, a thread is created and is assigned a priority value of 20 and a preemption-threshold of 15. Thus, only threads with priorities higher than 15 (i.e., 0 through 14) will be permitted to preempt this thread. Even though priorities 15 through 19 are higher than the thread's priority of 20, threads with those priorities will not be allowed to preempt this thread. This concept is discussed more thoroughly in Chapters 5 and 6.

¹⁶ Preemption-threshold is a trademark of Microsoft. There are several university research papers that analyze the use of preemption-threshold in real-time scheduling algorithms.

Priority	Comment
Preemption allowed for threads with	
U	priorities between 0 and 14 (inclusive)
:	
14	
15	Preemption Threshold = 15 [this has the effect of disabling preemption for threads with priority values between 15 and 19 (inclusive)]
:	
19	
20	Thread Priority = 20
:	
31	

Figure 18. Example of preemption-threshold

Key Terms and Phrases

asynchronous event	ready state
context switch	ready thread
cooperative multithreading	round-robin scheduling
determinism	RTOS
interrupt handling	scheduling
kernel	sleep mode
preemption	suspended state
preemption-threshold	suspended thread
priority	thread starvation
priority inheritance	time-slice
priority inversion	timer-tick

Problems

1. When a thread is removed from the suspended state, either it is placed in the ready state or it is terminated. Explain why there is not an option for that thread to become the currently executing thread immediately after leaving the suspended state.

- 2. Suppose every thread is assigned the same priority. What impact would this have on the scheduling of threads? What impact would there be if every thread had the same priority and was assigned the same duration time-slice?
- 3. Explain how it might be possible for a preempted thread to preempt its preemptor? Hint: Think about priority inheritance.
- 4. Discuss the impact of assigning every thread a preemption-threshold value of 0 (the highest priority).

Chapter 4 RTOS Building Blocks for System Development

Introduction

An RTOS must provide a variety of services to the developer of real-time embedded systems. These services allow the developer to create, manipulate, and manage system resources and entities in order to facilitate application development. The major goal of this chapter is to review the services and components that are available with Azure RTOS ThreadX. Figure 19 contains a summary of these services and components.

Threads	Message Queues	Counting Semaphores
Mutexes	Event Flags	Memory Block Pools
Memory Byte Pools	Application Timers	Time Counter & Interrupt Control

Figure 19. Azure RTOS ThreadX components

Defining Public Resources

Some of the components discussed are indicated as being *public* resources. If a component is a public resource, it means that it can be accessed from any thread. Note that accessing a component is not the same as owning it. For example, a mutex can be accessed from any thread, but it can be owned by only one thread at a time.

Azure RTOS ThreadX Data Types

Azure RTOS ThreadX uses special primitive data types that map directly to data types of the underlying C compiler. This is done to ensure portability between different C compilers. Figure 20 contains a summary of Azure RTOS ThreadX service call data types and their associated meanings.

Data Type	Description
UINT	Basic unsigned integer. This type must support 8-bit unsigned data; however, it is mapped to the most convenient unsigned data type, which may support 16- or 32-bit signed data.
ULONG	Unsigned long type. This type must support 32-bit unsigned data.
VOID	Almost always equivalent to the compiler's void type.
CHAR	Most often a standard 8-bit character type.

Figure 20. Azure RTOS ThreadX primitive data types

In addition to the primitive data types, Azure RTOS ThreadX uses system data types to define and declare system resources, such as threads and mutexes. Figure 21 contains a summary of these data types.

System Data Type	System Resource
TX_TIMER	Application Timer
TX_QUEUE	Message Queue
TX_THREAD	Application Thread
TX_SEMAPHORE	Counting Semaphore
TX_EVENT_FLAGS_GROUP	Event Flags Group
TX_BLOCK_POOL	Memory Block Pool
TX_BYTE_POOL	Memory Byte Pool
TX_MUTEX	Mutex

Figure 21. Azure RTOS ThreadX system data types

Thread

A thread is a semi-independent program segment. Threads within a process share the same memory space, but each thread must have its own stack. Threads are the essential building blocks because they contain most of the application programming logic. There is

no explicit limit on how many threads can be created and each thread can have a different stack size. When threads are executed, they are processed independently of each other.

Thread Control Block	
thread name	
thread entry input	
stack (pointer and size)	Thread entry function
priority	Thread entry function
preemption-threshold	
time-slice	
start option	

Figure 22. Attributes of a thread

When a thread is created, several attributes need to be specified, as indicated in Figure 22. Every thread must have a Thread Control Block (TCB) that contains system information critical to the internal processing of that thread. However, most applications have no need to access the contents of the TCB. Every thread is assigned a name, which is used primarily for identification purposes. The thread entry function is where the actual C code for a thread is located. The thread entry input is a value that is passed to the thread entry function when it first executes. The use for the thread entry input value is determined exclusively by the developer. Every thread must have a stack, so a pointer to the actual stack location is specified, as well as the stack size. The thread priority must be specified but it can be changed during run-time. The preemption-threshold is an optional value; a value equal to the priority disables the preemption-threshold feature. An optional time-slice may be assigned, which specifies the number of timer-ticks that this thread is allowed to execute before other ready threads with the same priority are permitted to run. Note that use of preemption-threshold disables the time-slice option. A time-slice value of zero (0) disables time-slicing for this thread. Finally, a start option must be specified that indicates whether the thread starts immediately or whether it is placed in a suspended state where it must wait for another thread to activate it.

Memory Pools

Several resources require allocation of memory space when those resources are created. For example, when a thread is created, memory space for its stack must be provided. Azure RTOS ThreadX provides two memory management techniques. The developer

may choose either one of these techniques for memory allocation, or any other method for allocating memory space.

The first of the memory management techniques is the memory byte pool, which is illustrated in Figure 23. As its name implies, the memory byte pool is a sequential collection of bytes that may be used for any of the resources. A memory byte pool is similar to a standard C heap. Unlike the C heap, there is no limit on the number of memory byte pools. In addition, threads can suspend on a pool until the requested memory is available. Allocations from a memory byte pool are based on a specified number of bytes. Azure RTOS ThreadX allocates from the byte pool in a *first-fit* manner, i.e., the first free memory block that satisfies the request is used. Excess memory from this block is converted into a new block and placed back in the free memory list, often resulting in *fragmentation*. Azure RTOS ThreadX *merges* adjacent free memory blocks together during a subsequent allocation search for a large enough block of free memory. This process is called *defragmentation*.




Figure 23. Memory byte pool

Figure 24 contains the attributes of a memory byte pool. Every memory byte pool must have a Control Block that contains essential system information. Every memory byte pool is assigned a name, which is used primarily for user identification purposes. The starting address of the byte pool must be provided, as well as the total number of bytes to be allocated to the memory byte pool.

The second type of memory management technique is the memory block pool, which is illustrated in Figure 25. A memory block pool consists of fixed-size memory blocks, so there is never a fragmentation problem. There is a lack of flexibility because the same amount of memory is allocated each time. However, there is no limit as to how many memory block pools can be created, and each pool could have a different memory block size. In general, memory block pools are preferred over memory byte pools because the fragmentation problem is eliminated and because access to the pool is faster.

Memory byte pool control block
Memory byte pool name
Location of byte pool
Total number of bytes allocated

Total number of bytes allocated
Figure 24. Attributes of a memory byte pool

Figure 26 contains the attributes of a memory block pool. Every memory block pool must have a Control Block that contains important system information. Every memory block pool is assigned a name, which is used primarily for identification purposes. The number of bytes in each fixed-size memory block must be specified. The address where the memory block pool is located must be provided. Finally, the total number of bytes available to the entire memory block pool must be indicated.

Fixed-size block
Fixed-size block
Fixed-size block
:
Fixed-size block

Figure 25. Memory block pool

Memory block pool control block
Memory block pool name
Number of bytes in each memory block
Location of memory block pool
Total number of bytes available

Figure 26. Attributes of a memory block pool

The total number of memory blocks in a memory block pool can be calculated as follows:

```
Total \ Number \ of \ Blocks \ = \ \frac{\textit{Total Number of Bytes Available}}{(\textit{Number of Bytes in Each Memory Block}) + (\textit{sizeof (void*)})}
```

Each memory block contains one pointer of overhead that is invisible to the user and is represented by the *sizeof* (*void**) expression in the preceding formula. Avoid wasting memory space by correctly computing the total number of bytes to allocate, based on the number of desired memory blocks.

Application Timer

Fast response to asynchronous external events is the most important function of real-time, embedded applications. However, many of these applications must also perform certain activities at predetermined intervals of time. Application timers enable applications to execute application C functions at specific intervals of time. It is also possible for an application timer to expire only once. This type of timer is called a *one-shot timer*, while repeating interval timers are called *periodic timers*. Each application timer is a public resource.

Application timer control block
Application timer name
Expiration function to call
Expiration input value to pass to function
Initial number of timer-ticks
Reschedule number of timer-ticks
Automatic activate option

Figure 27. Attributes of an application timer

Figure 27 contains the attributes of an application timer. Every application timer must have a Control Block that contains essential system information. Every application timer is assigned a name, which is used primarily for identification purposes. Other attributes include the name of the expiration function that is executed when the timer expires. Another attribute is a value that is passed to the expiration function. (This value is for the use of the developer.) An attribute containing the initial number of timer-ticks¹⁷ for the timer expiration is required, as is an attribute specifying the number of timer-ticks for all timer expirations after the first. The last attribute is used to specify whether the application timer is automatically activated at creation, or whether it is created in an inactive state that would require a thread to start it.

 $^{^{17}}$ The actual time between timer-ticks is specified by the application, but 10 ms is the value used here.

Application timers are very similar to ISRs, except the actual hardware implementation (usually a single periodic hardware interrupt is used) is hidden from the application. Such timers are used by applications to perform time-outs, periodic operations, and/or watchdog services. Just like ISRs, application timers most often interrupt thread execution. Unlike ISRs, however, application timers cannot interrupt each other.

Mutex

The sole purpose of a mutex is to provide mutual exclusion; the name of this concept provides the derivation of the name mutex (i.e., MUTual EXclusion). ¹⁸ A mutex is used to control the access of threads to critical section or certain application resources. A mutex is a public resource that can be owned by one thread only. There is no limit on the number of mutexes that can be defined. Figure 28 contains a summary of the attributes of a mutex.

Mutex control block
Mutex name
Priority inheritance option

Figure 28. Attributes of a mutex

Every mutex is assigned a name, which is used primarily for identification purposes. The third attribute indicates whether this mutex supports priority inheritance. Priority inheritance allows a lower-priority thread to temporarily assume the priority of a higher-priority thread that is waiting for a mutex owned by the lower-priority thread. This capability helps the application to avoid nondeterministic priority inversion by eliminating preemption of intermediate thread priorities. The mutex is the only Azure RTOS ThreadX resource that supports priority inheritance.

Counting Semaphore

A counting semaphore is a public resource. There is no concept of ownership of semaphores, as is the case with mutexes. The primary purposes of a counting semaphore

¹⁸ In the 1960s, Edsger Dijkstra proposed the concept of a mutual exclusion semaphore with two operations: the P operation (Prolaag, meaning to lower) and the V operation (Verhogen, meaning to raise). The P operation decrements the semaphore if its value is greater than zero, and the V operation increments the semaphore value. P and V are atomic operations.

are event notification, thread synchronization, and mutual exclusion. Azure RTOS ThreadX provides 32-bit counting semaphores where the count must be in the range from 0 to 4,294,967,295 or 2^{32} –1 (inclusive). When a counting semaphore is created, the count must be initialized to a value in that range. Each value in the semaphore is an *instance* of that semaphore. Thus, if the semaphore count is five, then there are five instances of that semaphore.

Figure 29 contains the attributes of a counting semaphore. Every counting semaphore must have a Control Block that contains essential system information. Every counting semaphore is assigned a name, which is used primarily for identification purposes. Every counting semaphore must have a Semaphore Count that indicates the number of instances available. As noted above, the value of the count must be in the range from 0x00000000 to 0xFFFFFFF (inclusive). A counting semaphore can be created either during initialization or during run-time by a thread. There is no limit to the number of counting semaphores that can be created.

Counting semaphore control block		
Counting semaphore name		
Semaphore count		

Figure 29. Attributes of a counting semaphore

Event Flags Group

An event flags group is a public resource. Event flags provide a powerful tool for thread synchronization. Each event flag is represented by a single bit, and event flags are arranged in groups of 32. When an event flags group is created, all the event flags are initialized to zero.

Figure 30 contains the attributes of an event flags group. Every event flags group must have a Control Block that contains essential system information. Every event flags group is assigned a name, which is used primarily for identification purposes. There must also be a group of 32 one-bit event flags, which is located in the Control Block.

Event flags group control block

¹⁹ In this instance, mutual exclusion is normally achieved with the use of a binary semaphore, which is a special case of a counting semaphore where the count is restricted to the values zero and one.

Event flags group name
Group of 32 one-bit event flags

Figure 30. Attributes of an event flags group

Event flags provide a powerful tool for thread synchronization. Threads can operate on all 32 event flags at the same time. An event flags group can be created either during initialization or during run-time by a thread. Figure 31 contains an illustration of an event flags group after it has been initialized. There is no limit to the number of event flags groups that can be created.




Figure 31. An event flags group

Message Queue

A message queue is a public resource. Message queues are the primary means of interthread communication. One or more messages can reside in a message queue. A message queue that holds a single message is commonly called a *mailbox*. Messages are placed at the rear of the queue,²⁰ and are removed from the front of the queue.

Message Queue Control Block
Message Queue Name
Size of each Message
Location of Message Queue
Total Size of the Message Queue

Figure 32. Attributes of a message queue

Figure 32 contains the attributes of a message queue. Every message queue must have a Control Block that contains essential system information. Every message queue is assigned a name, which is used primarily for identification purposes. Other attributes include the message size, the address where the message queue is located, and the total number of bytes allocated to the message queue. If the total number of bytes allocated to

 $^{^{\}rm 20}$ It is also possible to insert a message at the front of the queue.

the message queue is not evenly divisible by the message size, then the remaining bytes are not used.

Figure 33 contains an illustration of a message queue. Any thread may insert a message in the queue (if space is available) and any thread may remove a message from a queue.

messages inserted at rear of queue messages removed from front of queue message_n | ••• | message_3 | message_2 | message_1

Figure 33. A message queue

	Mutex	Counting Semaphore	
Speed	Somewhat slower than a semaphore	A semaphore is generally faster than a mutex and requires fewer system resources	
Thread Ownership	Only one thread can own a mutex	No concept of thread ownership for a semaphore – any thread can decrement a counting semaphore if its current count exceeds zero	
Priority Inheritance	Available only with a mutex	Feature not available for semaphores	
Mutual Exclusion	Primary purpose of a mutex – a mutex should be used only for mutual exclusion	Can be accomplished with the use of a binary semaphore, but there may be pitfalls	
Inter-Thread Synchronization	Do not use a mutex for this purpose	Can be performed with a semaphore, but an event flags group should be considered also	
Event Notification	Do not use a mutex for this purpose	Can be performed with a semaphore	
Thread Suspension	Thread can suspend if another thread already owns the mutex (depends on value of wait option)	Thread can suspend if the value of a counting semaphore is zero (depends on value of wait option)	

Figure 34. Comparison of a mutex with a counting semaphore

Summary of Thread Synchronization and Communication Components

Similarities exist between a mutex and a counting semaphore, especially when implementing mutual exclusion. In particular, a binary semaphore has many of the same

properties as that of a mutex. Figure 34 contains a comparison of these two resources and recommendations as to how each should be used.

We discussed four public resources that a thread can use for various purposes, as well as four types of situations where each can be useful. Figure 35 contains a summary of the recommended uses of these resources.

	Thread Synchronization	Event Notification	Mutual Exclusion	Inter-Thread Communication
Mutex	Cynonicalion	Houncation	Preferred	Communication
Counting Semaphore	OK – better for one event	Preferred	ОК	
Event Flags Group	Preferred	ОК		
Message Queue	OK	ОК		Preferred

Figure 35. Recommended uses of resources

Key Terms and Phrases

application timer	mutex ownership
binary semaphore	mutual exclusion
control block	one-shot timer
counting semaphore	periodic timer
defragmentation	preemption
entry function	preemption-threshold
event flags group	primitive data type
event notification	priority
first-fit allocation	priority inheritance
fragmentation	public resource
heap	service call
ISR	stack
mailbox	system data type
memory block pool	thread
memory byte pool	thread suspension
message queue	thread synchronization

mutex

watchdog timer

Problems

- 1. Explain why the special primitive data types UINT, ULONG, VOID, and CHAR are used for service calls, rather than the standard C primitive data types.
- 2. What is the purpose of the thread entry function?
- 3. Under what circumstances would you use a binary semaphore rather than a mutex for mutual exclusion?
- 4. There is only one public resource that can be owned by a thread. Which resource is that?
- 5. Suppose you have a choice in using either a memory byte pool or a memory block pool. Which should you choose? Justify your answer.
- 6. What does it mean to get an instance of a counting semaphore?
- 7. What is the maximum number of numeric combinations that can be represented by an event flags group?
- 8. Messages are usually added to the rear of a message queue. Why would you want to add a message to the front of a message queue?
- 9. Discuss the differences between a one-shot timer and a periodic timer.
- 10. What is a timer-tick?

Chapter 5

The Thread—The Essential

Component

Introduction

You have investigated several aspects of threads in previous chapters, including their purpose, creation, composition, and usage. In this chapter, you will explore all the services that directly affect threads. To get started, you will review the purpose as well as the contents of the Thread Control Block. You will also examine each of the thread services, with an emphasis on the features and capabilities of each service.

Thread Control Block

The Thread Control Block (TCB)²¹ is a structure used to maintain the state of a thread during run-time. It is also used to preserve information about a thread when a context switch becomes necessary. Figure 36 contains many of the fields that make up the TCB.

Description
Control block ID
Thread's run counter
Thread's stack pointer
Stack starting address

Field	Description
tx state	Thread's
ix_state	execution state
tx_delayed_suspend	Delayed
tx_delayed_suspend	suspend flag
	Thread
tx_suspending	suspending
	flag
tx_preempt_threshold	Preemption-
rx_preempt_tilleshold	threshold

 $^{^{21}}$ The characteristics of each thread are contained in its TCB. This structure is defined in the tx_api.h file.

Azure RTOS ThreadX

tx_stack_end	Stack ending address
tx_stack_size	Stack size
tx_time_slice	Current time- slice
tx_new_time_slice	New time-slice
*tx_ready_next	Pointer to the next ready thread
*tx_ready_previous	Pointer to the previous ready thread
tx_thread_name	Pointer to thread's name
tx_priority	Priority of thread (0-31)

tx_priority_bit	Priority ID bit
*tx_thread_entry	Thread function entry point
tx_entry_parameter	Thread function parameter
tx_thread_timer	Thread timer block
*tx_suspend_cleanup	Thread's cleanup function and associated data
*tx_created_next	Pointer to the next thread in the created list
*tx_created_previous	Pointer to the previous thread in the created list

Figure 36. Thread Control Block

A TCB can be located anywhere in memory, but it is most common to make the Control Block a global structure by defining it outside the scope of any function. ²² Locating the Control Block in other areas requires a bit more care, as is the case for all dynamically allocated memory. If a Control Block were allocated within a C function, the memory associated with it would be allocated on the calling thread's stack. In general, avoid using local storage for Control Blocks because once the function returns, then its entire local variable stack space is released—regardless of whether another thread is using it for a Control Block.

In most cases, the developer need not know the contents of the TCB. However, in some situations, especially during debugging, inspecting certain fields (or members) becomes

²² Comments about the storage and use of the TCB are also applicable to Control Blocks for other Azure RTOS ThreadX entities.

quite useful. Figure 37Figure 37. Two useful members of the Thread Control Block contains detailed information about two of the more useful TCB fields for developers.

tx_run_count	This member contains a count of how many times the thread has been scheduled. An increasing counter indicates the thread is being scheduled and executed.	
tx_state	This member contains the state of the associated thread. The following list represents the possible thread states:	
	TX_READY	0x00
	TX_COMPLETED	0x01
	TX_TERMINATED	0x02
	TX_SUSPENDED	0x03
	TX_SLEEP	0x04
	TX_QUEUE_SUSP	0x05
	TX_SEMAPHORE_SUSP	0x06
	TX_EVENT_FLAG	0x07
	TX_BLOCK_MEMORY	0x08
	TX_BYTE_MEMORY	0x09
	TX_MUTEX_SUSP	0x0D
	TX_IO_DRIVER	0x0A

Figure 37. Two useful members of the Thread Control Block

There are many other useful fields in the TCB, including the stack pointer, time-slice value, and priority. The developer may inspect the members of the TCB, but is strictly prohibited from modifying them. There is no explicit value that indicates whether the thread is currently executing. Only one thread executes at a given time, and Azure RTOS ThreadX keeps track of the currently executing thread elsewhere. Note that the value of tx_state for an executing thread is TX_READY.

Summary of Thread Services

Appendices A through J form a Azure RTOS ThreadX User Guide. Each of these 10 appendices is devoted to a particular Azure RTOS ThreadX service. Appendix H contains detailed information about thread services, including the following items for each service: prototype, brief description of the service, parameters, return values, notes and warnings, allowable invocation, preemption possibility, and an example that illustrates how the

service can be used. Figure 38 contains a listing of all available thread services. In the following sections of this chapter, we will study each of these services. We will consider the many features of the services, and we will develop several illustrative examples.

Thread Service	Description
tx_thread_create	Create an application thread
tx_thread_delete	Delete an application thread
tx_thread_identify	Retrieves pointer to currently executing thread
tx_thread_info_get	Retrieve information about a thread
tx_thread_preemption_change	Change preemption-threshold of application thread
tx_thread_priority_change	Change priority of an application thread
tx_thread_relinquish	Relinquish control to other application threads
tx_thread_resume	Resume suspended application thread
tx_thread_sleep	Suspend current thread for specified time
tx_thread_suspend	Suspend an application thread
tx_thread_terminate	Terminates an application thread
tx_thread_time_slice_change	Changes time-slice of application thread
tx_thread_wait_abort	Abort suspension of specified thread
	00 Ti I I

Figure 38. Thread services

Thread Creation

A thread is declared with the TX_THREAD data type²³ and is defined with the tx_thread_create service. Each thread must have its own stack; the developer determines the stack size and the manner in which memory is allocated for the stack. Figure 39 illustrates a typical thread stack. There are several methods of allocating memory for the stack, including use of byte pools, block pools, and arrays; or simply specifying a physical starting address in memory. The stack size is crucial; it must be large enough to accommodate worst-case function call nesting, local variable allocation, and saving the thread's last execution context. The predefined minimum stack size constant, TX_MINIMUM_STACK, is probably too small for most applications. It is better to err toward a larger than a smaller stack.

²³ When a thread is declared, a Thread Control Block is created.

After a developer has debugged the application, he/she can fine-tune the stack in an attempt to reduce its size. One technique for determining stack space needed is to preset all stack areas with an easily identifiable data pattern, such as 0xEFEF, prior to creating the threads. After thoroughly testing the application, you can deduce how much space was actually used by finding the area of the stack where the preset pattern is still intact.

Threads can require stacks that are quite large. Therefore, it is important to design applications that create a reasonable number of threads and that avoid excessive stack usage within threads. Developers should generally avoid recursive algorithms and large local data structures.




Figure 39. Typical thread stack

What happens when a stack area is too small? In most cases, the run-time environment simply assumes there is enough stack space. This causes thread execution to corrupt memory adjacent to (usually before) its stack area. The results are very unpredictable, but most often include an unnatural change in the program counter. This is often called

jumping into the weeds. Of course, the only way to prevent this problem is to ensure that all thread stacks are large enough.

An important feature of multithreading is that the same C function can be called from multiple threads. This feature provides considerable versatility and also helps reduce code space. However, it does require that C functions called from multiple threads be reentrant. A reentrant function is one that can be safely called while it is already being executed. This would happen if, for example, the function were being executed by the current thread and then called again by a preempting thread.²⁴ To achieve reentrancy, a function stores the caller's return address on the current stack (as opposed to storing it, say, in a register) and does not rely on global or static C variables that it has previously set up. Most compilers do place the return address on the stack. Hence, application developers need only worry about the use of *globals* and *statics*.

An example of a non-reentrant function is the string token function strtok found in the standard C library. This function remembers the previous string pointer on subsequent calls by saving the pointer in a static variable. If this function were called from multiple threads, it would most likely return an invalid pointer.

Chapter 4 illustrates the various building blocks available in Azure RTOS ThreadX, including thread attributes. For convenience, the attributes of a thread are illustrated again in Figure 40. We will use the tx_thread_create service to create several threads in order to illustrate these attributes.

Thread Control Block	
thread name	
thread entry input	
stack (pointer and size)	Throad ontry function
priority	Thread entry function
preemption-threshold	
time-slice	
start option	

Figure 40. Attributes of a thread

For the first thread creation example, we will create a thread of priority 15 whose entry point is "my thread entry." This thread's stack area is 1,000 bytes in size, starting at

Microsoft

²⁴ It can also happen if the function is called recursively.

address 0x400000. We will not use the preemption-threshold feature and we will disable time-slicing. We will place the thread in a ready state as soon as it is created. We also need to create a thread entry function to complete the example. Figure 41 contains the code necessary to create a thread and its corresponding entry function.

```
TX THREAD my thread;
UINT status;
/* Create a thread of priority 15 whose entry point is
   "my thread entry". This thread's stack area is 1000
  bytes in size, starting at address 0x400000. The
  preemption-threshold is set equal to thread priority to
  disable the preemption threshold feature. Time-slicing
   is disabled. This thread is automatically put into a
   ready condition. */
status = tx thread create(&my thread, "my thread",
                          my thread entry, 0x1234,
                          (VOID *) 0x400000, 1000,
                          15, 15, TX NO TIME SLICE,
                          TX AUTO START);
/* If status equals TX SUCCESS, my thread is ready
   for execution */
/* Thread entry function - When "my thread" begins
   execution, control is transferred to this function */
VOID my thread entry (ULONG initial input)
/* The real work of the thread, including calls to
   other functions should be done here */
```

Figure 41. Creating a thread with priority 15

In this figure, the line

 $TX_THREAD\ my_thread;$

is used to define a thread called *my_thread*. Recall that TX_THREAD is a data type used to define a TCB. The line

UINT status;

declares a variable to store the return value from the service call invocation. Each time we invoke a service call, we will check the value of this status variable to determine whether the call was successful. We will use this convention for all invocations to service calls, not just for thread services. The lines beginning with

```
status = tx_thread_create ( ... );
```

create the thread, where the parameters specify the characteristics of the thread. Figure 42 contains descriptions for these parameters.

Parameter	Description
&my_thread	Pointer to a thread control block (defined by TX_THREAD)
"my_thread"	Pointer to the name of the thread – a user-defined name
my_thread_entry	Name of the thread entry function; when the thread begins execution, control is passed to this function
0x1234	A 32-bit value passed to the thread entry function – this value is reserved for the exclusive use of the application
(VOID *) 0x400000	Starting address of the stack's memory area; we used an actual address for the beginning location of the stack, although we have many choices on how to allocate stack space
1000	Number of bytes in the stack memory area
15	Priority – a value in the range from 0 to 31 (inclusive) must be specified
15	Preemption-threshold – a value equal to the priority disables preemption-threshold
TX_NO_TIME_SLICE	Time-slice option – this means we have disabled time- slicing for this thread
TX_AUTO_START	Initial thread status – this means that the thread starts immediately upon creation

Figure 42. Thread create parameters used in previous figure

We need to create a thread entry function for this thread. In this case, the lines

```
VOID my_thread_entry (ULONG initial_input)
{
...
}
```

define that function. As noted earlier, the real work of the thread, including calls to other functions, occurs in this function. The initial_input value is passed to the function and is used exclusively by the application. Many entry functions are in a "do forever" loop and never return, but if the function does return, then the thread is placed in a "completed" state. If a thread is placed in this state, it cannot be executed again.

Consult the appendices to find thorough descriptions of the parameters for all the service calls, as well as the return values that indicate whether a call was successful, and if not, the exact cause of the problem.

For our next thread creation example, we will create a thread of priority 20, also with an entry point of "my_thread_entry." This thread's stack area is 1,500 bytes in size, starting at address &my_stack. We will use a preemption-threshold value of 14 and we will disable time-slicing. Note that using preemption-threshold automatically disables time-slicing. A preemption-threshold value of 14 means that this thread can be preempted only by threads with priorities higher than 14, i.e., priorities from 0 to 13 (inclusive). Figure 43 contains the code necessary to create this thread.

```
TX_THREAD my_thread;
UINT status;

/* Create a thread of priority 20 whose entry point is "my_thread_entry". This thread's stack area is 1500 bytes in size, starting at address &my_stack. The preemption-threshold is setup to allow preemption at priorities above 14. Time-slicing is disabled. This thread is automatically put into a ready condition. */

status = tx_thread_create(&my_thread, "my_thread", my_thread_entry, 0x1234, &my_stack, 1500, 20, 14, TX_NO_TIME_SLICE, TX_AUTO_START);

/* If status equals TX_SUCCESS, my_thread is ready for execution */
```

Figure 43. Creating a thread with priority = 20 and preemption-threshold = 14

For our final thread creation example, we will create a thread of priority 18, again with an entry point of "my thread entry" and a stack starting at &my_stack. This thread's stack

area is 1,000 bytes in size. We will not use preemption-threshold value but we will use a time-slice value of 100 timer-ticks. Figure 44 contains the code necessary to create this thread. Note that time-slicing does result in a small amount of system overhead. It is useful only in cases in which multiple threads share the same priority. If threads have unique priorities, time-slicing should not be used.

```
TX_THREAD my_thread;
UINT status;

/* Create a thread of priority 18 whose entry point is "my_thread_entry". This thread's stack area is 1000 bytes in size, starting at address &my_stack. The preemption-threshold feature is disabled. The time-slice is 100 timer-ticks. This thread is automatically put into a ready condition. */

status = tx_thread_create(&my_thread, "my_thread", my_thread_entry, 0x1234, &my_stack, 1000, 18, 18, 100, TX_AUTO_START);

/* If status equals TX_SUCCESS, my_thread is ready for execution */
```

Figure 44. Creating a thread with priority 18 and no preemption-threshold

There are eight possible return values for thread creation, but only one indicates a successful thread creation. Make certain that you check the return status after every service call.

Thread Deletion

A thread can be deleted only if it is in a terminated or completed state. Consequently, this service cannot be called from a thread attempting to delete itself. Typically, this service is called by timers or by other threads. Figure 45 contains an example showing how thread *my_thread* can be deleted.

```
TX_THREAD my_thread;
UINT status;
...
/* Delete an application thread whose control block is created with a call to tx_thread_create. */
status = tx_thread_delete(&my_thread);
/* If status equals TX_SUCCESS, the application thread has been deleted. */
```

Figure 45. Deletion of thread *my_thread*

It is the responsibility of the application to manage the memory area used by the deleted thread's stack, which is available after the thread has been deleted. Furthermore, the application must prevent use of a thread after it has been deleted.

Identify Thread

The tx_thread_identify service returns a pointer to the currently executing thread. If no thread is executing, this service returns a null pointer. Following is an example showing how this service can be used.

```
my_thread_ptr = tx_thread_identify();
```

If this service is called from an ISR, then the return value represents the thread that was running prior to the executing interrupt handler.

Get Thread Information

All the Azure RTOS ThreadX objects have three services that enable you to retrieve vital information about that object. The first such service for threads—the tx_thread_info_get service—retrieves a subset of information from the Thread Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the tx_thread_performance_info_get service—provides an information summary for a particular thread up to the time the service is invoked. By contrast the tx_thread_performance_system_info_get retrieves an information summary for all threads in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_thread_info_get25 service obtains information that includes the thread's current execution state, run count, priority, preemption-threshold, time-slice, pointer to the next created thread, and pointer to the next thread in the suspension list. Figure 46 shows how this service can be used.

Azure RTOS ThreadX

²⁵ By default, only the tx_thread_info_get service is available. The other two information-gathering services must be enabled in order to use them.

```
TX_THREAD my_thread;
CHAR *name;
UINT state:
ULONG run count;
UINT priority;
UINT preemption threshold:
UINT time slice:
TX THREAD *next thread;
TX_THREAD *suspended_thread;
UINT status:
/* Retrieve information about the previously created thread
  "my thread." */
status = tx_thread_info_get(&my_thread, &name, &state,
                 &run_count, &priority, &preemption_threshold,
                 &time slice, &next thread, &suspended thread);
/* If status equals TX SUCCESS, the information request is valid. */
```

Figure 46. Example showing how to retrieve thread information

If the variable *status* contains the value TX_SUCCESS, the information was successfully retrieved.

Preemption-Threshold Change

The preemption-threshold of a thread can be established when it is created or during runtime. The service tx_thread_preemption_change changes the preemption-threshold of an existing thread. The preemption-threshold prevents preemption of a thread by other threads that have priorities equal to or less than the preemption-threshold value. Figure 47 shows how the preemption-threshold value can be changed so that preemption by any other thread is prohibited.

In this example, the preemption-threshold value is changed to zero (0). This is the highest possible priority, so this means that no other threads may preempt this thread. However, this does not prevent an interrupt from preempting this thread. If *my_thread* was using time-slicing prior to the invocation of this service, then that feature would be disabled.

Priority Change

When a thread is created, it must be assigned a priority at that time. However, a thread's priority can be changed at any time by using this service. Figure 48 shows how the priority of thread *my_thread* can be changed to one (1).

When this service is called, the preemption-threshold of the specified thread is automatically set to the new priority. If a new preemption-threshold is desired, the tx_thread_preemption_change service must be invoked after the priority change service has completed.

Figure 47. Change preemption-threshold of thread *my_thread*

Figure 48. Change priority of thread *my_thread*

Relinquish Control

A thread may voluntarily relinquish control to another thread by using the tx_thread_relinquish service. This action is typically taken in order to achieve a form of *round-robin scheduling*. This action is a cooperative call made by the currently executing thread that temporarily relinquishes control of the processor, thus permitting the execution of other threads of the same or higher priority. This technique is sometimes called *cooperative multithreading*. Following is a sample service call that illustrates how a thread can relinquish control to other threads.

```
tx_thread_relinquish();
```

Calling this service gives all other ready threads at the same priority (or higher) a chance to execute before the tx thread relinquish caller executes again.

Resume Thread Execution

When a thread is created with the TX_DONT_START option, it is placed in a suspended state. When a thread is suspended because of a call to tx_thread_suspend, it is also placed in a suspended state. The only way such threads can be resumed is when another thread calls the tx_thread_resume service and removes them from the suspended state. Figure 49 illustrates how a thread can be resumed.

```
TX_THREAD my_thread;
UINT status;
...
/* Resume the thread named "my_thread". */
status = tx_thread_resume(&my_thread);

/* If status equals TX_SUCCESS, the application thread is now ready to execute. */
```

Figure 49. Example showing the resumption of thread my_thread

Thread Sleep

On some occasions, a thread needs to be suspended for a specific amount of time. This is achieved with the tx thread sleep service, which causes the calling thread to

suspend for the specified number of timer-ticks. Following is a sample service call that illustrates how a thread suspends itself for 100 timer-ticks:

```
status = tx\_thread\_sleep(100);
```

If the variable *status* contains the value TX_SUCCESS, the currently running thread was suspended (or slept) for the prescribed number of timer-ticks.

Suspend Thread Execution

A specified thread can be suspended by calling the tx_thread_suspend service. A thread can suspend itself, it can suspend another thread, or it can be suspended by another thread. If a thread is suspended in such a manner, then it must be resumed by a call to the tx_thread_resume service. This type of suspension is called *unconditional suspension*. Note that there are other forms of conditional suspension, e.g., in which a thread is suspended because it is waiting for a resource that is not available, or a thread is sleeping for a specific period of time. Following is a sample service call that illustrates how a thread (possibly itself) can suspend a thread called *some_thread*.

status = tx thread suspend(&some thread);

If the variable status contains the value TX_SUCCESS, the specified thread is unconditionally suspended. If the specified thread is already suspended conditionally, the unconditional suspension is held internally until the prior suspension is lifted. When the prior suspension is lifted, the unconditional suspension of the specified thread is then performed. If the specified thread is already unconditionally suspended, then this service call has no effect.

Terminate Application Thread

This service terminates the specified application thread, regardless of whether or not that thread is currently suspended. A thread may terminate itself. A terminated thread cannot be executed again. If you need to execute a terminated thread, then you can either reset²⁶

²⁶The tx_thread_reset service can be used to reset a thread to execute at the entry point defined at thread creation. The thread must be in either a completed state or a terminated state in order to be reset.

it or delete it and then create it again. Following is a sample service call that illustrates how a thread (possibly itself) can terminate thread *some_thread*.

```
status = tx_thread_suspend(&some_thread);
```

If the variable *status* contains the value TX_SUCCESS, the specified thread has been terminated.

Time-Slice Change

The optional time-slice for a thread may be specified when the thread is created, and it may be changed at any time during execution. This service permits a thread to change its own time-slice or that of another thread. Figure 50 shows how a time-slice can be changed.

Figure 50. Example showing a time-slice change for thread my_thread

Selecting a time-slice for a thread means that it will not execute more than the specified number of timer-ticks before other threads of the same or higher priorities are given an opportunity to execute. Note that if a preemption-threshold has been specified, then time-slicing for that thread is disabled.

Abort Thread Suspension

In some circumstances, a thread may be forced to wait an unacceptably long time (even forever!) for some resource. The Wait Abort Suspension service assists the developer in preventing such an unwanted situation. This service aborts sleep or any wait-related suspension for a specified thread. If the wait is successfully aborted, a

TX_WAIT_ABORTED value is returned from the service that the thread was waiting on. Note that this service does not release explicit suspension that is made by the tx_thread_suspend service. Following is an example that illustrates how this service can be used:

```
status = tx_thread_wait_abort(&some_thread);
```

If the variable *status* contains the value TX_SUCCESS, the sleep or suspension condition of thread <code>some_thread</code> has been aborted, and a return value of TX_WAIT_ABORTED is available to the suspended thread. The previously suspended thread is then free to take whatever action it deems appropriate.

Thread Notification Services

There are two thread notification services: the tx_thread_entry_exit_notify service and the tx_thread_stack_error_notify service. Each of these services registers a notification callback function. If the tx_thread_entry_exit_notify service has been successfully invoked for a particular thread, then each time that thread is entered or exited, the corresponding callback function is invoked. The processing of this function is the responsibility of the application. In a similar fashion, if the tx_thread_stack_error_notify service has been successfully invoked for a particular thread, then the corresponding callback function is invoked if a stack error occurs. The processing of this error is the responsibility of the application.

Execution Overview

There are four types of program execution within a Azure RTOS ThreadX application:

- 1. initialization
- 2. thread execution
- 3. interrupt service routines (ISRs)
- 4. application timers

Figure 51 shows each type of program execution.




Figure 51. Types of program execution

Initialization is the first type of program execution. Initialization includes all program execution between processor reset and the entry point of the *thread scheduling loop*.

After initialization is complete, Azure RTOS ThreadX enters its thread scheduling loop. The scheduling loop looks for an application thread that is ready for execution. When a ready thread is found, Azure RTOS ThreadX transfers control to it. Once the thread is finished (or another higher-priority thread becomes ready), execution transfers back to the thread scheduling loop in order to find the next-highest-priority ready thread. This process of continually executing and scheduling threads is the most common type of program execution in Azure RTOS ThreadX applications.

Interrupts are the cornerstone of real-time systems. Without interrupts, it would be extremely difficult to respond to changes in the external world in a timely manner. What happens when an interrupt occurs? Upon detection of an interrupt, the processor saves key information about the current program execution (usually on the stack), then transfers control to a predefined program area. This predefined program area is commonly called an interrupt service routine. In most cases, interrupts occur during thread execution (or in

the thread scheduling loop). However, interrupts may also occur inside an executing ISR or an application timer.

Application timers are very similar to ISRs, except the actual hardware implementation (usually a single periodic hardware interrupt is used) is hidden from the application. Such timers are used by applications to perform time-outs, periodic operations, and/or watchdog services. Just like ISRs, application timers most often interrupt thread execution. Unlike ISRs, however, application timers cannot interrupt each other.




Figure 52. Thread state transition

Thread States

Understanding the different processing states of threads is vital to understanding the entire multithreaded environment. There are five distinct thread states: *ready*, *suspended*,

executing, *terminated*, and *completed*. Figure 52 shows the thread state transition diagram for Azure RTOS ThreadX.

A thread is in a ready state when it is ready for execution. A ready thread is not executed until it is the highest-priority thread ready. When this happens, Azure RTOS ThreadX executes the thread, which changes its state to *executing*. If a higher-priority thread becomes ready, the executing thread reverts back to a *ready* state. The newly ready high-priority thread is then executed, which changes its logical state to *executing*. This transition between *ready* and *executing* states occurs every time thread preemption occurs.

Note that at any given moment only one thread is in an *executing* state. This is because a thread in the *executing* state actually has control of the underlying processor. Threads that are in a *suspended* state are not eligible for execution. Reasons for being in a *suspended* state include suspension for a predetermined time; waiting on message queues, semaphores, mutexes, event flags, or memory; and explicit thread suspension. Once the cause for suspension is removed, the thread returns to a *ready* state.

If a thread is in a *completed* state, this means that the thread has completed its processing and has returned from its entry function. Remember that the entry function is specified during thread creation. A thread that is in a *completed* state cannot execute again unless it is reset to its original state by the tx thread reset service.

A thread is in a *terminated* state because another thread called the tx_thread_terminate service, or it called the service itself. A thread in a *terminated* state cannot execute again unless it is reset to its original state by the tx_thread_reset service.

As noted in Chapter 3, threads in the ready state are eligible for execution. When the scheduler needs to schedule a thread for execution, it selects the ready thread that has the highest priority and which has been waiting the longest. If an executing thread is interrupted for any reason, its context is saved and it is placed back in the ready state, ready to resume execution. Threads residing on the suspended state are not eligible for execution because they are waiting for an unavailable resource, they are in "sleep" mode, they were created with a TX_DONT_START option, or they were explicitly suspended.

When a suspended thread has its condition(s) removed, then it is eligible for execution and is moved to the ready state.

Thread Design

Azure RTOS ThreadX imposes no limits on either the number of threads that can be created or the combinations of priorities that can be used. However, in order to optimize performance and minimize the target size, developers should observe the following guidelines:

- Minimize the number of threads in the application system.
- Choose priorities carefully.
- Minimize the number of priorities.
- Consider preemption-threshold.
- Consider priority inheritance when mutexes are employed.
- Consider round-robin scheduling.
- Consider time-slicing.

There are other guidelines as well, such as making certain that a thread is used to accomplish a particular unit of work, rather than a series of disparate actions.

Minimize the Number of Threads

In general, the number of threads in an application significantly affects the amount of system overhead. This is due to several factors, including the amount of system resources needed to maintain the threads, and the time required for the scheduler to activate the next ready thread. Each thread, whether necessary or not, consumes stack space as well as memory space for the thread itself, and memory for the TCB.

Choose Priorities Carefully

Selecting thread priorities is one of the most important aspects of multithreading. A common mistake is to assign priorities based on a *perceived* notion of thread importance rather than determining what is actually required during run-time. Misuse of thread priorities can starve other threads, create priority inversion, reduce processing bandwidth,

and make the application's run-time behavior difficult to understand. If thread starvation is a problem, an application can employ added logic that gradually raises the priority of starved threads until they get a chance to execute. However, properly selecting the priorities in the first place may significantly reduce this problem.

Minimize the Number of Priorities

As noted earlier, Azure RTOS ThreadX provides 1,024 distinct priority values that can be assigned to threads, where the default number of priorities is 32. However, developers should assign priorities carefully and should base priorities on the relative importance of the threads in question. An application that has many different thread priorities inherently requires more system overhead than one with a smaller number of priorities. Recall that Azure RTOS ThreadX provides a priority-based, preemptive-scheduling algorithm. This means that lower-priority threads do not execute until there are no higher-priority threads ready for execution. If a higher-priority thread is always ready, the lower-priority threads never execute.

To understand the effect that thread priorities have on context switch overhead, consider a three-thread scenario with threads named *thread_1*, *thread_2*, and *thread_3*. Furthermore, assume that all the threads are suspended and waiting for a message. When *thread_1* receives a message, it immediately forwards it to *thread_2*. *Thread_2* then forwards the message to *thread_3*. *Thread_3* simply discards the message. After each thread processes its message, it suspends itself again and waits for another message. The processing required to execute these three threads varies greatly depending on their priorities. If all the threads have the same priority, a single context switch occurs between the execution of each thread. The context switch occurs when each thread suspends on an empty message queue.

However, if *thread_2* has higher priority than *thread_1* and *thread_3* has higher priority than *thread_2*, the number of context switches doubles. This is because another context switch occurs inside the tx_queue_send service when it detects that a higher-priority thread is now ready.

If distinct priorities for these threads are required, then the Azure RTOS ThreadX preemption-threshold mechanism can prevent these extra context switches. This is an important feature because it allows several distinct thread priorities during thread

scheduling, while at the same time eliminating some of the unwanted context switching that occurs during thread execution.

Consider Preemption-Threshold

Recall that a potential problem associated with thread priorities is priority inversion. Priority inversion occurs when a higher-priority thread becomes suspended because a lower-priority thread has a resource needed by the higher-priority thread. In some instances, it is necessary for two threads of different priority to share a common resource. If these threads are the only ones active, the priority inversion time is bounded by the time that the lower-priority thread holds the resource. This condition is both deterministic and quite normal. However, if one or more threads of an intermediate priority become active during this priority inversion condition—thus preempting the lower-priority thread—the priority inversion time becomes nondeterministic and the application may fail.

There are three primary methods of preventing priority inversion in Azure RTOS ThreadX. First, the developer can select application priorities and design run-time behavior in a manner that prevents the priority inversion problem. Second, lower-priority threads can utilize preemption-threshold to block preemption from intermediate threads while they share resources with higher-priority threads. Finally, threads using Azure RTOS ThreadX mutex objects to protect system resources may utilize the optional mutex priority inheritance to eliminate nondeterministic priority inversion.

Consider Priority Inheritance

In priority inheritance, a lower-priority thread temporarily acquires the priority of a higher-priority thread that is attempting to obtain the same mutex owned by the lower priority thread. When the lower-priority thread releases the mutex, its original priority is then restored and the higher-priority thread is given ownership of the mutex. This feature eliminates priority inversion by bounding the inversion time to the time the lower priority thread holds the mutex. Note that priority inheritance is available only with a mutex but not with a counting semaphore.

Consider Round-Robin Scheduling

Azure RTOS ThreadX supports round-robin scheduling of multiple threads that have the same priority. This is accomplished through cooperative calls to the tx_thread_relinquish service. Calling this service gives all other ready threads with the same priority a chance to execute before the caller of the tx_thread_relinquish service executes again.

Consider Time-Slicing

Time-slicing provides another form of round-robin scheduling for threads with the same priority. Azure RTOS ThreadX makes time-slicing available on a per-thread basis. An application assigns the thread's time-slice when it creates the thread and can modify the time-slice during run-time. When a thread's time-slice expires, all other ready threads with the same priority get a chance to execute before the time-sliced thread executes again.

Thread Internals

When the TX_THREAD data type is used to declare a thread, a TCB is created, and that TCB is added to a doubly linked circular list, as illustrated in Figure 53. The pointer named tx_thread_created_ptr points to the first TCB in the list. See the fields in the TCB for thread attributes, values, and other pointers.




Figure 53. Created thread list

When the scheduler needs to select a thread for execution, it chooses a ready thread with the highest priority. To determine such a thread, the scheduler first determines the priority of the next ready thread. In order to get this priority, the scheduler consults the map of ready thread priorities. Figure 54 shows an example of this priority map.




Figure 54. Map showing ready thread priorities

This priority map (actually a ULONG variable) represents each of the 32 priorities with one bit. The bit pattern in the preceding example indicates that there are ready threads with priorities 0, 2, and 31.

When the highest priority of the next ready thread is determined, the scheduler uses an array of ready thread head pointers to select the thread to be executed. Figure 55 illustrates the organization of this array.

This array of TX_THREAD list-head pointers is directly indexed by thread priority. If an entry is non-NULL, there is at least one thread at that priority ready for execution. The threads in each priority list are managed in a doubly linked, circular list of TCBs, as illustrated in Figure 55. The thread in the front of the list represents the next thread to execute for that priority.




Figure 55. Example of array of ready thread head pointers indexed by priority

Overview

A thread is a dynamic entity that constitutes the basis for RTOS application development.

Azure RTOS ThreadX supplies 13 services designed for a range of actions, including thread creation, deletion, modification, and termination.

The Thread Control Block (TCB) is a structure used to store vital information about a thread's state during execution. It also preserves vital thread information when a context switch becomes necessary.

Application developers have several options available when they create threads, including use of time-slicing and preemption-threshold. However, these options can be changed at any time during thread execution.

A thread can voluntarily relinquish control to another thread, it can resume execution of another thread, and it can abort the suspension of another thread.

A thread has five states: ready, suspended, executing, terminated, and completed. Only one thread executes at any point in time, but there may be many threads in the ready state and the suspended state. Threads in the former list are eligible for execution, while threads in the latter list are not.

Key Terms and Phrases

abort thread suspension creating a thread

application timer currently executing thread

auto start option deleting a thread

change preemption-threshold entry function input executing state

change time-slice execution context

completed state interrupt service routine cooperative multithreading preemption-threshold

priority suspended state
ready state suspension of thread
ready thread terminate thread service

reentrant function terminated state

relinquish processor control Thread Control Block (TCB)

resume thread execution thread entry function round-robin scheduling thread execution state service return values thread run-count sleep mode thread scheduling loop stack size thread start option suspended state time-slice

Problems

- 1. What is the value of tx_state (a member of the TCB) immediately after the service tx thread sleep(100); has been called?
- 2. What is the primary danger of specifying a thread stack size that is too small?
- 3. What is the primary danger of specifying a thread stack size that is too large?
- 4. Suppose tx_thread_create is called with a priority of 15, a preemption-threshold of 20, and a time-slice of 100. What would be the result of this service call?
- 5. Give an example showing how the use of reentrant functions is helpful in multithreaded applications.
- 6. Answer the following questions for this thread create sequence, where &my_stack is a valid pointer to the thread stack:

- a. At what point in time will this thread be placed in the ready state?
- b. Is preemption-threshold used? If so, what is its value?
- c. Is time-slicing used? If so, what is its value?
- d. What is the size of the thread stack?
- e. What is the value of the variable *status* after this service is executed?

- 7. What is the difference between thread deletion and thread termination?
- 8. Given a pointer to any arbitrary thread, which thread service obtains the state of that thread and the number of times that thread has been executed?
- 9. If an executing thread has priority 15 and a preemption-threshold of 0, will another thread with priority 5 be able to preempt it?
- 10. Explain the difference between time-slicing and cooperative multithreading.
- 11. Under what circumstances will a thread be placed in the ready state? Under what circumstances will it be removed?
- 12. Under what circumstances will a thread be placed in the suspended state? Under what circumstances will it be removed?
- 13. Give an example in which using the tx_thread_wait_abort service would be essential.
- 14. How does the thread scheduling loop select a thread for execution?
- 15. Under what circumstances will a thread be preempted? What happens to that thread when it is preempted?
- 16. Describe the five states of a thread. Under what circumstances would the status of a thread be changed from executing to ready? From ready to suspended? From suspended to ready? From completed to ready?

Chapter 6

Mutual Exclusion Challenges

and Considerations

Introduction

On many occasions, we need to guarantee that a thread has exclusive access to a shared resource or to a critical section. However, several threads may need to obtain these items, so we need to synchronize their behavior to ensure that exclusive access can be provided. In this chapter, we consider the properties of the mutex, which is designed solely to provide mutual exclusion protection by avoiding conflict between threads and preventing unwanted interactions between threads.

A mutex is a public resource that can be owned by, at most, one thread at any point in time. Furthermore, a thread (and only that same thread) can repeatedly²⁷ obtain the same mutex 2^{32} –1 times to be exact. However, that same thread (and only that thread) must give up that mutex the same number of times before the mutex becomes available again.

Protecting a Critical Section

A critical section is a code segment in which instructions must be executed in sequence without interruption. The mutex helps in achieving this goal. Consider Figure 56, which shows a code segment that is a critical section. To enter this critical section, a thread must first obtain ownership of a certain mutex that protects the critical section. Thus, when the thread is ready to begin executing this code segment, it first attempts to acquire that

²⁷ Some writers describe this type of mutex as a recursive mutex because of the same-thread, multiple-ownership capability. However, we will not use that terminology here.

mutex. After the thread has acquired the mutex, it executes the code segment, and then relinquishes the mutex.




Figure 56. Mutex protecting a critical section

Providing Exclusive Access to Shared Resources

A mutex can provide exclusive access to one shared resource in the same manner that it can protect a critical section. That is, a thread must first obtain the mutex before it can access the shared resource. However, if a thread must have exclusive access to two (or more) shared resources at the same time, then it must protect each shared resource with a separate mutex. In this case, the thread must first obtain a particular mutex for each of the shared resources before continuing. Figure 57 illustrates this process. When the thread is ready to access these resources, it first gets the two mutexes that protect these resources. After the thread has acquired both mutexes, it accesses the shared resources, and then relinquishes both mutexes after it has finished with these resources.




Figure 57. Mutexes providing exclusive access to multiple shared resources

Mutex Control Block

The Mutex Control Block (MCB)²⁸ is a structure used to maintain the state of a mutex during run-time. It contains a variety of information, including the mutex owner, the ownership count, the priority inheritance flag, the original priority of the owning thread, the original preemption-threshold of the owning thread, the suspension count, and a pointer to the suspension list. Figure 58 contains many of the fields that make up the MCB.

Field	Description	
tx_mutex_id	Control block ID	
tx_mutex_name	Pointer to mutex name	
tx_mutex_ownership_count	Mutex ownership count	
*tx_mutex_owner	Mutex ownership pointer	
tx_mutex_inherit	Priority inheritance flag	
tx_mutex_original_priority	Original priority of owning thread	
tx_mutex_original_threshold	Original preemption-threshold of owning thread	
*tx_mutex_suspension_list	Pointer to suspension list	
tx_mutex_suspended_count	Suspension list count	
*tx_mutex_created_next	Pointer to the next mutex in the created list	
*tx_mutex_created_previous	Pointer to the previous mutex in the created list	

Figure 58. Mutex Control Block

In most cases, the developer can ignore the contents of the MCB. However, in some situations, especially during debugging, inspecting certain members of the MCB is useful. Note that although Azure RTOS ThreadX allows inspection of an MCB, it strictly prohibits the modification of one.

Summary of Mutex Services

Appendix E contains detailed information about mutex services, providing the information on the following: prototype, brief description of the service, parameters, return values, notes and warnings, allowable invocation, preemption possibility, and an

-

²⁸ The characteristics of each mutex are contained in its MCB. This structure is defined in the tx api.h file.

example that illustrates how the service can be used. Figure 59 contains a listing of all available mutex services. In the following sections of this chapter, you will study each of these services. We will consider the many features of the services, and we will develop an illustrative example of a sample system that uses them.

Mutex Service	Description	
tx_mutex_create	Create a mutex	
tx_mutex_delete	Delete a mutex	
tx_mutex_get	Attempt to obtain ownership of a mutex	
tx_mutex_info_get	Retrieve information about a mutex	
tx_mutex_prioritize	Put highest priority suspended thread at front of suspension list	
tx_mutex_put	Release ownership of mutex	

Figure 59. Mutex services

Creating a Mutex

A mutex is declared with the TX_MUTEX data type²⁹ and is defined with the tx mutex create service. When defining a mutex, you need to specify the MCB, the name of the mutex, and the priority inheritance option.

Mutex Control Block	
Mutex Name	
Priority Inheritance Option	

Figure 60. Attributes of a mutex

Figure 60 contains a list of these attributes. We will develop one example of mutex creation to illustrate the use of this service. We will give our mutex the name "my mutex" and we will activate the priority inheritance feature. Priority inheritance allows a lower-priority thread to temporarily assume the priority of a higher-priority thread that is waiting for a mutex owned by the lower-priority thread. This feature helps the application to avoid priority inversion by eliminating preemption of intermediate

²⁹ When a mutex is declared, an MCB is created.

thread priorities. Figure 61 contains an example of mutex creation with priority inheritance.

If you wanted to create a mutex without the priority inheritance feature, you would use the TX_NO_INHERIT parameter rather than the TX_INHERIT parameter.

Figure 61. Creating a mutex with priority inheritance

Deleting a Mutex

A mutex can be deleted with the tx_mutex_delete service. When a mutex is deleted, all threads that have been suspended because they are waiting for that mutex are resumed (that is, placed in the ready state). Each of these threads will receive a TX_DELETED return status from its call to tx_mutex_get. Figure 62 contains an example showing how the mutex called "my_mutex" can be deleted.

```
TX_MUTEX my_mutex;
UINT status;
...
/* Delete a mutex. Assume that the mutex has already been created. */
status = tx_mutex_delete(&my_mutex);
/* If status equals TX_SUCCESS, the mutex has been deleted.
*/
```

Figure 62. Deleting a mutex

Obtaining Ownership of a Mutex

The tx_mutex_get service enables a thread to attempt to obtain exclusive ownership of a mutex. If no thread owns that mutex, then that thread acquires ownership of the mutex.

If the calling thread already owns the mutex, then <code>tx_mutex_get</code> increments the ownership counter and returns a successful status. If another thread already owns the mutex, the action taken depends on the calling option used with <code>tx_mutex_get</code>, and whether the mutex has priority inheritance enabled. These actions are displayed in Figure 63.

tx_mutex_get wait option	Priority Inheritance Enabled in Mutex	Priority Inheritance Disabled in Mutex
TX_NO_WAIT	Immediate return	Immediate return
TX_WAIT_FOREVER	If the owning thread has a higher priority, the calling thread's priority is raised to that of the owning thread, then the calling thread is placed on the suspension list, and the calling thread waits indefinitely	Thread placed on suspension list and waits indefinitely
timeout value	If the owning thread has a higher priority, the calling thread's priority is raised to that of the owning thread, then the calling thread is placed on the suspension list, and the calling thread waits until the number of specified timer-ticks has expired	Thread placed on suspension list and waits until the number of specified timer-ticks has expired

Figure 63. Actions taken when mutex is already owned by another thread

If you use priority inheritance, make certain that you do not allow another thread to modify the priority of the thread that has inherited a higher priority during mutex ownership. Figure 64 contains an example of a thread attempting to obtain ownership of a mutex.

If the variable *status* contains the value TX_SUCCESS, then this was a successful get operation. The TX_WAIT_FOREVER option was used in this example. Therefore, if the mutex is already owned by another thread, the calling thread will wait indefinitely in the suspension list.

```
TX_MUTEX my_mutex;
UINT status;
...
/* Obtain exclusive ownership of the mutex "my_mutex". If the mutex called "my_mutex" is not available, suspend until it becomes available. */
status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
```

Figure 64. Obtain ownership of a mutex

Retrieving Mutex Information

There are three services that enable you to retrieve vital information about mutexes. The first such service for mutexes—the <code>tx_mutex_info_get</code> service—retrieves a subset of information from the Mutex Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the <code>tx_mutex_performance_info_get</code> service—provides an information summary for a particular mutex up to the time the service is invoked. By contrast the <code>tx_mutex_performance_system_info_get</code> retrieves an information summary for all mutexes in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The <code>tx_mutex_info_get30</code> service obtains information that includes the ownership count, the location of the owning thread, the location of the first thread on the suspension list, the number of suspended threads, and the location of the next created mutex. Figure 65 shows how this service can be used current information about the mutex.

```
TX_MUTEX my_mutex;
CHAR *name;
ULONG count;
TX_THREAD *owner;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_MUTEX *next_mutex;
UINT status;
...
/* Retrieve information about the previously created mutex called "my_mutex." */
status = tx_mutex_info_get(&my_mutex, &name, &count, &owner, &first_suspended, &suspended_count, &next_mutex);

/* If status equals TX_SUCCESS, the information was successfully received */
```

Figure 65. Example showing how to retrieve mutex information

³⁰ By default, only the tx_mutex_info_get service is available. The other two information-gathering services must be enabled in order to use them.

If the variable *status* contains the value TX_SUCCESS, the information was successfully retrieved.

Prioritizing the Mutex Suspension List

When a thread is suspended because it is waiting for a mutex, it is placed in the appropriate suspension list in a FIFO manner. When the mutex becomes available, the first thread in the suspension list (regardless of priority) will obtain ownership of that mutex. The tx_mutex_prioritize service places the highest-priority thread suspended for ownership of a specific mutex at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended. Figure 66 shows how this service can be used.

```
TX_MUTEX my_mutex;
UINT status;
...

/* Ensure that the highest priority thread will receive ownership of the mutex when it becomes available. */

status = tx_mutex_prioritize(&my_mutex);

/* If status equals TX_SUCCESS, the highest priority suspended thread has been placed at the front of the list. The next tx_mutex_put call that releases ownership of the mutex will give ownership to this thread and wake it up. */
```

Figure 66. Prioritizing the mutex suspension list

If the variable *status* contains the value TX_SUCCESS, then the highest-priority thread in the suspension list that is waiting for the mutex called "my_mutex" has been placed at the front of the suspension list. If no thread was waiting for this mutex, the return value is also TX_SUCCESS and the suspension list remains unchanged. Note that this service does not sort the suspension list—it simply moves the highest priority thread to the front of the list.

Releasing Ownership of a Mutex

The tx_mutex_put service enables a thread to release ownership of a mutex. Assuming that the thread owns the mutex, the ownership count is decremented. If the ownership count becomes zero, the mutex becomes available. If the mutex becomes available and if

priority inheritance is enabled for this mutex, then the priority of the releasing thread reverts to the priority it had when it originally obtained ownership of the mutex. Any other priority changes made to the releasing thread during ownership of the mutex may be undone also. Figure 67 shows how this service can be used.

```
TX_MUTEX my_mutex;
UINT status;
...
/* Release ownership of "my_mutex." */
status = tx_mutex_put(&my_mutex);
/* If status equals TX_SUCCESS, the mutex ownership count has been decremented and if zero, released. */
```

Figure 67. Releasing ownership of a mutex

If the variable *status* contains the value TX_SUCCESS, then the put operation was successful, and the ownership count was decremented.

Avoiding the Deadly Embrace

One of the potential pitfalls in using mutexes³¹ is the so-called *deadly embrace*. This is an undesirable situation in which two or more threads become suspended indefinitely while attempting to get mutexes already owned by other threads. Figure 68 illustrates a scenario that leads to a deadly embrace. Following is the sequence of events depicted in this figure.

- 1. Thread 1 obtains ownership of Mutex 1
- 2. Thread 2 obtains ownership of Mutex 2
- 3. Thread 1 suspends because it attempts to obtain ownership of Mutex 2
- 4. Thread 2 suspends because it attempts to obtain ownership of Mutex 1

Thus, *Thread 1* and *Thread 2* have entered a deadly embrace because they have suspended indefinitely, each waiting for the mutex that the other thread owns.

³¹ This problem is also associated with the use of semaphores, which we discuss in a later chapter.




Figure 68. Sequence of actions leading to a deadly embrace

How can you avoid deadly embraces? Prevention at the application level is the only method for real-time systems. The only way to guarantee the absence of deadly embraces is to permit a thread to own at most one mutex at any time. If threads must own multiple mutexes, you can generally avoid deadly embraces if you make the threads gather the mutexes in the same order. For example, the deadly embrace in Figure 68 could be prevented if the threads would always obtain the two mutexes in consecutive order, i.e., *Thread 1* (or *Thread 2*) would attempt to acquire *Mutex 1*, and then would immediately attempt to acquire *Mutex 2*. The other thread would attempt to acquire *Mutex 1* and *Mutex 2* in the same order. In either case, a thread would not maintain ownership of one mutex unless it could also obtain ownership of the other mutex.

One way to recover from a deadly embrace is to use the suspension time-out feature associated with the tx_mutex_get service, which is one of the three available wait options. Another way to recover from a deadly embrace is for another thread to invoke the tx_thread_wait_abort service to abort the suspension of a thread trapped in a deadly embrace.

Sample System Using a Mutex to Protect Critical Sections

We will create a sample system to illustrate how a mutex can be used to protect the critical sections of two threads. This system was introduced in Chapter 2 where *speedy_thread* and *slow_thread* each had four activities, two of which were critical sections. Figure 69 and Figure 70 show the sequence of activities for each of these two threads, where the shaded boxes represent the critical sections.




Figure 69. Activities of the *Speedy_Thread* (priority = 5)




Figure 70. Activities of the *Slow_Thread* (priority = 15)




Figure 71. Basic system structure

In order to develop this system, we will need to create two threads and one mutex. Each thread must have its own stack, which we will implement as an array, rather than as a memory byte pool. We will need to create the thread entry functions that perform the desired activities. Because we will create this system in its entirety, we outline this process with Figure 71, which is a variation of the basic four-part system structure that first appeared in Chapter 2.

For the first part of the system, we declare as global entities the two threads, the one mutex, and the two thread stacks as follows:

```
TX_THREAD Speedy_Thread, Slow_Thread;
TX_MUTEX my_mutex;
#DEFINE STACK_SIZE 1024;
CHAR stack speedy [STACK SIZE], stack slow[STACK SIZE];
```

The process of declaring the threads creates two Thread Control Blocks (TCBs), and declaring the mutex creates its MCB as well. The thread stacks will be ready for use in the tx_application_define function.

The second part of the system is where we define the main entry point, which is the call to enter the Azure RTOS ThreadX kernel.

The third part of the system is where we define the threads and the mutex. Following is the definition of *speedy_thread*.

speedy_thread has a priority of 5, but does not have a preemption-threshold, nor does it have a time-slice. Following is the definition of *slow_thread*.

slow_thread has a priority of 15, but does not have a preemption-threshold, nor does it have a time-slice. Both threads will start immediately. Following is the definition of *my_mutex*.

```
tx mutex create(&my mutex, "my mutex", TX NO INHERIT);
```

The mutex is given a name but does not have the priority inheritance feature.

The fourth part of our system is where we develop the thread entry functions. Following is a portion of the entry function for the *speedy_thread*.

```
/* Activity 1: 2 timer-ticks. */
    tx_thread_sleep(2);
/* Activity 2-critical section-5 timer-ticks
    Get the mutex with suspension */
tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
tx_thread_sleep(5);
/* Release the mutex */
tx_mutex_put(&my_mutex);
```

The first two activities of *speedy_thread* are represented here. Activity 1 is not a critical section, so we immediately sleep for two timer-ticks. Activity 2 is a critical section, so to execute it we must first obtain ownership of the mutex. After we get the mutex, we sleep for five timer-ticks. The other activities for both threads follow a similar pattern. When we develop the complete system, we will check the status of the return values to make certain the service calls have been performed correctly.

Figure 72 through Figure 76 contain a complete listing for this sample system, separated into five parts, where the last two parts are the thread entry functions. The complete program listing called 06_sample_system.c is located in a later section of this chapter.

```
/* 06 sample system.c
 Create two threads, and one mutex.
 Use an array for the thread stacks.
 The mutex protects the critical sections. */
#include "tx api.h"
#include <stdio.h>
#define
                           1024
         STACK_SIZE
CHAR stack speedy[STACK SIZE];
CHAR stack_slow[STACK_SIZE];
/* Define the Azure RTOS ThreadX object control
blocks. */
TX_THREAD
                    Speedy_Thread;
TX THREAD
                    Slow Thread;
TX_MUTEX
                    my_mutex;
/* Define the thread prototypes. */
    Speedy_Thread_entry(ULONG thread_input);
void Slow_Thread_entry(ULONG thread_input);
```

Figure 72. Definitions, declarations, and prototypes

The first part of the sample system (Figure 72) contains all the necessary directives, declarations, definitions, and prototypes.

The second part of the sample system (Figure 73) contains the main entry point. This is the entry into the Azure RTOS ThreadX kernel. Note that the call to tx_kernel_enter does not return, so do not place any processing after it.

```
/* Define main entry point. */
int main()
{

    /* Enter the Azure RTOS ThreadX
kernel. */
    tx_kernel_enter();
}
```

Figure 73. The main entry point

The third part of the sample system (Figure 74) consists of the application definition function called tx_application_define. This function can be used to define all the application resources in the system. This function has a single input parameter, which is the first available RAM address. This is typically used as a starting point for initial runtime memory allocations of thread stacks, queues, and memory pools.

The fourth part of the sample system (Figure 75) consists of the entry function for the *speedy_thread*. This function defines the four activities of the thread, and displays the current time when the thread finishes a complete cycle.

Figure 74. Application definitions

```
/* Define the activities for the Speedy Thread */
void Speedy Thread entry(ULONG thread input)
UINT status:
ULONG current time;
while(1)
/* Activity 1: 2 timer-ticks. */
tx thread sleep(2);
/* Activity 2 - critical section - 5 timer-ticks - Get the mutex with suspension. */
status = tx mutex get(&my mutex, TX WAIT FOREVER);
if (status != TX_SUCCESS) break; /* Check status */
tx_thread_sleep(5);
/* Release the mutex. */
status = tx_mutex_put(&my_mutex);
if (status != TX SUCCESS) break; /* Check status */
/* Activity 3: 4 timer-ticks. */
tx_thread_sleep(4);
/* Activity 4 - critical section - 3 timer-ticks
   Get the mutex with suspension. */
   status = tx mutex get(&my mutex, TX WAIT FOREVER);
if (status != TX_SUCCESS) break; /* Check status */
tx thread sleep(3);
/* Release the mutex. */
status = tx_mutex_put(&my_mutex);
if (status != TX SUCCESS) break; /* Check status */
current time = tx time get();
printf("Current Time: %lu Speedy_Thread finished cycle...\n", current_time);
```

Figure 75. Speedy_Thread entry function

The fifth and final part of the sample system (Figure 76) consists of the entry function for the *slow_thread*. This function defines the four activities of the thread, and displays the current time when the thread finishes a complete cycle.

```
/* Define the activities for the Slow Thread */
      Slow_Thread_entry(ULONG thread_input)
UINT status;
ULONG current_time;
 while(1)
 {
   /* Activity 5 - critical section - 12 timer-ticks - Get the mutex with suspension. */
   status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
   if (status != TX SUCCESS) break; /* Check status */
   tx thread sleep(12);
   /* Release the mutex. */
   status = tx_mutex_put(&my_mutex);
   if (status != TX SUCCESS) break; /* Check status */
   /* Activity 6: 8 timer-ticks. */
   tx_thread_sleep(8);
   /* Activity 7 - critical section - 11 timer-ticks
   Get the mutex with suspension. */
   status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
   if (status != TX_SUCCESS) break; /* Check status */
   tx thread sleep(11);
   /* Release the mutex. */
   status = tx_mutex_put(&my_mutex);
   if (status != TX SUCCESS) break; /* Check status */
   /* Activity 8: 9 timer-ticks. */
   tx thread sleep(9);
   current_time = tx_time_get();
   printf("Current Time: %lu Slow Thread finished cycle...\n", current time);
```

Figure 76. Slow_Thread entry function

Output Produced by Sample System

Figure 77 contains some output produced by executing the sample system for a few thread activity cycles. Your output should be similar, but not necessarily identical.

```
Current Time:
               34 Speedy Thread finished cycle...
Current Time:
               40 Slow Thread finished cycle...
Current Time:
               56 Speedy_Thread finished cycle...
Current Time:
               77 Speedy_Thread finished cycle...
Current Time:
               83 Slow Thread finished cycle...
Current Time:
              99 Speedy Thread finished cycle...
Current Time: 120 Speedy_Thread finished cycle...
Current Time: 126 Slow_Thread finished cycle...
Current Time: 142 Speedy_Thread finished cycle...
Current Time: 163 Speedy_Thread finished cycle...
```

Figure 77. Some output produced by sample system

The minimum amount of time that the *speedy_thread* requires to complete its cycle of activities is 14 timer-ticks. By contrast, the *slow_thread* requires at least 40 timer-ticks to complete one cycle of its activities. However, the critical sections of the *slow_thread* will cause delays for the *speedy_thread*. Consider the sample output in Figure 77, in which the *speedy_thread* finishes its first cycle at time 34, meaning that it encountered a delay of 20 timer-ticks because of the *slow_thread*. The *speedy_thread* completes subsequent cycles in a more timely fashion but it will always spend a lot of time waiting for the *slow_thread* to complete its critical section.

To better understand what is happening with the sample system, let us trace a few actions that occur. After initialization has been completed, both threads are in the ready state and are ready to execute. The scheduler selects <code>speedy_thread</code> for execution because it has a higher priority than <code>slow_thread</code>. <code>speedy_thread</code> begins Activity 1, which causes it to sleep two timer-ticks, i.e., it is placed on the suspended state during this time. <code>slow_thread</code> then gets to execute and it begins Activity 5, which is a critical section. <code>slow_thread</code> takes ownership of the mutex and goes to sleep for 12 times timer-ticks, i.e., it is placed in the suspended state during this time. At time 2, <code>speedy_thread</code> is removed from the suspended state, placed in the ready state, and begins Activity 2, which is a critical section. <code>speedy_thread</code> attempts to obtain ownership of the mutex, but it is already owned, so <code>speedy_thread</code> is placed in the suspended state until the mutex is available. At time 12, <code>slow_thread</code> is placed back in the ready state and gives up ownership of the mutex. Figure 78 contains a partial trace of the actions for the sample system.

Time	Actions Performed	Owner
Initial	Speedy and Slow are both ready	none
0	Speedy sleeps 2, suspends TSL, Slow takes mutex, sleeps 12 and suspends	Slow
2	Speedy is ready, unable to get mutex, suspends	Slow
12	Slow is ready, gives up mutex, Speedy preempts Slow, Speedy takes mutex, sleeps 5 and suspends, Slow sleeps 8 and suspends	Speedy
17	Speedy is ready, gives up mutex, sleeps 4 and suspends	
20	Slow is ready, takes mutex, sleeps 11 and suspends	Slow
21	Speedy is ready, unable to get mutex, suspends	Slow
31	Slow is ready, gives up mutex, Speedy preempts Slow, Speedy takes mutex, sleeps 3and suspends, Slow sleeps 9 and suspends	Speedy
34	Speedy is ready, gives up mutex, sleeps 3 and suspends (this completes one full cycle for Speedy)	
37	Speedy is ready, sleeps 2 and suspends	none
39	Speedy is ready, takes mutex, sleeps 5 and suspends	Speedy
40	Slow is ready, unable to get mutex, suspends (this completes one full cycle for Slow)	Speedy

Mutev

Figure 78. Partial activity trace of sample system

Listing for 06_sample_system.c

The complete listing for 06_sample_system.c appears below; line numbers have been added for easy reference.

```
010
011 #include "tx_api.h"
012 #include <stdio.h>
013
014 #define STACK_SIZE
                               1024
015
016 CHAR stack_speedy[STACK_SIZE];
017 CHAR stack_slow[STACK_SIZE];
018
019
020 /* Define the Azure RTOS ThreadX object control blocks... */
021
022 TX_THREAD
                         Speedy_Thread;
023 TX_THREAD
                         Slow_Thread;
024
025 TX_MUTEX
                         my_mutex;
026
027
028 /* Define thread prototypes. */
029
030 void Speedy_Thread_entry(ULONG thread_input);
031 void Slow_Thread_entry(ULONG thread_input);
032
033
034 /*******************************
035 /*
                  Main Entry Point
036 /*******************************
037
038 /* Define main entry point. */
039
040 int main()
041 {
042
043
      /* Enter the Azure RTOS ThreadX kernel. */
044
      tx_kernel_enter();
045 }
046
047
048 /*******************************
049 /*
                 Application Definitions
050 /*****************************
```

```
051
052 /* Define what the initial system looks like. */
053
            tx_application_define(void *first_unused_memory)
054 void
055 {
056
057
058
       /* Put system definitions here,
059
          e.g., thread and mutex creates */
060
061
       /* Create the Speedy_Thread. */
       tx_thread_create(&Speedy_Thread, "Speedy_Thread",
062
063
                        Speedy_Thread_entry, 0,
064
                        stack_speedy, STACK_SIZE,
065
                        5, 5, TX_NO_TIME_SLICE, TX_AUTO_START);
066
067
       /* Create the Slow_Thread */
       tx_thread_create(&Slow_Thread, "Slow_Thread",
068
069
                        Slow_Thread_entry, 1,
070
                        stack_slow, STACK_SIZE,
071
                        15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
072
073
       /* Create the mutex used by both threads */
074
       tx_mutex_create(&my_mutex, "my_mutex", TX_NO_INHERIT);
075
076 }
077
078
079 /**********************************/
                    Function Definitions
080 /*
081 /*******************************
082
083 /* Define the activities for the Speedy_Thread */
084
085 void
            Speedy_Thread_entry(ULONG thread_input)
086 {
087 UINT
            status;
            current_time;
088 ULONG
089
090
       while(1)
091
       {
```

```
092
093
          /* Activity 1: 2 timer-ticks. */
094
         tx_thread_sleep(2);
095
096
         /* Activity 2: 5 timer-ticks *** critical section ***
097
          Get the mutex with suspension. */
098
099
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
          if (status != TX_SUCCESS) break; /* Check status */
100
101
102
         tx_thread_sleep(5);
103
104
         /* Release the mutex. */
105
         status = tx_mutex_put(&my_mutex);
106
          if (status != TX_SUCCESS) break; /* Check status */
107
108
         /* Activity 3: 4 timer-ticks. */
109
         tx_thread_sleep(4);
110
111
         /* Activity 4: 3 timer-ticks *** critical section ***
112
          Get the mutex with suspension. */
113
114
          status = tx_mutex_qet(&my_mutex, TX_WAIT_FOREVER);
         if (status != TX_SUCCESS) break; /* Check status */
115
116
117
         tx_thread_sleep(3);
118
119
         /* Release the mutex. */
120
          status = tx_mutex_put(&my_mutex);
121
          if (status != TX_SUCCESS) break; /* Check status */
122
123
          current_time = tx_time_get();
124
          printf("Current Time: %lu Speedy_Thread finished cycle...\n",
125
                 current_time);
126
127
       }
128 }
129
131
132 /* Define the activities for the Slow_Thread */
```

```
133
134 void
            Slow_Thread_entry(ULONG thread_input)
135 {
136 UINT
            status;
137 ULONG current_time;
138
139
       while(1)
140
       {
141
142
          /* Activity 5: 12 timer-ticks *** critical section ***
          Get the mutex with suspension. */
143
144
145
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
          if (status != TX_SUCCESS) break; /* Check status */
146
147
148
          tx_thread_sleep(12);
149
150
          /* Release the mutex. */
151
          status = tx_mutex_put(&my_mutex);
152
          if (status != TX_SUCCESS) break; /* Check status */
153
154
          /* Activity 6: 8 timer-ticks. */
155
          tx_thread_sleep(8);
156
157
          /* Activity 7: 11 timer-ticks *** critical section ***
158
          Get the mutex with suspension. */
159
160
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
161
          if (status != TX_SUCCESS) break; /* Check status */
162
163
          tx_thread_sleep(11);
164
165
          /* Release the mutex. */
166
          status = tx_mutex_put(&my_mutex);
167
          if (status != TX_SUCCESS) break; /* Check status */
168
169
          /* Activity 8: 9 timer-ticks. */
170
          tx_thread_sleep(9);
171
172
          current_time = tx_time_get();
          printf("Current Time: %lu Slow_Thread finished cycle...\n",
173
```

```
174
                    current_time);
175
176
        }
177 }
```

Mutex Internals

When the TX_MUTEX data type is used to declare a mutex, an MCB is created, and that MCB is added to a doubly linked circular list, as illustrated in Figure 79.




Figure 79. Created mutex list

The pointer named tx mutex created ptr points to the first MCB in the list. See the fields in the MCB for mutex attributes, values, and other pointers.

Action	Priority of my_thread
my_thread obtains my_mutex	25
big_thread (priority = 10) attempts to obtain my_mutex, but is suspended because the mutex is owned by my_thread, which inherits a priority of 10 while it owns my_mutex	10
my_thread changes its own priority to 15	15
my_thread changes its own priority to 21	21
my_thread releases my_mutex	25

Figure 80. Example showing effect of priority inheritance on thread priority

If the priority inheritance feature has been specified (i.e., the MCB field named tx mutex inherit has been set), the priority of the owning thread will be increased to match that of a thread with a higher priority that suspends on this mutex. When the owning thread releases the mutex, then its priority is restored to its original value, regardless of any intermediate priority changes. Consider Figure 80, which contains a sequence of operations for the thread named *my_thread* with priority 25, which successfully obtains the mutex named *my_mutex*, which has the priority inheritance feature enabled.

The thread called *my_thread* had an initial priority of 25, but it inherited a priority of 10 from the thread called *big_thread*. At this point, *my_thread* changed its own priority twice (perhaps unwisely because it lowered its inherited priority!). When *my_thread* released the mutex, its priority reverted to its original value of 25, despite the intermediate priority changes. Note that if *my_thread* had previously specified a preemption threshold, then the new preemption-threshold value would be changed to the new priority when a change-priority operation was executed. When *my_thread* released the mutex, then the preemption threshold would be changed to the original priority value, rather than to the original preemption-threshold value.

Overview

A mutex is a public resource that can be owned by at most one thread at any point in time. It has only one purpose: to provide exclusive access to a critical section or to shared resources.

Declaring a mutex has the effect of creating an MCB, which is a structure used to store vital information about that mutex during execution.

There are eight services designed for a range of actions involving mutexes, including creating a mutex, deleting a mutex, prioritizing a suspension list, obtaining ownership of a mutex, retrieving mutex information (3), and relinquishing ownership of a mutex.

Developers can specify a priority inheritance option when defining a mutex, or during later execution. Using this option will diminish the problem of priority inversion.

Another problem associated with the use of mutexes is the deadly embrace, and several tips for avoiding this problem were presented.

We developed a complete system that employs two threads and one mutex that protects the critical section of each thread. We presented and discussed a partial trace of the threads.

Key Terms and Phrases

creating a mutex ownership of mutex

critical section prioritize mutex suspension list

deadly embrace priority inheritance deleting a mutex priority inversion

exclusive access ready state

multiple mutex ownership recovery from deadly embrace

mutex shared resources
Mutex Control Block (MCB) suspended state

mutex wait options synchronize thread behavior

mutual exclusion

Problems

- 1. Describe precisely what happens as a result of the following mutex declaration: TX_MUTEX mutex_1;
- 2. What is the difference between mutex declaration and mutex creation?
- 3. Suppose that a mutex is not owned, and a thread acquires that mutex with the tx_mutex_get service. What is the value of tx_mutex_suspended_count (a member of the MCB) immediately after that service has completed?
- 4. Suppose a thread with the lowest possible priority owns a certain mutex, and a ready thread with the highest possible priority needs that mutex. Will the high priority thread be successful in taking that mutex from the low-priority thread?
- 5. Describe all the circumstances (discussed so far) that would cause an executing thread to be moved to the suspended state.

- 6. Suppose a mutex has the priority-inheritance option enabled and a thread that attempted to acquire that mutex had its priority raised as a result. Exactly when will that thread have its priority restored to its original value?
- 7. Is it possible for the thread in the previous problem to have its priority changed while it is in the suspended state? If so, what are the possible problems that might arise? Are there any circumstances that might justify performing this action?
- 8. Suppose you were charged with the task of creating a watchdog thread that would try to detect and correct deadly embraces. Describe, in general terms, how you would accomplish this task.
- 9. Describe the purpose of the tx_mutex_prioritize service, and give an example.
- 10. Discuss two ways in which you can help avoid the priority inversion problem.
- 11. Discuss two ways in which you can help avoid the deadly embrace problem.
- 12. Consider Figure 78, which contains a partial activity trace of the sample system. Exactly when will the *speedy_thread* preempt the *slow_thread*?

Chapter 7

Memory Management: Byte Pools and Block Pools

Introduction

Recall that we used arrays for the thread stacks in the previous chapter. Although this approach has the advantage of simplicity, it is frequently undesirable and is quite inflexible. This chapter focuses on two Azure RTOS ThreadX memory management resources that provide a good deal of flexibility: memory byte pools and memory block pools.

A *memory byte pool* is a contiguous block of bytes. Within such a pool, byte groups of any size (subject to the total size of the pool) may be used and reused. Memory byte pools are flexible and can be used for thread stacks and other resources that require memory. However, this flexibility leads to some problems, such as fragmentation of the memory byte pool as groups of bytes of varying sizes are used.

A *memory block pool* is also a contiguous block of bytes, but it is organized into a collection of fixed-size memory blocks. Thus, the amount of memory used or reused from a memory block pool is always the same—the size of one fixed-size memory block. There is no fragmentation problem, and allocating and releasing memory blocks is fast. In general, the use of memory block pools is preferred over memory byte pools.

We will study and compare both types of memory management resources in this chapter. We will consider the features, capabilities, pitfalls, and services for each type. We will also create illustrative sample systems using these resources.

Summary of Memory Byte Pools

A memory byte pool is similar to a standard C heap.³² In contrast to the C heap, a Azure RTOS ThreadX application may use multiple memory byte pools. In addition, threads can suspend on a memory byte pool until the requested memory becomes available.

Allocations from memory byte pools resemble traditional *malloc* calls, which include the amount of memory desired (in bytes). Azure RTOS ThreadX allocates memory from the memory byte pool in a *first-fit* manner, i.e., it uses the first free memory block that is large enough to satisfy the request. Azure RTOS ThreadX converts excess memory from this block into a new block and places it back in the free memory list. This process is called *fragmentation*.

When Azure RTOS ThreadX performs a subsequent allocation search for a large-enough block of free memory, it merges adjacent free memory blocks together. This process is called *defragmentation*.

Each memory byte pool is a public resource; Azure RTOS ThreadX imposes no constraints on how memory byte pools may be used.³³ Applications may create memory byte pools either during initialization or during run-time. There are no explicit limits on the number of memory byte pools an application may use.

The number of allocatable bytes in a memory byte pool is slightly less than what was specified during creation. This is because management of the free memory area introduces some overhead. Each free memory block in the pool requires the equivalent of two C pointers of overhead. In addition, when the pool is created, Azure RTOS ThreadX automatically divides it into two blocks, a large free block and a small permanently allocated block at the end of the memory area. This allocated end block is used to improve performance of the allocation algorithm. It eliminates the need to continuously check for the end of the pool area during merging. During run-time, the amount of overhead in the pool typically increases. This is partly because when an odd number of bytes is allocated, Azure RTOS ThreadX pads out the block to ensure proper alignment

³² In C, a heap is an area of memory that a program can use to store data in variable amounts that will not be known until the program is running.

³³ However, memory byte pool services cannot be called from interrupt service routines. (This topic will be discussed in a later chapter.)

of the next memory block. In addition, overhead increases as the pool becomes more fragmented.

The memory area for a memory byte pool is specified during creation. Like other memory areas, it can be located anywhere in the target's address space. This is an important feature because of the considerable flexibility it gives the application. For example, if the target hardware has a high-speed memory area and a low-speed memory area, the user can manage memory allocation for both areas by creating a pool in each of them.

Application threads can suspend while waiting for memory bytes from a pool. When sufficient contiguous memory becomes available, the suspended threads receive their requested memory and are resumed. If multiple threads have suspended on the same memory byte pool, Azure RTOS ThreadX gives them memory and resumes them in the order they occur on the Suspended Thread List (usually FIFO). However, an application can cause priority resumption of suspended threads, by calling

tx_byte_pool_prioritize prior to the byte release call that lifts thread suspension. The byte pool prioritize service places the highest priority thread at the front of the suspension list, while leaving all other suspended threads in the same FIFO order.

Field	Description
tx_byte_pool_id	Byte pool ID
tx_byte_pool_name	Pointer to byte pool name
tx_byte_pool_available	Number of available bytes
tx_byte_pool_fragments	Number of fragments in the pool
tx_byte_pool_list	Head pointer of the byte pool
tx_byte_pool_search	Pointer for searching for memory
tx_byte_pool_start	Starting address of byte pool area
tx_byte_pool_size	Byte pool size (in bytes)
*tx_byte_pool_owner	Pointer to owner of a byte pool during a search
*tx_byte_pool_suspension_list	Byte pool suspension list head
tx_byte_pool_suspended_count	Number of threads suspended
*tx_byte_pool_created_next	Pointer to the next byte pool in the created list
*tx_byte_pool_created_previous	Pointer to the previous byte pool in the created list

Figure 81. Memory Byte Pool Control Block

Memory Byte Pool Control Block

The characteristics of each memory byte pool are found in its Control Block.³⁴ It contains useful information such as the number of available bytes in the pool. Memory Byte Pool Control Blocks can be located anywhere in memory, but it is most common to make the control block a global structure by defining it outside the scope of any function. Figure 81 contains many of the fields that comprise this control block.

In most cases, the developer can ignore the contents of the Memory Byte Pool Control Block. However, there are several fields that may be useful during debugging, such as the number of available bytes, the number of fragments, and the number of threads suspended on this memory byte pool.

Pitfalls of Memory Byte Pools

Although memory byte pools provide the most flexible memory allocation, they also suffer from somewhat nondeterministic behavior. For example, a memory byte pool may have 2,000 bytes of memory available but not be able to satisfy an allocation request of even 1,000 bytes. This is because there is no guarantee on how many of the free bytes are contiguous. Even if a 1,000-byte free block exists, there is no guarantee on how long it might take to find the block. The allocation service may well have to search the entire memory pool to find the 1,000-byte block. Because of this problem, it is generally good practice to avoid using memory byte services in areas where deterministic, real-time behavior is required. Many such applications pre-allocate their required memory during initialization or run-time configuration. Another option is to use a memory block pool (discussed later in this chapter).

Users of byte pool allocated memory must not write outside its boundaries. If this happens, corruption occurs in an adjacent (usually subsequent) memory area. The results are unpredictable and quite often catastrophic.

Summary of Memory Byte Pool Services

Appendix B contains detailed information about memory byte pool services. This appendix contains information about each service, such as the prototype, a brief

-

³⁴ The structure of the Memory Byte Pool Control Block is defined in the **tx_api.h** file.

description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used. Figure 82 contains a listing of all available memory byte pool services. In the subsequent sections of this chapter, we will investigate each of these services.

We will first consider the tx_byte_pool_create service because it must be invoked before any of the other services.

Service	Description
tx_byte_allocate	Allocate bytes of memory
tx_byte_pool_create	Create a memory byte pool
tx_byte_pool_delete	Delete a memory byte pool
tx_byte_pool_info_get	Retrieve information about the memory byte pool
tx_byte_pool_prioritize	Prioritize the memory byte pool suspension list
tx_byte_release	Release bytes back to the memory byte pool

Figure 82. Services of the memory byte pool

Creating a Memory Byte Pool

Memory Byte Pool

A memory byte pool is declared with the TX_BYTE_POOL data type and is defined with the tx_byte_pool_create service. When defining a memory byte pool, you need to specify its Control Block, the name of the memory byte pool, the address of the memory byte pool, and the number of bytes available. Figure 83 contains a list of these attributes.

Memory Byte Pool Control Block	
Memory Byte Pool Name	
Location of Memory Byte Pool	
Total Number of Bytes Available for Memory Byte Pool	

Figure 83. Attributes of a memory byte pool

We will develop one example of memory byte pool creation to illustrate the use of this service. We will give our memory byte pool the name "my_pool." Figure 84 contains an example of memory byte pool creation.

```
UINT status;

TX_BYTE_POOL my_pool;

/* Create a memory pool whose total size is 2000 bytes starting at address 0x500000. */

status=tx_byte_pool_create(&my_pool, "my_pool", (VOID *) 0x500000, 2000);

/* If status equals TX_SUCCESS, my_pool is available for allocating memory. */
```

Figure 84. Creating a memory byte pool

If variable *status* contains the return value TX_SUCCESS, then a memory byte pool called my_pool that contains 2,000 bytes, and which begins at location 03500000 has been created successfully.

Allocating from a Memory Byte Pool

After a memory byte pool has been declared and defined, we can start using it in a variety of applications. The tx_byte_allocate service is the method by which bytes of memory are allocated from the memory byte pool. To use this service, we must indicate how many bytes are needed, and what to do if enough memory is not available from this byte pool. Figure 85 shows a sample allocation, which will "wait forever" if adequate memory is not available. If the allocation succeeds, the pointer memory_ptr contains the starting location of the allocated bytes.

```
TX_BYTE_POOL my_pool;
unsigned char *memory_ptr; UINT status;

/* Allocate a 112 byte memory area from my_pool. Assume that the byte pool has already been created with a call to tx_byte_pool_create. */

status = tx_byte_allocate (&my_pool, VOID **) &memory_ptr,

112, TX_WAIT_FOREVER);

/* If status equals TX_SUCCESS, memory_ptr contains the address of the allocated memory area. */
```

Figure 85. Allocating bytes from a memory byte pool

If variable *status* contains the return value TX_SUCCESS, then a block of 112 bytes, pointed to by memory_ptr has been created successfully.

Note that the time required by this service depends on the block size and the amount of fragmentation in the memory byte pool. Therefore, you should not use this service during time-critical threads of execution.

Deleting a Memory Byte Pool

A memory byte pool can be deleted with the tx_byte_pool_delete service. All threads that are suspended because they are waiting for memory from this byte pool are resumed and receive a TX_DELETED return status. Figure 86 shows how a memory byte pool can be deleted.

```
TX_BYTE_POOL my_pool;
UINT status;
...

/* Delete entire memory pool. Assume that the pool has already been created with a call to tx_byte_pool_create. */
status = tx_byte_pool_delete(&my_pool);

/* If status equals TX_SUCCESS, the memory pool is deleted. */
```

Figure 86. Deleting a memory byte pool

If variable *status* contains the return value TX_SUCCESS, then the memory byte pool has been deleted successfully.

Retrieving Memory Byte Pool Information

There are three services that enable you to retrieve vital information about memory byte pools. The first such service for memory byte pools—the tx_byte_pool_info_get service—retrieves a subset of information from the Memory Byte Pool Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the tx_byte_pool_performance_info_get service—provides an information summary for a particular memory byte pool up to the time the service is invoked. By contrast the

tx_byte_pool_performance_system_info_get retrieves an information summary for all memory byte pools in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_byte_pool_info_get4 service retrieves a variety of information about a memory byte pool. The information that is retrieved includes the byte pool name, the number of bytes available, the number of memory fragments, the location of the thread that is first on the suspension list for this byte pool, the number of threads currently suspended on this byte pool, and the location of the next created memory byte pool. Figure 87 shows how this service can be used to obtain information about a memory byte pool.

```
TX_BYTE_POOL my_pool;
CHAR *name;
ULONG available;
ULONG fragments;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_BYTE_POOL *next_pool;
UINT status;
...
/* Retrieve information about the previously created block pool "my_pool." */
status = tx_byte_pool_info_get(&my_pool, &name, &available, &fragments, &first_suspended, &suspended_count, &next_pool);

/* If status equals TX_SUCCESS, the information requested is valid. */
```

Figure 87. Retrieving information about a memory byte pool

If variable *status* contains the return value TX_SUCCESS, then valid information about the memory byte pool has been obtained successfully.

Prioritizing a Memory Byte Pool Suspension List

When a thread is suspended because it is waiting for a memory byte pool, it is placed in the suspension list in a FIFO manner. When a memory byte pool regains an adequate amount of memory, the first thread in the suspension list (regardless of priority) receives an opportunity to allocate bytes from that memory byte pool. The tx_byte_pool_prioritize service places the highest-priority thread suspended for

ownership of a specific memory byte pool at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended. Figure 88 shows how this service can be used.

If the variable *status* contains the value TX_SUCCESS, then the operation succeeded: the highest-priority thread in the suspension list has been placed at the front of the suspension list. The service also returns TX_SUCCESS if no thread was suspended on this memory byte pool. In this case the suspension list remains unchanged.

```
TX_BYTE_POOL my_pool;
UINT status;
...
/* Ensure that the highest priority thread will receive the next free memory from this pool. */
status = tx_byte_pool_prioritize(&my_pool);

/* If status equals TX_SUCCESS, the highest priority suspended thread is at the front of the list. The next tx_byte_release call will wake up this thread, if there is enough memory to satisfy its request. */
```

Figure 88. Prioritizing the memory byte pool suspension list

Releasing Memory to a Byte Pool

The tx_byte_release service releases a previously allocated memory area back to its associated pool. If one or more threads are suspended on this pool, each suspended thread receives the memory it requested and is resumed—until the pool's memory is exhausted or until there are no more suspended threads. This process of allocating memory to suspended threads always begins with the first thread on the suspension list. Figure 89 shows how this service can be used.

```
unsigned char *memory_ptr; UINT status;
...

/* Release a memory back to my_pool. Assume that the memory area was previously allocated from my_pool. */

status = tx_byte_release((VOID *) memory_ptr);

/* If status equals TX_SUCCESS, the memory pointed to by memory_ptr has been returned to the pool. */
```

Figure 89. Releasing bytes back to the memory byte pool

If the variable *status* contains the value TX_SUCCESS, then the memory block pointed to by memory_ptr has been returned to the memory byte pool.

Memory Byte Pool Example—Allocating Thread Stacks

In the previous chapter, we used arrays to provide memory space for thread stacks. In this example, we will use a memory byte pool to provide memory space for the two threads. The first step is to declare the threads and a memory byte pool as follows:

```
TX_THREAD Speedy_Thread, Slow_Thread;
TX_MUTEX my_mutex;
#DEFINE STACK_SIZE 1024;
TX BYTE POOL my pool;
```

Before we define the threads, we need to create the memory byte pool and allocate memory for the thread stack. Following is the definition of the byte pool, consisting of 4,500 bytes and starting at location 03500000.

Assuming that the return value was TX_SUCCESS, we have successfully created a memory byte pool. Next, we allocate memory from this byte pool for the *speedy_thread* stack, as follows:

Assuming that the return value was TX_SUCCESS, we have successfully allocated a block of memory for the stack, which is pointed to by stack_ptr. Next, we define speedy_thread using this block of memory for its stack (in place of the array stack_speedy used in the previous chapter), as follows:

We define the *slow_thread* in a similar fashion. The thread entry functions remain unchanged.

Memory Byte Pool Internals

When the TX_BYTE_POOL data type is used to declare a byte pool, a byte pool Control Block is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 90.




Figure 90. Created memory byte pool list

The pointer named tx_byte_pool_created_ptr points to the first control block in the list. See the fields in the Byte Pool Control Block for byte pool attributes, values, and other pointers.

Allocations from memory byte pools resemble traditional *malloc* calls, which includes the amount of memory desired (in bytes). Azure RTOS ThreadX allocates from the pool in a first-fit manner, converts excess memory from this block into a new block, and places it back in the free memory list. This process is called *fragmentation*.

Azure RTOS ThreadX *merges* free memory blocks together during a subsequent allocation search for a large enough free memory block. This process is called *defragmentation*.

The number of allocatable bytes in a memory byte pool is slightly less than what was specified during creation. This is because management of the free memory area introduces some overhead. Each free memory block in the pool requires the equivalent of two C pointers of overhead. In addition, when the pool is created Azure RTOS ThreadX automatically allocates two blocks, a large free block and a small permanently allocated block at the end of the memory area. This allocated end block is used to improve

performance of the allocation algorithm. It eliminates the need to continuously check for the end of the pool area during merging.

During run-time, the amount of overhead in the pool typically increases. This is partly because when an odd number of bytes is allocated, Azure RTOS ThreadX pads out the allocated block to ensure proper alignment of the next memory block. In addition, overhead increases as the pool becomes more fragmented.

Figure 91 contains an illustration of a memory byte pool after it has been created, but before any memory allocations have occurred.




Figure 91. Organization of a memory byte pool upon creation

Initially, all usable memory space is organized into one contiguous block of bytes. However, each successive allocation from this byte pool can potentially subdivide the usable memory space. For example, Figure 92 shows a memory byte pool after the first memory allocation.

Summary of Memory Block Pools

Allocating memory in a fast and deterministic manner is essential in real-time applications. This is made possible by creating and managing multiple pools of fixed-size memory blocks called memory block pools.

Because memory block pools consist of fixed-size blocks, using them involves no fragmentation problems. This is crucial because fragmentation causes behavior that is

inherently nondeterministic. In addition, allocating and freeing fixed-size blocks is fast—the time required is comparable to that of simple linked-list manipulation. Furthermore, the allocation service does not have to search through a list of blocks when it allocates and deallocates from a memory block pool—it always allocates and deallocates at the head of the available list. This provides the fastest possible linked list processing and might help keep the currently used memory block in cache.




Figure 92. Memory byte pool after the first allocation

Lack of flexibility is the main drawback of fixed-size memory pools. The block size of a pool must be large enough to handle the worst-case memory requirements of its users. Making many different-sized memory requests from the same pool may cause memory waste. One possible solution is to create several different memory block pools that contain different sized memory blocks.

Each memory block pool is a public resource. Azure RTOS ThreadX imposes no constraints as to how pools may be used. Applications may create memory block pools either during initialization or during run-time from within application threads. There is no limit to the number of memory block pools an application may use.

As noted earlier, memory block pools contain a number of fixed-size blocks. The block size, in bytes, is specified during creation of the pool. Each memory block in the pool imposes a small amount of overhead—the size of a C pointer. In addition, Azure RTOS ThreadX may pad the block size in order to keep the beginning of each memory block on proper alignment.

The number of memory blocks in a pool depends on the block size and the total number of bytes in the memory area supplied during creation. To calculate the capacity of a pool (number of blocks that will be available), divide the block size (including padding and the pointer overhead bytes) into the total number of bytes in the supplied memory area.

The memory area for the block pool is specified during creation, and can be located anywhere in the target's address space. This is an important feature because of the considerable flexibility it gives the application. For example, suppose that a communication product has a high-speed memory area for I/O. You can easily manage this memory area by making it a memory block pool.

Application threads can suspend while waiting for a memory block from an empty pool. When a block is returned to the pool, Azure RTOS ThreadX gives this block to the suspended thread and resumes the thread. If multiple threads are suspended on the same memory block pool, Azure RTOS ThreadX resumes them in the order that they occur on the suspend thread list (usually FIFO).

However, an application can also cause the highest-priority thread to be resumed. To accomplish this, the application calls <code>tx_block_pool_prioritize</code> prior to the block release call that lifts thread suspension. The block pool prioritize service places the highest priority thread at the front of the suspension list, while leaving all other suspended threads in the same FIFO order.

Memory Block Pool Control Block

The characteristics of each memory block pool are found in its Control Block.³⁵ It contains information such as block size, and the number of memory blocks left. Memory pool Control Blocks can be located anywhere in memory, but they are commonly defined as global structures outside the scope of any function. Figure 93 lists most members of the Memory Pool Control Block.

Field	Description
tx_block_pool_id	Block pool ID
tx_block_pool_name	Pointer to block pool name
tx_block_pool_available	Number of available blocks
tx_block_pool_total	Initial number of blocks in the pool
tx_block_pool_available_list	Head pointer of the available block pool
tx_block_pool_start	Starting address of the block pool memory area
tx_block_pool_size	Block pool size in bytes
tx_block_pool_block_size	Individual memory block size - rounded
*tx_block_pool_suspension_list	Block pool suspension list head
tx_block_pool_suspended_count	Number of threads suspended
*tx_block_pool_created_next	Pointer to the next block pool in the created list
*tx_block_pool_created_previous	Pointer to the previous block pool in the created list

Figure 93. Memory Block Pool Control Block

The user of an allocated memory block must not write outside its boundaries. If this happens, corruption occurs in an adjacent (usually subsequent) memory area. The results are unpredictable and quite often catastrophic.

In most cases, the developer can ignore the contents of the Memory Block Pool Control Block. However, there are several fields that may be useful during debugging, such as the number of available blocks, the initial number of blocks, the actual block size, the total number of bytes in the block pool, and the number of threads suspended on this memory block pool.

Microsoft

 $^{^{35}}$ The structure of the Memory Block Pool Control Block is defined in the $tx_api.h$ file.

Summary of Memory Block Pool Services

Appendix A contains detailed information about memory block pool services. This appendix contains information about each service, such as the prototype, a brief description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used. Figure 94 contains a list of all available memory block pool services. In the succeeding sections of this chapter, we will investigate each of these services.

Service	Description
tx_block_allocate	Allocate a fixed-size block of memory
tx_block_pool_create	Create a pool of fixed-size memory blocks
tx_block_pool_delete	Delete a memory block pool
tx_block_pool_info_get	Retrieve information about a memory block pool
tx_block_pool_prioritize	Prioritize the memory block pool suspension list
tx_block_release	Release a fixed-sized memory block back to the pool

Figure 94. Services of the memory block pool

We will first consider the tx_block_pool_create service because it must be invoked before any of the other services.

Creating a Memory Block Pool

Memory Block Pool

A memory block pool is declared with the TX_BLOCK_POOL data type and is defined with the tx_block_pool_create service. When defining a memory block pool, you need to specify its Control Block, the name of the memory block pool, the address of the memory block pool, and the number of bytes available. Figure 95 contains a list of these attributes.

Memory Block Pool Control Block	
Name of memory block pool	
Number of bytes in each fixed-size memory block	

Starting address of the memory block pool

Total number of bytes available to the block pool

Figure 95. Memory block pool attributes

We will develop one example of memory block pool creation to illustrate the use of this service, and we will name it "my_pool." Figure 96 contains an example of memory block pool creation.

TX_BLOCK_POOL my_pool; UINT status;

/* Create a memory pool whose total size is 1000 bytes starting at address 0x100000. Each block in this pool is defined to be 50 bytes long. */

status = tx_block_pool_create(&my_pool, "my_pool_name", 50, (VOID *) 0x100000, 1000);

/* If status equals TX_SUCCESS, my_pool contains 18 memory blocks of 50 bytes each. The reason there are not 20 blocks in the pool is because of the one overhead pointer associated with each block. */

Figure 96. Creating a memory block pool

If variable *status* contains the return value TX_SUCCESS, then we have successfully created a memory block pool called my_pool that contains a total of 1,000 bytes, with each block containing 50 bytes. The number of blocks can be calculated as follows:

$$Total \ Number of \ Blocks = \frac{Total \ Number of \ Bytes \ Available}{\left(Number of \ Bytes \ in each Memory \ Block\right) + \left(size of \left(void*\right)\right)}$$

Assuming that the value of size of $(void^*)$ is four bytes, the total number of blocks available is calculated thus:

Total Number of Blocks =
$$\frac{1000}{(50)+(4)}$$
 = 18.52 = 18 blocks

Use the preceding formula to avoid wasting space in a memory block pool. Be sure to carefully estimate the needed block size and the amount of memory available to the pool.

Allocating a Memory Block Pool

After a memory block pool has been declared and defined, we can start using it in a variety of applications. The tx_block_allocate service is the method that allocates a fixed size block of memory from the memory block pool. Because the size of the memory block pool is determined when it is created, we need to indicate what to do if enough memory is not available from this block pool. Figure 97 contains an example of allocating one block from a memory block pool, in which we will "wait forever" if adequate memory is not available. After memory allocation succeeds, the pointer memory_ptr contains the starting location of the allocated fixed-size block of memory.

```
TX_BLOCK_POOL my_pool;
unsigned char *memory_ptr;
UINT status;
...

/* Allocate a memory block from my_pool. Assume that the pool has already been created with a call to tx_block_pool_create. */

status = tx_block_allocate(&my_pool, (VOID **) &memory_ptr, TX_WAIT_FOREVER);

/* If status equals TX_SUCCESS, memory_ptr contains the address of the allocated block of memory. */
```

Figure 97. Allocation of a fixed-size block of memory

If variable *status* contains the return value TX_SUCCESS, then we have successfully allocated one fixed-size block of memory. This block is pointed to by memory_ptr.

Deleting a Memory Block Pool

A memory block pool can be deleted with the tx_block_pool_delete service. All threads that are suspended because they are waiting for memory from this block pool are resumed and receive a TX_DELETED return status. Figure 98 shows how a memory block pool can be deleted.

If variable *status* contains the return value TX_SUCCESS, then we have successfully deleted the memory block pool.

```
TX_BLOCK_POOL my_pool;
UINT status;
...
/* Delete entire memory block pool. Assume that the pool has already been created with a call to tx_block_pool_create. */
status = tx_block_pool_delete(&my_pool);
/* If status == TX_SUCCESS, the memory block pool has been deleted. */
```

Figure 98. Deleting a memory block pool

Retrieving Memory Block Pool Information

The tx_block_pool_info_get service retrieves a variety of information about a memory block pool. The information that is retrieved includes the block pool name, the number of blocks available, the total number of blocks in the pool, the location of the thread that is first on the suspension list for this block pool, the number of threads currently suspended on this block pool, and the location of the next created memory block pool. Figure 99 show how this service can be used to obtain information about a memory block pool.

```
TX_BLOCK_POOL my_pool;
CHAR *name;
ULONG available;
ULONG total_blocks;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_BLOCK_POOL *next_pool;
UINT status;
...
/* Retrieve information about the previously created block pool "my_pool." */
status = tx_block_pool_info_get(&my_pool, &name, &available,&total_blocks, &first_suspended, &suspended_count, &next_pool);
/* If status equals TX_SUCCESS, the information request is valid. */
```

Figure 99. Retrieving information about a memory block pool

If variable *status* contains the return value TX_SUCCESS, then we have successfully obtained valid information about the memory block pool.

Prioritizing a Memory Block Pool Suspension List

When a thread is suspended because it is waiting for a memory block pool, it is placed in the suspension list in a FIFO manner. When a memory block pool regains a block of memory, the first thread in the suspension list (regardless of priority) receives an opportunity to take a block from that memory block pool. The tx_block_pool_prioritize service places the highest-priority thread suspended for ownership of a specific memory block pool at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended. Figure 100 contains an example showing how this service can be used.

```
TX_BLOCK_POOL my_pool;
UINT status;
...

/* Ensure that the highest priority thread will receive the next free block in this pool. */
status = tx_block_pool_prioritize(&my_pool);

/* If status equals TX_SUCCESS, the highest priority suspended thread is at the front of the list. The next tx_block_release call will wake up this thread. */
```

Figure 100. Prioritizing the memory block pool suspension list

If the variable *status* contains the value TX_SUCCESS, the prioritization request succeeded. The highest-priority thread in the suspension list that is waiting for the memory block pool called "my_pool" has moved to the front of the suspension list. The service call also returns TX_SUCCESS if no thread was waiting for this memory block pool. In this case, the suspension list remains unchanged.

```
TX_BLOCK_POOL my_pool;
unsigned char *memory_ptr;
UINT status;
...
/* Release a memory block back to my_pool. Assume that the pool has been created and the memory block has been allocated. */
status = tx_block_release((VOID *) memory_ptr);
```

```
/* If status equals TX_SUCCESS, the block of memory pointed to by memory_ptr has been returned to the pool. */
```

Figure 101. Release one block to the memory block pool

Releasing a Memory Block

The tx_block_release service releases one previously allocated memory block back to its associated block pool. If one or more threads are suspended on this pool, each suspended thread receives a memory block and is resumed until the pool runs out of blocks or until there are no more suspended threads. This process of allocating memory to suspended threads always begins with the first thread on the suspended list. Figure 101 shows how this service can be used.

If the variable *status* contains the value TX_SUCCESS, then the memory block pointed to by memory_ptr has been returned to the memory block pool.

Memory Block Pool Example—Allocating Thread Stacks

In the previous chapter, we allocated thread stack memory from arrays, and earlier in this chapter we allocated thread stacks from a byte pool. In this example, we will use a memory block pool. The first step is to declare the threads and a memory block pool as follows:

```
TX_THREAD Speedy_Thread, Slow_Thread;
TX_MUTEX my_mutex;
#DEFINE STACK_SIZE 1024;
TX BLOCK POOL my pool;
```

Before we define the threads, we need to create the memory block pool and allocate memory for the thread stack. Following is the definition of the block pool, consisting of four blocks of 1,024 bytes each and starting at location 03500000.

Assuming that the return value was TX_SUCCESS, we have successfully created a memory block pool. Next, we allocate memory from that block pool for the *speedy_thread* stack, as follows:

```
CHAR *stack ptr;
```

Assuming that the return value was TX_SUCCESS, we have successfully allocated a block of memory for the stack, which is pointed to by stack_ptr. Next, we define *speedy_thread* by using that block of memory for its stack, as follows:

We define the *slow_thread* in a similar fashion. The thread entry functions remain unchanged.

Memory Block Pool Internals

When the TX_BLOCK_POOL data type is used to declare a block pool, a Block Pool Control Block is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 102.




Figure 102. Created memory block pool list

The pointer named tx_block_pool_created_ptr points to the first Control Block in the list. See the fields in the Block Pool Control Block for block pool attributes, values, and other pointers.

As noted earlier, block pools contain fixed-size blocks of memory. The advantages of this approach include fast allocation and release of blocks, and no fragmentation issues. One possible disadvantage is that space could be wasted if the block size is too large. However, developers can minimize this potential problem by creating several block pools

with different block sizes. Each block in the pool entails a small amount of overhead, i.e., an owner pointer and a next block pointer. Figure 102 illustrates the organization of a memory block pool.

Overview and Comparison

We considered two approaches for memory management in this chapter. The first approach is the memory byte pool, which allows groups of bytes of variable size to be used and reused. This approach has the advantage of simplicity and flexibility, but leads to fragmentation problems. Because of fragmentation, a memory byte pool may have enough total bytes to satisfy a request for memory, but can fail to satisfy that request because the available bytes are not contiguous. Therefore, we generally recommend that you avoid using memory byte pools for deterministic, real-time applications.

The second approach for memory management is the memory block pool, which consists of fixed-size memory blocks, thus eliminating the fragmentation problem. Memory block pools lose some flexibility because all memory blocks are the same size, and a given application may not need that much space. However, developers can alleviate this problem by creating several memory block pools, each with a different block size. Furthermore, allocating and releasing memory blocks is fast and predictable. In general, we recommend the use of memory block pools for deterministic, real-time applications.

Key Terms and Phrases

allocation of memory fixed-size block block size calculation fragmentation

creating memory pools information retrieval defragmentation memory block pool

deleting memory pools Memory Block Pool Control Block

memory byte pool release of memory

Memory Byte Pool Control Block suspend while waiting for memory pointer overhead thread stack memory allocation

prioritize memory pool suspension list wait option

Problems

- 1. Memory block pools are recommended for deterministic, real-time applications. Under what circumstances should you use memory byte pools?
- 2. In the previous chapter, thread stacks were allocated from arrays. What advantages do memory block pools have over arrays when providing memory for thread stacks?
- 3. Suppose that an application has created a memory byte pool and has made several allocations from it. The application then requests 200 bytes when the pool has 500 total bytes available. Explain why the pool might not fulfill that request in a timely fashion.
- 4. Suppose that a memory block pool is created with a total of 1,000 bytes, with each block 100 bytes in size. Explain why this pool contains fewer than 10 blocks.
- 5. Create the memory block pool in the previous problem and inspect the following fields in the Control Block: tx_block_pool_available, tx_block_pool_size, tx_block_pool_block_size, and tx_block_pool_suspended_count.
- 6. The section titled *Memory Block Pool Example—Allocating Thread Stacks* contains a definition for *speedy_thread* using a block of memory for its stack. Develop a definition for *slow_thread* using a block of memory for its stack, and then build and debug the resulting system.

Chapter 8

Internal System Clock and

Application Timers

Introduction

Fast response to asynchronous external events is the most important function of real-time, embedded applications. However, many of these applications must also perform certain activities at predetermined intervals of time.

Azure RTOS ThreadX application timers enable you to execute application C functions at specific intervals of time. You can also set an application timer to expire only once. This type of timer is called a *one-shot timer*, while repeating interval timers are called *periodic timers*. Each application timer is a public resource.

Time intervals are measured by periodic timer interrupts. Each timer interrupt is called a timer-tick. The actual time between timer-ticks is specified by the application, but 10 ms is the norm for many implementations.³⁶

The underlying hardware must be able to generate periodic interrupts in order for application timers to function. In some cases, the processor has a built-in periodic interrupt capability. If not, the user's computer board must have a peripheral device that can generate periodic interrupts.

Azure RTOS ThreadX can still function even without a periodic interrupt source. However, all timer-related processing is then disabled. This includes time-slicing, suspension timeouts, and timer services.

³⁶ The periodic timer setup is typically found in the tx_ill assembly file.

Timer expiration intervals are specified in terms of timer-ticks. The timer count starts at the specified expiration value and decreases by one on each timer-tick. Because an application timer could be enabled just prior to a timer interrupt (or timer-tick), the timer could expire up to one tick early.

If the timer-tick rate is 10 ms, application timers may expire up to 10 ms early. This inaccuracy is more significant for 10 ms timers than for one-second timers. Of course, increasing the timer interrupt frequency decreases this margin of error.

Application timers execute in the order in which they become active. For example, if you create three timers with the same expiration value and then activate them, their corresponding expiration functions³⁷ are guaranteed to execute in the order that you activated the timers.

By default, application timers execute from within a hidden system thread that runs at priority zero, which is higher than any application thread. Therefore, you should keep processing inside timer expiration functions to a minimum. It is important to avoid suspending on any service calls made from within the application timer's expiration function.

It is also important to avoid, whenever possible, using timers that expire every timer tick. This might induce excessive overhead in the application.

In addition to the application timers, Azure RTOS ThreadX provides a single continuously incrementing 32-bit tick counter. This tick counter, or internal system clock, increments by one on each timer interrupt. An application can read or set this 32-bit counter with calls to tx_time_get and tx_time_set, respectively. The use of the internal system clock is determined completely by the application.

We will first consider the two services for the internal system clock (i.e., tx_time_get and tx_time_set), and then we will investigate application timers.

_

³⁷ An expiration function is sometimes called a timeout function.

Internal System Clock Services

Azure RTOS ThreadX sets the internal system clock to zero during application initialization, and each timer-tick³⁸ increases the clock by one. The internal system clock is intended for the sole use of the developer; Azure RTOS ThreadX does not use it for any purpose, including implementing application timers. Applications can perform exactly two actions on the internal system clock: either read the current clock value, or set its value. Appendix I contains additional information about internal system clock services.

The tx_time_get service retrieves the current time from the internal system clock. Figure 103 illustrates how this service can be used.

```
ULONG current_time;

/* Retrieve the current system time, in timer-ticks. */

current_time = tx_time_get();

/* Variable current_time now contains the current system time */
```

Figure 103. Get current time from the internal system clock

After invoking this service, the variable current_time contains a copy of the internal system clock. This service can be used to measure elapsed time and perform other time-related calculations.

The tx_time_set service sets the current time of the internal system clock to some specified value. Figure 104 illustrates how this service can be used.

```
/* Set the internal system time to 0x1234. */

tx_time_set(0x1234);

/* Current time now contains 0x1234 until the next timer interrupt. */
```

Figure 104. Set current time of the internal system clock

 $^{^{\}rm 38}$ The actual time represented by each timer-tick is application specific.

After invoking this service, the current time of the internal system clock contains the value 031234. The time will remain at this value until the next timer-tick, when it will be incremented by one.

Application Timer Control Block

The characteristics of each application timer are found in its Application Timer Control Block.³⁹ It contains useful information such as the ID, application timer name, the number of remaining timer-ticks, the re-initialization value, the pointer to the timeout function, the parameter for the timeout function, and various pointers. As with the other Control Blocks, Azure RTOS ThreadX prohibits an application from explicitly modifying the Application Timer Control Block.

Application Timer Control Blocks can be located anywhere in memory, but it is most common to make the Control Block a global structure by defining it outside the scope of any function. Figure 105 contains many of the fields that comprise this Control Block.

Field	Description	
tx_timer_id	Application timer ID	
tx_timer_name	Pointer to application timer name	
tx_remaining_ticks	Number of remaining timer-ticks	
tx_re_initialize_ticks	Re-initialization timer-tick value	
tx_timeout_function	Pointer to timeout function	
tx_timeout_param	Parameter for timeout function	
tx_active_next	Pointer to next active internal timer	
tx_active_previous	Pointer to previous active internal timer	
tx_list_head	Pointer to head of list of internal timers	
tx_timer_created_next	Pointer to the next byte pool in the created list	
tx_timer_created_previous	Pointer to the previous byte pool in the created list	

Figure 105. Application Timer Control Block

An Application Timer Control Block is created when an application timer is declared with the TX_TIMER data type. For example, we declare my_timer as follows:

TX_TIMER my_timer;

Azure RTOS ThreadX

 $^{^{39}}$ The structure of the Application Timer Control Block is defined in the $tx_api.h$ file.

The declaration of application timers normally appears in the declaration and definition section of the application program.

Summary of Application Timer Services

Appendix J contains detailed information about application timer services. This appendix contains information about each service, such as the prototype, a brief description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used. Figure 106 contains a listing of all available application timer services. We will investigate each of these services in the subsequent sections of this chapter.

Application Timer Service	Description	
tx_timer_activate	Activate an application timer	
tx_timer_change	Change characteristics of an application timer	
tx_timer_create	Create an application timer	
tx_timer_deactivate	Deactivate an application timer	
tx_timer_delete	Delete an application timer	
tx_timer_info_get	Retrieve information about an application timer	

Figure 106. Services of the application timer

We will first consider the tx_timer_pool_create service because it needs to be invoked before any of the other services.

Creating an Application Timer

An application timer is declared with the TX_TIMER data type and is defined with the tx_timer_create service. When defining an application timer, you must specify its Control Block, the name of the application timer, the expiration function to call when the timer expires, the input value to pass to the expiration function, the initial number of timer-ticks before timer expiration, the number of timer-ticks for all timer expirations

130

after the first, and the option that determines when the timer is activated. The valid range of values for the initial number of timer-ticks is from 1 to 0xFFFFFFF (inclusive).

For subsequent time timer-ticks, the valid range of values is from 0 to 0xFFFFFFFF (inclusive), where the value of 0 means this is a *one-shot timer*, and all other values in that range are for *periodic timers*. Figure 107 contains a list of these attributes.

We will illustrate the application timer creation service with an example. We will give our application timer the name "my_timer" and cause it to activate immediately. The timer will expire after 100 timer-ticks, call the expiration function called "my_timer_function," and will continue to do so every 25 timer-ticks thereafter. Figure 107 contains an example of application timer creation.

Application Timer Control Block		
Application timer name		
Expiration Function to call when the timer expires		
Input to pass to the Expiration Function		
Initial number of timer-ticks		
Number of timer-ticks for all timer expirations after the first		
Auto activate option		

Figure 107. Attributes of an application timer

If variable *status* contains the return value TX_SUCCESS, we have successfully created the application timer. We must place a prototype for the expiration function in the declaration and definition section of our program as follows:

```
void my timer function (ULONG);
```

The expiration function definition appears in the final section of the program, where the thread entry functions are defined. Following is a skeleton of that function definition.

```
void my_timer_function (ULONG invalue)
{
:
}
```

Activating an Application Timer

When an application timer is created with the TX_NO_ACTIVATE option, it remains inactive until the tx_timer_activate service is called. Similarly, if an application timer is deactivated with the tx_timer_deactive service, it remains inactive until the tx_timer_activate service is called. If two or more application timers expire at the same time, the corresponding expiration functions are executed in the order in which they were activated. Figure 108 contains an example of application timer activation.

```
TX_TIMER my_timer;
UINT status;
...
/* Activate an application timer. Assume that the application timer has already been created. */
status = tx_timer_activate(&my_timer);
/* If status equals TX_SUCCESS, the application timer is now active. */
```

Figure 108. Activation of an application timer

Changing an Application Timer

When you create an application timer, you must specify the initial number of timer-ticks before timer expiration, as well as the number of timer-ticks for all timer expirations after the first. Invoking the tx_timer_change service can change these values. You must deactivate the application timer before calling this service, and call tx_timer_activate after this service to restart the timer. Figure 109 illustrates how this service can be called.

```
TX_TIMER my_timer;
UINT status;
...

/* Change a previously created and now deactivated timer
to expire every 50 timer-ticks, including the initial expiration. */
status = tx_timer_change(&my_timer,50, 50);

/* If status equals TX_SUCCESS, the specified timer is changed to
expire every 50 timer-ticks. */

/* Activate the specified timer to get it started again. */
status = tx_timer_activate(&my_timer);
```

Figure 109. Change characteristics of an application timer

If variable *status* contains the return value TX_SUCCESS, we have successfully changed the number of timer-ticks for initial and subsequent expiration to 50.

Deactivating an Application Timer

Before modifying the timing characteristics of an application timer, that timer must first be deactivated. This is the sole purpose of the tx_timer_deactivate service. Figure 110 shows how to use this service.

```
TX_TIMER my_timer;
UINT status;
...
/* Deactivate an application timer. Assume that the application timer has already been created. */
status = tx_timer_deactivate(&my_timer);
/* If status equals TX_SUCCESS, the application timer is now deactivated. */
```

Figure 110. Deactivate an application timer

If variable *status* contains the value TX_SUCCESS, the application timer is now deactivated. This timer remains in an inactive state until it is activated with the tx_timer_activate service.

Deleting an Application Timer

The tx_timer_delete service deletes an application timer. Figure 111 shows how to delete an application timer.

```
TX_TIMER my_timer;
UINT status;
...
/* Delete application timer. Assume that the application timer has already been created. */
status = tx_timer_delete(&my_timer);
/* If status equals TX_SUCCESS, the application timer is deleted. */
```

Figure 111. Deleting an application timer

If variable *status* contains the return value TX_SUCCESS, we have successfully deleted the application timer. Make certain that you do not inadvertently use a deleted timer.

Retrieving Application Timer Information

There are three services that enable you to retrieve vital information about application timers. The first such service for application timers—the tx_timer_pool_info_get service—retrieves a subset of information from the Application Timer Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the tx_timer_pool_performance_info_get service—provides an information summary for a particular application timer up to the time the service is invoked. By contrast the tx_timer_pool_performance_system_info_get retrieves an information summary for all application timers in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_timer_info_get⁴⁰ service retrieves a variety of information about an application timer. The information that is retrieved includes the application timer name, its active/inactive state, the number of timer-ticks before the timer expires, the number of subsequent timer-ticks for timer expiration after the first expiration, and a pointer to the next created application timer. Figure 112 shows how this service can be used to obtain information about an application timer.

If variable *status* contains the return value TX_SUCCESS, we have retrieved valid information about the timer.

⁴⁰ By default, only the *tx_timer_info_get* service is enabled. The other two information-gathering services must be enabled in order to use them.

Figure 112. Retrieve Information about an application timer

Sample System Using Timers to Measure Thread Performance

In Chapter 6, we created a sample system that produced output beginning as follows:

```
Current Time: 34 Speedy_Thread finished cycle...

Current Time: 40 Slow_Thread finished cycle...

Current Time: 56 Speedy Thread finished cycle...
```

The timing data in this output was captured with the use of the internal system clock. Following are the statements near the end of the *speedy_thread* entry function that generate information about the performance of *speedy_thread*.

```
current_time = tx_time_get();
printf("Current Time: %5lu Speedy_Thread finished cycle...\n",
current time);
```

We used the tx_time_get service to retrieve the current time from the internal system clock. Each time the *speedy_thread* finished its cycle it displayed the preceding timing information.

For this sample system, we will eliminate the display of information at the end of each thread cycle. However, we will continue to use the internal system clock to determine the time duration of a thread cycle, but we will display a summary of information at designated intervals, say every 500 timer-ticks. We will use an application timer to

trigger this periodic display. Following is a portion of the sample output we would like to have displayed on a periodic basis:

```
**** Timing Info Summary
Current Time: 500
Speedy_Thread counter: 22
Speedy_Thread avg time: 22
Slow_Thread counter: 11
Slow Thread avg time: 42
```

We need to compute the average cycle time for both the *speedy_thread* and the *slow_thread*. To accomplish this, we need two variables for each of the two threads: one to store the total time spent in the cycle, and one to count the total number of cycles completed. Figure 113 contains these variable declarations and the other additions to the declarations and definitions section of the program.

```
/* Declare the application timer */
TX_TIMER stats_timer;

/* Declare the counters and accumulators */
ULONG Speedy_Thread_counter = 0,
total_speedy_time = 0;
ULONG Slow_Thread_counter = 0,
total_slow_time = 0;

/* Define prototype for expiration function */
void print_stats(ULONG);
```

Figure 113. Additions to the declarations and definitions section

We need to add the timer creation service to the tx_application_define function, as indicated by Figure 114.

Figure 114. Additions to the application definitions section

We need to modify the entry functions for the *speedy_thread* and the *slow_thread*. Delete the following statements at the end of the *speedy_thread* entry function:

136

```
current_time = tx_time_get();
printf("Current Time: %lu Speedy_Thread finished cycle...\n",
current time);
```

We will use the internal system clock to compute the time to complete each cycle. We also need to compute the total cycle time as follows:

$$total_speedy_time = \sum cycle_time$$

Figure 115 contains the necessary additions for the speedy_thread.

```
/* Insert at the beginning of Speedy_Thread entry function */
ULONG start_time, cycle_time;

/* Get the starting time for this cycle */
    start_time = tx_time_get();
...

/* Insert at the end of Speedy_Thread entry function */
    /* Increment thread counter, compute cycle time & total time */
    Speedy_Thread_counter++;
    current_time = tx_time_get();
    cycle_time = current_time - start_time;
    total_speedy_time = total_speedy_time + cycle_time;
```

Figure 115. Additions to the *Speedy_Thread* entry function

The entry function for *slow_thread* requires similar additions, but we leave that as an exercise for the reader. These computations store the total number of cycles that have been completed, and the total amount of time spent in those cycles. The expiration function called print_stats will use these values to compute average cycle time for both threads and will display summary information.

Every 500 timer-ticks, the application timer called stats_timer expires and invokes the expiration function print_stats. After determining that both thread counters are greater than zero, that function computes the average cycle times for *speedy_thread* and *slow_thread*, as follows:

```
avg\_slow\_time = \frac{total\_slow\_time}{slow\_thread\_counter} and avg\_speedy\_time = \frac{total\_speedy\_time}{speedy\_thread\_counter}
```

Function print_stats then displays the current time, the average cycle times, and the number of cycles completed by each of the threads. Figure 116 contains a listing of the print_stats expiration function.

```
/* Display statistics at periodic intervals */
void print_stats (ULONG invalue)
{
    ULONG current_time, avg_slow_time, avg_speedy_time;

    if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
    {
        current_time = tx_time_get();
        avg_slow_time = total_slow_time / Slow_Thread_counter;
        avg_speedy_time = total_speedy_time / Speedy_Thread_counter;

        printf("\n**** Timing Info Summary\n\n");
        printf("Current Time: %lu\n", current_time);
        printf(" Speedy_Thread counter: %lu\n", Speedy_Thread_counter);
        printf(" Speedy_Thread avg time: %lu\n", avg_speedy_time);
        printf(" Slow_Thread counter: %lu\n", Slow_Thread_counter);
        printf(" Slow_Thread avg time: %lu\n\n", avg_slow_time);
    }
    else printf("Bypassing print_stats, Time: %lu\n", tx_time_get());
}
```

Figure 116. Expiration function to display summary information

This program can be modified easily to display other timing information, and the timer can be changed to expire at different time intervals as well. The complete program listing is located in the next section of this chapter.

Listing for 08_sample_system.c

The sample system named 08_sample_system.c appears below; line numbers have been added for easy reference.

```
001 /* 08_sample_system.c
002
003
       Create two threads, and one mutex.
004
       Use arrays for the thread stacks.
005
       The mutex protects the critical sections.
       Use an application timer to display thread timings. */
006
007
008 /*******************************/
          Declarations, Definitions, and Prototypes
009
    /***********************************
010
011
012 #include
               "tx_api.h"
               <stdio.h>
013 #include
014
015 #define
                                   1024
                STACK_SIZE
016
017 CHAR stack_speedy[STACK_SIZE];
018 CHAR stack_slow[STACK_SIZE];
019
020
021 /* Define the Azure RTOS ThreadX object control blocks... */
022
023 TX_THREAD
                            Speedy_Thread;
                            slow_Thread;
024 TX_THREAD
025
026 TX_MUTEX
                            my_mutex;
027
028 /* Declare the application timer */
029 TX_TIMER
                    stats_timer;
030
031 /* Declare the counters and accumulators */
032 ULONG
                    Speedy_Thread_counter = 0,
                    total_speedy_time = 0;
033
034 ULONG
                    Slow_Thread_counter = 0,
035
                    total_slow_time = 0;
036
037 /* Define prototype for expiration function */
```

```
038 void
           print_stats(ULONG);
039
040 /* Define thread prototypes. */
041
042 void
           Speedy_Thread_entry(ULONG thread_input);
043 void
           Slow_Thread_entry(ULONG thread_input);
044
045
046 /*******************************/
047 /*
                   Main Entry Point
048 /***********************************/
049
050 /* Define main entry point. */
051
052 int main()
053 {
054
055
       /* Enter the Azure RTOS ThreadX kernel. */
056
       tx_kernel_enter();
057 }
058
059
060 /******************************
061 /*
                 Application Definitions
062 /******************************
063
064 /* Define what the initial system looks like. */
065
066 void
           tx_application_define(void *first_unused_memory)
067 {
068
069
070
       /* Put system definitions here,
071
         e.g., thread and mutex creates */
072
       /* Create the Speedy_Thread. */
073
074
       tx_thread_create(&Speedy_Thread, "Speedy_Thread",
075
                      Speedy_Thread_entry, 0,
076
                      stack_speedy, STACK_SIZE,
077
                       5, 5, TX_NO_TIME_SLICE, TX_AUTO_START);
078
```

```
079
       /* Create the Slow_Thread */
080
       tx_thread_create(&Slow_Thread, "Slow_Thread",
081
                      Slow_Thread_entry, 1,
082
                      stack_slow, STACK_SIZE,
083
                      15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
084
085
      /* Create the mutex used by both threads */
086
      tx_mutex_create(&my_mutex, "my_mutex", TX_NO_INHERIT);
087
088
      /* Create and activate the timer */
089
      tx_timer_create (&stats_timer, "stats_timer", print_stats,
                      0x1234, 500, 500, TX_AUTO_ACTIVATE);
090
091
092 }
093
094
096 /*
                  Function Definitions
                                                   */
098
099 /* Define the activities for the Speedy_Thread */
100
101 void
           Speedy_Thread_entry(ULONG thread_input)
102 {
103 UINT
          status;
104 ULONG
           current_time;
105 ULONG
           start_time, cycle_time;
106
107
      while(1)
108
109
110
         /* Get the starting time for this cycle */
111
         start_time = tx_time_get();
112
113
         /* Activity 1: 2 timer-ticks. */
114
         tx_thread_sleep(2);
115
         /* Activity 2: 5 timer-ticks *** critical section ***
116
117
         Get the mutex with suspension. */
118
119
         status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
```

```
120
          if (status != TX_SUCCESS) break; /* Check status */
121
122
         tx_thread_sleep(5);
123
124
         /* Release the mutex. */
125
          status = tx_mutex_put(&my_mutex);
126
          if (status != TX_SUCCESS) break; /* Check status */
127
128
          /* Activity 3: 4 timer-ticks. */
129
         tx_thread_sleep(4);
130
131
          /* Activity 4: 3 timer-ticks *** critical section ***
132
         Get the mutex with suspension. */
133
134
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
         if (status != TX_SUCCESS) break; /* Check status */
135
136
137
         tx_thread_sleep(3);
138
139
         /* Release the mutex. */
140
          status = tx_mutex_put(&my_mutex);
141
         if (status != TX_SUCCESS) break; /* Check status */
142
143
          /* Increment thread counter, compute cycle time & total time */
144
          Speedy_Thread_counter++;
145
          current_time = tx_time_get();
146
          cycle_time = current_time - start_time;
147
          total_speedy_time = total_speedy_time + cycle_time;
148
149
       }
150 }
151
153
154 /* Define the activities for the Slow_Thread */
155
156 void
           Slow_Thread_entry(ULONG thread_input)
157 {
158 UINT
           status;
159 ULONG
           current_time;
160 ULONG
           start_time, cycle_time;
```

```
161
162
       while(1)
163
       {
164
165
          /* Get the starting time for this cycle */
166
          start_time = tx_time_get();
167
168
          /* Activity 5: 12 timer-ticks *** critical section ***
169
          Get the mutex with suspension. */
170
171
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
172
          if (status != TX_SUCCESS) break; /* Check status */
173
174
          tx_thread_sleep(12);
175
176
          /* Release the mutex. */
177
          status = tx_mutex_put(&my_mutex);
          if (status != TX_SUCCESS) break; /* Check status */
178
179
180
          /* Activity 6: 8 timer-ticks. */
181
          tx_thread_sleep(8);
182
183
          /* Activity 7: 11 timer-ticks *** critical section ***
184
          Get the mutex with suspension. */
185
186
          status = tx_mutex_get(&my_mutex, TX_WAIT_FOREVER);
          if (status != TX_SUCCESS) break; /* Check status */
187
188
189
          tx_thread_sleep(11);
190
191
          /* Release the mutex. */
192
          status = tx_mutex_put(&my_mutex);
193
          if (status != TX_SUCCESS) break; /* Check status */
194
195
          /* Activity 8: 9 timer-ticks. */
196
          tx_thread_sleep(9);
197
          /* Increment thread counter, compute cycle time & total time */
198
199
          Slow_Thread_counter++;
200
          current_time = tx_time_get();
201
          cycle_time = current_time - start_time;
```

```
202
          total_slow_time = total_slow_time + cycle_time;
203
204
       }
205 }
206
208
209 /* Display statistics at periodic intervals */
210 void print_stats (ULONG invalue)
211 {
212
       ULONG
              current_time, avg_slow_time, avg_speedy_time;
213
214
       if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
215
216
          current_time = tx_time_get();
217
          avg_slow_time = total_slow_time / Slow_Thread_counter;
218
          avg_speedy_time = total_speedy_time / Speedy_Thread_counter;
219
220
          printf("\n**** Timing Info Summary\n\n");
221
          printf("Current Time:
                                            %lu\n", current_time);
222
          printf(" Speedy_Thread counter: %lu\n", Speedy_Thread_counter);
          printf(" Speedy_Thread avg time: %lu\n", avg_speedy_time);
223
224
          printf("
                     Slow_Thread counter: %lu\n", Slow_Thread_counter);
          printf("
225
                    Slow_Thread avg time: %lu\n\n", avg_slow_time);
226
227
       else printf("Bypassing print_stats, Time: %lu\n", tx_time_qet());
228 }
```

Application Timer Internals

When the TX_TIMER data type is used to declare an application timer, a Timer Control Block is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 117.




Figure 117. Created application timer list

The pointer named tx_timer_created_ptr points to the first Control Block in the list. See the fields in the Timer Control Block for timer attributes, values, and other pointers.

To quickly determine when the next timer will expire, Azure RTOS ThreadX maintains an array of active timer linked-list head pointers, as illustrated in Figure 118. Each head pointer points to a linked list of Timer Control Blocks, such as illustrated in Figure 117.

The name of the array of active timer head pointers is <code>_tx_timer_list</code>. There is a pointer named <code>_tx_timer_current_ptr</code> that moves to the next position in this array at every timer-tick (in wrap-around fashion). Every time this pointer moves to a new array position, all the timers in the corresponding linked list are processed. The actual expiration values are "hashed" to the array index so there is no searching involved, thus optimizing processing speed. Thus, the next timer to expire will always be in the list pointed to by <code>_tx_timer_current_ptr</code>. For more information about this process, see the files named <code>tx_timer_h</code>, <code>tx_timer_interrupt.c</code>, and <code>tx_timer_interrupt.s</code>.

-

⁴¹ Note that "processed" does not necessarily mean that all the timers on the list have expired. Timers on the list that have an expiration value greater than the size of the list simply have their expiration value decremented by the list size and are then reinserted in the list. Thus, each timer list will be processed within a single timer-tick, but some timers may be only partially processed because they are not due to expire.




Figure 118. Example of array of active timer head pointers

Overview

The internal system clock is essential for capturing timing information, as illustrated by the sample program in this chapter.

Azure RTOS ThreadX provides two services for interacting with the internal system clock—getting the current time and setting the clock to a new value. There is only one internal system clock; by contrast, applications may create an unlimited number of application timers.

A one-shot application timer expires once, executes its expiration function, and then terminates. A periodic timer expires repeatedly until it is stopped, with each expiration resulting in a call to its expiration function. A periodic timer has an initial expiration value, and a reschedule value for continuing expirations.

When a timer is created, it can be activated immediately, or it can be activated at some later time by a thread.

Eight services are available for use with application timers: *create*, *activate*, *change*, *deactivate*, *retrieve information* (3 services), and delete.

Key Terms and Phrases

activation of timer application timer Application Timer Control Block application timer services

compute timing performance

creating a timer
deactivation of timer
deleting a timer
expiration function
expiration time

internal system clock one-shot timer periodic interrupt periodic timer system clock services tick counter

timeout function

timer activation options

timer interrupt timer-tick

Problems

- 1. Describe a scenario in which you would use the internal system clock rather than an application timer.
- 2. Describe a scenario in which you would use an application timer rather than the internal system clock.
- 3. If an application timer is created with the TX_AUTO_ACTIVATE option, when will that timer be activated? If that timer is created with the TX_NO_ACTIVATE option, when will that timer become activated?
- 4. When an application timer is created, the initial number of timer-ticks must be greater than zero. Given a timer that has already been created and deactivated, how would you cause its expiration function print_stats to execute at some arbitrary time in the future?
- 5. Assume that application timer my_timer and variable status have been declared. What will happen as a result of the following timer creation service call?

- 6. Assume that application timer my_timer has been created as in the previous problem. Inspect the following fields in its Control Block: tx_remaining_ticks and tx_re_initialize_ticks.
- 7. The section titled "Sample System Using Timers to Measure Thread Performance" presents most of the needed modifications from the previous chapter's examples. Complete and execute this sample system.
- 8. Assume that application timer my_timer has been created. What services would you use to change that timer to a one-shot timer that expires exactly 70 timer-ticks from some arbitrary current time?
- 9. Assume that application timer my_timer has been created. What services would you use to carry out the following operations: if the remaining number of timerticks exceeds 60, then change the timer so that it expires in exactly 2 timer-ticks, and every 75 timer-ticks after the first expiration?
- 10. Suppose you want to create one application timer that expires exactly at the following times: 50, 125, 150, and 210. How would you do this? State your assumptions.
- 11. In general, which method is better for obtaining new timer behavior: (1) delete an application timer, then create a new timer with the same name and with new characteristics, or (2) deactivate that timer and change its characteristics?

Chapter 9

Event Notification and

Synchronization with Counting

Semaphores

Introduction

Azure RTOS ThreadX provides 32-bit counting semaphores with counts that range in value from 0 to 2³² 2 1, or 4,294,967,295 (inclusive). There are two operations that affect the values of counting semaphores: tx_semaphore_get and tx_semaphore_put. The get operation decreases the semaphore by one. If the semaphore is 0, the get operation fails. The inverse of the get operation is the put operation, which increases the semaphore by one.

Each counting semaphore is a public resource. Azure RTOS ThreadX imposes no constraints as to how counting semaphores are used.

An *instance* of a counting semaphore is a single count. For example, if the count is five, then that semaphore has five instances. Similarly, if the count is zero, then that semaphore has no instances. The get operation takes one instance from the counting semaphore by decrementing its count. Similarly, the put operation places one instance in the counting semaphore by incrementing its count.

Like mutexes, counting semaphores are often used for mutual exclusion. One major difference between these objects is that counting semaphores do not support ownership, a

concept that is central to mutexes. Even so, counting semaphores are more versatile; they can also be used for event notification and interthread synchronization.

Mutual exclusion pertains to controlling threads' access to certain application areas (typically, *critical sections* and *application resources*). When used for mutual exclusion, the "current count" of a semaphore represents the total number of threads that are allowed access to that semaphore's associated resource. In most cases, counting semaphores used for mutual exclusion have an initial value of 1, meaning that only one thread can access the associated resource at a time. Counting semaphores that have values restricted to 0 or 1 are commonly called *binary semaphores*.

If a binary semaphore is used, the user must prevent that same thread from performing a get operation on a semaphore it already controls. A second get would fail and could suspend the calling thread indefinitely, as well as make the resource permanently unavailable.

Counting semaphores can also be used for event notification, as in a *producer-consumer* application. In this application, the consumer attempts to get the counting semaphore before "consuming" a resource (such as data in a queue); the producer increases the semaphore count whenever it makes something available. In other words, the producer *places* instances in the semaphore and the consumer attempts to *take* instances from the semaphore. Such semaphores usually have an initial value of 0 and do not increase until the producer has something ready for the consumer.

Applications can create counting semaphores either during initialization or during runtime. The initial count of the semaphore is specified during creation. An application may use an unlimited number of counting semaphores.

Application threads can suspend while attempting to perform a get operation on a semaphore with a current count of zero (depending on the value of the wait option).

When a put operation is performed on a semaphore and a thread suspended on that semaphore, the suspended thread completes its get operation and resumes. If multiple

Microsoft

⁴² Review the discussion about mutual exclusion in the preceding chapter dealing with mutexes.

threads are suspended on the same counting semaphore, they resume in the same order they occur on the suspended list (usually in FIFO order).

An application can cause a higher-priority thread to be resumed first, if the application calls tx_semaphore_prioritize prior to a semaphore put call. The semaphore prioritization service places the highest-priority thread at the front of the suspension list, while leaving all other suspended threads in the same FIFO order.

Counting Semaphore Control Block

The characteristics of each counting semaphore are found in its Control Block.⁴³ It contains useful information such as the current semaphore count and the number of threads suspended for this counting semaphore. Counting Semaphore Control Blocks can be located anywhere in memory, but it is most common to make the Control Block a global structure by defining it outside the scope of any function. Figure 119 contains many of the fields that comprise this Control Block.

Field	Description
tx_semaphore_id	Counting Semaphore ID
tx_semaphore_name	Pointer to counting semaphore name
tx_semaphore_count	Actual semaphore count
tx_semaphore_suspension_list	Pointer to counting semaphore suspension list
tx_semaphore_suspended_count	Number of threads suspended for this semaphore
tx_semaphore_created_next	Pointer to the next semaphore in the created list
tx_semaphore_created_previous	Pointer to the previous semaphore in the created list

Figure 119. Counting Semaphore Control Block

A Counting Semaphore Control Block is created when a counting semaphore is declared with the TX_SEMAPHORE data type. For example, we declare my_semaphore as follows:

TX_SEMAPHORE my_semaphore;

The declaration of counting semaphores normally appears in the declaration and definition section of the application program.

_

 $^{^{43}}$ The structure of the Counting Semaphore Control Block is defined in the $tx_api.h$ file.

Avoiding Deadly Embrace

One of the most dangerous pitfalls associated in using semaphores for mutual exclusion is the so-called *deadly embrace*. A deadly embrace, or *deadlock*, is a condition in which two or more threads are suspended indefinitely while attempting to get semaphores already owned by the other threads. Refer to the discussion in Chapter 6 to find remedies for deadly embrace. This discussion applies to the counting semaphore object as well.

Avoiding Priority Inversion

Counting Semaphore

Another pitfall associated with mutual exclusion semaphores is *priority inversion*, which was also discussed in Chapters 5 and 6. The groundwork for trouble is laid when a lower-priority thread acquires a mutual exclusion semaphore that a higher-priority thread needs. This sort of priority inversion in itself is normal. However, if threads that have intermediate priorities acquire the semaphore, the priority inversion may last for a nondeterministic amount of time. You can prevent this by carefully selecting thread priorities, by using preemption-threshold, and by temporarily raising the priority of the thread that owns the resource to that of the high-priority thread. Unlike mutexes, however, counting semaphores do not have a priority inheritance feature.

Service	Description	
tx_semaphore_create	Create a counting semaphore	
tx_semaphore_delete	Delete a counting semaphore	
tx_semaphore_get	Get an instance from a counting semaphore	
tx_semaphore_info_get	Retrieve information about a counting semaphore	
tx_semaphore_prioritize	Prioritize the counting semaphore suspension list	
tx_semaphore_put	Place an instance in a counting semaphore	

Figure 120. Services of the counting semaphore

Summary of Counting Semaphore Services

Appendix G contains detailed information about counting semaphore services. This appendix contains information about each service such as the prototype, a brief description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used. Figure 120

contains a listing of all available counting semaphore services. We will investigate each of these services in subsequent sections of this chapter.

Creating a Counting Semaphore

A counting semaphore is declared with the TX_SEMAPHORE data type and is defined with the tx_semaphore_create service. When defining a counting semaphore, you must specify its Control Block, the name of the counting semaphore, and the initial count for the semaphore. Figure 121 lists the attributes of a counting semaphore. The value for the count must be in the range from 0x000000000 to 0xFFFFFFFF (inclusive).




Figure 121. Counting semaphore attributes

Figure 122 illustrates the use of this service to create a counting semaphore. We give our counting semaphore the name "my_semaphore" and we give it an initial value of one. As noted before, this is typically the manner in which a *binary semaphore* is created.

Figure 122. Creating a counting semaphore

If the variable *status* contains the return value of TX_SUCCESS, we have successfully created a counting semaphore.

Deleting a Counting Semaphore

Use the tx_semaphore_delete service to delete a counting semaphore. All threads that have been suspended because they are waiting for a semaphore instance are resumed and receive a TX_DELETED return status. Make certain that you don't try to use a deleted semaphore. Figure 123 shows how a counting semaphore can be deleted.

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Delete counting semaphore. Assume that the counting semaphore has already been created. */
status = tx_semaphore_delete(&my_semaphore);

/* If status equals TX_SUCCESS, the counting semaphore has been deleted. */
Figure 123. Deleting a counting semaphore
```

If variable *status* contains the return value TX_SUCCESS, we have successfully deleted the counting semaphore.

Getting an Instance of a Counting Semaphore

The tx_semaphore_get service retrieves an instance (a single count) from the specified counting semaphore. If this call succeeds, the semaphore count decreases by one. Figure 124 shows how to get an instance of a counting semaphore, where we use the wait option value TX_WAIT_FOREVER.

```
TX_SEMAPHORE my_semaphore;
UINT status;
...

/* Get a semaphore instance from the semaphore "my_semaphore." If the semaphore count is zero, suspend until an instance becomes available.
Note that this suspension is only possible from application threads. */

status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);

/* If status equals TX_SUCCESS, the thread has obtained an instance of the semaphore. */
```

Figure 124. Get an instance from a counting semaphore

If variable *status* contains the return value TX_SUCCESS, we have successfully obtained an instance of the counting semaphore called my_semaphore.

Retrieving Information about Counting Semaphores

There are three services that enable you to retrieve vital information about semaphores. The first such service for semaphores—the tx_semaphore_info_get service retrieves a subset of information from the Semaphore Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of runtime performance data. One service—the tx_semaphore_performance_info_get service—provides an information summary for a particular semaphore up to the time the service is invoked. By contrast the tx_semaphore_performance_system_info_get retrieves an information summary for all semaphores in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_semaphore_info_get⁴⁴ service retrieves several useful pieces of information about a counting semaphore. The information that is retrieved includes the counting semaphore name, its current count, the number of threads suspended for this semaphore, and a pointer to the next created counting semaphore. Figure 125 shows how this service can be used to obtain information about a counting semaphore.

If variable *status* contains the return value TX_SUCCESS, we have obtained valid information about the counting semaphore called my_semaphore.

Prioritizing a Counting Semaphore Suspension List

When a thread is suspended because it is waiting for a counting semaphore, it is placed in the suspension list in a FIFO manner. When a counting semaphore instance becomes available, the first thread in that suspension list (regardless of priority) obtains ownership of that instance. The tx_semaphore_prioritize service places the highest-priority thread suspended on a specific counting semaphore at the front of the suspension list. All

⁴⁴ By default, only the *tx_semaphore_info_get* service is enabled. The other two information gathering services must be enabled in order to use them.

other threads remain in the same FIFO order in which they were suspended. Figure 125 shows how this service can be used.

```
TX_SEMAPHORE my_semaphore;
CHAR *name;
ULONG current_value;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_SEMAPHORE *next_semaphore;
UINT status;
...
/* Retrieve information about the previously created semaphore "my_semaphore." */
status = tx_semaphore_info_get(&my_semaphore, &name, &current_value, &first_suspended, &suspended_count, &next_semaphore);
/* If status equals TX_SUCCESS, the information requested is valid. *
```

Figure 125. Get Information about a counting semaphore

```
TX_SEMAPHORE my_semaphore;
UINT status;

/* Ensure that the highest priority thread will
receive the next instance of this semaphore. */
...
status = tx_semaphore_prioritize(&my_semaphore);

/* If status equals TX_SUCCESS, the highest priority suspended thread is at the
front of the list. The next tx_semaphore_put call made to this semaphore
will wake up this thread. */
```

Figure 126. Prioritize the counting semaphore suspension list

If variable *status* contains the return value TX_SUCCESS, the highest-priority thread suspended on an instance of my_semaphore has been placed at the front of the suspension list.

Placing an Instance in a Counting Semaphore

The tx_semaphore_put service places an instance in a counting semaphore, i.e., it increases the count by one. If there is a thread suspended on this semaphore when the put service is performed, the suspended thread's get operation completes and that thread is resumed. Figure 127 shows how this service can be used.

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Increment the counting semaphore "my_semaphore." */
status = tx_semaphore_put(&my_semaphore);

/* If status equals TX_SUCCESS, the semaphore count has been incremented. Of course, if a thread was waiting, it was given the semaphore instance and resumed. */
```

Figure 127. Place an instance on a counting semaphore

If variable *status* contains the return value TX_SUCCESS, the semaphore count has been incremented (an instance has been placed in the semaphore). If a thread was suspended for this semaphore, then that thread receives this instance and resumes execution.

Placing an Instance in a Semaphore Using a Ceiling

The tx_semaphore_put service places an instance in a counting semaphore without regard to the current count of the semaphore. However, if you want to make certain that the count is always less than or equal to a certain value, use the

tx_semaphore_ceiling_put service. When this service is invoked, the semaphore is incremented only if the resulting count would be less than or equal to the ceiling value. Figure 128 shows how this service can be used.

```
TX_SEMAPHORE my_semaphore; UINT status;
...

/* Increment the semaphore "my_semaphore" using a ceiling */
status = tx_semaphore_ceiling_put(&my_semaphore, 3);

/* If status equals TX_SUCCESS, the semaphore count has been incremented.
Of course, if a thread was waiting, it was given the semaphore instance and resumed.

If status equals TX_CEILING_EXCEEDED than the semaphore is not incremented because the resulting value would have been greater than the ceiling value of 3. */
```

Figure 128. Place an instance on a semaphore using a ceiling

Semaphore Notification and Event-Chaining⁴⁵

The tx_semaphore_put_notify service registers a notification callback function that is invoked whenever an instance is placed on the specified semaphore. The processing of the notification callback is defined by the application. This is an example of event-chaining where notification services are used to chain various synchronization events together. This is typically useful when a single thread must process multiple synchronization events.

Comparing a Counting Semaphore with a Mutex

A counting semaphore resembles a mutex in several respects, but there are differences, as well as reasons to use one resource over the other. Figure 129 reproduces the comparison chart for these two objects, which first appeared in Chapter 4.

A mutex is exceptionally robust in providing mutual exclusion. If this is crucial to your application, then using a mutex is a good decision. However, if mutual exclusion is not a major factor in your application, then use a counting semaphore because it is slightly faster and uses fewer system resources.

To illustrate the use of a counting semaphore, we will replace a mutex with a binary semaphore in the next sample system.

Microsoft

⁴⁵ Event-chaining is a trademark of Microsoft.

Mutex		Counting Semaphore
Speed	Somewhat slower	Semaphore is generally faster than a mutex
Thread ownership	Only one thread can own a mutex	No concept of thread ownership for a semaphore – any thread can decrement a counting semaphore if its current count exceeds zero
Priority inheritance	Available only with a mutex	Feature not available for semaphores
Mutual exclusion	Primary purpose of a mutex – a mutex should be used only for mutual exclusion	Can be accomplished with the use of a binary semaphore, but there may be pitfalls
Inter-thread synchronization	Do not use a mutex for this purpose	Can be performed with a semaphore, but an event flags group should be considered also
Event notification	Do not use a mutex for this purpose	Can be performed with a semaphore
Thread suspension	Thread can suspend if another thread already owns the mutex (depends on value of wait option)	Thread can suspend if the value of a counting semaphore is zero (depends on value of wait option)

Figure 129. Comparison of a mutex with a counting semaphore

Sample System Using a Binary Semaphore in Place of a Mutex

This sample system is a modification of the one discussed in the preceding chapter. The only goal here is to replace the mutex from that system with a binary semaphore. We will retain the timing facilities of that system to compare the results of thread processing by using a mutex versus using a binary semaphore.

Figure 130 shows a modification of the *speedy_thread* activities, in which we have replaced references to a mutex with references to a binary semaphore. The priorities and times remain the same as in the previous system. The shaded boxes represent the critical sections.




Figure 130. Activities of the *Speedy_Thread* (priority = 5)

Figure 131 shows a modification of the *slow_thread* activities. The only change we have made is to replace references to mutexes with references to binary semaphores.




Figure 131. Activities of the *Slow_Thread* (priority = 15)

In Chapter 8, we created a sample system that produced output that began as follows:

```
**** Timing Info Summary
Current Time: 500
Speedy_Thread counter: 22
Speedy_Thread avg time: 22
Slow_Thread counter: 11
Slow_Thread avg time: 42
```

We want our new sample system to perform the same operations as the previous system. We will discuss a series of changes to be applied to the previous system so that all references to a mutex will be replaced with references to a binary semaphore. The complete program listing, called $9a_sample_system.c$, is located in the next section of this chapter.

The first change occurs in the declaration and definitions section of our program, where we replace the declaration of a mutex with the declaration of a binary semaphore, as follows.

```
TX SEMAPHORE my semaphore;
```

A binary semaphore is a special case of a counting semaphore, so the declaration of each is the same. The next change occurs in the application definitions section of our program, where we replace the creation of a mutex with the creation of a binary semaphore, as follows:

```
/* Create the binary semaphore used by both threads */
tx_semaphore_create(&my_semaphore, "my_semaphore", 1);
```

There are two primary differences between the definition of a mutex and the definition of a binary semaphore. First, only mutexes support priority inheritance, so that option does not appear in the argument list for semaphore creation. Second, only semaphores have counts, so the argument list must include an initial value. In the above semaphore creation, the initial count is one (1), which is the most commonly used initial value for a binary semaphore.⁴⁶ This means that the binary semaphore has one instance available that may be obtained by a thread.

The remaining changes occur in the function definitions section of our program. We need to change all references to mutexes to binary semaphores to protect critical sections in Activities 2 and 4 for the *speedy_thread*, and Activities 5 and 7 for the *slow_thread*. We will show only the changes for the *speedy_thread* and will leave the *slow_thread* changes as an exercise for the reader. Figure 132 contains the necessary changes for Activity 2. Most of the modifications involve changing references to a mutex with references to a binary semaphore.

```
/* Activity 2: 5 timer-ticks *** critical section ***
Get an instance of the binary semaphore with suspension. */
status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
if (status != TX_SUCCESS) break; /* Check status */

tx_thread_sleep(5);

/* Place an instance in the binary semaphore. */
status = tx_semaphore_put(&my_semaphore);
if (status != TX_SUCCESS) break; /* Check status */
```

Figure 132. Changes to Activity 2

Figure 133 contains the necessary changes for Activity 4. Most of the modifications involve changing references to a mutex with references to a binary semaphore.

⁴⁶ The only other possible value is zero (0) but it is rarely used as an initial value for a binary semaphore.

```
/* Activity 4: 3 timer-ticks *** critical section ***
Get an instance of the binary semaphore with suspension. */
status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
if (status != TX_SUCCESS) break; /* Check status */

tx_thread_sleep(3);

/* Place an instance in the binary semaphore. */
status = tx_semaphore_put(&my_semaphore);
if (status != TX_SUCCESS) break; /* Check status */
```

Figure 133. Changes to Activity 4

Listing for 09a_sample_system.c

The sample system named $09a_sample_system.c$ appears below; line numbers have been added for easy reference.

```
001 /* 09a_sample_system.c
002
003
      Create two threads, and one mutex.
004
      Use arrays for the thread stacks.
      A binary semaphore protects the critical sections.
005
006
      Use an application timer to display thread timings. */
007
009 /*
         Declarations, Definitions, and Prototypes
010 /******************************
011
012
             "tx_api.h"
013 #include
014 #include <stdio.h>
015
016 #define
                               1024
              STACK_SIZE
017
018 CHAR stack_speedy[STACK_SIZE];
019 CHAR stack_slow[STACK_SIZE];
020
021
022 /* Define the Azure RTOS ThreadX object control blocks... */
```

```
023
                          Speedy_Thread;
024 TX_THREAD
025 TX_THREAD
                          slow_Thread;
026
027 TX_SEMAPHORE
                         my_semaphore;
028
029 /* Declare the application timer */
030 TX_TIMER
                 stats_timer;
031
032 /* Declare the counters and accumulators */
                  Speedy_Thread_counter = 0,
034
                  total_speedy_time = 0;
035 ULONG
                  Slow_Thread_counter = 0,
036
                  total_slow_time = 0;
037
038 /* Define prototype for expiration function */
039 void
          print_stats(ULONG);
040
041 /* Define thread prototypes. */
042
043 void
           Speedy_Thread_entry(ULONG thread_input);
044 void
           Slow_Thread_entry(ULONG thread_input);
045
046 /****************
047 /*
                   Main Entry Point
048 /*****************************
049
050 /* Define main entry point. */
051
052 int main()
053 {
054
055
       /* Enter the Azure RTOS ThreadX kernel. */
       tx_kernel_enter();
056
057 }
058
059 /*****************************
                 Application Definitions
061 /******************************
062
063 /* Define what the initial system looks like. */
```

```
064
065 void
           tx_application_define(void *first_unused_memory)
066 {
067
068
069
       /* Put system definitions here,
070
         e.g., thread and semaphore creates */
071
072
       /* Create the Speedy_Thread. */
073
       tx_thread_create(&Speedy_Thread, "Speedy_Thread",
074
                       Speedy_Thread_entry, 0,
075
                       stack_speedy, STACK_SIZE,
076
                       5, 5, TX_NO_TIME_SLICE, TX_AUTO_START);
077
078
       /* Create the Slow_Thread */
079
       tx_thread_create(&Slow_Thread, "Slow_Thread",
080
                       Slow_Thread_entry, 1,
081
                       stack_slow, STACK_SIZE,
082
                       15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
083
      /* Create the binary semaphore used by both threads */
084
      tx_semaphore_create(&my_semaphore, "my_semaphore", 1);
085
086
       /* Create and activate the timer */
087
088
       tx_timer_create (&stats_timer, "stats_timer", print_stats,
089
                       0x1234, 500, 500, TX_AUTO_ACTIVATE);
090
091 }
092
094 /*
                   Function Definitions
095 /****************************
096
097 /* Define the activities for the Speedy_Thread */
098
099 void
           Speedy_Thread_entry(ULONG thread_input)
100 {
101 UINT
           status;
102 ULONG current_time;
103 ULONG
           start_time, cycle_time;
104
```

```
105
       while(1)
106
107
          /* Get the starting time for this cycle */
108
109
          start_time = tx_time_get();
110
111
          /* Activity 1: 2 timer-ticks. */
112
          tx_thread_sleep(2);
113
114
          /* Activity 2: 5 timer-ticks *** critical section ***
115
          Get an instance of the binary semaphore with suspension. */
116
117
          status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
118
          if (status != TX_SUCCESS) break; /* Check status */
119
120
          tx_thread_sleep(5);
121
122
          /* Place an instance in the binary semaphore. */
123
          status = tx_semaphore_put(&my_semaphore);
124
          if (status != TX_SUCCESS) break; /* Check status */
125
126
          /* Activity 3: 4 timer-ticks. */
127
          tx_thread_sleep(4);
128
129
          /* Activity 4: 3 timer-ticks *** critical section ***
130
          Get an instance of the binary semaphore with suspension. */
131
132
          status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
133
          if (status != TX_SUCCESS) break; /* Check status */
134
135
          tx_thread_sleep(3);
136
137
          /* Place an instance in the binary semaphore. */
138
          status = tx_semaphore_put(&my_semaphore);
139
          if (status != TX_SUCCESS) break; /* Check status */
140
141
          /* Increment thread counter, compute cycle time & total time */
142
          Speedy_Thread_counter++;
143
          current_time = tx_time_get();
144
          cycle_time = current_time - start_time;
145
          total_speedy_time = total_speedy_time + cycle_time;
```

```
146
147
       }
148 }
149
151
152 /* Define the activities for the Slow_Thread */
153
154 void
           Slow_Thread_entry(ULONG thread_input)
155 {
156 UINT
           status;
           current_time;
157 ULONG
158 ULONG
           start_time, cycle_time;
159
160
      while(1)
161
162
          /* Get the starting time for this cycle */
163
164
         start_time = tx_time_get();
165
166
         /* Activity 5: 12 timer-ticks *** critical section ***
167
          Get an instance of the binary semaphore with suspension. */
168
169
          status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
170
          if (status != TX_SUCCESS) break; /* Check status */
171
172
         tx_thread_sleep(12);
173
174
          /* Place an instance in the binary semaphore. */
175
          status = tx_semaphore_put(&my_semaphore);
176
          if (status != TX_SUCCESS) break; /* Check status */
177
178
          /* Activity 6: 8 timer-ticks. */
179
         tx_thread_sleep(8);
180
181
          /* Activity 7: 11 timer-ticks *** critical section ***
182
          Get an instance of the binary semaphore with suspension. */
183
184
          status = tx_semaphore_qet(&my_semaphore, TX_WAIT_FOREVER);
185
          if (status != TX_SUCCESS) break; /* Check status */
186
```

```
187
          tx_thread_sleep(11);
188
189
          /* Place an instance in the binary semaphore. */
190
          status = tx_semaphore_put(&my_semaphore);
191
          if (status != TX_SUCCESS) break; /* Check status */
192
193
          /* Activity 8: 9 timer-ticks. */
          tx_thread_sleep(9);
194
195
196
          /* Increment thread counter, compute cycle time & total time */
197
          Slow_Thread_counter++;
198
          current_time = tx_time_get();
          cycle_time = current_time - start_time;
199
200
          total_slow_time = total_slow_time + cycle_time;
201
202
       }
203 }
204
206
207 /* Display statistics at periodic intervals */
208
209 void print_stats (ULONG invalue)
210 {
211
       ULONG
               current_time, avg_slow_time, avg_speedy_time;
212
213
       if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
214
       {
215
          current_time = tx_time_get();
216
          avg_slow_time = total_slow_time / Slow_Thread_counter;
217
          avq_speedy_time = total_speedy_time / Speedy_Thread_counter;
218
219
          printf("\n**** Timing Info Summary\n\n");
220
          printf("Current Time:
                                             %lu\n", current_time);
221
          printf(" Speedy_Thread counter: %lu\n", Speedy_Thread_counter);
222
          printf(" Speedy_Thread avg time: %lu\n", avg_speedy_time);
223
          printf("
                     Slow_Thread counter: %lu\n", Slow_Thread_counter);
224
          printf("
                    Slow_Thread avg time: %lu\n\n", avg_slow_time);
225
226
       else printf("Bypassing print_stats, Time: %lu\n", tx_time_get());
227 }
```

Sample System Using a Counting Semaphore in a Producer-Consumer Application

Counting semaphores are used primarily for mutual exclusion, event notification, or synchronization. We used a counting semaphore for mutual exclusion in the previous sample system; we will use a counting semaphore for event notification in this system. We will modify the previous system to achieve this purpose by creating a *producer-consumer* application. The *speedy_thread* will act as the producer and the *slow_thread* will act as the consumer. The *speedy_thread* will place instances in the counting semaphore (i.e., increment the semaphore count) and the *slow_thread* will wait for an instance in the semaphore and then take it (i.e., decrement the semaphore count). The counting semaphore simulates a storage facility, as illustrated by Figure 134. In this case, the facility just stores instances of the semaphore. In other applications, it could store data bytes, Internet packets, or practically anything. The application logic to use the semaphores remains the same regardless of what is stored.



Figure 134. Producer-consumer system

Figure 135 contains a modification of the activities for the *speedy_thread*, which serves as the producer in this system. The producer thread contains no critical sections. We will use the same activity times as the previous system.




Figure 135. Activities of the producer (Speedy_Thread) where priority = 5

Figure 136 contains a modification of the activities for the *slow_thread*, which serves as the consumer in this system. The consumer thread contains no critical sections and we will use the same activity times as the previous system.




Figure 136. Activities of the consumer (Slow_Thread) where priority = 15

If the consumer attempts to get an instance from the counting semaphore and no instances are available, then the consumer waits (suspends) until an instance becomes available.

This system provides a good example of event notification. The producer communicates with the consumer via the counting semaphore. The producer creates an event notification by placing an instance in the counting semaphore. The consumer, in effect, waits until this event notification is issued before getting an instance from the counting semaphore.

Following is a portion of the sample output that we would expect to be displayed from the producer-consumer system.

Producer-Consumer System—Timing Summary	
Current Time:	500
speedy_thread counter:	35
speedy_thread avg time:	14
slow_thread counter:	12
slow_thread avg time:	40
Producer-Consumer System–Timing Summary	
Current Time:	1000
speedy_thread counter:	71
speedy_thread avg time:	14
slow_thread counter:	24
slow_thread avg time:	40

We will use the same application timer and expiration function as the previous system. We will modify that system so that the *speedy_thread* becomes the producer and the *slow_thread* becomes the consumer, as illustrated by Figure 135 and Figure 136.

The first change occurs in the application definition section of our program, where the binary semaphore is changed to a counting semaphore. Figure 137 shows this change.

```
/* Create the counting semaphore used by both threads */
tx_semaphore_create(&my_semaphore, "my_semaphore", 0);
```

Figure 137. Creating Counting semaphore for producer-consumer system

Changing the initial value of the semaphore from 1 to 0 is the only change that appears in the previous figure. This emphasizes the difference between a binary semaphore, which is restricted to the values 1 and 0, and a counting semaphore, which has a count range of 0 to 0xFFFFFFFF, inclusive.

There are no critical sections in the producer-consumer system, so we must remove that protection wherever it occurs, i.e., in Activities 2, 4, 5, and 7. A critical section could be protected with a *get semaphore/put semaphore* pair. However, the producer will use only *put semaphore* operations for Activities 2 and 4. Conversely, the consumer will use only *get semaphore* operations for Activities 5 and 7—neither thread attempts to get and then put the semaphore. Figure 138 contains the necessary changes to Activity 2 of the producer.

```
/* Activity 2: 5 timer-ticks. */
/* Put an instance in the counting semaphore. */
status = tx_semaphore_put (&my_semaphore);
if (status != TX_SUCCESS) break; /* Check status */
tx_thread_sleep(5);
```

Figure 138. Activity 2 of the producer

The producer will always be able to place an instance on the counting semaphore. Activity 4 is similar to Activity 2, so we leave its changes as an exercise for the reader. See the following program listing for the changes to Activity 5 of the consumer.

The consumer must wait for an instance from the counting semaphore if one is not available. Activity 7 is similar to Activity 5, so we leave its changes as an exercise for the reader as well. The next section contains a complete listing of this system.

Listing for 09b_sample_system.c

The sample system named 09b_sample_system.c appears below; line numbers have been added for easy reference..

```
001 /* 09b_sample_system.c
002
003
       Producer-Consumer System
004
005
       Create two threads and one counting semaphore.
006
       Threads cooperate with each other via the semaphore.
       Timer generates statistics at periodic intervals.
007
       Producer (Speedy_Thread) - Consumer (Slow_Thread) */
800
009
010
011 /*******************************
          Declarations, Definitions, and Prototypes
013 /****************************
014
015 #include
              "tx_api.h"
016 #include
               <stdio.h>
017
018 #define
                                  1024
               STACK_SIZE
019
020 /* Declare stacks for both threads. */
021 CHAR stack_speedy[STACK_SIZE];
022 CHAR stack_slow[STACK_SIZE];
023
024 /* Define the Azure RTOS ThreadX object control blocks. */
025 TX THREAD
                           Speedy_Thread;
026 TX_THREAD
                           slow_Thread:
027 TX_SEMAPHORE
                           my_semaphore;
028
029 /* Declare the application timer */
030 TX_TIMER
                           stats_timer;
```

```
031
032 /* Declare the counters and accumulators */
033 ULONG
                 Speedy_Thread_counter = 0,
                 total_speedy_time = 0;
034
035 ULONG
                 Slow_Thread_counter = 0,
036
                 total_slow_time = 0;
037
038 /* Define thread prototypes. */
039 void Speedy_Thread_entry(ULONG thread_input);
040 void
          Slow_Thread_entry(ULONG thread_input);
041
042 /* Define prototype for expiration function */
043 void print_stats(ULONG);
044
045
046 /*******************************
047 /*
                  Main Entry Point
048 /*******************************
049
050 /* Define main entry point. */
051
052 int main()
053 {
054
055 /* Enter the Azure RTOS ThreadX kernel. */
056
     tx_kernel_enter();
057 }
058
059
060 /****************
061 /*
                Application Definitions
062 /******************************
063
064 /* Define what the initial system looks like. */
065
        tx_application_define(void *first_unused_memory)
066 void
067 {
068
   /* Put system definitions here,
069
```

```
070
          e.g., thread, semaphore, and timer creates */
071
072
       /* Create the Speedy_Thread. */
       tx_thread_create(&Speedy_Thread, "Speedy_Thread",
073
                        Speedy_Thread_entry, 0,
074
075
                        stack_speedy, STACK_SIZE,
076
                        5, 5, TX_NO_TIME_SLICE, TX_AUTO_START);
077
078
       /* Create the Slow_Thread */
       tx_thread_create(&Slow_Thread, "Slow_Thread",
079
080
                        Slow_Thread_entry, 1,
081
                        stack_slow, STACK_SIZE,
082
                        15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
083
084
       /* Create the counting semaphore used by both threads */
085
       tx_semaphore_create(&my_semaphore, "my_semaphore", 0);
086
       /* Create and activate the timer */
087
       tx_timer_create (&stats_timer, "stats_timer", print_stats,
880
089
                        0x1234, 500, 500, TX_AUTO_ACTIVATE);
090 }
091
092
093 /***********************************/
094 /*
                    Function Definitions
095 /****************************
096
097 /* Define the activities for the Producer (speedy) thread */
098
099 void
            Speedy_Thread_entry(ULONG thread_input)
100 {
101
102 UINT
            status:
103 ULONG
            start_time, cycle_time, current_time;
104
       while(1)
105
106
       {
107
          /* Get the starting time for this cycle */
          start_time = tx_time_get();
108
```

```
109
          /* Activity 1: 2 timer-ticks. */
110
111
          tx_thread_sleep(2);
112
113
          /* Put an instance in the counting semaphore. */
114
          status = tx_semaphore_put (&my_semaphore);
          if (status != TX_SUCCESS) break; /* Check status */
115
116
117
          /* Activity 2: 5 timer-ticks. */
118
          tx_thread_sleep(5);
119
120
          /* Activity 3: 4 timer-ticks. */
          tx_thread_sleep(4);
121
122
123
          /* Put an instance in the counting semaphore. */
124
          status = tx_semaphore_put (&my_semaphore);
125
          if (status != TX_SUCCESS) break; /* Check status */
126
127
            /* Activity 4: 3 timer-ticks. */
128
            tx_thread_sleep(3);
129
130
            /* Increment the thread counter and get timing info */
131
            Speedy_Thread_counter++;
132
133
            current_time = tx_time_get();
134
            cycle_time = current_time - start_time;
            total_speedy_time = total_speedy_time + cycle_time;
135
        }
136
137 }
138
139 /***********************************/
140
141 /* Define the activities for the Consumer (Slow) thread. */
142
143 void
            Slow_Thread_entry(ULONG thread_input)
144 {
145
146 UINT
            status;
            start_time, current_time, cycle_time;
147 ULONG
```

```
148
149
       while(1)
150
       {
151
          /* Get the starting time for this cycle */
152
          start_time = tx_time_get();
153
154
          /* Activity 5 - get an instance of the counting semaphore
155
             with suspension and hold it for 12 timer-ticks. */
156
157
          status = tx_semaphore_get (&my_semaphore, TX_WAIT_FOREVER);
158
          if (status != TX_SUCCESS) break; /* Check status */
159
160
          tx_thread_sleep(12);
161
162
          /* Activity 6: 8 timer-ticks. */
163
          tx_thread_sleep(8);
164
165
          /* Activity 7: get an instance of the counting semaphore
166
167
             with suspension and hold it for 11 timer-ticks. */
168
169
          status = tx_semaphore_get (&my_semaphore, TX_WAIT_FOREVER);
170
171
          if (status != TX_SUCCESS) break; /* Check status */
172
173
174
          tx_thread_sleep(11);
175
176
          /* Activity 8: 9 timer-ticks. */
          tx_thread_sleep(9);
177
178
179
          /* Increment the thread counter and get timing info */
          Slow_Thread_counter++;
180
181
182
          current_time = tx_time_get();
183
          cycle_time = current_time - start_time;
184
          total_slow_time = total_slow_time + cycle_time;
185
        }
186 }
```

```
187
189
190 /* Display statistics at periodic intervals */
191
192 void print_stats (ULONG invalue)
193 {
194
       ULONG
              current_time, avg_slow_time, avg_speedy_time;
195
196
       if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
197
198
          current_time = tx_time_get();
          avg_slow_time = total_slow_time / Slow_Thread_counter;
199
200
          avg_speedy_time = total_speedy_time / Speedy_Thread_counter;
201
202
          printf("\nProducer-Consumer System - Timing Summary\n");
203
          printf("
                      Current Time:
                                                      %lu\n",
204
                current_time);
          printf("
205
                          Speedy_Thread counter:
                                                      %lu\n'',
206
                Speedy_Thread_counter);
                         Speedy_Thread avg time:
207
          printf("
                                                      %lu\n'',
208
                avg_speedy_time);
209
          printf("
                            Slow_Thread counter:
                                                      %lu\n",
210
                Slow_Thread_counter);
211
          printf("
                           Slow_Thread avg time:
                                                      %lu\n\n'',
212
                avg_slow_time);
213
       else printf("Bypassing print_stats function, Current Time:
214 %lu\n",
                  tx_time_get());
215
216 }
```

Counting Semaphore Internals

When the TX_SEMAPHORE data type is used to declare a counting semaphore, a Semaphore Control Block (SCB) is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 139.




Figure 139. Created counting semaphore list

The pointer named tx_semaphore_created_ptr points to the first Control Block in the list. See the fields in the SCB for timer attributes, values, and other pointers.

Overview

Both counting semaphores and mutexes can be used to provide mutual exclusion. However, mutexes should be used *only* for mutual exclusion, while counting semaphores are more versatile because they can also be used for event notification and thread synchronization.

A mutex is exceptionally robust in providing mutual exclusion. If this is crucial to your application, then using a mutex is a good decision. However, if mutual exclusion is not a major factor in your application, then use a counting semaphore because it is slightly faster and uses fewer system resources.

A special case of the counting semaphore is the binary semaphore, which has count values restricted to zero and one. If you want to use a counting semaphore for mutual exclusion, then you must use a binary semaphore.

Incrementing a semaphore's count is equivalent to placing an instance in the counting semaphore. Decrementing the count value corresponds to getting an instance from the counting semaphore.

There is no concept of ownership of counting semaphores as there is for mutexes. The producer-consumer system presented in this chapter illustrates this difference. speedy_thread placed instances in the semaphore without gaining ownership; slow_thread took instances from the semaphore whenever they were available, also without first gaining ownership. Furthermore, the priority inheritance feature is not available for

counting semaphores as it is for mutexes. For a comparison of mutexes and counting semaphores, as well as recommended uses for each, refer to Figure 129 earlier in the chapter.

Key Terms and Phrases

binary semaphore instance

Control Block mutual exclusion counting semaphore place an instance creating a semaphore priority inversion

current count producer-consumer system

deadlock put operation

deadly embrace retrieve an instance

decrement count semaphore

deleting a semaphore semaphore ceiling

event notification semaphore information retrieval

FIFO order suspend on semaphore

get operation suspension list increment count synchronization

Problems

- 1. Describe a scenario in which you would use a binary semaphore rather than a mutex.
- Assume that you have a common resource that can be shared by no more than
 three threads. Describe how you would use a counting semaphore to handle this
 situation.
- 3. Discuss why the count of a binary semaphore is usually initialized to one when it is created.
- 4. Describe how you would modify the producer-consumer system discussed in this chapter so that the current count of the semaphore would be displayed by the print_stats expiration function.
- 5. What would happen if a thread placed an instance in a counting semaphore where the current count equaled 0xFFFFFFF?

- 6. Describe what you would do to stop a thread from placing an instance in a counting semaphore that had a current count equal to 0xFFFFFFF.
- 7. What would happen if the tx_semaphore_prioritize service was invoked, but no thread was in a suspended state?
- Assume that my_semaphore has been declared as a counting semaphore.
 Describe two possible outcomes of invoking the following: tx_semaphore_get (&my_semaphore, 5);
 (Hint: Check Appendix G.

Chapter 10

Synchronization of Threads Using Event Flags Groups

Introduction

Event flags provide a powerful tool for thread synchronization. Event flags can be set or cleared⁴⁷ by any thread and can be inspected by any thread. Threads can suspend while waiting for some combination of event flags to be set. Each event flag is represented by a single bit. Event flags are arranged in groups of 32 as illustrated by Figure 140.




Figure 140. An event flags group

Threads can operate on all 32 event flags in a group simultaneously. To set or clear event flags, you use the tx_event_flags_set service and you "get" them (wait on them) with the tx_event_flags_get service.

Setting or clearing event flags is performed with a logical AND or OR operation between the current event flags and the new event flags. The user specifies the type of logical operation (either AND or OR) in the call to the tx_event_flags_set service.

There are similar logical options for getting event flags. A get request can specify that all specified event flags are required (a logical AND). Alternatively, a get request can

⁴⁷ We set a flag by storing the value 1 in that flag and we clear a flag by storing the value 0 in that flag.

specify that any of the specified event flags will satisfy the request (a logical OR). The user specifies the type of logical operation in the tx_event_flags_get call.

Event flags that satisfy a get request are cleared if the request specifies either of the options TX_OR_CLEAR or TX_AND_CLEAR. The flag values remain unchanged when you use the TX_AND or TX_OR options in a get request.

Each event flags group is a public resource. Azure RTOS ThreadX imposes no constraints as to how an event flags group can be used.

An application can create event flags groups either during initialization or during runtime. At the time of their creation, all event flags in the group are initialized to zero. There is no limit to the number of event flags groups an application may use.

Application threads can suspend while attempting to get any logical combination of event flags from a group. Immediately after one or more flags of a group have been set, Azure RTOS ThreadX reviews the get requests of all threads suspended on that event flags group.⁴⁸ All the threads whose get requests were satisfied by the set operation are resumed.

As noted above, when at least one flag of a group has been set, Azure RTOS ThreadX reviews all the threads suspended on that group. This review process creates overhead, so try to limit the number of threads using the same group to a reasonable number.

Field	Description
tx_event_flags_id	Event Flags Group ID
tx_event_flags_name	Pointer to event flags group name
tx_event_flags_current	Actual current event flags in this group
T TY EVENT HANG TEGET GEATCH	Reset search flag set when ISR sets flags during search of suspended threads list
tx_event_flags_suspension_list	Pointer to event flags group suspension list
tx_event_flags_suspended_count	Number of threads suspended for event flags group
tx_event_flags_created_next	Pointer to next event flags group in the created list
tx_event_flags_created_previous	Pointer to previous event flags group in created list

⁴⁸ More precisely, if the TX_OR option is used with the tx_event_flags_set service, then a review of the suspension list will occur. If the TX_AND option is used, no such review will be performed. See the section on setting flags for more information.

Figure 141. Event Flags Group Control Block

Event Flags Group Control Block

The characteristics of each event flags group are found in its Control Block. It contains information such as the values of current event flags, the reset search flag, the pointer to the suspension list for this event flags group, and the number of threads suspended for this group. ⁴⁹ Figure 141 contains many of the fields that comprise this Control Block.

An Event Flags Group Control Block (ECB) can be located anywhere in memory, but it is common to make the Control Block a global structure by defining it outside the scope of any function. An ECB is created when an event flags group is declared with the TX_EVENT_FLAGS data type. For example, we declare my_event_group as follows:

TX_EVENT_FLAGS_GROUP my_event_group;

Event Flags Group Service

The declaration of event flags groups normally appears in the declaration and definition section of the program.

Summary of Event Flags Group Control Services

Appendix C contains detailed information about event flags group services. This appendix contains information about each service, such as the prototype, a brief description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used.

Event i lags Group Service	Description
tx_event_flags_create	Create an event flags group
tx_event_flags_delete	Delete an event flags group
tx_event_flags_get	Get event flags from an event flags group
tx_event_flags_info_get	Retrieve information about an event flags group
tx_event_flags_set	Set event flags in an event flags group

Description

 $^{^{49}}$ The structure of the Event Flags Group Control Block is defined in the \mathbf{tx} _api.h file.

Figure 142. Services of the event flags group

Figure 142 contains a list of all available services for an event flags group. We will investigate each of these services in the subsequent sections of this chapter.

Creating an Event Flags Group

An event flags group is declared with the TX_EVENT_FLAGS_GROUP data type and is defined with the tx_event_flags_create service. When defining an event flags group, you must specify its Control Block and the name of the event flags group. When created, all the event flags of a group are initialized to zero. Figure 143 lists the attributes of an event flags group.




Figure 143. Attributes of an event flags group

Figure 144 illustrates how to use this service to create an event flags group. We will give our event flags group the name "my_event_group." If the variable *status* contains the return value TX_SUCCESS, we have successfully created an event flags group.

Figure 144. Creating an event flags group

Deleting an Event Flags Group

The tx_event_flags_delete service deletes an event flags group. When a group is deleted, all threads suspended on it resume and receive a TX_DELETED return status. Make certain that you do not attempt to use an event flags group that has been deleted. Figure 145 shows how to delete an event flags group.

If variable *status* contains the return value TX_SUCCESS, we have successfully deleted the event flags group.

```
TX_EVENT_FLAGS_GROUP my_event_group;
UINT status;
...
/* Delete event flags group. Assume that the group has already been created with a call to
    tx_event_flags_create. */
status = tx_event_flags_delete(&my_event_group);
/* If status equals TX_SUCCESS, the event flags group has been deleted. */
```

Figure 145. Deleting an event flags group

Getting Event Flags from an Event Flags Group

The tx_event_flags_get service "gets," or waits on event flags from an event flags group. A get request is *satisfied* if the requested flags have been set in the specified event flags group. The *wait_option* determines what action will be taken if the get request is not satisfied. The process of satisfying a get request depends on the *get_option*, which is a logical AND or OR operation, as depicted in Figure 146.

Get Option	Description
TX_AND	All requested event flags must be set in the specified event flags group
TX_AND_CLEAR	All requested event flags must be set in the specified event flags group; event flags that satisfy the request are cleared
TX_OR	At least one requested event flag must be set in the specified event flags group
TX_OR_CLEAR	At least one requested event flag must be set in the specified event flags group; event flags that satisfy the request are cleared

Figure 146. Options to satisfy a get request

For example, assume that we want to determine whether event flags 0, 4, and 8 are all set. Furthermore, if those flags are all set, then we want them all cleared. Figure 147 illustrates an event flags group with flags 0, 4, and 8 set.




Figure 147. Example of an event flags group where flags 0, 4, and 8 are set

This corresponds to a hexadecimal value of 0x111, which we will use in our sample get operation. If all the desired event flags are not set when the request is made, then we will specify a maximum wait of 20 timer-ticks for them to become set. We will use the tx_event_flags_get service in Figure 148 in an attempt to determine whether event flags 0, 4, and 8 are all set.

If return variable *status* equals TX_SUCCESS, then event flags 0, 4, and 8 were found in a set state, and those flags were subsequently cleared. The variable *actual_events* contains the state of those flags as found before they were cleared, as well as the state of the remaining flags from the event flags group.

Figure 148. Getting event flags from an event flags group

Suppose that the value of the event flags group is 0x537, as represented in Figure 149 and the tx_event_flags_get service in Figure 148 is invoked.




Figure 149. Event flags group with a value of 0x537

After calling this service, the get operation is satisfied and the new value of the event flags group is 0x426, as illustrated in Figure 150.




Figure 150. Event flags group with a value of 0x426

The variable *actual_events* now contains 0x537, which is the original value of the event flags group. By contrast, if the *get_option* was TX_AND (rather than TX_AND_CLEAR), the get operation would have also been satisfied and the event flags group would have remained unchanged with the value 0x537. In this case, the variable *actual_events* would have also contained the value 0x537 after the service returned.

The previous example uses the TX_AND and the TX_AND_CLEAR *get_options*. We will consider another example that illustrates the effect of the TX_OR and the TX_OR_CLEAR *get_options*. Assume that we want to determine whether at least one of the event flags 0, 5, and 10 is set. Furthermore, we will clear all those flags that are set. Figure 151 illustrates an event flags group with flags 0, 5, and 10 set.




Figure 151. Event Flags group with flags 0, 5, and 10 set

This corresponds to a hexadecimal value of 0x421, which we will use in our get operation. If none of the event flags are set when we make the get request, then we will wait indefinitely for at least one of them to become set. Assume that the value of the event flags group is 0x537. We will use the TX_OR get_option with the tx_event_

186

flags_get service in Figure 152 to determine whether one or more of event flags 0, 5, and 10 is set.

Figure 152. Getting event flags from an event flags group

If return variable *status* equals TX_SUCCESS, at least one of event flags 0, 5, and 10 was set and the value of the event flags group remains unchanged. The variable *actual_events* contains the value 0x537, which is the original value of the event flags group.

Suppose that the value of the event flags group is 0xFF0C, as represented in Figure 153 and the tx_event_flags_get service in Figure 152 is invoked.




Figure 153. Event flags group with value 0xFF0C

After calling this service, the get operation is satisfied because flag 10 is set. The value of the event flags group remains unchanged, and the variable *actual_events* contains a copy of this value. However, if we used the TX_OR_CLEAR *get_option* then the event flags group would change to a value of 0xFB0C, as represented in Figure 154. (Flag 10 would be cleared by the get operation.)

0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	1	0	1	1	0	0	0	0	1	1	0	0	
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	--

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0 Figure 154. Event Flags group with value 0xFB0C

The return variable *actual_events* would contain 0xFF0C, which was the original value of the event flags group.

Sample System Using an Event Flags Group to Synchronize Two Threads

We used counting semaphores for mutual exclusion and for event notification in the two previous sample systems. In this sample system, we will focus on synchronizing thread behavior by using an event flags group. An event flags group provides a powerful means of communication between threads because it consists of 32 one-bit flags, thus providing an extensive number of flag combinations. We will modify the previous sample system and replace all references to a counting semaphore with references to an event flags group.

We will restrict our attention to two flag values that will be used by *speedy_thread* and *slow_thread* to communicate with each other. There are no critical sections in this sample system. The threads synchronize their activities with the event flags group. The two event flag values we will use are 0xF0, which we will call *speedy_flags*, and 0x0F, which we will call *slow_flags*. Note that when *speedy_thread* enters Activity 2 or Activity 4, it tries to get slow_flags. If it is successful, it clears those flags, sets speedy_ flags, and continues processing.

Note that when *slow_thread* enters Activity 5 or Activity 7, it tries to get speedy_flags. If it is successful, it clears those flags, sets slow_flags, and continues processing.

Following is a portion of the output produced by this sample system.

Event Flags Group synchronizes 2 threads

Current Time: 500

speedy_thread counter: 13

speedy_thread avg time: 37

slow_thread counter: 12

⁵⁰ Note that speedy_flags and slow_flags each represent 4 requested event flags from a set of 32 possible flags. We use these constants to illustrate the use of TX_AND and TX_OR operations.

slow_thread avg time:	40
Event Flags Group synchronizes 2 threads	
Current Time:	1000
speedy_thread counter:	25
speedy_thread avg time:	38
slow_thread counter:	24
slow_thread avg time:	40

Note that *speedy_thread* and *slow_thread* each complete about the same number of cycles, even though *speedy_thread* has a higher priority. In this sample system, the event flags group serves as a toggle switch and ensures that the threads take an equal number of turns processing.

We will discuss a series of changes to be applied to the system from Chapter 8 so that all references to a binary semaphore will be replaced with references to an event flags group. The complete program listing, called 10_sample_system.c, is located in the next section of this chapter.

The first change occurs in the declaration and definitions section of our program, in which we replace the declaration of a counting semaphore with the declaration of an event flags group, as follows.

```
TX EVENT FLAGS GROUP my event group;
```

We also declare and initialize the variables *speedy_flags*, *slow_flags*, and *actual_flags* as follows:

```
ULONG      speedy_flags = 0xF0,
      slow_flags = 0x0F
      actual events;
```

We will use the variable *actual_flags* for our get operations. The next change occurs in the application definitions section of our program, in which we replace the creation of a binary semaphore with the creation and initialization of an event flags group, as follows.

```
/* Create the event flags group used by both threads, initialize to
    slow_flags (OXOF). */
tx_event_flags_create (&my_event_group, "my_event_group");
tx event flags set (&my event group, slow flags, TX OR);
```

We arbitrarily set the event flags group to the value <code>slow_flags</code> in the preceding statement. The only consequence of this particular initialization is that <code>speedy_thread</code> will be the first thread to execute. We could have set the event flags group to the value <code>speedy_flags</code>, thereby giving <code>slow_thread</code> the first opportunity to execute.

The remaining changes occur in the function definitions section of our program. We need to change all references to a binary semaphore with references to an event flags group. We will show only the changes for the *speedy_thread* and will leave the *slow_thread* changes as an exercise for the reader. The following program listing contains the necessary changes for Activity 2.

The following program listing contains Exsssssthe necessary changes for Activity 4. Most of the modifications involve changing binary semaphore calls to event flags group calls.

Retrieving Information about an Event Flags Group

There are three services that enable you to retrieve vital information about event flags groups. The first such service for event flags groups—the tx_event_flags_info_get service—retrieves a subset of information from the Event Flags Group Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the tx_event_flags_performance_info_get service—provides an information summary for a particular event flags group up to the time the service is invoked. By contrast the tx_event_flags_performance_system_info_get retrieves an information summary for all event flags groups in the system up to the time the service is invoked. These services are useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_event_flags_info_get51 service retrieves several useful items of information about an event flags group. This information includes the name of the event flags group,

⁵¹ By default, only the *tx_event_flags_info_get* service is enabled. The other two information gathering services must be enabled in order to use them.

the current value of the event flags, the number of threads suspended for this group, and a pointer to the next created event flags group. Figure 155 shows how this service can be used to obtain information about an event flags group.

Figure 155. Retrieving information about an event flags group

If return variable *status* contains the value TX_SUCCESS, we have successfully retrieved information about the event flags group.

Setting Event Flags in an Event Flags Group

The tx_event_flags_set service sets or clears one or more event flags in a group. When the set service is performed and actually sets one or more of the flags, the Azure RTOS ThreadX scheduler checks whether there are any threads suspended for that event flags group. If there are other threads suspended for the resulting value of this group, then those threads are resumed.

The process of setting or clearing event flags depends on the *set_option*, which is a logical AND or OR operation, as depicted in Figure 156.

Set Option	Description
TX_AND	The specified event flags are ANDed into the current event flags group; this option is often used to clear event flags in a group

TX_OR	The specified event flags are ORed with the current event flags group ⁵²
-------	---

Figure 156. Set options

For example, suppose that we want to clear all flags except flags 0, 4, and 8, in which the current values of the event flags group is 0xFF0C. We would pass the value 0x111 (i.e., event flags 0, 4, and 8) and use the TX_AND option. Figure 157 illustrates this operation.

Current Event Flags Group	Value:	0xFF0C
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0 0	1 1 0 0
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7	6 5 4	3 2 1 0
Flags to Set	Value:	0x111
$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	0 0 1	0 0 0 1
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7	6 5 4	3 2 1 0



New Current Event Flags Group																				V	alι	ıe:		0x1	100						
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	Q	8	7	6	5	4	3	2	1	0

Figure 157. Clearing flags with the TX_AND option

The new value of the event flags group is 0x100 because flag 8 is the only flag in common for the values 0xFF0C and 0x111. However, if the TX_OR option is used, then the new event flags group value is 0xFF1D, as illustrated in Figure 158.

⁵² The TX_OR option forces the scheduler to review the suspension list to determine whether any threads are suspended for this event flags group.

Current I	Current Event Flags Group															٧	alι	ıe:	C	0xFF0C								
0 0 0 0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0															0	0	0	0	1	1	0	0					
31 30 29 2	8 27	26 2	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Flags to	Flags to Set															٧	alu	ıe:	e: 0x111									
0 0 0 0	0 0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	1								
31 30 29 2	8 27	26.1	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	Q	R	7	6	5	4	3	2	1	0



Ν	New Current Event Flags Group Value: 000000000000000000000000000000000000															C	0xFF1D														
C	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1	0	0	0	1	1	1	0	1
3	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

Figure 158. Setting flags with the TX_OR option

Figure 159 illustrates how the tx_event_flags_set service can be used to set the value 0x111 with the TX_OR option.

```
TX_EVENT_FLAGS_GROUP my_event_group;
UINT status;

/* Set event flags 0, 4, and 8. */
...
status = tx_event_flags_set(&my_event_group, 0x111, TX_OR);

/* If status equals TX_SUCCESS, the event flags have been set and any suspended thread whose request was satisfied has been resumed. */
```

Figure 159. Set event flags in an event flags group

If return variable *status* contains the value of TX_SUCCESS, the requested event flags have been set. Any threads that were suspended on these event flags have been resumed.

Event Flags Group Notification and Event-Chaining

The tx_event_flags_set_notify service registers a notification callback function that is invoked whenever one or more event flags are set in the specified event flags group. The processing of the notification callback is defined by the application. This is an example of event-chaining where notification services are used to chain various synchronization events together. This is typically useful when a single thread must process multiple synchronization events.

Listing for 10_sample_system.c

The sample system named 10_sample_system.c appears below; line numbers have been added for easy reference.

```
001 /* 10_sample_system.c
002
003
      Create two threads and one event flags group.
      The threads synchronize their behavior via the
004
      event flags group. */
005
006
007
008 /*****************************
009 /*
         Declarations, Definitions, and Prototypes
010 /******************
011
              "tx_api.h"
012 #include
013 #include
              <stdio.h>
014
015 #define
                                1024
               STACK_SIZE
016
017 /* Declare stacks for both threads. */
018 CHAR stack_speedy[STACK_SIZE];
019 CHAR stack_slow[STACK_SIZE];
020
021 /* Define the Azure RTOS ThreadX object control blocks. */
                          Speedy_Thread;
022 TX_THREAD
023 TX_THREAD
                          Slow_Thread;
024 TX_EVENT_FLAGS_GROUP
                          my_event_group;
025
```

```
026 /* Declare the application timer */
                          stats_timer:
027 TX_TIMER
028
029 /* Declare the counters, accumulators, and flags */
                   Speedy_Thread_counter = 0,
030 ULONG
031
                   total_speedy_time = 0;
                   Slow_Thread_counter = 0,
032 ULONG
033
                   total_slow_time = 0;
034 ULONG
                   slow_flags = 0x0f,
035
                   speedy_flags = 0xF0,
036
                   actual_events;
037
038 /* Define thread prototypes. */
           Speedy_Thread_entry(ULONG thread_input);
039 void
040 void
           Slow_Thread_entry(ULONG thread_input);
041
042 /* Define prototype for expiration function */
043 void
           print_stats(ULONG);
044
045
046 /******************************
047 /*
                   Main Entry Point
048 /******************************
049
050 /* Define main entry point. */
051
052 int main()
053 {
054
       /* Enter the Azure RTOS ThreadX kernel. */
055
       tx_kernel_enter();
056 }
057
058
059 /******************************/
060 /*
                  Application Definitions
061 /****************************
062
063 /* Define what the initial system looks like. */
064
```

```
065 void
            tx_application_define(void *first_unused_memory)
066 {
067
       /* Put system definitions here,
068
          e.g., thread and event flags group creates */
069
070
       /* Create the Speedy_Thread. */
071
       tx_thread_create(&Speedy_Thread, "Speedy_Thread",
072
                        Speedy_Thread_entry, 0,
073
                        stack_speedy, STACK_SIZE,
074
                        5, 5, TX_NO_TIME_SLICE, TX_AUTO_START);
075
076
       /* Create the Slow_Thread */
       tx_thread_create(&Slow_Thread, "Slow_Thread",
077
078
                        Slow_Thread_entry, 1,
079
                        stack_slow, STACK_SIZE,
080
                        15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
081
       /* Create the event flags group used by both threads,
082
          initialize to slow_flags (0X0F). */
083
       tx_event_flags_create (&my_event_group, "my_event_group");
084
       tx_event_flags_set (&my_event_group, slow_flags, TX_OR);
085
086
087
       /* Create and activate the timer */
       tx_timer_create (&stats_timer, "stats_timer", print_stats,
880
                        0x1234, 500, 500, TX_AUTO_ACTIVATE);
089
090
091 }
092
093
094 /******************************
095 /*
                    Function Definitions
096 /******************************/
097
098 /* "Speedy_Thread" - it has a higher priority than the other thread */
099
100 void
            Speedy_Thread_entry(ULONG thread_input)
101 {
102
103 UINT
            status;
```

```
104 ULONG
            start_time, cycle_time, current_time;
105
106
       while(1)
107
108
          /* Get the starting time for this cycle */
109
          start_time = tx_time_get();
110
111
          /* Activity 1: 2 timer-ticks. */
112
          tx_thread_sleep(2);
113
114
          /* Activity 2 - Wait for slow_flags in the event flags group, set it
115
             to speedy_flags, and hold it for 5 timer-ticks. */
116
117
          status = tx_event_flags_get (&my_event_group, slow_flags, TX_AND_CLEAR,
118
                                        &actual_events, TX_WAIT_FOREVER);
119
          if (status != TX_SUCCESS) break;
                                              /* Check status. */
120
121
          status = tx_event_flags_set (&my_event_group, speedy_flags, TX_OR);
122
          if (status != TX_SUCCESS) break; /* Check status. */
123
124
          tx_thread_sleep(5);
125
126
          /* Activity 3: 4 timer-ticks. */
127
          tx_thread_sleep(4);
128
129
          /* Activity 4 - Wait for slow_flags in the event flags group, set it
130
             to speedy_flags, and hold it for 3 timer-ticks. */
131
132
          status = tx_event_flags_get (&my_event_group, slow_flags, TX_AND_CLEAR,
133
                                        &actual_events, TX_WAIT_FOREVER);
134
135
          if (status != TX_SUCCESS) break;
                                              /* Check status. */
136
137
          status = tx_event_flags_set (&my_event_group, speedy_flags, TX_OR);
          if (status != TX_SUCCESS) break; /* Check status. */
138
139
140
           tx_thread_sleep(3);
141
142
           /* Increment the thread counter and get timing info */
```

```
Speedy_Thread_counter++;
143
144
145
           current_time = tx_time_get();
           cycle_time = current_time - start_time;
146
           total_speedy_time = total_speedy_time + cycle_time;
147
148
149
       }
150 }
151
153 /* "Slow_Thread" - it has a lower priority than the other thread */
154
155 void
           Slow_Thread_entry(ULONG thread_input)
156 {
157
158 UINT
           status;
159 ULONG
           start_time, current_time, cycle_time;
160
161
       while(1)
162
       {
         /* Get the starting time for this cycle */
163
         start_time = tx_time_get();
164
165
166
         /* Activity 5 - Wait for speedy_flags in the event flags group,
167
             set it to slow_flags, and hold it for 12 timer-ticks. */
168
          status = tx_event_flags_get (&my_event_group, speedy_flags,
                         TX_AND_CLEAR, &actual_events, TX_WAIT_FOREVER);
169
170
171
         if (status != TX_SUCCESS) break;
                                           /* Check status. */
172
173
          status = tx_event_flags_set (&my_event_group, slow_flags, TX_OR);
174
         if (status != TX_SUCCESS) break; /* Check status. */
175
176
         tx_thread_sleep(12);
177
178
          /* Activity 6: 8 timer-ticks. */
179
         tx_thread_sleep(8);
180
         /* Activity 7: Wait for speedy_flags in the event flags group,
181
```

```
182
              set it to slow_flags, and hold it for 11 timer-ticks. */
183
184
          status = tx_event_flags_get (&my_event_group, speedy_flags,
185
                        TX_AND_CLEAR, &actual_events, TX_WAIT_FOREVER);
186
187
          if (status != TX_SUCCESS) break; /* Check status. */
188
189
          status = tx_event_flags_set (&my_event_group, slow_flags, TX_OR);
190
191
          tx_thread_sleep(11);
192
193
          /* Activity 8: 9 timer-ticks. */
          tx_thread_sleep(9);
194
195
196
          /* Increment the thread counter and get timing info */
197
          Slow_Thread_counter++;
198
199
          current_time = tx_time_get();
200
          cycle_time = current_time - start_time;
          total_slow_time = total_slow_time + cycle_time;
201
202
203
       }
204 }
205
206 /***********************************/
207 /* print statistics at specified times */
208 void print_stats (ULONG invalue)
209 {
210
               current_time, avg_slow_time, avg_speedy_time;
       ULONG
211
212
       if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
213
       {
214
          current_time = tx_time_get();
215
          avg_slow_time = total_slow_time / Slow_Thread_counter;
216
          avg_speedy_time = total_speedy_time / Speedy_Thread_counter;
217
218
          printf("\nEvent Flags Group synchronizes 2 threads\n");
219
          printf("
                       Current Time:
                                                        %lu\n",
220
                 current_time);
```

```
printf("
221
                             Speedy_Thread counter:
                                                           %lu\n",
222
                  Speedy_Thread_counter);
223
           printf("
                            Speedy_Thread avg time:
                                                           %lu\n",
224
                  avg_speedy_time);
225
           printf("
                               Slow_Thread counter:
                                                           %lu\n",
226
                  Slow_Thread_counter);
227
           printf("
                              Slow_Thread avg time:
                                                           %lu\n\n'',
228
                  avg_slow_time);
229
       }
230
           else printf("Bypassing print_stats function, Current Time: %lu\n",
231
                         tx_time_get());
232 }
```

Event Flags Group Internals

When the TX_EVENT_FLAGS data type is used to declare an event flags group, an ECB is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 160.




Figure 160. Created event flags group list

When flags become set in an event flags group, Azure RTOS ThreadX immediately reviews all threads that are suspended on that event flags group. This introduces some overhead, so limit the number of threads using the same event flags group to a reasonable number.

Overview

Event flags provide a powerful tool for thread synchronization. Event flags groups do not support a concept of ownership, nor is there a limit to how many threads can access an event flags group.

Event flags can be set by any thread and can be inspected by any thread.

Threads can suspend while waiting for some combination of event flags to be set.

Threads can operate on all 32 event flags in a group simultaneously. Threads can set or clear event flags using the tx_event_flags_set service and get them (wait on them) by using the tx_event_flags_get service.

The clearing or setting of event flags entails a logical TX_AND or TX_OR operation between the current event flags and the new event flags. There are similar logical options for getting event flags. A get request can specify that all specified event flags are required (a logical TX_AND). Alternatively, a get request can specify that any of the specified event flags will satisfy the request (a logical TX_OR).

Event flags that satisfy a get request are cleared if either of the *clear options* TX_OR_CLEAR or TX_AND_CLEAR are specified by the request. The event flag values remain unchanged when the TX_AND or TX_OR options are used in a get request.

Application threads can suspend while attempting to get any logical combination of event flags from a group. When at least one event flag becomes set, the get requests of all threads suspended on that event flags group are reviewed. All the threads whose get requests are now satisfied are resumed.

As noted above, when at least one flag of a group becomes set, Azure RTOS ThreadX reviews all the threads suspended on that group. This review process creates overhead, so try to limit the number of threads using the same event flags group to a reasonable number.

Key Terms and Phrases

clearing event flags
creating an event flags group
deleting an event flags group
event flags group
Event Flags Group Control Block (ECB)
flag
get option
get request

initialization of event flags logical operations retrieval of event flags satisfying a get request set option setting event flags suspension of threads synchronization of threads wait option

Problems

- Compare mutexes, counting semaphores, and event flags groups. Describe three
 different scenarios in which using each object is better suited than using the other
 two objects.
- 2. Describe how you would determine how many threads are suspended for a certain event flags group.
- 3. Describe how you would determine the current value of an event flags group.
- 4. Suppose that you want to synchronize the operation of three threads. Describe how you would use an event flags group so that the threads are processed in a specific order, i.e., so that your application processes the first thread, the second thread, and then the third thread. (This process order is to repeat indefinitely.)
- 5. Suppose that you want to synchronize the operation of three threads. Describe how you would use an event flags group so that, at most, two of the threads can be processed at any time, but the third thread depends on one of the other two threads before it can execute.
- 6. Suppose that an event flags group contains one of the values 0x110, 0x101, or 0x011. Describe how you would perform a get operation that would be satisfied for any one of these values.
- 7. If an event flags group had the value 0xFDB, what successful get operation could have caused the value of this group to change to 0xBDA?
- 8. If an event flags group had the value 0xF4C, what successful set operation could have cause the value of this group to change to 0x148?

Chapter 11

Thread Communication with Message

Queues

Introduction

Message queues are the primary means of interthread communication in Azure RTOS ThreadX. One or more messages can reside in a message queue, which generally observes a FIFO discipline. A message queue that can hold just a single message is commonly called a *mailbox*.

The tx_queue_send service places messages in the rear of a queue and the tx_queue_receive service removes messages from the front of a queue. The only exception to this protocol occurs when a thread is suspended while waiting for a message from an empty queue. In this case, Azure RTOS ThreadX places the next message sent to the queue directly into the thread's destination area, thus bypassing the queue altogether. Figure 161 illustrates a message queue.

messages inserted at rear of queue

messages removed from front of queue



Figure 161. A message queue

Each message queue is a public resource. Azure RTOS ThreadX places no constraints on how message queues are used.

Applications can create message queues either during initialization or during runtime. There is no limit to the number of message queues an application may use.

Message queues can be created to support a variety of message sizes. The available message sizes are 1, 2, 4, 8, and 16 32-bit words. The message size is specified when the queue is created. If your application messages exceed 16 words, you must send your messages by pointer. To accomplish this, create a queue with a message size of one word (enough to hold a pointer), and then send and receive message pointers instead of the entire message.

The number of messages a queue can hold depends on its message size and the size of the memory area supplied during creation. To calculate the total message capacity of the queue, divide the number of bytes in each message into the total number of bytes in the supplied memory area.

For example, if you create a message queue that supports a message size of one 32-bit word (four bytes), and the queue has a 100-byte available memory area, its capacity is 25 messages.

The memory area for buffering messages is specified during queue creation. It can be located anywhere in the target's address space. This is an important feature because it gives the application considerable flexibility. For example, an application might locate the memory area of a very important queue in high-speed RAM to improve performance.

Application threads can suspend while attempting to send or receive a message from a queue. Typically, thread suspension involves waiting for a message from an empty queue. However, it is also possible for a thread to suspend trying to send a message to a full queue.

After the condition for suspension is resolved, the request completes and the waiting thread is resumed. If multiple threads are suspended on the same queue, they are resumed in the order they occur on the suspended list (usually FIFO). However, an application can cause a higher-priority thread to resume first by calling the tx_queue_prioritize service prior to the queue service that lifts thread suspension. The queue prioritize service places the highest-priority thread at the front of the suspension list, while leaving all other suspended threads in the same FIFO order.

Queue suspensions can also time out; essentially, a time-out specifies the maximum number of timer-ticks the thread will stay suspended. If a time-out occurs, the thread is resumed and the service returns with the appropriate error code.

Message Queue Control Block

The characteristics of each message queue are found in its Control Block. It contains information such as the message size, total message capacity, current number of messages in the queue, available queue storage space, and number of threads suspended on this message queue.⁵³ Figure 162 contains many of the fields that compose this Control Block.

Field	Description
tx_queue_id	Message Queue ID
tx_queue_name	Pointer to message queue name
tx_queue_message_size	Message size specified during queue creation
tx_queue_capacity	Total number of messages in the queue
tx_queue_enqueued	Current number of messages in the message queue
tx_queue_available_storage	Available message queue storage space
tx_queue_start	Pointer to the start of the queue message area
x_queue_end	Pointer to the end of the queue message area
tx_queue_read	Read pointer – used by receive requests
tx_queue_write	Write pointer – used by send requests
tx_queue_suspension_list	Pointer to the head of the queue suspension list
tx_queue_suspended_count	Count of how many threads are suspended
tx_queue_created_next	Pointer to next message queue in the created list
tx_queue_created_previous	Pointer to previous message queue in created list

Figure 162. Message Queue Control Block

A Message Queue Control Block can be located anywhere in memory, but it is common to make the Control Block a global structure by defining it outside the scope of any function. A Message Queue Group Control Block is created when a message queue is declared with the TX_QUEUE data type. For example, we declare my_queue as follows:

TX_QUEUE my_queue;

⁵³ The structure of the Message Queue Control Block is defined in the **tx api.h** file.

The declaration of a message queue normally appears in the declarations and definitions section of the program.

Summary of Message Queue Services

Appendix F contains detailed information about message queue services. This appendix contains information about each service, such as the prototype, a brief description of the service, required parameters, return values, notes and warnings, allowable invocation, and an example showing how the service can be used. Figure 163 contains a listing of all available services for a message queue. We will investigate each of these services in the subsequent sections of this chapter.

Message Queue Service	Description
tx_queue_create	Create a message queue
tx_queue_delete	Delete a message queue
tx_queue_flush	Empty all messages in a message queue
tx_queue_front_send	Send a message to the front of a message queue
tx_queue_info_get	Retrieve information about a message queue
tx_queue_prioritize	Prioritize a message queue suspension list
tx_queue_receive	Get a message from a message queue
tx_queue_send	Send a message to a message queue

Figure 163. Services of the message queue

Creating a Message Queue

A message queue is declared with the TX_QUEUE data type and is defined with the tx_queue_create service. When defining a message queue, you must specify its Control Block, the name of the message queue, the message size, the starting address of the queue, and the total number of bytes available for the message queue. Figure 164 lists the attributes of a message queue. The total number of messages is calculated from the specified message size and the total number of bytes in the queue. Note that if the total number of bytes specified in the queue's memory area is not evenly divisible by the specified message size, the remaining bytes in the memory area are not used.

Message Queue Control Block
Message Queue Name
Size of Each Message in the Queue
Address of the Message Queue
Total Number of Bytes for the Message Queue

Figure 164. Attributes of a message queue

Figure 165 illustrates the use of this service. We will give our message queue the name "my queue."

```
TX QUEUE my queue;
UINT status:
/* Create a message queue whose total size is 2000 bytes starting at address
0x300000.
 Each message in this queue is defined to be 4 32-bit words long. */
status = tx_queue_create(&my_queue, "my_queue_name",
                        TX_4_ULONG, (VOID *) 0x300000, 2000);
/* If status equals TX_SUCCESS, my_queue contains space for storing 125
messages:
 (2000 bytes / 16 bytes per message). */
```

Figure 165. Creating a message queue

Sending a Message to a Message Queue

The tx_queue_send service sends a message to the specified message queue. This service copies the message to be sent to the back of the queue from the memory area specified by the source pointer. Figure 166 shows how this service can be used to send a message to a queue.⁵⁴

```
TX_QUEUE my_queue; UINT status; ULONG my_message[4];
/* Send a message to "my_queue." Return immediately, regardless of success.
 This wait option is used for calls from initialization, timers, and ISRs. */
status = tx_queue_send(&my_queue, my_message, TX_NO_WAIT);
/* If status equals TX_SUCCESS, the message has been sent to the queue. */
```

⁵⁴ Note that TX_NO_WAIT is the only valid wait option if the tx_queue_send service is called from a non-thread, such as an application timer, initialization routine, or ISR.

Figure 166. Send a message to a queue

If return variable *status* contains the value TX_SUCCESS, we have successfully sent a message to the queue.

Receiving a Message from a Message Queue

The tx_queue_receive service retrieves a message from a message queue. This service copies the retrieved message from the front of the queue into the memory area that is specified by the destination pointer. That message is then removed from the queue. The specified destination memory area must be large enough to hold the message; i.e., the destination pointed to by destination_ptr must be at least as large as this queue's defined message size. Otherwise, memory corruption occurs in the memory area following the destination. Figure 167 shows how this service can be used to receive a message from a queue.⁵⁵

```
TX_QUEUE my_queue;
UINT status;
ULONG my_message[4];
...

/* Retrieve a message from "my_queue." If the queue is empty, suspend until a message is present. Note that this suspension is only possible from application threads. */

status = tx_queue_receive(&my_queue, my_message, TX_WAIT_FOREVER);

/* If status equals TX_SUCCESS, the message is in "my_message." */
```

Figure 167. Receive a message from a queue

Deleting a Message Queue

The tx_queue_delete service deletes a message queue. All threads that are suspended waiting for a message from this queue are resumed and receive a TX_DELETED return status. Do not attempt to use a message queue that has been deleted. Also, make certain

⁵⁵ Note that TX_NO_WAIT is the only valid wait option if the tx_queue_receive service is called from a non-thread, such as an application timer, initialization routine, or ISR.

that you manage the memory area associated with a queue that has been deleted. Figure 168 contains an example showing how to delete a message queue.

```
TX_QUEUE my_queue;
UINT status;
...
/* Delete entire message queue. Assume that the queue has already been created with a call to tx_queue_create. */
status = tx_queue_delete(&my_queue);
/* If status equals TX_SUCCESS, the message queue has been deleted. */
```

Figure 168. Deleting a message queue

If variable *status* contains the return value TX_SUCCESS, we have successfully deleted the message queue.

Flushing the Contents of a Message Queue

The tx_queue_flush service deletes all messages that are stored in a message queue. In addition, if the queue is full and there are threads suspended because of trying to send messages to that queue, then all the messages of those suspended threads are discarded, and each suspended thread is resumed with a successful return status. If the queue is empty, this service does nothing.

Figure 169 illustrates the use of this service. We will give our message queue the name "my queue."

If variable *status* contains the return value TX_SUCCESS, we have successfully emptied the message queue.

Sending a Message to the Front of a Message Queue

Normally, messages are sent to the rear of a queue, but applications can use the tx_queue_front_send service to send a message to the front location of the message queue. This service copies the message to the front of the queue from the memory area specified by the source pointer. Figure 170 illustrates the use of this service. We will give our message queue the name "my_queue" and we will use the wait option that returns immediately, regardless of whether or not the message was successfully placed at the

front of the queue. If the variable *status* contains the return value TX_SUCCESS, we have successfully sent a message to the front of a queue.

```
TX_QUEUE my_queue;
UINT status;
...
/* Delete all messages in the message queue. Assume that the queue has already been created with a call to tx_queue_create. */
status = tx_queue_flush(&my_queue);
/* If status equals TX_SUCCESS, the message queue is now empty. */
```

Figure 169. Flushing a message queue

```
TX_QUEUE my_queue;
UINT status;
ULONG my_message[TX_4_ULONG];
...
/* Send a message to the front of "my_queue." Return immediately, regardless of success. This wait option is used for calls from initialization, timers, and ISRs. */
status = tx_queue_front_send(&my_queue, my_message, TX_NO_WAIT);

/* If status equals TX_SUCCESS, the message has been placed at the front of the specified queue. */
```

Figure 170. Sending a message to the front of a queue

Retrieving Message Queue Information

There are three services that enable you to retrieve vital information about message queues. The first such service for message queues—the tx_queue_info_get service—retrieves a subset of information from the Message Queue Control Block. This information provides a "snapshot" at a particular instant in time, i.e., when the service is invoked. The other two services provide summary information that is based on the gathering of run-time performance data. One service—the tx_queue_performance_info_get service—provides an information summary for a particular queue up to the time the service is invoked. By contrast the tx_queue_performance_system_info_get retrieves an information summary for all message queues in the system up to the time the service is invoked. These services are

useful in analyzing the behavior of the system and determining whether there are potential problem areas. The tx_queue_info_get⁵⁶ service retrieves several useful items of information about a message queue. These include the name of the message queue, the number of messages currently in the queue, the queue's total available storage (in bytes), the number of threads suspended for this queue, a pointer to the first suspended thread, and a pointer to the next created message queue. Figure 171 shows how this service can be used.

Figure 171. Retrieving information about a message queue

If return variable *status* contains the value TX_SUCCESS, we have retrieved valid information about the message queue.

Prioritizing a Message Queue Suspension List

The tx_queue_prioritize service places the highest priority thread suspended for a message queue at the front of the suspension list. This applies either to a thread waiting to receive a message from an empty queue, or to a thread waiting to send a message to a full queue, as described in Figure 172. All other threads remain in the same FIFO order in which they were suspended.

Queue is Empty	The highest priority thread suspended for this queue will receive the next message placed on the queue	
Queue is Full	The highest priority thread suspended for this queue will send the next message to this queue when space becomes available	

Effect of Prioritization

⁵⁶ By default, only the *tx_queue_info_get* service is enabled. The other two information-gathering services must be enabled in order to use them.

Status of Queue

Figure 172. Effect of prioritizing a message queue suspension list

Figure 173 contains an example showing how this service can be used to prioritize a message queue suspension list.

TX_QUEUE my_queue; UINT status;

/* Depending on the queue status, this service ensures that the highest priority thread will either receive the next message placed on this queue, or will send the next message to the queue. */

status = tx_queue_prioritize(&my_queue);

/* If status equals TX_SUCCESS, the highest priority suspended thread is at the front of the list. If the suspended thread is waiting to receive a message, the next tx_queue_send or tx_queue_front_send call made to this queue will wake up this thread. If the suspended thread is waiting to send a message, the next tx_queue_receive call will wake up this thread. */

Figure 173. Prioritizing a message queue suspension list

If return variable *status* contains the value TX_SUCCESS, we have successfully prioritized the message queue suspension list.

Message Queue Notification and Event-Chaining

The tx_queue_send_notify service registers a notification callback function that is invoked whenever a message is sent to the specified queue. The processing of the notification callback is defined by the application. This is an example of event-chaining where notification services are used to chain various synchronization events together. This is typically useful when a single thread must process multiple synchronization events.

Sample System Using a Message Queue for Interthread Communication

We have used counting semaphores for mutual exclusion and for event notification in the two previous sample systems. We have also used an event flags group to synchronize the behavior of two threads. In this sample system, we will use a message queue to

communicate between two threads. We will modify the previous sample system and replace all references to an event flags group with references to a message queue.

In Figure 174, when *speedy_thread* enters Activity 2 or Activity 4, it attempts to send one counting message (i.e., 0, 1, 2, 3, ...) to the queue, but if the queue is full, it waits until space becomes available. *speedy_thread* has the same priority and similar activities as in the previous sample system.




Figure 174. Activities of the Speedy_Thread where priority = 5

In Figure 175, when <code>slow_thread</code> enters Activity 5 or Activity 7, it attempts to receive one message from the queue, but if the queue is empty, it waits until a message appears. <code>slow_thread</code> does not process the value of the message it receives; it simply removes the message from the queue and continues executing. <code>slow_thread</code> has the same priority and similar activities as in the previous sample system.




Figure 175. Activities of the *Slow_Thread* where priority = 15

We will design our message queue so that it can store a maximum of 100 messages. In the sample output for this system, the *speedy_thread* completes many more cycles than the *slow_thread*. However, when the queue becomes full, each thread completes the same number of cycles.

We will discuss a series of changes to be applied to the sample system from Chapter 10 so that all references to an event flags group will be replaced with references to a

message queue. The complete program list called 11_sample_system.c is located in the next section of this chapter.

The first change occurs in the declaration and definitions section of our program, to which we need to add the following #defines:

```
#define QUEUE_MSG_SIZE TX_1_ULONG
#define QUEUE TOTAL SIZE QUEUE SIZE*sizeof(ULONG)*QUEUE MSG SIZE
```

These #defines specify the message size (in ULONGs, not bytes) and the total size of the message queue in bytes. The second #define provides some flexibility so that if either the message size or queue capacity (number of messages) were changed, then the total queue size would be calculated accordingly.

We need to replace the declaration of an event flags group with the declaration of a message queue as follows:

```
TX_QUEUE my_queue;
```

We also need to delete the declarations for the event flags group, and specify several new declarations so that we can send and receive our messages, as follows:

```
ULONG send_message[QUEUE_MSG_SIZE]={0x0},
received message[QUEUE MSG SIZE];
```

The next change occurs in the application definitions section of our program, in which we replace the creation of an event flags group with the creation of a message queue, as follows:

```
/* Create the message queue used by both threads. */
tx_queue_create (&my_queue, "my_queue", QUEUE_MSG_SIZE,
queue_storage, QUEUE_TOTAL_SIZE);
```

The remaining changes occur in the function definitions section of our program. We need to change all references to an event flags group with references to a message queue. We will show only the changes for the *speedy_thread* and will leave the *slow_thread* changes as an exercise for the reader. Figure 176 contains the necessary changes for Activity 2.

```
/* Activity 2: send a message to the queue, then sleep 5 timer-ticks. */
send_message[QUEUE_MSG_SIZE-1]++;
status = tx_queue_send (&my_queue, send_message, TX_WAIT_FOREVER);
if (status != TX_SUCCESS) break; /* Check status */
tx_thread_sleep(5);
```

Figure 176. Changes to Activity 2

Figure 177 contains the necessary changes for Activity 4. Most of the modifications involve changing references to an event flags group with references to a message queue.

```
/* Activity 4: send a message to the queue, then sleep 3 timer-ticks */
send_message[QUEUE_MSG_SIZE-1]++;
status = tx_queue_send (&my_queue, send_message, TX_WAIT_FOREVER);
if (status != TX_SUCCESS) break; /* Check status */
tx_thread_sleep(3);
```

Figure 177. Changes to Activity 4

Listing for 11_sample_system.c

```
001 /* 11_sample_system.c
002
003
       Create two threads, one byte pool, and one message queue.
004
      The threads communicate with each other via the message queue.
       Arrays are used for the stacks and the queue storage space */
005
006
007
008 /******************************
009 /*
           Declarations, Definitions, and Prototypes
010 /******************************
011
012 #include "tx_api.h"
```

```
013 #include ,stdio.h.
014
015 #define STACK_SIZE
                            1024
016 #define QUEUE_SIZE
                            100
017 #define QUEUE_MSG_SIZE TX_1_ULONG
018 #define QUEUE_TOTAL_SIZE QUEUE_SIZE*sizeof(ULONG)*QUEUE_MSG_SIZE
019
020 /* Define thread stacks */
021 CHAR stack_speedy[STACK_SIZE];
022 CHAR stack_slow[STACK_SIZE];
023 CHAR queue_storage[QUEUE_TOTAL_SIZE];
024
025 /* Define the Azure RTOS ThreadX object control blocks */
026
027 TX_THREAD Speedy_Thread;
028 TX_THREAD Slow_Thread;
029
030 TX_TIMER stats_timer;
031
032 TX_QUEUE my_queue;
033
034
035 /* Define the counters used in the PROJECT application... */
036
037 ULONG Speedy_Thread_counter=0, total_speedy_time=0;
038 ULONG Slow_Thread_counter=0, total_slow_time=0;
039 ULONG send_message[QUEUE_MSG_SIZE]=\{0\times0\},
           received_message[QUEUE_MSG_SIZE];
040
041
042
043 /* Define thread prototypes. */
044
045 void Speedy_Thread_entry(ULONG thread_input);
046 void Slow_Thread_entry(ULONG thread_input);
047 void print_stats(ULONG);
048
049
050 /*******************************
051 /*
                    Main Entry Point
052 /******************************
```

```
053
054 /* Define main entry point. */
055
056 int main()
057 {
058
059
      /* Enter the Azure RTOS ThreadX kernel. */
      tx_kernel_enter();
060
061 }
062
063
064
065 /******************************
066 /*
                  Application Definitions
068
069
070 /* Define what the initial system looks like. */
071
072 void tx_application_define(void *first_unused_memory)
073 {
074
075
      /* Put system definition stuff in here, e.g., thread creates
         and other assorted create information. */
076
077
078
      /* Create the Speedy_Thread. */
079
      tx_thread_create(&Speedy_Thread, "Speedy_Thread",
080
                      Speedy_Thread_entry, 0,
081
                      stack_speedy, STACK_SIZE, 5, 5,
082
                      TX_NO_TIME_SLICE, TX_AUTO_START);
083
      /* Create the Slow_Thread */
084
085
      tx_thread_create(&Slow_Thread, "Slow_Thread",
086
                      Slow_Thread_entry, 1,
087
                      stack_slow, STACK_SIZE, 15, 15,
088
                      TX_NO_TIME_SLICE, TX_AUTO_START);
089
090
091
      /* Create the message queue used by both threads. */
092
      tx_queue_create (&my_queue, "my_queue", QUEUE_MSG_SIZE,
093
```

```
094
                      queue_storage, QUEUE_TOTAL_SIZE);
095
096
097
      /* Create and activate the timer */
098
      tx_timer_create (&stats_timer, "stats_timer", print_stats,
099
                      0×1234, 500, 500, TX_AUTO_ACTIVATE);
100
101
      }
102
103
      /****************/
104
105
                     Function Definitions
      /****************/
106
107
108
      /* Entry function definition of the "Speedy_Thread"
109
110
        it has a higher priority than the "Slow_Thread" */
111
112 void Speedy_Thread_entry(ULONG thread_input)
113 {
114
115 UINT status;
116 ULONG start_time, cycle_time=0, current_time=0;
117
118
119
      /* This is the higher priority "Speedy_Thread"-it sends
120
         messages to the message queue */
121
      while(1)
122
      {
123
124
        /* Get the starting time for this cycle */
125
        start_time 5 tx_time_get();
126
127
        /* Activity 1: 2 timer-ticks. */
128
       tx_thread_sleep(2);
129
130
        /* Activity 2: send a message, then sleep 5 timer-ticks. */
131
        send_message[QUEUE_MSG_SIZE-1]++;
132
133
        status=tx_queue_send (&my_queue, send_message, TX_WAIT_FOREVER);
134
```

```
135
      if (status !=TX_SUCCESS) break; /* Check status */
136
137
      tx_thread_sleep(5);
138
139
      /* Activity 3: 4 timer-ticks. */
140
      tx_thread_sleep(4);
141
142
      /* Activity 4: send a message, then sleep 3 timer-ticks */
143
      send_message[QUEUE_MSG_SIZE-1]++;
144
145
      status=tx_queue_send (&my_queue, send_message, TX_WAIT_FOREVER);
146
147
      if (status !=TX_SUCCESS) break; /* Check status */
148
149
      tx_thread_sleep(3);
150
151
152
      /* Increment the thread counter and get timing info */
      Speedy_Thread_counter++;
153
154
155
      current_time=tx_time_get();
156
      cycle_time=current_time - start_time;
157
      total_speedy_time=total_speedy_time+cycle_time;
158
159
    }
160 }
161
163
164 /* Entry function definition of the "Slow_Thread"
165
       it has a lower priority than the "Speedy_Thread" */
166
167 void Slow_Thread_entry(ULONG thread_input)
168 {
169
170 UINT status;
171 ULONG start_time, current_time=0, cycle_time=0;
172
173
174
      /* This is the lower priority "Slow_Thread"-it receives messages
         from the message queue */
175
```

```
176
      while(1)
177
178
179
         /* Get the starting time for this cycle */
180
         start_time=tx_time_get();
181
182
         /* Activity 5 - receive a message and sleep 12 timer-ticks.*/
         status=tx_queue_receive (&my_queue, received_message,
183
                                     TX_WAIT_FOREVER);
184
185
         if (status !=TX_SUCCESS) break; /* Check status */
186
187
         tx_thread_sleep(12);
188
189
         /* Activity 6: 8 timer-ticks. */
190
         tx_thread_sleep(8);
191
192
         /* Activity 7: receive a message and sleep 11 timer-ticks.*/
193
194
         /* receive a message from the queue */
195
         status=tx_queue_receive (&my_queue, received_message,
                                     TX_WAIT_FOREVER);
196
197
         if (status !=TX_SUCCESS) break; /* Check status */
198
199
         tx_thread_sleep(11);
200
201
         /* Activity 8: 9 timer-ticks. */
202
         tx_thread_sleep(9);
203
204
         /* Increment the thread counter and get timing info */
205
         Slow_Thread_counter++;
206
207
         current_time=tx_time_get();
208
         cycle_time=current_time-start_time;
209
         total_slow_time=total_slow_time+cycle_time;
210
211
      }
212 }
213
714 /*****************************
```

```
215 /* print statistics at specified times */
216 void print_stats (ULONG invalue)
217 {
218
       ULONG current_time, avg_slow_time, avg_speedy_time;
219
220
       if ((Speedy_Thread_counter>0) && (Slow_Thread_counter>0))
221
222
          current_time=tx_time_get();
223
          avg_slow_time=total_slow_time/Slow_Thread_counter;
224
           avg_speedy_time=total_speedy_time/Speedy_Thread_counter;
225
226
          printf("\n**** Threads communicate with a message
                   queue.\n\n");
227
          printf(" Current Time:
                                            %lu\n", current_time);
228
          printf(" Speedy_Thread counter: %lu\n",
                   Speedy_Thread_counter);
229
          printf(" Speedy_Thread avg time: %lu\n", avg_speedy_time);
                                            %lu\n", Slow_Thread_counter);
230
          printf(" Slow_Thread counter:
          printf(" Slow_Thread avg time:
                                            %lu\n", avg_slow_time);
231
232
          printf(" # messages sent:
                                            %lu\n\n",
233
                  send_message[QUEUE_MSG_SIZE-1]);
234
      }
235
         else printf("Bypassing print_stats function, Current
                                                               Time:
                          %lu\n",
236
                 tx_time_get());
237 }
```

Message Queue Internals

When the TX_QUEUE data type is used to declare a message queue, a Queue Control Block (QCB) is created, and that Control Block is added to a doubly linked circular list, as illustrated in Figure 178.




Figure 178. Created message queue list

The pointer named tx_queue_created_ptr points to the first control block in the list. See the fields in the QCB for timer attributes, values, and other pointers.

In general, the tx_queue_send and tx_queue_front_send operations copy the contents of a message to a position in the message queue, i.e., to the rear or the front of the queue, respectively. However, if the queue is empty and another thread is suspended because it is waiting for a message, then that message bypasses the queue entirely and goes directly to the destination specified by the other thread. Azure RTOS ThreadX uses this shortcut to enhance the overall performance of the system.

Overview

Message queues provide a powerful tool for interthread communication. Message queues do not support a concept of ownership, nor is there a limit to how many threads can access a queue. Any thread can send a message to a queue and any thread can receive a message from a queue.

If a thread attempts to send a message to a full queue, then its behavior will depend on the specified wait option. These options will cause the thread either to abort the message transmission or to suspend (indefinitely or for a specific number of timer-ticks) until adequate space is available in the queue.

Similarly, if a thread attempts to receive a message from an empty queue, it will behave according to the specified wait option.

Normally, messages on a queue behave in a FIFO manner, i.e., the first messages sent to the rear of the queue are the first to be removed from the front. However, there is a service that permits a message to be sent to the front of the queue, rather than to the rear of the queue.

A message queue is one type of public resource, meaning that it is accessible by any thread. There are four such public resources, and each has features that are useful for certain applications. Figure 179 compares the uses of message queues, mutexes, counting semaphores, and event flags groups. As this comparison suggests, the message queue is ideally suited for interthread communication.

	Thread Synchronization	Event Notification	Mutual Exclusion	Inter-Thread Communication
Mutex			Preferred	
Counting Semaphore	OK – better for one event	Preferred	ОК	
Event Flags Group	Preferred	ОК		
Message Queue	OK	ОК		Preferred

Figure 179. Recommended uses of public resources

Key Terms and Phrases

flush contents of a queue message queue FIFO discipline

front of queue message size

interthread communication prioritize a message queue suspension list

mailbox Queue Control Block (QCB)

message capacity queue storage space
message queue queue suspension
Message Queue Control Block
message queue creation receive message
message queue deletion receive message

Problems

- Describe how you would implement the producer-consumer system discussed in Chapter 9 so that it would use a message queue rather than a counting semaphore. State all your assumptions.
- 2. Suppose that you want to synchronize the operation of two threads by using a message queue. Describe what you would have to do in order to make certain that the threads take turns sharing the processor, i.e., thread 1 would access the processor, then thread 2, then thread 1, and so on.
- 3. Describe how you would determine how many messages are currently stored in a particular message queue.

- 4. Normally, messages are inserted at the rear of the queue, and are removed from the front of the queue. Describe a scenario in which you should insert messages at the front of the queue instead of the rear of the queue.
- 5. Suppose that three numbered threads (i.e., 1, 2, 3) use a message queue to communicate with each other. Each message consists of four words (i.e., TX_4_ULONG) in which the first word contains the thread number for which the message is intended, and the other words contain data. Describe how the message queue can be used so that one thread can send a message to any one of the other three threads, and a thread will remove a message from the queue only if it is intended for that thread.

Chapter 12

Advanced Topics

Introduction

Azure RTOS ThreadX provides several advanced features that can be essential during the development stage as well as during run-time. These features include real-time event-chaining⁵⁷, notification callback functions, and run-time performance metrics. We will investigate each of these topics in this chapter.

Event-Chaining

Event-chaining is a technique that enables the linking of several objects based on the occurrence of independent events. This is particularly useful in activating a thread that is suspended on two or more resources. Implementing this technique is a three-step process as follows:

- 1. Register one or more notification callback functions.
- The registered notification callback function is automatically invoked when an
 indicated event occurs. Each such function typically contains a
 tx_semaphore_put service call, which communicates to a waiting thread that a
 particular event has occurred. However, many other service calls could be used.
- A thread suspends on the semaphore mentioned above. Getting this semaphore signifies that the event in question has occurred and then the thread continues through the system.

⁵⁷ Event-chaining is a trademark of Microsoft.

There are three major types of event-chaining available that include sending a message to a queue, putting an instance on a semaphore, and setting an event flags group. The following sections contain descriptions of each of these types.

Queue Event-Chaining

As noted before, implementing event-chaining is a multiple-step process. Figure 180 contains a template that illustrates the components involved for event-chaining with a message queue.




Figure 180. Template for event-chaining with a message queue

An important advantage of this technique is that one or more threads waiting for an event to occur are automatically activated when the event actually does occur. In general, this technique will reduce the number of threads needed and will reduce the associated resources required for processing systems of this nature. We will investigate the components of event-chaining with semaphores and event-chaining with event flags in the following sections. Then we will study a complete sample system that uses event-chaining.

Semaphore Event-Chaining

Figure 181 contains a template that illustrates the components involved for event-chaining with a semaphore.

This template is meant to illustrate the components of event-chaining with a semaphore. Normally, event-chaining is best used when a thread suspends on two or more objects, as we will see in the sample system later in this chapter.

Event Flags Group Event-Chaining

Figure 182 contains a template that illustrates the components involved for event-chaining with an event flags group.

A typical use for event-chaining is to create a mechanism for a thread to suspend on two or more objects. For example, this technique can be used to permit a thread to suspend on any of the following situations:

- Suspend on a queue, a semaphore, and an event flags group
- Suspend on a queue or a semaphore
- Suspend on a queue or an event flags group
- Suspend on two queues
- Suspend on three queues
- Suspend on four queues

This is only a sample of how event-chaining can be used and many other possibilities exist. In the next section, we investigate a system where a thread suspends on two queues.

```
TX SEMAPHORE my semaphore;
                                               /* The semaphores, the registration of
TX SEMAPHORE gatekeeper;
                                               the notification callback function, and
tx_semaphore_put_notify (&my_semaphore,
                                               the prototype for the notification
                         semaphore notify);
                                               callback function are usually placed in
                                               the application define function, which
void semaphore notify (TX SEMAPHORE
                                               is part of the initialization process */
                       *my_semaphore);
                                               /* A semaphore is put somewhere in
                                               the application. Whenever the
                                               semaphore is incremented, the
tx_semaphore_put (&my_semaphore,
                                               notification callback function is
                  TX WAIT FOREVER);
                                               automatically invoked, thus causing
                                               the semaphore gatekeeper to be
                                               incremented. */
                                               /* Somewhere in the application, a
                                               thread suspends on semaphore
tx_semaphore_get (&gatekeeper,
                                               gatekeeper, which is equivalent to
                  TX WAIT FOREVER);
                                               waiting for an instance on the
                                               semaphore named my semaphore */
void semaphore notify (TX SEMAPHORE
                                               /* Notification callback function to
                      *my_semaphore)
                                               increment the semaphore called
                                               gatekeeper whenever semaphore
                                               my semaphore has been incremented
 tx semaphore put (&gatekeeper);
```

Figure 181. Template for event-chaining with a counting semaphore

Sample System Using Event-Chaining

All the thread suspension examples in previous chapters involved one thread waiting on one object, such as a mutex, a counting semaphore, an event flags group, or a message queue. In this sample system, we have threads waiting on multiple objects. Specifically, threads wait for a message to appear on either *queue_1* or *queue_2*. For convenience, we simplify the system setup that we have used in previous examples.

We use the same speedy_thread and slow_thread as in previous examples. For simplicity, we reduce the number of activities for each thread from four to two as indicated in Figure 183. As before, speedy_thread has priority 5 and slow_thread has priority 15. Use event-chaining to automatically increment the counting semaphore named gatekeeper whenever a message is sent to either queue_1 or queue_2. We use two application timers to send messages to queue_1 or queue_2 at periodic time intervals and the threads wait for a message to appear.

```
TX EVENT FLAGS GROUP my group;
                                                /* The event flags group and
                                                semaphore declarations, the
TX_SEMAPHORE gatekeeper;
                                                registration of the notification callback
tx event flags set notify (&my group,
                                                function, and the prototype for the
                                                notification callback function are
                          event flags notify);
                                                usually placed in the
void event flags notify
                                                application define function, which is
(TX EVENT_FLAGS_GROUP *my_group);
                                                part of the initialization process */
                                                /* The events flags group called
                                                my group is set somewhere in the
                                                application. Whenever one or more
tx_event_flags_set (&my_group,
                                                event flags in my group is set, the
                                                notification callback function is
                   0x1234, TX OR);
                                                automatically invoked, thus causing
                                                the semaphore gatekeeper to be
                                                incremented. */
                                                /* Somewhere in the application, a
                                                thread suspends on semaphore
                                                gatekeeper, which is equivalent to
tx_semaphore_get (&gatekeeper,
                  TX WAIT FOREVER);
                                                waiting for one or more event flags to
                                                be set in the event flags group called
                                                my group */
void event flags notify
(TX_EVENT_FLAGS_GROUP *my_group)
                                                /* Notification callback function to
                                                increment the semaphore called
                                                gatekeeper whenever the event flags
 tx_semaphore_put (&gatekeeper);
                                                group called my_group is set */
```

Figure 182. Template for event-chaining with an event flags group




Figure 183. Multiple object suspension problem

Figure 184 contains a description of the two activities for speedy_thread.




Figure 184. speedy_thread activities

Note that *speedy_thread* and *slow_thread* each have only two activities rather than four in the previous examples. Figure 185 contains a description of the activities for *slow_thread*.




Figure 185. slow_thread activities

We modify the sample system in Chapter 8 for our purposes here. The following modifications are needed for the event-chaining example:

- Create gatekeeper semaphore to handle multiple object suspension for speedy_thread and slow_thread
- 2. Create *queue_1* and *queue_2* threads suspend on these queues
- 3. Create two timers to send messages to the queues at periodic intervals
- 4. Declare variables needed for the tx_queue_info_get service calls—these variables provide information about the queues that will be displayed
- 5. Create the event notification functions
- 6. Modify Activity 2 and Activity 3 to implement the multiple object suspensions

Activity 2 is identical to Activity 3, except for the "sleep" times. Following is pseudo code for Activity 2:

Wait forever to get an instance on the semaphore named gatekeeper (an instance on this semaphore means that there is at least one message available on one of the queues)

If a message appears on queue_1, receive it.

else Receive a message from queue_2.

Sleep 5 ticks

Following is some sample output for this system after it has executed for 500 timer ticks:

Event-Chaining: 2 threads waiting for 2 queues			
Current Time:	500		
speedy_thread counter:	69		
speedy_thread avg time:	7		
slow_thread counter:	24		
slow_thread avg time:	20		
total # queue_1 messages sent:	41		
total # queue_2 messages sent:	55		
current # messages in queue_1:	0		
current # messages in queue_2:	1		

The queue information was obtained from the tx_queue_info_get service. We could get additional information about the two queues by using the queue performance information services described earlier in this chapter.

Listing for 12_sample_system.c

The sample system named 12_sample_system.c appears below; line numbers have been added for easy reference.

```
000 /* 12 sample system.c
001
002
      Create two threads, one byte pool, two message queues, three timers, and
003
      one counting semaphore. This is an example of multiple object suspension
      using event-chaining, i.e., speedy thread and slow thread wait for a
004
005
      message to appear on either of two queues */
006
007
800
      /*****************
009
            Declarations, Definitions, and Prototypes
      /****************
010
011
012
      #include "tx api.h"
```

```
013
       #include <stdio.h>
014
015
      #define STACK SIZE
                                  1024
016
       #define BYTE POOL SIZE
                                  9120
017
       #define NUMBER OF MESSAGES 100
018
       #define MESSAGE SIZE
                                 TX_1_ULONG
019
       #define QUEUE SIZE
                                 MESSAGE SIZE*sizeof(ULONG)*NUMBER OF MESSAGES
020
021
022
       /* Define the Azure RTOS ThreadX object control blocks... */
023
024
       TX THREAD speedy thread; /* higher priority thread */
       TX THREAD slow thread; /* lower priority thread */
025
026
       TX BYTE POOL my byte pool; /* byte pool for stacks and queues */
027
028
       TX SEMAPHORE gatekeeper; /* indicate how many objects available */
029
       TX QUEUE queue 1; /* queue for multiple object suspension */
030
031
       TX QUEUE queue 2; /* queue for multiple object suspension */
032
      TX TIMER stats timer; /* generate statistics at intervals */
033
034
       TX TIMER queue timer 1; /* send message to queue 1 at intervals */
       TX TIMER queue timer 2; /* send message to queue 2 at intervals */
035
036
       /* Variables needed to get info about the message queue */
037
038
       CHAR *info queue name;
039
       TX THREAD *first suspended;
       TX QUEUE *next queue;
040
       ULONG enqueued 1=0, enqueued 2=0, suspended count=0, available storage=0;
041
042
043
      /* Define the variables used in the sample application... */
       ULONG speedy thread counter=0, total speedy time=0;
044
       ULONG slow thread counter=0, total slow time=0;
045
       ULONG send message 1[TX \ 1 \ ULONG] = \{0X0\}, send message 2[TX \ 1 \ ULONG] = \{0X0\};
046
047
       ULONG receive message 1[TX 1 ULONG], receive message 2[TX 1 ULONG];
048
       /st speedy thread and slow thread entry function prototypes st/
049
       void speedy thread entry (ULONG thread input);
050
051
       void slow thread entry (ULONG thread input);
052
053
      /* timer entry function prototypes */
```

```
void queue timer_1_entry(ULONG thread_input);
054
      void queue_timer_2_entry(ULONG thread input);
055
056
      void print stats(ULONG);
057
058
      /* event notification function prototypes used for event-chaining */
059
      void queue 1 send notify(TX QUEUE *queue 1 ptr);
      void queue 2 send notify(TX_QUEUE *queue_2_ptr);
060
061
062
063
      /****************
064
                     Main Entry Point
      /***************
065
066
067
      /* Define main entry point. */
068
069
     int main()
070
      /* Enter the Azure RTOS ThreadX kernel. */
071
072
       tx kernel enter();
073
074
075
      /*****************
076
077
                  Application Definitions
      078
079
080
      /* Define what the initial system looks like. */
081
082
083
      void tx application define(void *first unused memory)
084
      {
085
086
      CHAR *speedy stack ptr;
087
      CHAR *slow stack ptr;
      CHAR *queue 1 ptr;
088
089
      CHAR *queue 2 ptr;
090
       /* Create a byte memory pool from which to allocate the thread stacks. */
091
092
       tx byte pool create (&my byte pool, "my byte pool",
093
                  first unused memory, BYTE POOL SIZE);
094
```

```
/* Create threads, queues, the semaphore, timers, and register functions
095
096
           for event-chaining */
097
098
         /* Allocate the stack for speedy thread. */
099
         tx byte allocate(&my byte pool, (VOID **) &speedy stack ptr, STACK SIZE,
100
                     TX NO WAIT);
101
102
         /* Create speedy thread. */
103
        tx thread create (&speedy thread, "speedy thread", speedy thread entry, 0,
104
                     speedy stack ptr, STACK SIZE, 5, 5, TX NO TIME SLICE,
105
                     TX AUTO START);
106
107
         /* Allocate the stack for slow thread. */
108
         tx byte allocate(&my byte pool, (VOID **)&slow stack ptr, STACK SIZE,
109
                     TX NO WAIT);
110
        /* Create slow thread */
111
         tx thread create (&slow thread, "slow thread", slow thread entry, 1,
112
113
                     slow stack ptr, STACK SIZE, 15, 15, TX NO TIME SLICE,
                     TX AUTO START);
114
115
116
         /* Create the message queues used by both threads. */
         tx byte allocate(&my byte pool, (VOID **) &queue 1 ptr,
117
118
                     QUEUE SIZE, TX NO WAIT);
119
120
         tx queue create (&queue 1, "queue 1", MESSAGE SIZE,
121
                     Queue 1 ptr, QUEUE SIZE);
122
123
         tx byte allocate(&my byte pool, (VOID **) &queue 2 ptr,
124
                     QUEUE SIZE, TX NO WAIT);
125
126
         tx queue create (&queue 2, "queue 2", MESSAGE SIZE,
                     Queue 2 ptr, QUEUE SIZE);
127
128
129
         /* Create the gatekeeper semaphore that counts the available objects */
130
         tx semaphore create (&gatekeeper, "gatekeeper", 0);
131
         /* Create and activate the stats timer */
132
133
         tx timer create (&stats timer, "stats timer", print stats,
134
                     0x1234, 500, 500, TX AUTO ACTIVATE);
135
```

```
/st Create and activate the timer to send messages to queue 1 st/
136
        tx timer create (&queue timer 1, "queue timer", queue timer 1 entry,
137
                    0x1234, 12, 12, TX AUTO ACTIVATE);
138
139
140
        /\!\!^* Create and activate the timer to send messages to queue 2 ^*/\!\!^-
        tx timer create (&queue timer 2, "queue timer", queue timer 2 entry,
141
                    0x1234, 9, 9, TX AUTO ACTIVATE);
142
143
144
        /* Register the function to increment the gatekeeper semaphore when a
           message is sent to queue 1 */
145
146
        tx queue send notify(&queue 1, queue 1 send notify);
147
        /* Register the function to increment the gatekeeper semaphore when a
148
149
           message is sent to queue 2 */
        tx queue send notify(&queue 2, queue 1 send notify);
150
151
152
153
       /****************/
154
155
                        Function Definitions
       /****************
156
157
158
159
      /* Entry function definition of speedy thread
          it has a higher priority than slow thread */
160
161
162
      void speedy thread entry (ULONG thread input)
163
164
165
       ULONG start time, cycle time=0, current time=0;
166
      UINT status;
167
        /* This is the higher priority speedy thread */
168
169
170
        while(1)
171
          /\star Get the starting time for this cycle \star/
172
          start time = tx time get();
173
174
175
          /* Activity 1: 2 ticks. */
          tx thread sleep(2);
176
```

```
177
          /* Activity 2: 5 ticks. */
178
179
          /* wait for a message to appear on either one of the two queues */
180
          tx semaphore get (&gatekeeper, TX WAIT FOREVER);
181
182
          /\star Determine whether a message queue 1 or queue 2 is available \star/
          status = tx queue receive (&queue 1, receive message 1, TX NO WAIT);
183
184
          if (status == TX SUCCESS)
185
186
              ; /* A message on queue 1 has been found-process */
187
           else
              /* Receive a message from queue 2 */
188
              tx queue receive (&queue 2, receive message 2, TX WAIT FOREVER);
189
190
191
          tx thread sleep(5);
192
193
          /* Increment the thread counter and get timing info */
          speedy thread counter++;
194
195
          current time = tx time get();
          cycle time = current time-start time;
196
197
          total speedy time = total speedy time + cycle time;
198
       }
199
200
201
       /***********************************
202
203
       /* Entry function definition of slow thread
          it has a lower priority than speedy thread */
204
205
206
       void slow thread entry (ULONG thread input)
207
       {
208
       ULONG start time, current time=0, cycle time=0;
209
210
       UINT status;
211
212
213
       while(1)
214
           /* Get the starting time for this cycle */
215
              start time=tx time get();
216
217
```

```
/* Activity 3-sleep 12 ticks. */
218
219
           /* wait for a message to appear on either one of the two queues */
          tx semaphore get (&gatekeeper, TX WAIT FOREVER);
220
221
222
           /* Determine whether a message queue 1 or queue 2 is available */
223
          status = tx queue receive (&queue 1, receive message 1, TX NO WAIT);
224
225
           if (status == TX SUCCESS)
226
               ; /* A message on queue 1 has been found-process */
227
           else
228
               /* Receive a message from queue 2 */
229
               tx queue receive (&queue 2, receive message 2, TX WAIT FOREVER);
230
231
          tx thread sleep(12);
232
233
234
          /* Activity 4: 8 ticks. */
          tx thread sleep(8);
235
236
          /* Increment the thread counter and get timing info */
237
          slow thread counter++;
238
239
          current time = tx time get();
240
241
          cycle time = current time-start time;
           total slow time = total slow time + cycle time;
242
243
        }
244
       }
245
       /***********************************
246
247
       /* print statistics at specified times */
248
       Void print stats (ULONG invalue)
249
       ULONG current time, avg slow time, avg speedy time;
250
251
        If ((speedy thread counter>0) && (slow_thread_counter>0))
252
253
254
             current time = tx time get();
             avg slow time = total slow time/slow thread counter;
255
256
             avg speedy time = total speedy time/speedy thread counter;
             tx queue info get (&queue 1, &info queue name, &enqueued 1,
257
                         &available storage, &first suspended,
258
```

```
259
                        &suspended count, &next queue);
260
            tx queue info get (&queue 2, &info queue name, &enqueued 2,
261
                        &available storage, &first suspended,
262
                        &suspended count, &next queue);
263
          printf("\nEvent-Chaining: 2 threads waiting for 2 queues\n\n");
          printf(" Current Time:
264
                                         %lu\n", current time);
265
          printf(" speedy thread counter: %lu\n", speedy thread counter);
266
          printf(" speedy thread avg time: %lu\n", avg speedy time);
267
          printf(" slow thread counter: %lu\n", slow thread counter);
          printf(" slow thread avg time: %lu\n", avg slow time);
268
269
          printf(" total # queue 1 messages sent:
270
          %lu\n", send message 1[TX 1 ULONG-1]);
          printf(" total # queue 2 messages sent:
271
272
          lu\n'', send message 2[TX 1 ULONG-1]);
          printf(" current # messages in queue 1:
273
          lu\n", enqueued 1);
274
          printf(" current # messages in queue 2: %lu\n\n", enqueued 2);
275
276
        else printf("Bypassing print stats function, Current Time: %lu\n",
277
278
                   tx time get());
279
      }
280
281
282
      283
284
      /* Send a message to queue 1 at specified times */
      void queue timer 1 entry (ULONG invalue)
285
286
287
288
        /* Send a message to queue 1 using the multiple object suspension approach
        /* The gatekeeper semaphore keeps track of how many objects are available
289
290
           via the notification function */
291
        send message 1[TX 1 ULONG-1]++;
        tx queue send (&queue 1, send message 1, TX NO WAIT);
292
293
294
      }
295
      296
297
      /* Send a message to the queue at specified times */
```

```
298
       void queue timer 2 entry (ULONG invalue)
299
300
301
        /\star Send a message to queue 2 using the multiple object suspension approach \star/
302
        /* The gatekeeper semaphore keeps track of how many objects are available
303
           via the notification function */
        send message 2[TX 1 ULONG--1]++;
304
        tx queue send (&queue 2, send message 2, TX NO WAIT);
305
306
307
308
       /***********************************
309
310
       /* Notification function to increment gatekeeper semaphore
311
          whenever a message has been sent to queue 1 */
      void queue 1 send notify(TX QUEUE *queue ptr 1)
312
313
314
       tx semaphore put (&gatekeeper);
315
316
      /***********************************
317
318
      /* Notification function to increment gatekeeper semaphore
319
          whenever a message has been sent to queue 2 */
      void queue 2 send notify(TX QUEUE *queue ptr 2)
320
321
322
        Tx semaphore put (&gatekeeper);
323
```

Figure 186 contains several comments about this listing, using the line numbers as references.

Run-Time Performance Metrics

Information is available during run-time for each of the Azure RTOS ThreadX resources. This information can be useful in determining whether the application is performing properly, as well as helping to optimize the application. Information can be retrieved for a single resource or cumulative information can be obtained for all such resources in the system. Figure 187 contains a summary of the run-time performance information retrieval services.

For example, the tx_queue_performance_info_get service retrieves run-time performance information for a single queue. However, the

tx_queue_performance_system_info_get service retrieves cumulative performance information for all queues in the system. In the sections that follow, we will consider performance information retrieval for each of the resources.

Lines	Comments
024 through 035	Declaration of system resources including threads, byte pool, semaphore, queues, and timers
037 through 047	Declaration of variables used in the system including parameters for the queue info get services
049 through 060	Declaration of prototypes for thread entry functions, timer entry function, and event notification functions
116 through 127	Creation of the two queues used for multiple object suspension
129 and 130	Creation of the gatekeeper semaphore used for event-chaining
132 through 142	Creation of the timer fo display statistics at periodic intervals, and creation of the two timers to send messages to the queues at various intervals
144 through 150	Registration of the two functions that increment the gatekeeper semaphore whenever messages are sent to the queues
159 through 199	Entry function for Speedy Thread; lines 178 through 191 contain the implementation of Activity 2
203 through 244	Entry function for Slow Thread; lines 218 through 231 contain the implementation of Activity 3
247 through 276	Entry function for timer print stats, which includes calculating average cycle time, number of times through each cycle, and info get for the two queues
281 through 304	Entry functions for timers to send messages to queue_1 and queue_2 at periodic intervals
307 through 320	Entry functions for the notification callback functions; these functions increment semaphore gatekeeper whenever a message is send to either queue_1 or queue_2; these functions are essential to the event-chaining technique

Figure 186. Comments about sample system listing

Resource	Performance Information Services
Block Pool	tx_block_pool_performance_info_get tx_block_pool_performance_system_info_get
Byte Pool	tx_byte_pool_performance_info_get tx_byte_pool_performance_system_info_get
Event Flags	tx_event_flags_performance_info_get tx_event_flags_performance_system_info_get
Mutex	tx_mutex_performance_info_get tx_mutex_performance_system_info_get
Queue	tx_queue_performance_info_get tx_queue_performance_system_info_get
Semaphore	tx_semaphore_performance_info_get tx_semaphore_performance_system_info_get
Thread	tx_thread_performance_info_get tx_thread_performance_system_info_get
Timer	tx_timer_performance_info_get tx_timer_performance_system_info_get

Figure 187. Performance information services

Performance Information Service	Parameter	Description
	pool_ptr	Pointer to a memory block pool
	allocates	Number of allocate requests
ty block pool porformance	releases	Number of release requests
tx_block_pool_performance_ info_get	suspensions	Number of thread allocation suspensions
	timeouts	Number of thread allocation suspension timeouts
tx_block_pool_performance_ system_info_get	Parameters are identical to the tx_block_pool_performance_info_get service except that the pointer reference to a particular memory block pool is not included. Furthermore, all parameters represent total counts for all memory block pool attributes.	

Figure 188. Block pool performance information parameters

Block Pool Performance Information

There are two services that provide run-time performance information. One service retrieves performance information for a particular memory block pool and the other service retrieves cumulative performance information for all memory block pools in the system. Figure 188 contains a description of the parameters for each of these services.

Figure 189 contains an example that illustrates information retrieval for the memory block pool called "my_pool."

Figure 189. Block pool performance information retrieval

When this service is executed we would obtain the number of allocations, releases, suspensions, and timeouts that have occurred at the point in time when the service was invoked. The service to retrieve cumulative performance information for all memory block pools is similar except that there is no reference to a specific memory block pool.

Byte Pool Performance Information

As with memory block pools, there are two services that provide run-time performance information for memory byte pools. One service retrieves performance information for a particular memory byte pool and the other service retrieves cumulative performance information for all memory byte pools in the system. Figure 190 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	pool_ptr	Pointer to a memory block pool
	allocates	Number of allocate requests
	fragments_ searched	Number of memory fragments searched during allocation requests
ty bute neel performance	merges	Number of memory blocks merged during allocation requests
tx_byte_pool_performance_ info_get	splits	Number of memory blocks split (or fragmented) during allocation requests
	releases	Number of release requests
	suspensions	Number of thread allocation suspensions
	timeouts	Number of thread allocation suspension timeouts
tx_byte_pool_performance_ system_info_get	Parameters are identical to the tx_byte_pool_performance_info_get service except that the pointer reference to a particular memory byte pool is not included. Furthermore, all parameters represent total counts for all memory byte pool attributes.	

Figure 190. Byte pool performance information parameters

Figure 191 contains an example that illustrates information retrieval for the memory byte pool called "my pool."

Figure 191. Byte pool performance information retrieval

When this service is executed we would obtain the number of allocations, releases, merges, fragments searched, merges, splits, suspensions, and timeouts that have occurred at the point in time when the service was invoked. The number of fragments searched, merges, and splits would be of particular interest because that might suggest that using this byte pool would lead to undeterministic behavior because of the variable amount of time required to respond to allocation requests.

Event Flags Performance Information

There are two services that provide run-time performance information for event flags groups. One service retrieves performance information for a particular event flags group and the other service retrieves cumulative performance information for all event flags groups in the system. Figure 192 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	group_ptr	Pointer to an event flags group
	sets	Number of set requests
tx_event_flags_performance_	gets	Number of get requests
info_get	suspensions	Number of thread get suspensions
	timeouts	Number of thread get suspension timeouts
tx_event_flags_performance_ system_info_get	Parameters are identical to the tx_event_flags_performance_info_get service except that the pointer reference to a particular event flags group is not included. Furthermore, all parameters represent total counts for all event flags group attributes.	

Figure 192. Event flags group performance information parameters

Figure 193 contains an example that illustrates information retrieval for the event flags group called "my_event_flag_group."

Figure 193. Event flags group performance information retrieval

When this service is executed we would obtain the number of event flag set requests, get requests, suspensions, and timeouts performed for this event flags group.

Mutex Performance Information

There are two services that provide run-time performance information for mutexes. One service retrieves performance information for a particular mutex and the other service retrieves cumulative performance information for all mutexes in the system. Figure 194 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	mutex_ptr	Pointer to a mutex
	puts	Number of put requests for this mutex
	gets	Number of get requests for this mutex
	suspensions	Number of thread get suspensions
tx_mutex_performance_ info_get	timeouts	Number of thread get suspension timeouts for this mutex
	inversions	Number of thread priority inversions for this mutex
	inheritances	Number of thread priority inheritance operations for this mutex
tx_mutex_performance_ system_info_get	Parameters are identical to the tx_mutex_performance_info_get service except that the pointer reference to a particular mutex is not included. Furthermore, all parameters represent total counts for all mutex attributes.	

Figure 194. Mutex performance information parameters

Figure 195 contains an example that illustrates information retrieval for the mutex called "my_mutex."

Figure 195. Mutex performance information retrieval

When this service is executed we would obtain the number of gets, puts, suspensions, timeouts, inversions, and priority inheritances for this mutex.

Queue Performance Information

There are two services that provide run-time performance information for queues. One service retrieves performance information for a particular queue and the other service retrieves cumulative performance information for all queues in the system. Figure 196 contains a description of the parameters for each of these services.

Figure 197 contains an example that illustrates information retrieval for the queue called "my_queue."

When this service is executed we would obtain the number of messages sent, messages received, queue empty suspensions, queue full suspensions, queue full errors, and thread suspension timeouts for this queue.

Semaphore Performance Information

There are two services that provide run-time performance information for counting semaphores. One service retrieves performance information for a particular semaphore and the other service retrieves cumulative performance information for all semaphores in the system. Figure 198 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	queue_ptr	Pointer to a queue
	messages_sent	Number of send requests for this queue
tx_queue_performance_	messages_received	Number of receive requests for this queue
info_get	empty_suspensions	Number of queue empty suspensions
	full_suspensions	Number of queue full suspensions
	full_errors	Number of queue full errors
	timeouts	Number of thread suspension timeouts for this queue
tx_queue_performance_ system_info_get	Parameters are identical to the tx_queue_performance_info_get service except that the pointer reference to a particular queue is not included. Furthermore, all parameters represent total counts for all queue attributes.	

Figure 196. Queue performance information parameters

Figure 197. Queue performance information retrieval

Figure 199 contains an example that illustrates information retrieval for the semaphore called "my_semaphore."

When this service is executed we would obtain the number of put requests, get requests, thread suspensions, and thread suspension timeouts for this semaphore.

Thread Performance Information

There are two services that provide run-time performance information for threads. One service retrieves performance information for a particular thread and the other service retrieves cumulative performance information for all threads in the system. Figure 203 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	semaphore_ptr	Pointer to a semaphore
	puts	Number of put requests for this semaphore
tx_semaphore_performance_ info_get	gets	Number of get requests for this semaphore
inio_get	suspensions	Number of thread suspensions for this semaphore
	timeouts	Number of thread suspension timeouts for this semaphore
tx_semaphore_performance_ system_info_get	Parameters are identical to the tx_semaphore_performance_info_get service except that the pointer reference to a particular semaphore is not included. Furthermore, all parameters represent total counts for all semaphore attributes.	

Figure 198. Semaphore performance information parameters

Figure 199. Semaphore performance information retrieval

Figure 200 contains an example that illustrates information retrieval for the thread called "my_thread."

```
TX_THREAD my_thread;
ULONG resumptions;
ULONG suspensions:
ULONG solicited_preemptions;
ULONG interrupt_preemptions;
ULONG priority inversions;
ULONG time_slices;
ULONG relinquishes;
ULONG timeouts:
ULONG wait_aborts;
TX THREAD *last preempted by;
/* Retrieve performance information on the previously created thread. */
status = tx_thread_performance_info_get(&my_thread, &resumptions,
       &suspensions, &solicited_preemptions, &interrupt_preemptions,
       &priority_inversions, &time_slices, &relinquishes, &timeouts,
       &wait aborts, &last preempted by);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

Figure 200. Thread performance information retrieval

Figure 201 contains sample performance information for *speedy_thread* in the first sample system that appears in Chapter 2. These results were produced after the sample system executed for 1,000 timer ticks.

thread resumptions	231
thread suspensions	231
solicited_preemptions	0
interrupt_preemptions	0
priority_inversions	47
time_slices	0
timeouts	0
wait_aborts	0

Figure 201. Results of speedy_thread performance information

The performance results show that after the system executed for 1,000 timer ticks, speedy_thread had 231 thread suspensions and resumptions. The suspensions occurred as a result of the sleep service invocations when speedy_thread was placed on the suspension list. The resumptions occurred when the sleep time expired and speedy_thread was placed back on the ready list. The 47 priority inversions occurred as a result of speedy_thread attempting to gain ownership of the mutex when slow_thread owned it.

Timer Performance Information

There are two services that provide run-time performance information for application timers. One service retrieves performance information for a particular timer and the other service retrieves cumulative performance information for all timers in the system. Figure 202 contains a description of the parameters for each of these services.

Performance Information Service	Parameter	Description
	activates	Number of activation requests
	reactivates	Number of automatic reactivations
tx_timer_performance_	deactivates	Number of deactivation requests
info_get	expirations	Number of expirations
	expiration_adjusts	Number of internal expiration adjustments
tx_timer_performance_ system_info_get	Parameters are identical to the tx_timer_performance_info_get service except that the pointer reference to a particular timer is not included. Furthermore, all parameters represent total counts for all timer attributes.	

Figure 202. Timer performance information parameters

Performance Information Service	Parameter	Description
	thread_ptr	Pointer to a thread
	resumptions	Number of resumptions
	suspensions	Number of suspensions
	solicited_preemptions	Number of solicited preemptions
to the seed to enforce and	interrupt_preemptions	Number of interrupt preemptions
tx_thread_performance_ info_get	priority_inversions	Number of priority inversions
##IIO_got	time_slices	Number of time-slices
	relinquishes	Number of relinquishes
	timeouts	Number of thread suspension timeouts for this thread
	wait_aborts	Number of wait aborts

	last_preempted_by	Pointer to thread that last preempted this thread
	resumptions	Number of resumptions
	suspensions	Number of suspensions
	solicited_preemptions	Number of solicited preemptions
	interrupt_preemptions	Number of interrupt preemptions
	priority_inversions	Number of priority inversions
	time_slices	Number of time-slices
	relinquishes	Number of relinquishes
tx_thread_performance_ system_info_get	timeouts	Number of thread suspension timeouts for this thread
	wait_aborts	Number of wait aborts
	non_idle_returns	Number of times a thread returns to the system and another thread is ready to execute
	idle_returns	Number of times a thread returns to the system and no other thread is ready to execute

Figure 203. Thread performance information parameters

Figure 204 contains an example that illustrates information retrieval for the timer called "my_timer."

Figure 204. Timer performance information retrieval

When this service is executed we would obtain the number of activation requests, automatic reactivations, deactivation requests, expirations, and internal expiration adjustments for this application timer.

Key Terms and Phrases

block pool performance information byte pool performance information event flags group event-chaining event flags performance information event-chaining multiple object suspension mutex performance information notification callback function performance metrics queue event-chaining queue performance information semaphore event-chaining semaphore performance information thread performance information timer performance information

Chapter 13

Case Study: Designing a

Multithreaded System

Introduction

The purpose of this chapter is to develop a case study based on an application that could use the Azure RTOS ThreadX RTOS. The application we will consider is a real-time video/audio/motion (VAM) recording system that could be useful for numerous commercial motorized vehicle fleets around the world.⁵⁸

The VAM system features a small recording device that could be attached to a vehicle's windshield directly behind the rear-view mirror to avoid intrusion into the driver's field of vision. When triggered by an accident or unsafe driving, the VAM system automatically records everything the driver sees and hears in the 12 seconds preceding and the 12 seconds following the event. Events are stored in the unit's digital memory, along with the level of G-forces on the vehicle. In the event of an accident, unsafe driving, warning, or other incident, the VAM system provides an objective, unbiased account of what actually happened.

To complete the system, there should be a driving feedback system that downloads the data from the VAM system unit and provides playback and analysis. This system could also be used to create a database of incidents for all the drivers in the vehicle fleet. We will not consider that system; instead, we will focus on the capture of real-time data for the VAM system unit.

_

 $^{^{58}}$ The VAM system is a generic design and is not based on any actual implementation.

As noted earlier, most of the VAM unit could be located behind the rear-view mirror, so it would not obscure the vision of the driver. The unit would have to be installed so that the lenses have a clear forward view and rear view. The system includes a readily accessible *emergency button* so the driver can record an unusual, serious, or hazardous incident whenever necessary. The VAM system is constantly recording everything the driver sees, hears, and feels. That is, the VAM system records all visual activities (front and rear of the vehicle), audible sounds, and G-forces.

As an illustration of how the VAM system could be used, consider the following scenario. A driver has been inattentive and has failed to stop at a red traffic light. By the time the driver realizes the error, the vehicle has already entered the intersection and is headed toward an oncoming vehicle. The driver vigorously applies the brakes and swerves to the right. Typical G-forces for this incident are about -0.7 (forward) and +0.7 (side). Thus, the VAM system detects this incident and records it as an unsafe driving event in the protected memory.

When we download and analyze the data from the VAM system, we should be able to clearly see that the driver ran a red light and endangered passengers and other people on the highway, as well as the vehicle itself. The driver's employer would have been legally liable for the driver's actions if this incident had resulted in a collision.

In this scenario, no collision resulted from this incident. However, this recording would show that this driver was clearly at fault and perhaps needs some refresher training. Figure 205 illustrates the G-forces that can be detected, where the front of the vehicle appears at the top of the illustration.

256




Figure 205. Directions of G-forces

The system stores the 24 seconds of video, audio, and motion recording that surround the time of this incident in protected memory and illuminates a red light that indicates a driving incident has occurred. This light can be turned off only when the special downloading process has been performed; the driver cannot turn it off.

We will design the VAM system with the Azure RTOS ThreadX RTOS. For simplicity, we will omit certain details that are not important to the development of this system, such as file-handling details.⁵⁹

Statement of Problem

The VAM system is based on a set of sensors that measure G-forces experienced by a driver in a motorized vehicle. The system uses two sets of measurements. One set indicates forward or backward motion of the vehicle. Negative forward values indicate deceleration, or G-forces pushing against the driver's front side, while positive forward values indicate acceleration, or G-forces pushing against the driver's back. The other set of measurements indicates sideways motion of the vehicle. Negative side values indicate acceleration to the right, or G-forces pushing against the driver's left side, while positive side values indicate acceleration to the left, or G-forces pushing against the driver's right side. For example, if a vehicle makes a hard left turn, then the sensors produce a positive side value.

The VAM system detects and reports four categories of events. We assign each category a priority,⁶⁰ indicating the importance of the event. Figure 206 lists the event categories and their corresponding priorities.

Event	Priority
Crash	1
Unsafe Driving	2
Warning	3
Manually Triggered	4

Figure 206. Events and corresponding priorities

Event priorities serve two primary purposes. First, a priority indicates the severity of an event. Second, an event priority determines whether the current event can overwrite a previously stored event in the protected memory. For example, assume that the protected memory is full and the driver hits the *emergency button*, thereby creating a manually

⁵⁹ We could use a software companion to Azure RTOS ThreadX that could handle those file operations. That software product is *FileX*, but discussing it is beyond the scope of this book. ⁶⁰ This event priority is not the same as a Azure RTOS ThreadX thread or interrupt priority. We use event priorities to classify the relative importance of the events; we do not use them to affect the time when the events are processed.

triggered event. The only way that this event can be saved is if a previous manually triggered event has already been stored. Thus, a new event can overwrite a stored event of the same or lower priority, but it cannot overwrite a stored event with a higher priority.

If the G-force sensors detect an accident, unsafe driving, or warning, the VAM system generates an interrupt so that Azure RTOS ThreadX can take appropriate action and archive that event. Figure 207 contains a graphical representation of the G-forces in this system, in which the event labeled by the letter "W" is a warning event.

The driver may hit the *emergency button* at any time to generate an interrupt, signifying a manually triggered event.




Figure 207. Graphical classification of events by G-forces

Figure 208 contains the actual G-force values that are used to detect and report these events. We assume symmetry in how we classify forward and side G-forces, but we could easily modify that assumption without affecting our design.

Event	Forward G-Force	Side G-Force
Crash	+1.6 ≤ Forward	+1.6 ≤ Side
Unsafe Driving	+1.6 > Forward >= +0.7	+1.6 > Side >= +0.7
Warning	+0.7 > Forward >= +0.4	+0.7 > Side >= +0.4
Normal Driving	+0.4 > Forward > -0.4	+0.4 > Side > -0.4
Warning	-0.4 >= Forward > -0.7	-0.4 >= Side > -0.7
Unsafe Driving	-0.7 >= Forward > -1.6	-0.7 >= Side > -1.6
Crash	-1.6 >= Forward	-1.6 >= Side

Figure 208. G-Forces and event classifications

To add some perspective about G-forces, consider a vehicle accelerating from zero to 60 miles per hour (0 to 96 kilometers/hour) in six seconds. This produces a G-force of about 0.4—not enough to trigger an unsafe incident report, but enough to trigger a warning event. However, if a driver is applying "hard braking" to a vehicle, it could produce a G-force of about 0.8, which would trigger an unsafe driving event. If a vehicle crashes into a solid wall while traveling at 62 mph (100 km/hr), this produces a G-force of almost 100!

The VAM system uses two nonvolatile memory systems: a temporary memory system and a protected memory system. The protected memory system stores only detected or manually triggered incidents, while the other system is a temporary memory that records video, audio, and G-forces. It's not necessary to retain ordinary driving activities, so the temporary memory system is overwritten after some period of time, depending on the size of the temporary memory. As noted previously, the protected memory system stores all crash events, unsafe driving events, warnings, and manually triggered events, plus associated audio and video, as long as memory space is available. The protected memory system could be available in several different sizes, and our design will be able to accommodate those different memory sizes.

Analysis of the Problem

Figure 209 illustrates the temporary memory system used for continuous recording. This is actually a circular list where the first position logically follows the last position in the list.



Figure 209. Temporary memory (Circular list)

This system provides temporary storage that is overwritten repeatedly. Its main purpose is to provide data storage for an event that needs to be saved in the protected memory. When an event occurs, the 12 seconds preceding the event have already been stored in the temporary memory. After the 12 seconds of data following the event have been stored, the system stores this 24 seconds of data in protected memory.

The actual size of the temporary memory can be configured to the needs of the user. Figure 210 illustrates the protected memory that is used to store the automatically detected or manually triggered events.

Priority	Time	Data: Audio, Video, G-Forces
•		
•		
	•	•

Figure 210. Protected memory

The size of the protected memory can also be configured according to the needs of the user. We arbitrarily assume that this memory can store 16 events, although we can change this value without affecting our design. In addition to the actual data for the event, the protected memory must store the priority and time of the event's occurrence. This information is essential in the case where the protected memory becomes full and another event is detected or manually triggered. An event can never overwrite a higher-priority

event, but it can overwrite an event with the same or lower priority. Figure 211 summarizes the event overwrite rules.

Priority	Overwrite Rule When Protected Memory is Full
1	Overwrite the oldest event of Priority 4. If no Priority 4 event exists, overwrite the oldest event of Priority 3. If no Priority 3 event exists, overwrite the oldest event of Priority 2. If no Priority 2 event exists, overwrite the oldest event of Priority 1.
2	Overwrite the oldest event of Priority 4. If no Priority 4 event exists, overwrite the oldest event of Priority 3. If no Priority 3 event exists, overwrite the oldest event of Priority 2. If no Priority 2 event exists, do not save the new event.
3	Overwrite the oldest event of Priority 4. If no Priority 4 event exists, overwrite the oldest event of Priority 3. If no Priority 3 event exists, do not save the new event.
4	Overwrite the oldest event of Priority 4. If no Priority 4 event exists, do not save the new event.

Figure 211. Event overwrite rules

As stated previously, when the G-force sensors detect a crash, the system generates an interrupt with event priority 1. Unsafe driving events are logged as event priority 2, warnings as event priority 3, and manual events (pushing the *emergency button*) as event priority 4. Our objective is to respond to these events (which will appear to the system as interrupts), as well as to handle initialization and to process routine data.

Design of the System

Our design will be simplified and will concentrate on control issues. In this section, we will consider thread design issues, and public resources design. We will assume that other processes will handle⁶¹ the actual storing and copying of data.

⁶¹ This is a good use of a memory byte pool because space is allocated from the pool only once, thus eliminating fragmentation problems. Furthermore, the memory allocations are of different sizes.

Thread Design

We need a thread to perform various initialization duties such as setting pointers and variables, opening the files for the temporary memory and the protected memory, and establishing communication paths and buffers. We will assign the name *initializer* to this thread. Figure 212 depicts this thread.




Figure 212. Initialization of the VAM system

We need a thread to coordinate the capture and storage of data from the VAM system unit to the temporary memory. This thread manages the transfer of audio, video, and G-force data from the VAM system unit to an internal buffer, and then to the temporary memory. We will assign the name *data_capture* to this thread. Figure 213 illustrates this thread's operation.




Figure 213. Capturing data from the VAM unit




Figure 214. Overview of event interrupts and data recording

We need four ISRs to handle the detected and triggered events. We need one message queue called *event_notice* to store information about an event until the copying process begins. We also need one thread to process the copying of data from the temporary memory to the protected memory. We will assign the name *event_recorder* to this thread. This thread is activated 12 seconds after an event has been detected. At this time, the temporary memory contains the 12 seconds of data preceding the event and 12 seconds of data following the event. The *event_recorder* thread then takes identifying information from the *event_notice* queue and then copies the audio, video, G-force, and timing data for this event from the temporary memory to the protected memory, including the event priority. If protected memory is full, the event *recorder thread* employs the overwrite rules shown in Figure 211.

We will use four timers to simulate the arrival of external interrupts for the detectable and triggered events. To simulate such an interrupt, the timer in question saves the thread context, invokes the corresponding ISR, and then restores the thread context. We will assign the names <code>crash_interrupt</code>, <code>unsafe_interrupt</code>, <code>warning_interrupt</code>, and <code>manual_interrupt</code> to these four timers. Figure 214 presents an overview of the interaction between the timers that simulate interrupts, their associated ISRs, the scheduling timers, and the event recorder thread that actually performs the copying.

Public Resources Design

We will use one mutex to provide protection for the protected memory while copying data from the temporary memory. To begin copying data, the *event_recorder* thread must obtain ownership of this mutex. We will assign the name *memory_mutex* to this mutex.

We need four application timers to schedule the copying of data from temporary memory to protected memory. When an event is detected, the corresponding application timer is activated and expires precisely 12 seconds later. At this point in time, the <code>event_recorder</code> thread begins copying data. We will assign the names <code>crash_timer</code>, <code>unsafe_timer</code>, <code>warning_timer</code>, and <code>manual_timer</code> to these four application timers. Figure 215 illustrates how these application timers generate interrupts and schedule the processing of events.

As illustrated by Figure 215, an event interrupt is simulated by one of the four timers created for this purpose. One of four corresponding ISRs is invoked and it sends event information to the message queue, activates one of four corresponding scheduling timers, and sets it to expire in 12 seconds. When that timer expires, it *resumes* the *event_recorder* thread, which should be in a suspended state unless it is in the process of copying information from temporary memory to protected memory.

When the <code>event_recorder</code> thread resumes execution, it takes one message from the queue. This message contains two pieces of information about an event: the frame index and the event priority. The frame index is a location in temporary memory that specifies where information about the event begins. The <code>event_recorder</code> thread then obtains the <code>memory_mutex</code> and if successful, proceeds to copy information from temporary memory to protected memory. When the thread completes copying, it releases the mutex and suspends itself.




Figure 215. Event processing

Figure 216 contains a summary of the public resources needed for this case study.

Public Resource	Type	Description
initializer	thread	perform initialization operations
data_capture	thread	perform routine capture of data to temporary memory
event_recorder	thread	copy event information from temporary memory to protected memory
event_notice	queue	message queue containing key information about detected or triggered events
memory_mutex	mutex	mutex to guard protected memory during copying
my_byte_pool	byte_pool	provide memory for thread stacks and message queue
crash_interrupt	timer	generate a simulated crash event interrupt at periodic intervals
unsafe_interrupt	timer	generate a simulated unsafe event interrupt at periodic intervals
warning_interrupt	timer	generate a simulated warning event interrupt at periodic intervals
manual_interrupt	timer	generate a simulated manually triggered event interrupt at periodic intervals
crash_copy_scheduler	timer	schedule the time at which copying of a crash event should begin
unsafe_copy_scheduler	timer	schedule the time at which copying of an unsafe event should begin
warning_copy_scheduler	timer	schedule the time at which copying of a warning event should begin
manual_copy_scheduler	timer	schedule the time at which copying of a manually triggered event should begin
stats_timer	timer	print system statistics at periodic intervals

Figure 216. Summary of public resources used for the VAM system

Figure 217 contains a summary of the definitions, arrays, and variables used. We will simulate the temporary memory file system and the protected memory file system with arrays.

The event counters in Figure 217 are used when printing periodic statistics about the state of the system. We also need a collection of functions to perform the actions of the timers and the threads. Figure 218 summarizes all thread entry functions and timer expiration functions used in this system.

We will develop the complete program for our system in the next section. We will develop the individual components of our system and then present a complete listing of the system in a later section.

Name	Type	Description
STACK_SIZE	define	represents the size of each thread stack
BYTE_POOL_SIZE	define	represents the size of the memory byte pool
MAX_EVENTS	define	represents the maximum number of events that can be stored in protected memory
MAX_TEMP_MEMORY	define	represents the maximum number of data frames that can be stored in temporary memory
temp_memory	ULONG	array representing temporary memory
protected_memory	ULONG	array representing protected memory
frame_data	ULONG	array representing information about an event
frame_index	ULONG	location in temporary memory where an event occurred
event_count	ULONG	number of entries in protected memory
num_crashes	ULONG	counter for the number of crash events
num_unsafe	ULONG	counter for the number of unsafe events
num_warning	ULONG	counter for the number of warning events
num_manual	ULONG	counter for the number of manual events

Figure 217. Definitions, arrays, and counters used in the VAM system

Function	Description

initializer_process	invoked by thread initializer; perform initialization operations
data_capture_process	invoked by thread data_capture; perform routine capture of data to temporary memory
event_recorder_process	invoked by thread event_recorder; copy event data from temporary memory to protected memory
crash_ISR	invoked by timer crash_interrupt when crash event detected; initiates crash event processing
unsafe_ISR	invoked by timer unsafe_interrupt when unsafe event detected; initiates unsafe event processing
warning_ISR	invoked by timer warning_interrupt when warning event detected; initiates warning event processing
manual_ISR	invoked by timer manual_interrupt when manual event triggered; initiates manual event processing

crash_copy_activate	invoked by timer crash_copy_scheduler 12 seconds after event occurrence; schedules event copying
unsafe_copy_activate	invoked by timer unsafe_copy_scheduler 12 seconds after event occurrence; schedules event copying
warning_copy_activate	invoked by timer warning_copy_scheduler 12 seconds after event occurrence; schedules event copying
manual_copy_activate	invoked by timer manual_copy_scheduler 12 seconds after event occurrence; schedules event copying
print_stats	invoked by timer print_stats; prints system statistics at periodic intervals

Figure 218. Entry and expiration functions used in the VAM system

Implementation

Our implementation will be simplified because we are primarily interested in developing a control structure for this system. Thus, we will omit all file-handling details, represent files as arrays, and simulate capture of data once per second. (An actual implemented system would capture data about 20 to 40 times per second.) For convenience, we will represent each clock timer-tick as one second.

```
VAM System - Trace of Event Activities Begins...
*Event**
           Time:
                    410
                           Count:
                                        Pri: 3
*Event**
           Time:
                    760
                                        Pri: 2
                           Count:
*Event**
           Time:
                    820
                                        Pri: 3
                           Count:
*Event**
                                        Pri: 4
           Time:
                    888
                           Count:
*** VAM System Periodic Event Summary
    Current Time:
      Number of Crashes:
                                   0
      Number of Unsafe Events:
                                   1
      Number of Warnings:
                                   2
      Number of Manual Events:
*** Portion of Protected Memory Contents
 Time
             Data
  410
           3
              4660
                    4660
                           4660
                                 4660
                                        4660
                                               4660
                                                        (etc.)
  760
              4660
                    4660
                           4660
                                 4660
                                        4660
                                               4660
                                                        (etc.)
  820
              4660
                    4660
                           4660
                                 4660
                                        4660
                                               4660
                                                        (etc.)
  888
              4660
                    4660
                           4660
                                 4660
                                               4660
                                        4660
                                                        (etc.
```

Figure 219 . Sample output produced by VAM system

For this system, we will display information on the screen to show when events are generated and how they are processed. We will also display summary information on a

periodic basis. Figure 219 contains sample diagnostic output for our system that we could use during development.

We will arbitrarily schedule a summary of system statistics every 1,000 timer-ticks. Note that in Figure 219, warning events occur at times 410 and 820. Recall that a warning event has priority 3. Also, an unsafe event occurs at time 760 and a manually triggered event occurs at time 888. When the system summary is displayed at time 1,000, we note that the four detected events have been stored in protected memory. The repeated data values of 4660 (or 0x1234) are used only to suggest the capture of data from the VAM unit.

We will use the same basic structure for the VAM system as we used for the sample programs in previous chapters. Figure 220 contains an overview of this structure.




Figure 220. Basic structure for the VAM system

We will begin by creating the declarations, definitions, and prototypes needed for our system. Figure 221 contains the first part of this section. The values we have chosen for the stack size, memory byte pool size, the size of the protected memory, and the size of the temporary memory can be modified if desired. Many of the entries in Figure 221 are definitions of public resources, such as threads, timers, the message queue, the mutex, and the memory byte pool. ⁶²

Microsoft

⁶² This is another good use of a memory byte pool because space is allocated from the pool only once, thus eliminating fragmentation problems. Furthermore, the memory allocations are of different sizes.

```
#include "tx_api.h"
#include <stdio.h>
#define STACK SIZE
                        1024
#define BYTE POOL SIZE 9120
#define MAX_EVENTS
                          16
#define MAX_TEMP_MEMORY
/* Define the Azure RTOS ThreadX object
control blocks */
TX THREAD
             initializer:
TX THREAD
             data capture:
TX THREAD event recorder:
TX_QUEUE
             event_notice;
TX_MUTEX
             memory_mutex;
TX_BYTE_POOL my_byte_pool;
TX TIMER
            crash interrupt;
TX_TIMER
            unsafe_interrupt;
TX_TIMER
            warning_interrupt;
TX_TIMER
            manual_interrupt;
TX TIMER
            crash_copy_scheduler;
TX TIMER
            unsafe copy scheduler:
TX_TIMER
            warning_copy_scheduler;
TX TIMER
            manual_copy_scheduler;
TX_TIMER
            stats timer;
```

Figure 221. Declarations and definitions — Part 1

Figure 222 contains the second part of the program section, devoted to declarations, definitions, and prototypes. We declare the counters, variables, and arrays for our system, as well as the prototypes for our thread entry functions, the timer expiration functions, and the function to display periodic system statistics.

```
/* Define thread and function prototypes. */
void initializer_process(ULONG);
void data_capture_process(ULONG);
void event_recorder_process(ULONG);
void crash_ISR(ULONG);
void unsafe_ISR(ULONG);
void warning_ISR(ULONG);
void manual_ISR(ULONG);
void crash_copy_activate(ULONG);
void unsafe_copy_activate(ULONG);
void warning_copy_activate(ULONG);
void warning_copy_activate(ULONG);
void manual_copy_activate(ULONG);
void print_stats(ULONG);#include "tx_api.h"
#include <stdio.h>
```

Figure 222. Declarations, definitions, and prototypes—Part 2

The two arrays declared in Figure 222 represent file systems that would be used in an actual implementation. The array named *temp_array* represents the temporary memory used by the system. As noted earlier, the primary purpose of temporary memory is to provide an ongoing repository of video, audio, and motion data. When an event is detected or manually triggered, the 12 seconds of data before and after that event are copied to protected memory. Temporary memory is overwritten repeatedly because it is limited in size. Figure 223 illustrates the organization of temporary memory.



Figure 223. Organization of temporary memory

The array named *protected_memory* represents the protected memory in our system. Each entry in this array represents an event that has occurred. Figure 223 illustrates the organization of protected memory. Each stored event contains the time the event occurred, the event priority, and the captured data for the event.

Event time	Event priority	24 second of data for event
Event time	Event priority	24 second of data for event
	•	
	•	
	•	
	Event priority	24 second of data for event

The size of the protected memory is relatively small and is specified as MAX_EVENT in Figure 221. Having a small size is reasonable because the number of vehicle events should also be relatively small.

The main entry point is the same as that used in all the sample systems in the preceding chapters. This is the entry into the Azure RTOS ThreadX kernel. Note that the call to tx_kernel_enter does not return, so do not place any processing after it. Figure 224 contains the main entry point for the VAM system.

Figure 224. The main entry point

The next portion of our system is the application definitions section, which we will divide into two parts. In the first part, we will define the public resources needed for our system. This includes the memory byte pool, the three threads, the nine timers, and the message queue. Figure 225 contains the first part of the applications definitions section.

This part of our system consists of the application definition function called tx_application_define. This function defines all the application resources in the system. This function has a single input parameter, which is the first available RAM address. This is typically used as a starting point for run-time memory allocations of thread stacks, queues, and memory pools.

The first declaration in Figure 225 is the following:

```
CHAR *byte pointer;
```

This pointer is used when allocating memory from the byte pool for the threads and for the message queue. We then create the memory byte pool, as follows:

We need to allocate stack space from the byte pool and create the *initializer* thread, as follows:

We assign the initializer thread the highest priority of the three threads in our system. This thread needs to perform its operations immediately, and then it terminates. The other two threads continue operating for the life of the system. We create the *data_capture* thread and the *event_recorder* thread in a similar fashion. However, we assign the *event_recorder* thread a higher priority than the *data_capture* thread because it is essential that the event recording operation be performed in a timely manner. Note that we use neither the time-slicing option nor the preemption-threshold option for any of these threads. However, the *event_recorder* thread is given the TX_DON'T_START option, but the other two threads are given the TX_AUTO_START option.

⁶³ The actual values of the priorities are not important, provided that the *initializer* thread has the highest priority, and the *event_recorder* thread has a higher priority than the *data_capture* thread.

```
Application Definitions
/* Define what the initial system looks like. */
void tx application define(void *first unused memory)
CHAR *byte_pointer;
/* Put system definition stuff in here, e.g., thread creates and other assorted create information.
/* Create a memory byte pool from which to allocate the thread stacks and the message queue.
tx byte pool create(&my byte pool, "my byte pool", first unused memory,
BYTE_POOL_SIZE);
/* Allocate the stack for the initializer thread. */
tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer, STACK_SIZE, TX_NO_WAIT);
/* Create the initializer thread. */
tx_thread_create(&initializer, "initializer", initializer_process, 0, byte_pointer, STACK_SIZE, 11,
11,
                TX_NO_TIME_SLICE, TX_AUTO_START);
/* Allocate the stack for the data capture thread. */
tx byte allocate(&my byte pool, (VOID **) &byte pointer, STACK SIZE, TX NO WAIT);
/* Create the data_capture thread. */
tx_thread_create(&data_capture, "data_capture", data_capture_process, 0, byte_pointer,
                STACK_SIZE, 15, 15, TX_NO_TIME_SLICE, TX_AUTO_START);
/* Allocate the stack for the event_recorder thread. */
tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer, STACK_SIZE, TX_NO_WAIT);
/* Create the event recorder thread. */
tx_thread_create(&event_recorder, "event_recorder", event_recorder_process, 0, byte_pointer,
                 STACK_SIZE, 12, 12, TX_NO_TIME_SLICE, TX_DONT_START);
```

Figure 225. Application definitions—Part 1

The second part of the applications definitions section appears in Figure 226; this part contains definitions of our timers and the message queue.

```
tx_timer_create (&warning_interrupt, "warning_interrupt", warning_ISR, 0x1234, 410, 410,
                TX_AUTO_ACTIVATE);
tx_timer_create (&manual_interrupt, "manual_interrupt", manual_ISR, 0x1234, 888, 888,
                TX_AUTO_ACTIVATE);
/* Create and activate the 4 timers to initiate data copying */
tx_timer_create (&crash_copy_scheduler, "crash_copy_scheduler", crash_copy_activate,
                0x1234, 12, 12, TX_NO_ACTIVATE);
tx_timer_create (&unsafe_copy_scheduler, "unsafe_copy_scheduler", unsafe_copy_activate,
               0x1234, 12, 12, TX_NO_ACTIVATE);
tx_timer_create (&warning_copy_scheduler, "warning_copy_scheduler", warning_copy_activate,
               0x1234, 12, 12, TX NO ACTIVATE);
tx_timer_create (&manual_copy_scheduler, "manual_copy_scheduler", manual_copy_activate,
                0x1234, 12, 12, TX_NO_ACTIVATE);
/* Create and activate the timer to print statistics periodically */
tx timer create (&stats timer, "stats timer", print stats, 0x1234, 1000, 1000,
                TX_AUTO_ACTIVATE);
/* Create the message queue that holds the indexes for all events. The frame_index is a position
 marker for the temp_memory array. When an event occurs, the event ISR sends the current
 frame_index and event priority to the queue to store crash event information. Allocate memory
 space for the queue, then create the queue. */
tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer, MAX_EVENTS*2*sizeof(ULONG),
                                TX_NO_WAIT);
tx_queue_create (&event_notice, "event_notice", TX_2_ULONG, byte_pointer,
                 MAX_EVENTS*2*sizeof(ULONG));
```

Figure 226. Application definitions—Part 2

We create nine timers and one message queue in Figure 226. There are four timers dedicated to simulating interrupts, four timers to schedule event recording, and one timer to display system statistics. We first create the *crash_interrupt* timer, which simulates crash events. We arbitrarily simulate crash events every 1,444 timer-ticks—recall that we simulate one second with one timer-tick. Following is the definition of the *crash_interrupt* timer.

The expiration function associated with the *crash_interrupt* timer is *crash_ISR*, which we will define in the next section of our system. This function is activated every 1,444 timerticks. We do not use a parameter in the expiration function, so we will specify an

arbitrary argument value when we create the timer—in this case, the value 0x1234. The *unsafe_interrupt* timer, the *warning_interrupt* timer, and the *manual_interrupt* timer are created in a similar manner. However, we specify different expiration values for each of these timers. Note that we give each of these timers the TX_AUTO_ACTIVATE option.

We create four timers to schedule the copying of an event from temporary memory to protected memory. We first create the *crash_copy_scheduler* timer as follows:

When an event is detected (or generated, in our system), the associated ISR activates the corresponding scheduling timer—note that the TX_NO_ACTIVATE option is specified for each of the scheduling timers. Each of the scheduling timers has an expiration value of 12 timer-ticks, so it will expire exactly 12 timer-ticks after an event has been detected. As before, we pass a dummy argument to the expiration function. The <code>unsafe_copy_scheduler</code> timer, the <code>warning_copy_scheduler</code> timer, and the <code>manual_copy_scheduler</code> timer are each created in a similar fashion.

The timer to print system statistics on a periodic basis is created as follows:

We create this timer with the TX_AUTO_ACTIVATE option, so it expires every 1,000 timer-ticks. When this timer does expire, it invokes the expiration function *print_stats*, which displays the summary statistics.

The last definition in Figure 226 creates the message queue *event_notice*. We must first allocate space from the memory byte pool for the message queue, and then create the queue. Following is the creation of this queue:

The expression

```
MAX EVENTS*2*sizeof(ULONG)
```

computes the amount of space needed by the message queue, based on the maximum number of events in protected memory, the size of each message, and the size of the ULONG data type. We use this same expression to specify the amount of space for the queue when it is created. The tx_byte_allocate service creates a block of bytes specified by this expression; the block pointer that receives the address of this block is pointed to by &byte_pointer. We specify the TX_NO_WAIT option as the wait option.⁶⁴

The TX_2_ULONG option specifies the size of each message in the queue. The location of memory space for the queues is pointed to by *byte_pointer*. Figure 227 illustrates the contents of the *event_notice* message queue.

The frame index contains the location in temporary memory where the event began. The event priority indicates the type of event that occurred.

The last portion of our system is the function definitions section, which we will divide into five parts. In the first part, we will define the *initializer* entry function, which performs basic initialization operations. The second part contains the definition of the *data_capture_process* entry function, which simulates data capture. The third part contains definitions of the *crash_ISR* expiration function and the *crash_copy_activate* expiration function. The fourth part contains the definition of the *event_recorder_process* entry function, which copies an event from temporary memory to protected memory. The fifth part contains the *print_stats* expiration function, which displays system statistics at periodic intervals.



Figure 227. Message queue event_notice

Figure 228 contains the definition for the *initializer* entry function. This is the first function that is executed. This function merely initializes the *frame_index* and *event_count* global variables. These variables point to the current position of temporary

⁶⁴ The TX_NO_WAIT option is the only valid wait option when the tx_byte_allocate service is called from initialization.

memory and protected memory, respectively. If an actual file system were used, the *initializer* function would have considerably more work to do.

```
/* Entry function definition of the initializer thread */

void initializer_process(ULONG thread_input)
{
    /* Perform initialization tasks
    Because we are using arrays to represent files, there is very little initialization to perform. We initialize two global variables that represent starting array indexes. */

printf("VAM System - Trace of Event Activities Begins...\n\n");
    event_count=0;
}
```

Figure 228. Function definitions Part 1—initializer entry function

Figure 229 contains the definition for the *data_capture_process* entry function. This function runs constantly and simulates the capture of data from the VAM unit every timer-tick. We will use the value 0x1234 to suggest data that is being captured and we will get the current value of the system clock. We will then store those two values in the *temp_memory* array, which represents the temporary memory file. The value of the *frame_index* is advanced by one during each timer-tick, and it wraps around to the beginning when it encounters the last position of the array.

Figure 230 contains definitions for the *crash_ISR* expiration function and the *crash_copy_activate* expiration function. These two functions are placed together because they are closely related to each other. The *crash_ISR* function sends the *frame_index* value and the priority (i.e., 1 for a crash) to the *event_notice* message queue. It then activates the *crash_copy_scheduler* timer, which expires in 12 seconds and then invokes the *crash_copy_activate* expiration function. The *crash_copy_activate* function resumes the *event_recorder* thread and then deactivates the *crash_copy_scheduler* timer. We do not show the corresponding expiration functions for the unsafe, warning, and manual events because they are quite similar. One difference is that different priority values are associated with these events.

```
/* Entry function definition of the data_capture thread */

void data_capture_process(ULONG thread_input)
{

/* Perform data capture from the VAM system to temporary memory. This function simulates the data capture operation by writing to an array, which represents a temporary memory file. For simplicity, we will write to the array once every timer-tick */

while (1) {

temp_memory[frame_index][0] = tx_time_get();

temp_memory[frame_index][1] = 0x1234;

frame_index = (frame_index + 1) % MAX_TEMP_MEMORY;

tx_thread_sleep(1);

}
```

Figure 229. Function definitions Part 2—data_capture_process entry function

```
"* crash event detection and processing ********/
/* Timer function definition for simulated crash interrupt. This is a simulated ISR-an
 actual ISR would probably begin with a context save and would end with a
 context restore. */
void crash ISR (ULONG timer input)
 ULONG frame_data[2]; frame_data[0] = frame_index; frame_data[1] = 1;
 num crashes++;
/* Activates timer to expire in 12 seconds - end of event */
/* Put frame_index and priority on queue for crash events */
 tx queue send (&event notice, frame data, TX NO WAIT);
 tx timer activate (&crash copy scheduler);
/* Timer function definition for timer crash_copy_scheduler, which resumes
  thread that performs recording of crash data */
void crash_copy_activate (ULONG timer_input)
   /* resume recorder thread to initiate data recording */
   tx thread resume(&event recorder);
   tx_timer_deactivate (&crash_copy_scheduler);
```

Figure 230. Function definitions Part 3—crash_ISR and crash_copy_scheduler expiration functions

Figure 231 contains the definition for the *event_recorder_process* entry function, which is part of the *event_recorder thread*. When this thread is resumed by one of the scheduler timers, this function copies a crash event, an unsafe event, a warning event, or a manual event from temporary memory to protected memory. Following are the operations performed by this function:

- 1. Get the first message on the queue.
- 2. Extract the frame index and priority for the event from the message.

- 3. Get the frame in temporary memory (containing the time and captured data) pointed to by the frame index.
- 4. Compute the copy starting point, which is 12 seconds before the current frame.
- 5. If protected memory is not full, do the following:
 - a. Get the mutex.
 - b. Store the event time and priority in the next available position in protected memory.
 - c. Store the 24 seconds of frame data from temporary memory to protected memory.
 - d. Increment the event counter.
 - e. Release the mutex.

```
/* Entry function definition of thread event_record ****/
void event_recorder_process(ULONG thread_input)
 ULONG frame, event_priority, event_time, index, frame_data[2];
 while (1)
 /* Copy an event from temporary memory to protected memory. Get frame_index from
   event message queue and copy 24 frames from temp_memory to protected_memory. */
   tx queue receive (&event notice, frame data, TX NO WAIT);
   /* Store event time and event priority in protected memory */
   frame = frame_data[0]; event_priority = frame_data[1]; event_time =
temp_memory[frame][0];
   printf("**Event** Time: %5lu Count: %2lu Pri: %lu", event_time, event_count,
event_priority);
   if (event count < MAX EVENTS)
     tx_mutex_get (&memory_mutex, TX_WAIT_FOREVER);
     protected_memory[event_count][0] = event_time;
     protected_memory[event_count][1] = event_priority;
     if (frame < 11) frame = (MAX_TEMP_MEMORY-1) - (frame_index+1);
     for (index=0; index<24; index++)
      protected_memory[event_count][index+2] = temp_memory[frame][1];
      frame = (frame+1) % MAX_TEMP_MEMORY;
```

```
tx_mutex_put (&memory_mutex);
    event_count++;
}
else printf(" **not processed**");
printf ("\n");
tx_thread_suspend(&event_recorder);
}
}
```

Figure 231. Function definitions Part 4—event recorder entry function

We will not implement the overwrite rules in the case when protected memory is full. These rules depend on the actual file system used, and are left as an exercise for the reader. When protected memory is full, we will display a message to that effect, but will not copy the event.

Figure 232 contains the definition for the print_stats expiration function, which is part of the timer called stats_timer. This timer expires every 1,000 timer-ticks and the function displays a statistical summary of the system.

```
/********************
void print_stats (ULONG invalue)
   %lu\n", tx_time_get());
%lu\n", num_crashes);
                    Number of Unsafe Events: %lu\n", num_crashes);
Number of Warnings: %lu\n", num_unsafe);
Number of Warnings: %lu\n", num_warning);
   prịntf(̀"
                    Number of Unsafe Events: %lu\n", num_unsafe);
Number of Warnings: %lu\n", num_warning);
Number of Manual Events: %lu\n", num_manual);
   prịntf("
   printf("
   if (event_count > 0)
      printf("\n\n**** Portion of Protected Memory Contents\n\n");
printf("%6s%6s\n", "Time", "Pri", "Data");
       for (row = 0; row < event_count; row++)
          for (col = 0; col < 8; col++)
             printf("%6lu", protected_memory[row][col]);
ntf(" (etc.)\n");
          printf("
       }
   if (event_count >= MAX_EVENTS)
                   Warning: Protected Memory is full...\n\n");
```

Figure 232. Function definitions Part 5—print_stats expiration function

We have now discussed most of the components of the VAM system. The next section contains a complete listing of this system.

Listing of VAM System

```
001 /* 13_case_study.c
002
003
       Implement a simplified version of a real-time, video/audio/motion (VAM)
004
       recording system.
005
006
       Create three threads named: initializer, data_capture, event_recorder
007
       Create one byte pool for thread stacks and message queue: my_byte_pool
800
       Create one mutex to guard protected memory: memory_mutex
009
       Create one message queue to store event notices: event_notice
010
       Create nine application timers named: crash_interrupt, unsafe_interrupt,
011
        warning_interrupt, manual_interrupt, crash_copy_scheduler,
012
        unsafe_copy_scheduler, manual_copy_scheduler, stats_timer
013
014
       For this system, assume that each timer-tick represents one second */
015
    /************************************/
016
017
          Declarations, Definitions, and Prototypes
    /****************/
018
019
020 #include "tx_api.h"
021 #include <stdio.h>
022
023 #define STACK_SIZE
                                 1024
024 #define
              BYTE_POOL_SIZE
                                 9120
025 #define
              MAX_EVENTS
                                  16
                                  200
026 #define
              MAX_TEMP_MEMORY
027
028
029 /* Define the Azure RTOS ThreadX object control blocks */
030
031 TX_THREAD
                  initializer;
032 TX_THREAD
                  data_capture;
033 TX_THREAD
                  event_recorder;
034
```

```
035 TX_QUEUE
                   event_notice;
036
037
    TX_MUTEX
                   memory_mutex;
038
    TX_BYTE_POOL
                  my_byte_pool;
039
040 TX_TIMER
                   crash_interrupt;
041 TX_TIMER
                   unsafe_interrupt;
042 TX_TIMER
                   warning_interrupt;
                   manual_interrupt;
043 TX_TIMER
044
045 TX_TIMER
                   crash_copy_scheduler;
046 TX_TIMER
                   unsafe_copy_scheduler;
047 TX_TIMER
                   warning_copy_scheduler;
048 TX_TIMER
                   manual_copy_scheduler;
049
    TX_TIMER
                   stats_timer:
050
051
052
    /* Define the counters and variables used in the VAM system */
053
054
    ULONG num_crashes=0, num_unsafe=0, num_warning=0, num_manual=0;
055
    ULONG frame_index, event_count, frame_data[2];
056
057
                                                                   */
    /* Define the arrays used to represent temporary memory
    /* and protected memory. temp_memory contains pair of data
                                                                   */
059 /* in the form time-data and protected_memory contains rows
                                                                   */
060 /* of 26 elements in the form time-priority-data-data-data...
                                                                   */
    /* The working index to temp_memory is frame_index and the
                                                                   */
    /* working index to protected_memory is event_count.
                                                                   */
062
063
064
     ULONG temp_memory[MAX_TEMP_MEMORY][2],
065
            protected_memory[MAX_EVENTS][26];
066
    /* Define thread and function prototypes.
067
068
069
    void initializer_process(ULONG);
070 void data_capture_process(ULONG);
071 void event_recorder_process(ULONG);
    void crash_ISR(ULONG);
073
    void unsafe_ISR(ULONG);
```

```
074 void warning_ISR(ULONG);
075 void manual_ISR(ULONG);
076 void crash_copy_activate(ULONG);
077 void unsafe_copy_activate(ULONG);
078 void warning_copy_activate(ULONG);
079 void manual_copy_activate(ULONG);
   void print_stats(ULONG);
081
082
083
   /*********************************
084
                   Main Entry Point
    /*****************/
085
086
087
    /* Define main entry point. */
088
   int main()
089
090
    {
091
092
      /* Enter the Azure RTOS ThreadX kernel. */
      tx_kernel_enter();
093
094 }
095
096
097
098
    /*****************
099
                 Application Definitions
    /****************/
100
101
102
    /* Define what the initial system looks like. */
103
104
105
   void tx_application_define(void *first_unused_memory)
106
    {
107
108
           *byte_pointer;
   CHAR
109
110
      /* Put system definition stuff in here, e.g., thread creates
         and other assorted create information. */
111
112
```

```
/* Create a memory byte pool from which to allocate
113
114
           the thread stacks. */
115
        tx_byte_pool_create(&my_byte_pool, "my_byte_pool",
           first_unused_memory, BYTE_POOL_SIZE);
116
117
118
        /* Allocate the stack for the initializer thread. */
119
        tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer,
120
           STACK_SIZE, TX_NO_WAIT);
121
122
        /* Create the initializer thread. */
123
        tx_thread_create(&initializer, "initializer",
124
                         initializer_process, 0,
125
                         byte_pointer, STACK_SIZE, 11, 11,
126
                         TX_NO_TIME_SLICE, TX_AUTO_START);
127
        /* Allocate the stack for the data_capture thread. */
128
129
        tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer,
130
           STACK_SIZE, TX_NO_WAIT);
131
        /* Create the data_capture thread. */
132
       tx_thread_create(&data_capture, "data_capture",
133
134
                         data_capture_process, 0,
                         byte_pointer, STACK_SIZE, 15, 15,
135
                         TX_NO_TIME_SLICE, TX_AUTO_START);
136
137
138
        /* Allocate the stack for the event_recorder thread. */
139
        tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer,
140
           STACK_SIZE, TX_NO_WAIT);
141
        /* Create the event_recorder thread. */
142
        tx_thread_create(&event_recorder, "event_recorder",
143
144
                         event_recorder_process, 0,
145
                         byte_pointer, STACK_SIZE, 12, 12,
146
                         TX_NO_TIME_SLICE, TX_DONT_START);
147
        /* Create and activate the 4 timers to simulate interrupts */
148
       tx_timer_create (&crash_interrupt, "crash_interrupt", crash_ISR,
149
                         0x1234, 1444, 1444, TX_AUTO_ACTIVATE);
150
        tx_timer_create (&unsafe_interrupt, "unsafe_interrupt", unsafe_ISR,
151
```

```
152
                         0x1234, 760, 760, TX_AUTO_ACTIVATE);
153
        tx_timer_create (&warning_interrupt, "warning_interrupt", warning_ISR,
                         0x1234, 410, 410, TX_AUTO_ACTIVATE);
154
        tx_timer_create (&manual_interrupt, "manual_interrupt", manual_ISR,
155
156
                         0x1234, 888, 888, TX_AUTO_ACTIVATE);
157
158
        /* Create and activate the 4 timers to initiate data copying */
        tx_timer_create (&crash_copy_scheduler, "crash_copy_scheduler",
159
160
                         crash_copy_activate, 0x1234, 12, 12, TX_NO_ACTIVATE);
        tx_timer_create (&unsafe_copy_scheduler, "unsafe_copy_scheduler",
161
                         unsafe_copy_activate, 0x1234, 12, 12, TX_NO_ACTIVATE);
162
163
        tx_timer_create (&warning_copy_scheduler, "warning_copy_scheduler",
164
                         warning_copy_activate, 0x1234, 12, 12, TX_NO_ACTIVATE);
165
        tx_timer_create (&manual_copy_scheduler, "manual_copy_scheduler",
166
                         manual_copy_activate, 0x1234, 12, 12, TX_NO_ACTIVATE);
167
168
        /* Create and activate the timer to print statistics periodically */
169
        tx_timer_create (&stats_timer, "stats_timer", print_stats,
170
                         0x1234, 1000, 1000, TX_AUTO_ACTIVATE);
171
172
       /* Create the message queue that holds the frame_indexes for all events. */
173
       /* The frame_index is a position marker for the temp_memory array.
                                                                        */
174
       /* Whenever an event occurs, the event ISR sends the current frame_index */
175
       /* and event priority to the queue for storing crash event information.
                                                                        */
176
       /* First, allocate memory space for the queue, then create the queue.
                                                                        */
177
       tx_byte_allocate(&my_byte_pool, (VOID **) &byte_pointer,
178
                         MAX_EVENTS*2*sizeof(ULONG), TX_NO_WAIT);
       tx_queue_create (&event_notice, "event_notice", TX_2_ULONG,
179
                         byte_pointer, MAX_EVENTS*2*sizeof(ULONG));
180
181
182
    }
183
184
    /******************
185
                        Function Definitions
186
     /********************
187
188
189
190 /* Entry function definition of the initializer thread */
```

```
191
192
   void initializer_process(ULONG thread_input)
    {
193
194 /* Perform initialization tasks
                                                           */
195 /* Because we are using arrays to represent files, there is */
   /* very little initialization to perform. We initialize two */
   /* global variables that represent starting array indexes.
198
       printf("VAM System - Trace of Event Activities Begins...\n\n");
199
       frame_index=0:
200
       event_count=0;
201 }
202
   203
    /* Entry function definition of the data_capture thread */
205
206 void
           data_capture_process(ULONG thread_input)
207
   {
208 /* Perform data capture from the VAM system to temporary memory */
209 /* This function simulates the data capture operation by writing */
210 /* to an array, which represents a temporary memory file. For
    /* simplicity, we will write to the array once every timer-tick
211
212
       while (1) {
         temp_memory[frame_index][0] = tx_time_get();
213
         temp_memory[frame_index][1] = 0x1234;
214
         frame_index = (frame_index + 1) % MAX_TEMP_MEMORY;
215
216
         tx_thread_sleep(1);
217
       }
218 }
219
220
    /********************
221
    /****** crash event detection and processing *******/
    /********************
223
224
225
   /* Timer function definition for simulated crash interrupt
                                                               */
   /* This is a simulated ISR -- an actual ISR would probably begin */
227
    /* with a context save and would end with a context restore.
228
229 void
           crash_ISR (ULONG timer_input)
```

```
230 {
231
       ULONG frame_data[2];
232
       frame_data[0] = frame_index;
233
       frame_data[1] = 1;
234
       num_crashes++;
235
   /* Activates timer to expire in 12 seconds - end of event */
   /* Put frame_index and priority on queue for crash events */
237
       tx_queue_send (&event_notice, frame_data, TX_NO_WAIT);
238
       tx_timer_activate (&crash_copy_scheduler);
239 }
241 /* Timer function definition for timer crash_copy_scheduler,
    /* which resumes thread that performs recording of crash data */
243
244
   void
           crash_copy_activate (ULONG timer_input)
   {
245
246
         /* resume recorder thread to initiate data recording */
247
         tx_thread_resume(&event_recorder);
248
         tx_timer_deactivate (&crash_copy_scheduler);
249 }
250
    252
    /**** Entry function definition of thread event_recorder ****/
    /***********************************
253
254
255
    void
           event_recorder_process(ULONG thread_input)
256
257
       ULONG frame, event_priority, event_time, index, frame_data[2];
       while (1)
258
259
       /* Copy an event from temporary memory to protected memory.
260
261
       /* Get frame_index from event message queue and copy 24 frames */
       /* from temp_memory to protected_memory.
                                                                */
262
263
         tx_queue_receive (&event_notice, frame_data, TX_NO_WAIT);
         /* Store event time and event priority in protected memory */
264
265
         frame
                       = frame_data[0];
266
         event_priority = frame_data[1];
267
         event_time
                       = temp_memory[frame][0];
         printf("**Event**
                           Time: %5lu
                                      Count: %2lu Pri: %lu",
268
```

```
269
                 event_time, event_count, event_priority);
270
          if (event_count < MAX_EVENTS)</pre>
271
          {
272
             tx_mutex_get (&memory_mutex, TX_WAIT_FOREVER);
273
             protected_memory[event_count][0] = event_time;
274
             protected_memory[event_count][1] = event_priority;
275
             if (frame < 11)
276
                frame = (MAX_TEMP_MEMORY-1) - (frame_index+1);
277
             for (index=0; index<24; index++)</pre>
278
             {
279
                protected_memory[event_count][index+2] = temp_memory[frame][1];
280
                frame = (frame+1) % MAX_TEMP_MEMORY;
281
             }
282
             tx_mutex_put (&memory_mutex);
283
             event_count++;
          }
284
285
          else printf(" **not processed**");
          printf ("\n");
286
287
          tx_thread_suspend(&event_recorder);
       }
288
289 }
290
    291
    /****** unsafe event detection and processing *******/
    /**********************************
293
294
295
    /* Timer function definition for simulated unsafe interrupt
                                                                   */
    /* This is a simulated ISR -- an actual ISR would probably begin */
    /* with a context save and would end with a context restore.
297
                                                                   */
298
299 void
            unsafe_ISR (ULONG timer_input)
300
    {
301
       ULONG frame_data[2];
       frame_data[0] = frame_index;
302
       frame_data[1] = 2;
303
304
       num_unsafe++;
305 /* Activates timer to expire in 12 seconds - end of event */
    /* Put frame_index and priority on queue for unsafe events */
306
307
       tx_queue_send (&event_notice, frame_data, TX_NO_WAIT);
```

```
308
      tx_timer_activate (&unsafe_copy_scheduler);
309 }
311 /* Timer function definition for timer unsafe_copy_scheduler,
312
    /* which resumes thread that performs recording of unsafe data */
313
314
   void
           unsafe_copy_activate (ULONG timer_input)
    {
315
316
         /* resume event_recorder thread to initiate data recording */
317
         tx_thread_resume(&event_recorder);
         tx_timer_deactivate (&unsafe_copy_scheduler);
318
319 }
320
321
    /***********************************
322
    /****** warning event detection and processing *******/
323
    /************************
324
325
   /* Timer function definition for simulated warning interrupt
326
                                                             */
   /* This is a simulated ISR -- an actual ISR would probably begin */
    /* with a context save and would end with a context restore.
328
                                                             */
329
330 void
           warning_ISR (ULONG timer_input)
331 {
332
      ULONG frame_data[2];
      frame_data[0] = frame_index;
333
334
      frame_data[1] = 3;
335
      num_warning++;
   /* Activates timer to expire in 12 seconds - end of event
    /* Put frame_index and priority on gueue for warning events */
      tx_queue_send (&event_notice, frame_data, TX_NO_WAIT);
338
339
      tx_timer_activate (&warning_copy_scheduler);
340 }
342 /* Timer function definition for timer warning_copy_scheduler,
                                                             */
   /* which resumes thread that performs recording of warning data
343
344
           warning_copy_activate (ULONG timer_input)
345 void
346 {
```

```
347
         /* resume event_recorder thread to initiate data recording */
348
         tx_thread_resume(&event_recorder);
         tx_timer_deactivate (&warning_copy_scheduler);
349
350 }
351
352
    /********************
353
354 /****** manual event detection and processing ********/
    /**********************************
355
356
357 /* Timer function definition for simulated manual interrupt
                                                              */
   /* This is a simulated ISR -- an actual ISR would probably begin */
   /* with a context save and would end with a context restore.
360
361 void
           manual_ISR (ULONG timer_input)
362 {
363
      ULONG frame_data[2];
      frame_data[0] = frame_index;
364
365
      frame_data[1] = 4;
366
      num_manual++;
367 /* Activates timer to expire in 12 seconds - end of event */
   /* Put frame_index and priority on queue for manual events */
       tx_queue_send (&event_notice, frame_data, TX_NO_WAIT);
369
370
       tx_timer_activate (&manual_copy_scheduler);
371 }
/* Timer function definition for timer manual_copy_scheduler,
373
    /* which resumes thread that performs recording of manual data */
374
375
376 void
           manual_copy_activate (ULONG timer_input)
   {
377
      /* resume event_recorder thread to initiate data recording */
378
379
       tx_thread_resume(&event_recorder);
       tx_timer_deactivate (&manual_copy_scheduler);
380
381 }
382
383
384 /**********************************
385 /******* print statistics at specified times *********/
```

```
386
    387
    void print_stats (ULONG invalue)
388
389
390
       UINT row, col;
391
       printf("\n\n**** VAM System Periodic Event Summary\n\n");
392
       printf("
                  Current Time:
                                              %lu\n", tx_time_get());
393
       printf("
                     Number of Crashes:
                                              %lu\n", num_crashes);
394
       printf("
                     Number of Unsafe Events: %lu\n", num_unsafe);
395
       printf("
                     Number of Warnings:
                                              %lu\n", num_warning);
396
       printf("
                     Number of Manual Events: %lu\n", num_manual);
397
398
       if (event_count > 0)
399
       {
          printf("\n\n**** Portion of Protected Memory Contents\n');
400
          printf("%6s%6s%6s\n", "Time", "Pri", "Data");
401
402
          for (row = 0; row < event_count; row++)</pre>
403
404
             for (col = 0; col < 8; col++)
                printf("%6lu", protected_memory[row][col]);
405
             printf("
                        (etc.)\n");
406
          }
407
       }
408
409
       if (event_count >= MAX_EVENTS)
                    Warning: Protected Memory is full...\n\n");
410
          printf("
411 }
```

Overview

This case study provides an excellent overview of developing a system with Azure RTOS ThreadX. We used a variety of Azure RTOS ThreadX services, including the following:

- application timers
- threads
- message queue
- mutex
- memory byte pool

This case study depends heavily on the use of application timers. One reason for using so many timers is because we need to schedule the copying of data from the temporary memory to the protected memory whenever any one of four events occurs. Our design provides the ability to record several events within each 24-second time frame, rather than just one. Application timers play a major role in providing this feature. We also used application timers to simulate interrupts that signify the occurrence of events, and we used one timer to display periodic system statistics.

We used only three threads for this case study. The initializer thread initializes the system, the data_capture thread coordinates the capture of data from the VAM unit to temporary memory, and the event_recorder thread copies event data from temporary memory to protected memory. We created the data_capture thread with the TX_AUTO_START option, so it would become ready immediately after initialization. We created the event_recorder thread with the TX_DON'T_START option, which means it cannot start until it is resumed by an application timer. When the event_recorder thread completes its data copying operation, it suspends itself and remains suspended until it is resumed by a timer.

We used one message queue to store information about events that had occurred. When the event_recorder thread is resumed, it takes the first message from the front of the message queue. This message contains information about the event data being copied from temporary memory to protected memory. Although we used only one message queue in this case study, typical applications tend to use a number of message queues.

We used one mutex to ensure that the event_recorder thread had exclusive access to protected memory before beginning the copying operation.

We used one memory byte pool to provide space for the thread stacks and for the message queue. This application is an excellent use of a memory byte pool because we need memory space of different sizes for the thread stacks and the message queue. Furthermore, these entities remain in existence for the life of the system, so there is no possibility of the fragmentation problems that can occur when bytes are repeatedly allocated and released.

We also demonstrated several examples of communication between resources. For example, timers send data to the message queue, a thread receives data from the message

queue, a timer activates another timer, a timer resumes a thread, and a thread obtains ownership of a mutex. All these entities interact to form an efficient and effective system.

Appendices

This series of appendices comprise a reference manual for Azure RTOS ThreadX.⁶⁵ Every service is described here, including purpose, parameters, return values, and examples. Following is a list of the services discussed in the appendices. Appendix K contains the *Azure RTOS ThreadX* API, which summarizes all the service calls.

- A Memory Block Pool Services
- B Memory Byte Pool Services
- C Event Flags Group Services
- D Interrupt Control Service
- E Mutex Services
- F Message Queue Services
- G Counting Semaphore Services
- H Thread Services
- I Time Services
- J Application Timer Services
- K Azure RTOS ThreadX API

Appendices A through J follow a common format as follows:

Service	Service name and brief description
Prototype	Prototype showing service name, parameter order, and data types
Description	Detailed information about the service
Input Parameters	Name and description of parameters that provide data to the service. (Note that the parameters may not be presented in the same order as the prototype, which specifies the correct order.)

⁶⁵ Azure RTOS ThreadX is a registered trademark of Microsoft. The Azure RTOS ThreadX API, associated data structures, and data types are copyrights of Microsoft.

Microsoft

Output	Name and description of parameters whose values
Parameters	are returned by the service
Return Values	Description of status values returned after invoking
	the service
Allowed From	List of objects that can call this service
Preemption Possible	Determination (Yes or No) of whether a preemption
	condition can arise as a result of calling this service,
	e.g., if "Yes" the thread executing this service may
	be preempted by a higher-priority thread because
	that service may resume a higher priority thread
Example	Complete example using this service
See Also	List of related services

Appendix A

Memory Block Pool Services

The memory block pool services described in this appendix are:

tx_block_allocate Allocate a fixed-size block of memory Create a pool of fixed-size memory blocks tx_block_pool_create tx block pool delete Delete pool of fixed-size memory blocks tx_block_pool_info_get Retrieve information about block pool tx_block_pool_performance_info_get Get block pool performance information tx_block_pool_performance_system_info_ Get block pool system performance information get Prioritize block pool suspension list tx_block_pool_prioritize tx_block_release Release a fixed-size block of memory

tx_block_allocate

Allocate a fixed-size block of memory

Prototype

Description

This service allocates a fixed-size memory block from the specified memory pool. The actual size of the memory block is determined during memory pool creation. This service modifies the Memory Block Pool Control Block through the parameter pool_ptr.

Input Parameter

pool_ptr Pointer to a previously created pool's memory Control Block.

Output Parameters

block_ptr Pointer to a destination block pointer. On successful allocation, the

address of the allocated memory block is placed where this parameter points to.

wait_option

Defines how the service behaves if no memory blocks are available. The wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. *This is the only valid option if the service is called from a non-thread; e.g., initialization, timer, or ISR.* Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until a memory block becomes available. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for a memory block.

Return Values

TX_SUCCESS ⁶⁶	(0x00)	Successful memory block allocation.
TX_DELETED	(0x01)	Memory block pool was deleted while
		thread was suspended.
TX_NO_MEMORY ⁶⁶	(0x10)	Service was unable to allocate a block of
		memory.
TX_WAIT_ABORTED ⁶⁶	(0x1A)	Suspension was aborted by another thread,
		timer, or ISR.
TX_POOL_ERROR	(0x02)	Invalid memory block pool pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer to destination pointer.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT
		was specified on a call from a non-thread.

⁶⁶ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

tx block pool create

Create a pool of fixed-size memory blocks

Prototype

Description

This service creates a pool of fixed-size memory blocks. The memory area specified is divided into as many fixed-size memory blocks as possible using the formula:

```
total blocks = (total bytes) / (block size + size of (void*)).
```

This service initializes the Memory Block Pool Control Block through the parameter pool_ptr.

WARNING:

Each memory block contains one pointer of overhead that is invisible to the user and is represented by the "sizeof(void*)" expression in the preceding formula.

Input Parameters

ck.
ol.

pool_size Total number of bytes available for the memory block pool.

Return Values

TX_SUCCESS ⁶⁷	(0x00)	Successful memory block pool creation.
TX_POOL_ERROR	(0x02)	Invalid memory block pool pointer. Either the pointer is NULL or the pool has already been created.
TX_PTR_ERROR	(0x03)	Invalid starting address of the pool.
TX_SIZE_ERROR	(0x05)	Size of pool is invalid.
TX_CALLER_ERR OR	(0x13)	Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

No

Example

TX_BLOCK_POOL my_pool;

Azure RTOS ThreadX

⁶⁷ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_block_pool_delete

Delete a pool of fixed-size memory blocks

Prototype

```
UINT tx block pool delete (TX BLOCK POOL *pool ptr)
```

Description

This service deletes the specified block memory pool. All threads suspended waiting for a memory block from this pool are resumed and given a TX_DELETED return status.

WARNING:

It is the application's responsibility to manage the memory area associated with the pool, which is available after this service completes. In addition, the application must not use a deleted pool or its formerly allocated memory blocks.

Input Parameter

pool_ptr Pointer to a previously created memory block pool's Control Block.

Return Values

TX_SUCCESS⁶⁸ (0x00) Successful memory block pool deletion.

⁶⁸ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

TX_POOL_ERROR	(0x02)	Invalid memory block pool pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

Yes

Example

```
TX_BLOCK_POOL my_pool;
UINT status;
...
/* Delete entire memory block pool. Assume that the pool has
   already been created with a call to tx_block_pool_create. */
status = tx_block_pool_delete (&my_pool);
/* If status equals TX_SUCCESS, the memory block pool is deleted.
   */
```

tx_block_pool_info_get

Retrieve information about a memory block pool

Prototype

Description

This service retrieves information about the specified block memory pool.

Input Parameter

pool_ptr Pointer to previously created memory block pool's Control Block.

Output Parameters

name	Pointer to destination for the pointer to the block pool's name.
available	Pointer to destination for the number of available blocks in the block pool.
total_blocks	Pointer to destination for the total number of blocks in the block pool.
first_suspended	Pointer to destination for the pointer to the thread that is first on the suspension list of this block pool.
suspended_count	Pointer to destination for the number of threads currently suspended on this block pool.
next_pool	Pointer to destination for the pointer of the next created block pool.

Return Values

TX_SUCCESS ⁶⁹	(0x00)	(0x00) Successful block pool information retrieve.
TX_POOL_ERROR	(0x02)	Invalid memory block pool pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any destination pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

⁶⁹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_BLOCK_POOL my_pool;
CHAR *name;
ULONG available;
ULONG total_blocks;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_BLOCK_POOL *next_pool;
UINT status;
...
/* Retrieve information about the previously created block pool "my_pool." */
status = tx_block_pool_info_get(&my_pool, &name, &available, &total_blocks, &first_suspended, &suspended_count, &next_pool);
/* If status equals TX_SUCCESS, the information requested is valid. */
```

tx_block_pool_performance_info_get

Get block pool performance information

Prototype

Description

This service retrieves performance information about the specified memory block pool.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_BLOCK_POOL_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

pool_ptr Pointer to previously created memory block pool.

allocates Pointer to destination for the number of allocate requests

performed on this pool.

releases Pointer to destination for the number of release requests

performed on this pool.

suspensions Pointer to destination for the number of thread allocation

suspensions on this pool.

timeouts Pointer to destination for the number of allocate suspension

timeouts on this pool.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00) Successful block pool performance get.

TX_PTR_ERROR (0x03) Invalid block pool pointer.

TX_FEATURE_NOT_ENABLED (0xFF) The system was not compiled with

performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

See Also

tx_block_allocate, tx_block_pool_create, tx_block_pool_delete, tx_block_pool_info_get, tx_block_pool_performance_info_get, tx_block_pool_performance_system_info_get, tx_block_release

tx_block_pool_performance_system_info_get

Get block pool system performance information

Prototype

Description

This service retrieves performance information about all memory block pools in the application.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_BLOCK_POOL_ENABLE_ PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

allocates Pointer to destination for the total number of allocate requests

performed on all block pools.

releases Pointer to destination for the total number of release requests

performed on all block pools.

suspensions Pointer to destination for the total number of thread allocation

suspensions on all block pools.

timeouts

Pointer to destination for the total number of allocate suspension timeouts on all block pools.

NOTE:

Supplying a TX NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00)	Successful block pool system performance
	get.
TX_FEATURE_NOT_ENABLED (0xFF)	The system was not compiled with
	performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
ULONG allocates;
ULONG releases;
ULONG suspensions;
ULONG timeouts;
...
/* Retrieve performance information on all the block pools in the system. */
status = tx_block_pool_performance_system_info_get(&allocates, &releases, &suspensions, &timeouts);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

tx_block_allocate, tx_block_pool_create, tx_block_pool_delete, tx_block_pool_info_get, tx_block_pool_performance_info_get, tx_block_pool_prioritize, tx_block_release

tx_block_pool_prioritize

Prioritize the memory block pool suspension list

Prototype

```
UINT tx_block_pool_prioritize(TX_BLOCK_POOL *pool_ptr)
```

Description

This service places the highest-priority thread suspended for a block of memory on this pool at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended.

Input Parameter

pool_ptr Pointer to a previously created memory block pool's Control Block.

Return Values

TX_SUCCESS ⁷⁰	(0x00)	Successful block pool prioritize.
TX_POOL_ERROR	(0x02)	Invalid memory block pool pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

```
TX_BLOCK_POOL my_pool;
UINT status;
...
/* Ensure that the highest priority thread will receive the next free block in this pool. */
status = tx_block_pool_prioritize(&my_pool);
/* If status equals TX_SUCCESS, the highest priority suspended thread is at the front of the list. The next tx_block_release call will wake up this thread. */
```

⁷⁰ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_block_pool_release

Release a fixed-size block of memory

Prototype

```
UINT tx block release(VOID *block ptr)
```

Description

This service releases a previously allocated block back to its associated memory pool. If one or more threads are suspended waiting for a memory block from this pool, the first thread on the suspended list is given this memory block and resumed.

WARNING:

The application must not use a memory block area after it has been released to the pool.

Input Parameter

block_ptr Pointer to the previously allocated memory block.

Return Values

TX_SUCCESS ⁷¹	(0x00)	Successful memory block release
TX_PTR_ERROR	(0x03)	Invalid pointer to memory block.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

⁷¹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
TX_BLOCK_POOL my_pool;
unsigned char *memory_ptr;
UINT status;
...
/* Release a memory block back to my_pool. Assume that the pool
   has been created and the memory block has been allocated. */
status = tx_block_release((VOID *) memory_ptr);
/* If status equals TX_SUCCESS, the block of memory pointed to by
   memory ptr has been returned to the pool. */
```

Appendix B

Memory Byte Pool Services

The memory byte pool services described in this appendix are:

tx_byte_allocate Allocate bytes of memory tx_byte_pool_create Create a memory pool of bytes tx_byte_pool_delete Delete a memory pool of bytes

tx_byte_pool_info_get
Retrieve information about a byte pool
tx_byte_pool_performance_info_get
Get byte pool performance information
tx_byte_pool_performance_system_info_get
Get byte pool system performance

information

tx_byte_pool_prioritize Prioritize the byte pool suspension list tx_byte_release Release bytes back to the memory pool

tx_byte_allocate

Allocate bytes of memory from a memory byte pool

Prototype

Description

This service allocates the specified number of bytes from the specified byte memory pool. This service modifies the Memory Pool Control Block through the parameter pool_ptr.

WARNING:

The performance of this service is a function of the block size and the amount of fragmentation in the pool. Hence, this service should not be used during time-critical threads of execution.

Input	Param	eters
-------	-------	-------

pool_ptr Pointer to a previously created memory byte pool's Control

Block.

memory_size Number of bytes requested.

wait_option Defines how the service behaves if there is not enough memory

available. The wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. *This is the only valid option if the service is called from initialization*. Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until enough memory is available. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for the memory.

Output Parameter

memory_ptr Pointer to a destination memory pointer. On successful allocation,

the address of the allocated memory area is placed where this

parameter points to.

Return Values

TX_SUCCESS ⁷²	(0x00)	Successful memory allocation.
TX_DELETED ⁷²	(0x01)	Memory pool was deleted while thread was suspended.
TX_NO_MEMORY ⁷²	(0x10)	Service was unable to allocate the memory.
TX_WAIT_ABORTED ⁷²	(0x1A)	Suspension was aborted by another thread, timer,
		or ISR.
TX_POOL_ERROR	(0x02)	Invalid memory pool pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer to destination pointer.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT was

⁷² This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

specified on a call from a non-thread.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

Yes

Example

tx_byte_pool_create

Create a memory pool of bytes

Prototype

```
UINT tx_byte_pool_create(
TX_BYTE_POOL *pool_ptr,
CHAR *name_ptr, VOID *pool_start,
ULONG pool size)
```

Description

This service creates a memory pool in the area specified. Initially, the pool consists of basically one very large free block. However, the pool is broken into smaller blocks as allocations are performed. This service initializes the Memory Pool Control Block through the parameter pool_ptr.

Input Parameters

pool_ptr	Pointer to a Memory Pool Control Block.
name_ptr	Pointer to the name of the memory pool.
pool_start	Starting address of the memory pool.

pool_size Total number of bytes available for the memory pool.

Return Values

TX_SUCCESS ⁷³	(0x00)	Successful memory pool creation.
TX_POOL_ERROR	(0x02)	Invalid memory pool pointer. Either the
		pointer is
		NULL or the pool has already been created.
TX_PTR_ERROR	(0x03)	Invalid starting address of the pool.
TX_SIZE_ERROR	(0x05)	Size of pool is invalid.
TX_CALLER_ERR	(0x13)	Invalid caller of this service.
OR		

Allowed From

Initialization and threads

Preemption Possible

No

⁷³ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_byte_pool_delete

Delete a memory pool of bytes

Prototype

```
UINT tx byte pool delete(TX BYTE POOL *pool ptr)
```

Description

This service deletes the specified memory pool. All threads suspended waiting for memory from this pool are resumed and receive a TX_DELETED return status.

WARNING:

It is the application's responsibility to manage the memory area associated with the pool, which is available after this service completes. In addition, the application must not use a deleted pool or memory previously allocated from it.

Input Parameter

pool_ptr Pointer to a previously created memory pool's Control Block.

Return Values³

TX_SUCCESS ³	(0x00)	Successful memory pool deletion.
TX_POOL_ERROR	(0x02)	Invalid memory pool pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

Yes

```
TX_BYTE_POOL my_pool;
UINT status;
...
/* Delete entire memory pool. Assume that the pool has already
```

```
been created with a call to tx_byte_pool_create. */
status = tx_byte_pool_delete(&my_pool);
/* If status equals TX SUCCESS, memory pool is deleted. */
```

tx_byte_pool_info_get

Retrieve information about a memory byte pool

Prototype

Description

This service retrieves information about the specified memory byte pool.

Input Parameter

pool_ptr Pointer to a previously created memory byte pool's Control Block.

Output Parameters

name Pointer to destination for the pointer to the byte pool's name. available Pointer to destination for the number of available bytes in the

pool.

fragments Pointer to destination for the total number of memory fragments

in the byte pool.

first_suspended Pointer to destination for the pointer to the thread that is first on

the suspension list of this byte pool.

suspended_count Pointer to destination for the number of threads currently

suspended on this byte pool.

next_pool Pointer to destination for the pointer of the next created byte pool.

Return Values

TX_SUCCESS ⁷⁴	(0x00)	Successful pool information retrieval.
TX_POOL_ERROR	(0x02)	Invalid memory pool pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any destination pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

tx_byte_pool_performance_info_get

Get byte pool performance information

Prototype

```
UINT tx_byte_pool_performance_info_get(TX_BYTE_POOL *pool_ptr,
```

⁷⁴ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
ULONG *allocates, ULONG *releases,
ULONG *fragments_searched,
ULONG *merges, ULONG *splits,
ULONG *suspensions,
ULONG *timeouts);
```

Description

This service retrieves performance information about the specified memory byte pool.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_BYTE_POOL_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

nool ntr	Pointer to	proviously	grantad	mamary	hvita nool
pool_ptr	r officer to	previousry	createu	memory	byte poor.

allocates Pointer to destination for the number of allocate requests performed

on this pool.

releases Pointer to destination for the number of release requests performed

on this pool.

fragments_ Pointer to destination for the number of internal memory fragments

searched searched during allocation requests on this pool.

merges Pointer to destination for the number of internal memory blocks

merged during allocation requests on this pool.

splits Pointer to destination for the number of internal memory blocks split

(fragments) created during allocation requests on this pool.

suspensions Pointer to destination for the number of thread allocation suspensions

on this pool.

timeouts Pointer to destination for the number of allocate suspension timeouts

on this pool.

Return Values

TX_SUCCESS (0x00) Successful byte pool performance get.

TX_PTR_ERROR (0x03) Invalid byte pool pointer.

TX_FEATURE_NOT_ENABLED The system was not compiled with (0xFF) performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX BYTE POOL my pool;
ULONG fragments searched;
ULONG merges;
ULONG splits;
ULONG allocates;
ULONG releases:
ULONG suspensions;
ULONG timeouts;
/* Retrieve performance information on the previously created
  byte pool. */
status = tx byte pool performance info get (
                  &my pool, &fragments searched,
                  &merges, &splits, &allocates,
                  &releases, &suspensions,
                  &timeouts);
/* If status is TX SUCCESS the performance information was
   successfully retrieved. */
```

See Also

tx_byte_allocate, tx_byte_pool_create, tx_byte_pool_delete, tx_byte_pool_info_get, tx_byte_pool_performance_system_info_get, tx_byte_pool_prioritize, tx_byte_release

tx_byte_pool_performance_system_info_get

Get byte pool system performance information

Prototype

Description

This service retrieves performance information about all memory byte pools in the system.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_BYTE_POOL_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

allocates Pointer to destination for the number of allocate requests performed

on this pool.

releases Pointer to destination for the number of release requests performed

on this pool.

fragments_ Pointer to destination for the total number of internal memory searched fragments searched during allocation requests on all byte pools.

merges Pointer to destination for the total number of internal memory blocks

merged during allocation requests on all byte pools.

splits Pointer to destination for the total number of internal memory blocks

split (fragments) created during allocation requests on all byte pools.

suspensions Pointer to destination for the total number of thread allocation

suspensions on all byte pools.

timeouts Pointer to destination for the total number of allocate suspension

timeouts on all byte pools.

NOTE:

Supplying a TX_NULL for any parameter indicates the parameter is not required.

Return Values

TX_SUCCESS (0x00) Successful byte pool performance get.

TX_FEATURE_NOT_ENABLED The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

tx_byte_allocate, tx_byte_pool_create, tx_byte_pool_delete, tx_byte_pool_info_get, tx_byte_pool_performance_info_get, tx_byte_pool_prioritize, tx_byte_release

tx_byte_pool_prioritize

Prioritize the memory byte pool suspension list

Prototype

```
UINT tx_byte_pool_prioritize(TX_BYTE_POOL *pool_ptr)
```

Description

This service places the highest-priority thread suspended for memory on this pool at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended.

Input Parameter

pool_ptr Pointer to a previously created memory pool's Control Block.

Return Values

TX_SUCCESS ⁷⁵	(0x00)	Successful memory pool prioritize.
TX_POOL_ERROR	(0x02)	Invalid memory pool pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
TX_BYTE_POOL my_pool;
UINT status;
...
/*
Ensure that the highest priority thread will receive the next
free memory from this pool. */
status = tx_byte_pool_prioritize(&my_pool);
/*
If status equals TX_SUCCESS, the highest priority suspended
thread is at the front of the list. The next tx_byte_release call
will wake up this thread, if there is enough memory to satisfy
its request. */
```

tx_byte_release

Release bytes back to a memory byte pool

Prototype

```
UINT tx_byte_release(VOID *memory_ptr)
```

Description

This service releases a previously allocated memory area back to its associated pool. If

⁷⁵ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

one or more threads are suspended waiting for memory from this pool, each suspended thread is given memory and resumed until the memory is exhausted or until there are no more suspended threads. This process of allocating memory to suspended threads always begins with the first thread on the suspended list.

WARNING:

The application must not use the memory area after it is released.

Input Parameter

memory_ptr Pointer to the previously allocated memory area.

Return Values

TX_SUCCESS ⁷⁶	(0x00)	Successful memory release.
TX_PTR_ERROR	(0x03)	Invalid memory area pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

Yes

```
unsigned char *memory_ptr;
UINT status;
...
/* Release a memory back to my_pool. Assume that the memory area
   was previously allocated from my_pool. */
status = tx_byte_release((VOID *) memory_ptr);
/* If status equals TX_SUCCESS, the memory pointed to by
   memory_ptr has been returned to the pool. */
```

⁷⁶ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Appendix C

Event Flags Group Services

The event flags group services described in this appendix are:

tx_event_flags_create Create an event flags group tx_event_flags_delete Delete an event flags group

tx_event_flags_get Get event flags from an event flags

group

tx_event_flags_info_get Retrieve information about an event

flags group

tx_event_flags_performance info_get Get event flags group performance

information

tx_event_flags_performance_system_info_get Retrieve performance system

information

tx_event_flags_set Set event flags in an event flags group tx_event_flags_set_notify Notify application when event flags are

set

tx_event_flags_create

Create an event flags group

Prototype

Description

This service creates a group of 32 event flags. All 32 event flags in the group are initialized to zero. Each event flag is represented by a single bit. This service initializes the group Control Block through the parameter group_ptr.

Input Parameters

name_ptr	Pointer to the name of the event flags group.
group_ptr	Pointer to an Event Flags Group Control Block.

Return Values

TX_SUCCESS ⁷⁷	(0x00)	Successful event group creation.
TX_GROUP_ERROR	(0x06)	Invalid event group pointer. Either the pointer
		is NULL or the event group has already been
		created.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

No

Example

tx_event_flags_delete

Delete an event flags group

⁷⁷ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Prototype

```
UINT tx_event_flags_delete (TX_EVENT_FLAGS_GROUP *group_ptr)
```

Description

This service deletes the specified event flags group. All threads suspended waiting for events from this group are resumed and receive a TX_DELETED return status.

WARNING:

The application must not use a deleted event flags group.

Input Parameter

group_ptr Pointer to a previously created event flags group's Control Block.

Return Values

TX_SUCCESS ⁷⁸	(0x00)	Successful event flags group deletion.
TX_GROUP_ERROR	(0x06)	Invalid event flags group pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

Yes

```
TX_EVENT_FLAGS_GROUP my_event_group;
UINT status;
...
/* Delete event flags group. Assume that the group has already
```

⁷⁸ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
been created with a call to tx_event_flags_create. */
status = tx_event_flags_delete (&my_event_group);
/* If status equals TX_SUCCESS, the event flags group is deleted.
*/
```

tx_event_flags_get

Get event flags from an event flags group

Prototype

Description

This service waits on event flags from the specified event flags group. Each event flags group contains 32 event flags. Each flag is represented by a single bit. This service can wait on a variety of event flag combinations, as selected by the parameters. If the requested combination of flags is not set, this service either returns immediately, suspends until the request is satisfied, or suspends until a time-out is reached, depending on the wait option specified.

Input Parameters

group_ptr	Pointer to a previously created event flags group's Control
	D1 1

Block.

requested_flags 32-bit unsigned variable that represents the requested event

flags.

get_option Specifies whether all or any of the requested event flags

are required. The following are valid selections:

 $TX_AND (0x02)$

TX_AND_CLEAR (0x03)

TX_OR (0x00)

TX_OR_CLEAR (0x01)

Selecting TX_AND or TX_AND_CLEAR specifies that all

event flags must be set (a logical '1') within the group. Selecting TX_OR or TX_OR_CLEAR specifies that any event flag is satisfactory. Event flags that satisfy the request are cleared (set to zero) if TX_AND_CLEAR or TX_OR_CLEAR are specified.

wait_option

Defines how the service behaves if the selected event flags are not set. The wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive) Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. This is the only valid option if the service is called from a non-thread; e.g., initialization, timer, or ISR. Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the event flags are available. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for the event flags.

Output Parameter

actual_flags_ptr

Pointer to destination where the retrieved event flags are placed. Note that the actual flags obtained may contain flags that were not requested.

Return Values

TX_SUCCESS ⁷⁹	(0x00)	Successful event flags get.
TX_DELETED ⁷⁹	(0x01)	Event flags group was deleted while thread
		was suspended.
TX_NO_EVENTS ⁷⁹	(0x07)	Service was unable to get the specified events.
TX_WAIT_ABORTED ⁷⁹	(0x1A)	Suspension was aborted by another thread,

⁷⁹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Azure RTOS ThreadX

		timer, or ISR.
TX_GROUP_ERROR	(0x06)	Invalid event flags group pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer for actual event flags.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT was
		specified on a call from a non-thread.
TX_OPTION_ERROR	(0x08)	Invalid get-option was specified.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

tx_event_flags_info_get

Retrieve information about an event flags group.

Prototype

```
UINT tx_event_flags_info_get (TX_EVENT_FLAGS_GROUP *group_ptr,
   CHAR **name, ULONG *current flags,
```

```
TX THREAD **first suspended,
ULONG *suspended count,
TX EVENT FLAGS GROUP **next group)
```

Description

This service retrieves information about the specified event flags group.

Input Parameter

Pointer to an Event Flags Group Control Block. group_ptr

Output Parameters

Name	Pointer to destination for the	pointer to the event flags

group's name.

current_flags Pointer to destination for the current set flags in the event

flags group.

Pointer to destination for the pointer to the thread that is first_suspended

first on the suspension list of this event flags group.

Pointer to destination for the number of threads currently suspended_count

suspended on this event flags group.

Pointer to destination for the pointer of the next created next_group

event flags group.

Return Values

TX_SUCCESS ⁸⁰	(0x00)	Successful event group information retrieval.
TX_GROUP_ERROR	(0x06)	Invalid event group pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any destination
		pointer.

Allowed From

Initialization, threads, timers, and ISRs

⁸⁰ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Preemption Possible

No

Example

```
TX_EVENT_FLAGS_GROUP my_event_group;
CHAR *name;
ULONG current_flags;
TX_THREAD *first_suspended;
ULONG suspended_count;
TX_EVENT_FLAGS_GROUP *next_group;
UINT status;
...
/* Retrieve information about the previously created event flags group "my_event_group." */
status = tx_event_flags_info_get(&my_event_group, &name, &current_flags, &first_suspended, &suspended_count, &next_group);
/* If status equals TX_SUCCESS, the information requested is valid. */
```

tx_event_flags_performance info_get

Get event flags group performance information

Prototype

Description

This service retrieves performance information about the specified event flags group. **NOTE:**

Azure RTOS ThreadX library and application must be built with TX_EVENT_FLAGS_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

group_ptr Pointer to previously created event flags group.

sets Pointer to destination for the number of event flags set requests

performed on this group.

gets Pointer to destination for the number of event flags get requests

performed on this group.

suspensions Pointer to destination for the number of thread event flags get

suspensions on this group.

timeouts Pointer to destination for the number of event flags get suspension

timeouts on this group.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00) Successful event flags group performance get.

TX_PTR_ERROR (0x03)

TX_FEATURE_NOT_ENABLED

(0xFF)

Invalid event flags group pointer.

The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

```
TX_EVENT_FLAGS_GROUP my_event_flag_group;
ULONG sets;
ULONG gets;
ULONG suspensions;
ULONG timeouts;
...
/* Retrieve performance information on the previously created event flag group. */
status = tx_event_flags_performance_info_get
(&my_event_flag_group, &sets, &gets, &suspensions, &timeouts);
/* If status is TX_SUCCESS the performance information was
```

```
successfully retrieved. */
```

See Also

```
tx_event_flags_create, tx_event_flags_delete, tx_event_flags_get, tx_event_flags_info_get, tx_event_flags_performance_system_info_get, tx_event_flags_set, tx_event_flags_set_notify
```

tx_event_flags_performance_system_info_get

Retrieve performance system information

Prototype

Description

This service retrieves performance information about all event flags groups in the system.

NOTE:

Azure RTOS ThreadX library and application must be built with TX_EVENT_FLAGS_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

sets	Pointer to destination for the total number of event flag	s set
------	---	-------

requests performed on all groups.

gets Pointer to destination for the total number of event flags get

requests performed on all groups.

suspensions Pointer to destination for the total number of thread event flags

get suspensions on all groups.

timeouts Pointer to destination for the total number of event flags get

suspension timeouts on all groups.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00)
TX_FEATURE_NOT_ENABLED (0xFF)

Successful event flags system performance get. The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

```
tx_event_flags_create, tx_event_flags_delete, tx_event_flags_get, tx_event_flags_info_get, tx_event_flags_performance_info_get, tx_event_flags_set, tx_event_flags_set_notify
```

tx_event_flags_set

Set event flags in an event flags group

Prototype

Azure RTOS ThreadX

Description

This service sets or clears event flags in an event flags group, depending upon the specified set-option. All suspended threads whose event flags requests are now satisfied are resumed.

Input Parameters

group_ptr	Pointer to the previously created event flags group's Control Block
flags_to_set	Specifies the event flags to set or clear based upon the set option

selected.

set_option Specifies whether the event flags specified are ANDed or ORed

into the current event flags of the group. The following are valid

selections:

TX_AND (0x02) TX_OR (0x00)

Selecting TX_AND specifies that the specified event flags are ANDed into the current event flags in the group. This option is often used to clear event flags in a group. Otherwise, if TX_OR is specified, the specified event flags are ORed with the current event

in the group.

NOTE:

The TX_OR option forces the scheduler to review the suspension list to determine whether any threads are suspended for this event flags group.

Return Values

TX_SUCCESS ⁵	(0x00)	Successful event flags set.
TX_GROUP_ERROR	(0x06)	Invalid pointer to event flags group.
TX_OPTION_ERROR	(0x08)	Invalid set-option specified.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

```
TX_EVENT_FLAGS_GROUP my_event_group;
UINT status;
...
/* Set event flags 0, 4, and 8. */
status = tx_event_flags_set(&my_event_group, 0x111, TX_OR);
/* If status equals TX_SUCCESS, the event flags have been set and any suspended thread whose request was satisfied has been resumed. */
```

tx_event_flags_set_notify

Notify application when event flags are set

Prototype

Description

This service registers a notification callback function that is called whenever one or more event flags are set in the specified event flags group. The processing of the notification callback is defined by the application.

Input Parameters

group_ptr Pointer to previously created event flags group.

events_set_notify Pointer to application's event flags set notification function.

If this value is TX_NULL, notification is disabled.

Return Values

TX_SUCCESS (0x00) Successful registration of event flags set

TX_GROUP_ERROR (0x06)
TX_FEATURE_NOT_ENABLED (0xFF)

notification.

Invalid event flags group pointer.

The system was compiled with notification capabilities disabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

tx_event_flags_create, tx_event_flags_delete, tx_event_flags_get, tx_event_flags_info_get, tx_event_flags_performance_info_get, tx_event_flags_performance_system_info_get, tx_event_flags_set

Appendix D

Interrupt Control Service

tx_interrupt_control

Enables and disables interrupts

Prototype

UINT tx interrupt control (UINT new posture)

Description

This service enables or disables interrupts as specified by the parameter *new_posture*.

NOTE:

If this service is called from an application thread, the interrupt posture remains part of that thread's context. For example, if the thread calls this routine to disable interrupts and then suspends, when it is resumed, interrupts are disabled again.

WARNING:

Do not use this service to enable interrupts during initialization! Doing so could cause unpredictable results.

Input Parameter

new_posture⁸¹ This parameter specifies whether interrupts are disabled or enabled. Legal values include **TX_INT_DISABLE** and **TX_INT_ENABLE**. The actual values for this parameter are port-specific. In addition, some processing architectures might support additional interrupt disable postures.

⁸¹ This value is processor-specific and is defined in the file tx_port.h. This value typically maps directly to the interrupt lockout/enable bits in the processor's status register. The user must take care in selecting an appropriate value for new_posture.

Return Values

previous posture This service returns the previous interrupt posture to the caller. This allows users of the service to restore the previous posture after interrupts are disabled.

Allowed From

Threads, timers, and ISRs

Preemption Possible

No

```
UINT my_old_posture;
...
/* Lockout interrupts */
my_old_posture = tx_interrupt_control(TX_INT_DISABLE);
/* Perform critical operations that need interrupts locked-out.
*/
...
/* Restore previous interrupt lockout posture. */
tx_interrupt_control(my_old_posture);
```

Appendix E

Mutex Services

The mutex services described in this appendix include:

tx_mutex_createCreate a mutual exclusion mutextx_mutex_deleteDelete a mutual exclusion mutextx_mutex_getObtain ownership of a mutextx_mutex_info_getRetrieve information about a

mutex

tx_mutex_performance_info_get Get mutex performance

information

information

tx_mutex_prioritize Prioritize the mutex suspension list tx_mutex_put Release ownership of a mutex

tx_mutex_create

Create a mutual exclusion mutex

Prototype

Description

This service creates a mutex for inter-thread mutual exclusion for resource protection. This service initializes the Mutex Control Block through the parameter mutex_ptr.

Input Parameters

mutex_ptr Pointer to a Mutex Control Block.
name_ptr Pointer to the name of the mutex.

priority inherit Specifies whether or not this mutex supports priority

inheritance. If this value is TX_INHERIT, then priority inheritance is supported. However, if TX_NO_INHERIT

is specified, priority inheritance is not supported by this mutex.

Return Values

TX_SUCCESS ⁸²	(0x00)	Successful mutex creation.
TX_MUTEX_ERROR	(0x1C)	Invalid mutex pointer. Either the pointer is
		NULL or the mutex has already been created.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.
TX_INHERIT_ERROR	(0x1F)	Invalid priority inheritance parameter.

Allowed From

Initialization and threads

Preemption Possible

No

Example

tx_mutex_delete

Delete a mutual exclusion mutex

Prototype

```
UINT tx_mutex_delete(TX_MUTEX *mutex_ptr)
```

⁸² This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Description

This service deletes the specified mutex. All threads suspended waiting for the mutex are resumed and receive a TX_DELETED return status.

WARNING:

It is the application's responsibility to prevent use of a deleted mutex

Input Parameter

mutex_ptr Pointer to a previously created mutex's Control Block.

Return Values

```
TX_SUCCESS<sup>83</sup> (0x00) Successful mutex deletion.
TX_MUTEX_ERROR (0x1C) Invalid mutex pointer.
TX_CALLER_ERROR (0x13) Invalid caller of this service.
```

Allowed From

Threads

Preemption Possible

Yes

Example

```
TX_MUTEX my_mutex;
UINT status;
...
/* Delete a mutex. Assume that the mutex has already been created. */
status = tx_mutex_delete(&my_mutex);
/* If status equals TX SUCCESS, the mutex is deleted. */
```

⁸³ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_mutex_get

Obtain ownership of a mutex

Prototype

```
UINT tx mutex get(TX MUTEX *mutex ptr, ULONG wait option)
```

Description

This service attempts to obtain exclusive ownership of the specified mutex. If the calling thread already owns the mutex, an internal counter is incremented and a successful status is returned. If the mutex is owned by another thread and the calling thread has higher priority and priority inheritance was enabled upon mutex creation, the lower-priority thread's priority becomes temporarily raised to that of the calling thread. This service may modify the mutex Control Block through the parameter mutex_ptr.

WARNING:

Note that the priority of the lower-priority thread owning a mutex with priority-inheritance should never be modified by an external thread during mutex ownership.

Input Parameters

mutex_ptr
wait_option

Pointer to a previously created mutex's Control Block.

Defines how the service behaves if the mutex is already owned by another thread. The wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive) Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. This is the only valid option if the service is called from initialization. Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until the mutex becomes available. Selecting a numeric value (1-0xFFFFFFE) specifies the

maximum number of timer-ticks to stay suspended while waiting for the mutex.

Return Values

(0x00)	Successful mutex get operation.
(0x01)	Mutex was deleted while thread was suspended.
(0x1D)	Service was unable to get ownership of the
	mutex.
(0x1A)	Suspension was aborted by another thread, timer,
	or ISR.
(0x1C)	Invalid mutex pointer.
(0x04)	A wait option other than TX_NO_WAIT was
	specified on a call from a non-thread.
(0x13)	Invalid caller of this service.
	(0x01) (0x1D) (0x1A) (0x1C) (0x04)

Allowed From

Initialization, threads, and timers

Preemption Possible

Yes

Example

```
TX_MUTEX my_mutex;
UINT status;
...
/* Obtain exclusive ownership of the mutex "my_mutex". If the
```

⁸⁴ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
mutex "my_mutex" is not available, suspend until it becomes
  available. */
status = tx mutex get(&my mutex, TX WAIT FOREVER);
```

tx_mutex_info_get

Retrieve information about a mutex

Prototype

Description

This service retrieves information from the specified mutex.

Input Parameter

mutex_ptr Pointer to a previously created Mutex Control Block.

Output Parameters

Name Pointer to destination for the pointer to the mutex name.

Count Pointer to destination for the ownership count of the mutex.

owner Pointer to destination for the owning thread's pointer.

first_suspended Pointer to destination for the pointer to the thread that is first on

the suspension list of this mutex.

suspended_count Pointer to destination for the number of threads currently

suspended on this mutex.

next_mutex Pointer to destination for the pointer of the next created mutex.

Return Values

TX_SUCCESS ⁸⁵	(0x00)	Successful mutex information
		retrieval.
TX_MUTEX_ERROR	(0x1C)	Invalid mutex pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any
		destination pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

tx_mutex_performance_info_get

Get mutex performance information

Prototype

⁸⁵ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Description

This service retrieves performance information about the specified mutex.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_MUTEX_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

mutex_ptr	Pointer to previously created mutex.
-----------	--------------------------------------

Puts Pointer to destination for the number of put requests performed

on this mutex.

Gets Pointer to destination for the number of get requests performed

on this mutex.

suspensions Pointer to destination for the number of thread mutex get

suspensions on this mutex.

timeouts Pointer to destination for the number of mutex get suspension

timeouts on this mutex.

inversions Pointer to destination for the number of thread priority

inversions on this mutex.

inheritances Pointer to destination for the number of thread priority

inheritance operations on this mutex.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX SUCCESS (0x00)

Successful mutex performance get.

TX_PTR_ERROR (0x03)
TX_FEATURE_NOT_ENABLED (0xFF)

Invalid mutex pointer.

The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_MUTEX my_mutex;
ULONG puts;
ULONG gets;
ULONG suspensions;
ULONG timeouts;
ULONG inversions;
ULONG inheritances;
...
/* Retrieve performance information on the previously created mutex. */
status = tx_mutex_performance_info_get (&my_mutex_ptr, &puts, &gets, &suspensions, &timeouts, &inversions, &inheritances);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

tx_mutex_create, tx_mutex_delete, tx_mutex_get, tx_mutex_info_get, tx_mutex_prioritize, tx_mutex_put

tx_mutex_performance_system_info_get

Get mutex system performance information

Prototype

Description

This service retrieves performance information about all the mutexes in the system.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_MUTEX_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

puts	Pointer to destination for the total number of put requests
------	---

performed on all mutexes.

gets Pointer to destination for the total number of get requests

performed on all mutexes.

suspensions Pointer to destination for the total number of thread mutex get

suspensions on all mutexes.

timeouts Pointer to destination for the total number of mutex get

suspension timeouts on all mutexes.

inversions Pointer to destination for the total number of thread priority

inversions on all mutexes.

inheritances Pointer to destination for the total number of thread priority

inheritance operations on all mutexes.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00)	Successful mutex system performance get.
TX_FEATURE_NOT_ENABLED	The system was not compiled with
(0xFF)	performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
ULONG puts;
ULONG gets;
ULONG suspensions;
ULONG timeouts;
ULONG inversions;
ULONG inheritances;
...
/* Retrieve performance information on all previously created mutexes. */
status = tx_mutex_performance_system_info_get(&puts, &gets, &suspensions, &timeouts, &inversions, &inheritances);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

```
tx_mutex_create, tx_mutex_delete, tx_mutex_get, tx_mutex_info_get, tx_mutex_performance_info_get, tx_mutex_prioritize, tx_mutex_put
```

tx_mutex_prioritize

Prioritize the mutex suspension list

Prototype

```
UINT tx_mutex_prioritize(TX_MUTEX *mutex_ptr)
```

Description

This service places the highest-priority thread suspended for ownership of the mutex at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended.

Input Parameter

mutex_ptr Pointer to the previously created mutex's Control Block.

Return Values

TX_SUCCESS⁸⁶ (0x00) Successful mutex prioritization.

TX_MUTEX_ERROR (0x1C) Invalid mutex pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

⁸⁶ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_MUTEX my_mutex;
UINT status;
....
/* Ensure that the highest priority thread will receive ownership of the mutex when it becomes available. */
status = tx_mutex_prioritize(&my_mutex);
/* If status equals TX_SUCCESS, the highest priority suspended thread is at the front of the list. The next tx_mutex_put call that releases ownership of the mutex will give ownership to this thread and wake it up. */
```

tx_mutex_put

Release ownership of a mutex

Prototype

```
UINT tx mutex put(TX MUTEX *mutex ptr)
```

Description

This service decrements the ownership count of the specified mutex. If the ownership count becomes zero, the mutex becomes available to entities attempting to acquire ownership. This service modifies the Mutex Control Block through the parameter mutex_ptr.

WARNING:

If priority inheritance was selected during mutex creation, the priority of the releasing thread will revert to the priority it had when it originally obtained ownership of the mutex. Any other priority changes made to the releasing thread during ownership of the mutex may be undone.

Input Parameter

mutex_ptr Pointer to the previously created mutex's Control Block.

Return Values

TX_SUCCESS ⁸⁷	(0x00)	Successful mutex release.
TX_NOT_OWNED88	(0x1E)	Mutex is not owned by caller.
TX_MUTEX_ERROR	(0x1C)	Invalid pointer to mutex.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

Yes

Example

```
TX_MUTEX my_mutex;
UINT status;
...
/* Release ownership of "my_mutex." */
status = tx_mutex_put(&my_mutex);
/* If status equals TX_SUCCESS, the mutex ownership count has been decremented and if zero, released. */
```

⁸⁷ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

⁸⁸ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Appendix F

Message Queue Services

The message queue services described in this appendix include:

tx_queue_create Create a message queue tx_queue_delete Delete a message queue

tx_queue_flush Empty all messages in a message queue

tx_queue_front_send Send a message to the front of a message queue tx_queue_info_get Retrieve information about a message queue

tx_queue_performance_info_get Get queue performance information

tx_queue_performance_system Get queue system performance information

_info_get

tx_queue_prioritize Prioritize a message queue suspension list tx_queue_receive Get a message from a message queue tx_queue_send Send a message to a message queue

tx_queue_send_notify Notify application when message is sent to queue

tx_queue_create

Create a message queue

Prototype

Description

This service creates a message queue that is typically used for inter-thread communication. This service calculates the total number of messages the queue can hold from the specified message size and the total number of bytes in the queue. This service initializes the Queue Control Block through the parameter queue_ptr.

WARNING:

If the total number of bytes specified in the queue's memory area is not evenly divisible by the specified message size, the remaining bytes in the memory area are not used.

Input Parameters

queue_ptr Pointer to a Message Queue Control Block.
name_ptr Pointer to the name of the message queue.

message_size Specifies the size of each message in the queue (in ULONGs).

Message

sizes range from 1 32-bit word to 16 32-bit words. Valid message

size options are defined as follows:

TX_1_ULONG (0x01) TX_2_ULONG (0x02) TX_4_ULONG (0x04) TX_8_ULONG (0x08) TX_16_ULONG (0x10)

queue_start Starting address of the message queue.

queue_size Total number of bytes available for the message queue.

Return Values

TX_SUCCESS ⁸⁹	(0x00)	Successful message queue creation.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer. Either the pointer is NULL or the queue has already been created.
TX_PTR_ERROR	(0x03)	Invalid starting address of the message queue.
TX_SIZE_ERROR	(0x05)	Specified message queue size is invalid.

⁸⁹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

TX_CALLER_ERROR

(0x13)

Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

No

Example

tx_queue_delete

Delete a message queue

Prototype

```
UINT tx queue delete (TX QUEUE *queue ptr)
```

Description

This service deletes the specified message queue. All threads suspended waiting for a message from this queue are resumed and receive a TX_DELETED return status.

WARNING:

It is the application's responsibility to manage the memory area associated with the queue, which is available after this service completes. In addition, the application must not use a deleted queue.

Input Parameter

queue_ptr Pointer to a previously created message queue's Control Block.

Return Values

TX_SUCCESS ⁹⁰	(0x00)	Successful message queue deletion.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

Yes

Example

```
TX_QUEUE my_queue;
UINT status;
...
/* Delete entire message queue. Assume that the queue has already
  been created with a call to tx_queue_create. */
status = tx_queue_delete(&my_queue);
/* If status equals TX_SUCCESS, the message queue is deleted. */
```

tx_queue_flush

Empty all messages in a message queue

 $^{^{90}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Prototype

```
UINT tx queue flush (TX_QUEUE *queue_ptr)
```

Description

This service deletes all messages stored in the specified message queue. If the queue is full, messages of all suspended threads are discarded. Each suspended thread is then resumed with a return status that indicates the message send was successful. If the queue is empty, this service does nothing. This service may modify the Queue Control Block through the parameter queue_ptr.

Input Parameter

queue_ptr Pointer to a previously created message queue's Control Block.

Return Values

TX_SUCCESS ⁹¹	(0x00)	Successful message queue flush.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

```
TX_QUEUE my_queue;
UINT status;
...
/* Flush out all pending messages in the specified message queue.
```

⁹¹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
Assume that the queue has already been created with a call to tx_queue_create. */
status = tx_queue_flush(&my_queue);
/* If status equals TX SUCCESS, the message queue is empty. */
```

tx_queue_front_send

Send a message to the front of a queue

Prototype

Description

This service sends a message to the front location of the specified message queue. The message is copied to the front of the queue from the memory area specified by the source pointer. This service modifies the Queue Control Block through the parameter queue_ptr.

Input Parameters

queue_ptr Pointer to a previously created message queue's Control Block.

source_ptr Pointer to the message.

wait_option Defines how the service behaves if the message queue is full. The

wait options are defined as follows:

TX NO WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. *This is the only valid option if the service is called from a non-thread*; e.g., *initialization, timer, or ISR*. Selecting TX_WAIT_FOREVER

causes the calling thread to suspend indefinitely until there is room in the queue. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for room in the queue.

D 4	T 7 1
Keturn	Values

TX_SUCCESS ⁹²	(0x00)	Successful send of message.
TX_DELETED	(0x01)	Message queue was deleted while thread was suspended.
TX_QUEUE_FULL	(0x0B)	Service was unable to send message because the queue was full.
TX_WAIT_ABORTED	(0x1A)	Suspension was aborted by another thread, timer, or ISR.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.
TX_PTR_ERROR	(0x03)	Invalid source pointer for message.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT was specified on a call from a non-thread.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

TX_QUEUE my_queue; UINT status;

⁹² This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
ULONG my_message[4];
...
/* Send a message to the front of "my_queue." Return immediately,
    regardless of success. This wait option is used for calls from
    initialization, timers, and ISRs. */
status = tx_queue_front_send(&my_queue, my_message, TX_NO_WAIT);
/* If status equals TX_SUCCESS, the message is at the front of
    the specified queue. */
```

tx_queue_info_get

Retrieve information about a queue

Prototype

Description

This service retrieves information about the specified message queue.

Input Parameter

queue_ptr Pointer to a previously created message queue's Control Block.

Output Parameters

name Pointer to destination for pointer to the queue's name.

enqueued Pointer to destination for the number of messages

currently in the queue.

available_storage Pointer to destination for the number of messages the

queue currently has space for.

first_suspended Pointer to destination for the pointer to the thread that is

first on the suspension list of this queue.

suspended_count Pointer to destination for the number of threads

currently suspended on this queue.

next_queue Pointer to destination for the pointer of the next created

queue.

Return Values

TX_SUCCESS ⁵	(0x00)	Successful queue information retrieval.	
TX QUEUE ERROR	(0x09)	Invalid message queue pointer.	

TX_PTR_ERROR (0x03) Invalid pointer (NULL) for any destination

pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
TX_QUEUE my_queue;
CHAR *name;
ULONG enqueued;
TX_THREAD *first_suspended;
ULONG suspended_count;
ULONG available_storage;
TX_QUEUE *next_queue;
UINT status;
...
/* Retrieve information about the previously created message queue "my_queue." */
status = tx_queue_info_get(&my_queue, &name, &enqueued, &available storage, &first suspended,
```

```
&suspended_count, &next_queue);
/* If status equals TX_SUCCESS, the information requested is valid. */
```

tx_queue_performance_info_get

Get queue performance information

Prototype

```
UINT tx_queue_performance_info_get(TX_QUEUE *queue_ptr,
   ULONG *messages_sent,
   ULONG *messages_received,
   ULONG *empty_suspensions,
   ULONG *full_suspensions,
   ULONG *full_errors,
   ULONG *timeouts);
```

Description

This service retrieves performance information about the specified queue.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_QUEUE_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

Pointer to previously created queue.
Pointer to destination for the number of send requests
performed on this queue.
Pointer to destination for the number of receive requests
performed on this queue.
Pointer to destination for the number of queue empty
suspensions on this queue.
Pointer to destination for the number of queue full
suspensions on this queue.
Pointer to destination for the number of queue full errors
on this queue.
Pointer to destination for the number of thread suspension

timeouts on this queue.

NOTE:

366

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00)

Successful queue performance get.

TX_PTR_ERROR (0x03)

Invalid queue pointer.

TX_FEATURE_NOT_ENABLED (0xFF)

The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_QUEUE my_queue;
ULONG messages_sent;
ULONG messages_received;
ULONG empty_suspensions;
ULONG full_suspensions;
ULONG full_errors; ULONG timeouts;
...
/* Retrieve performance information on the previously created queue. */
status = tx_queue_performance_info_get(&my_queue, &messages_sent, &messages_received, &empty_suspensions, &full_suspensions, &full_errors, &timeouts);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

tx_queue_create, tx_queue_delete, tx_queue_flush, tx_queue_front_send, tx_queue_info_get, tx_queue_performance_system_info_get, tx_queue_prioritize, tx_queue_receive, tx_queue_send, tx_queue_send_notify

Azure RTOS ThreadX

tx_queue_performance_system_info_get

Get queue system performance information

Prototype

Description

This service retrieves performance information about all the queues in the system.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_QUEUE_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

messages_sent	Pointer to destination for the total number of send requests
---------------	--

performed on all queues.

messages_received Pointer to destination for the total number of receive

requests performed on all queues.

empty_suspensions Pointer to destination for the total number of queue empty

suspensions on all queues.

full_suspensions Pointer to destination for the total number of queue full

suspensions on all queues.

full_errors Pointer to destination for the total number of queue full

errors on all queues.

timeouts Pointer to destination for the total number of thread

suspension timeouts on all queues.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

```
TX_SUCCESS (0x00)
TX_FEATURE_NOT_ENABLED (0xFF)
```

Successful queue system performance get. The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

tx_queue_create, tx_queue_delete, tx_queue_flush, tx_queue_front_send, tx_queue_info_get, tx_queue_performance_info_get, tx_queue_prioritize, tx_queue_receive, tx_queue_send, tx_queue_send_notify

tx_queue_prioritize

Prioritize the queue suspension list

Prototype

```
UINT tx_queue_prioritize(TX_QUEUE *queue_ptr)
```

Description

This service places the highest-priority thread suspended to get a message (or to place a message) on this queue at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended.

Input Parameter

queue_ptr Pointer to a previously created message queue's Control Block.

Return Values

TX_SUCCESS ⁹³	(0x00)	Successful queue prioritization.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
TX_QUEUE my_queue;
UINT status;
...
/* Ensure that the highest priority thread will receive the next
  message placed on this queue. */
status = tx_queue_prioritize(&my_queue);
/* If status equals TX_SUCCESS, the highest priority suspended
  thread is at the front of the list. The next tx_queue_send or
  tx_queue_front_send call made to this queue will wake up this
  thread. */
```

⁹³ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_queue_receive

Get a message from a message queue

Prototype

Description

This service retrieves a message from the specified message queue. The retrieved message is copied from the queue into the memory area specified by the destination pointer. That message is then removed from the queue. This service may modify the Queue Control Block through the parameter queue_ptr.

WARNING:

The specified destination memory area must be large enough to hold the message; i.e., the message destination pointed to by destination_ptr must be at least as large as the message size for this queue. Otherwise, if the destination is not large enough, memory corruption occurs in the memory area following the destination.

Input Parameters

queue_ptr wait_option Pointer to a previously created message queue's Control Block. Defines how the service behaves if the message queue is empty. The

wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. This is the only

valid option if the service is called from a non-thread; e.g.,

initialization, timer, or ISR. Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until a message becomes available. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for a

message.

Output Parameter

destination_ptr

Location of memory area to receive a copy of the message.

Return Values

TX_SUCCESS ⁹⁴	(0x00)	Successful retrieval of message.
TX_DELETED	(0x01)	Message queue was deleted while thread
		was suspended.
TX_QUEUE_EMPTY	(0x0A)	Service was unable to retrieve a message
		because the queue was empty.
TX_WAIT_ABORTED94	(0x1A)	Suspension was aborted by another
		thread, timer, or ISR.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.
TX_PTR_ERROR	(0x03)	Invalid destination pointer for message.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT
		was specified on a call from a non-thread.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

TX_QUEUE my_queue;

 $^{^{94}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
UINT status;
ULONG my_message[4];
...
/* Retrieve a message from "my_queue." If the queue is empty,
    suspend until a message is present. Note that this suspension
    is only possible from application threads. */
status = tx_queue_receive(&my_queue, my_message,TX_WAIT_FOREVER);
/* If status equals TX_SUCCESS, the message is in "my_message."
*/
```

tx_queue_send

Send a message to a message queue

Prototype

Description

This service sends a message to the specified message queue. The sent message is copied to the queue from the memory area specified by the source pointer. This service may modify the Queue Control Block through the parameter queue_ptr.

Input Parameters

queue_ptr Pointer to a previously created message queue's Control

Block.

source_ptr Pointer to the message.

wait_option Defines how the service behaves if the message queue is full.

The wait options are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. *This is the only valid option if the service is called from a non-thread; e.g., initialization, timer, or ISR.* Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until there is room in the queue. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for room in the queue.

Return Values

TX_SUCCESS ⁹⁵	(0x00)	Successful sending of message.
TX_DELETED	(0x01)	Message queue was deleted while
		thread was suspended.
TX_QUEUE_FULL	(0x0B)	Service was unable to send message
		because the queue was full.
TX_WAIT_ABORTED	(0x1A)	Suspension was aborted by another
		thread, timer, or ISR.
TX_QUEUE_ERROR	(0x09)	Invalid message queue pointer.
TX_PTR_ERROR	(0x03)	Invalid source pointer for message.
TX_WAIT_ERROR	(0x04)	A wait option other than
		TX_NO_WAIT was specified on a
		call from a non-thread.

Allowed From

Initialization, threads, timers, and ISRs

⁹⁵ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Preemption Possible

Yes

374

Example

```
TX_QUEUE my_queue;
UINT status;
ULONG my_message[4];
...
/* Send a message to "my_queue." Return immediately, regardless of success. This wait option is used for calls from initialization, timers, and ISRs. */
status = tx_queue_send(&my_queue, my_message, TX_NO_WAIT);
/* If status equals TX SUCCESS, the message is in the queue. */
```

tx_queue_send_notify

Notify application when message is sent to queue

Prototype

Description

This service registers a notification callback function that is called whenever a message is sent to the specified queue. The processing of the notification callback is defined by the application.

Input Parameters

queue_ptr Pointer to previously created queue.

queue_send_notify Pointer to application's queue send notification function. If

this value is TX NULL, notification is disabled.

Return Values

TX_SUCCESS (0x00)

Successful registration of queue send

notification.

TX_QUEUE_ERROR (0x09)

Invalid queue pointer.

TX_FEATURE_NOT_ENABLED (0xFF)

The system was compiled with notification capabilities disabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_QUEUE my_queue;
...
/* Register the "my_queue_send_notify" function for monitoring
   messages sent to the queue "my_queue." */
status = tx_queue_send_notify(&my_queue, my_queue_send_notify);
/* If status is TX_SUCCESS the queue send notification function
   was successfully registered. */
...
void my_queue_send_notify(TX_QUEUE *queue_ptr)
{
/* A message was just sent to this queue! */
}
```

See Also

```
tx_queue_create, tx_queue_delete, tx_queue_flush, tx_queue_front_send, tx_queue_info_get, tx_queue_performance_info_get, tx_queue_performance_system_info_get, tx_queue_prioritize, tx_queue_receive, tx_queue_send
```

Appendix G

Counting Semaphore Services

The counting semaphore services described in this appendix are:

tx_semaphore_ceiling_put Place an instance in counting

semaphore with ceiling

semaphore

tx_semaphore_info_get Retrieve information about a

counting semaphore

tx_semaphore_performance_info_get Get semaphore performance

information

information

tx_semaphore_prioritize Prioritize a counting semaphore

suspension list

tx_semaphore_put Place an instance in a counting

semaphore

tx_semaphore_put_notify Notify application when semaphore

is put

tx_semaphore_ceiling_put

Place an instance in counting semaphore with ceiling

Prototype

Description

This service puts an instance into the specified counting semaphore, which in reality

increments the counting semaphore by one. If the counting semaphore's current value is greater than or equal to the specified ceiling, the instance will not be put and a TX_CEILING_EXCEEDED error will be returned.

Input Parameters

semaphore_ptr Pointer to previously created semaphore.

Ceiling Maximum limit allowed for the semaphore (valid values range from

1 through 0xFFFFFFF).

Return Values

```
TX_SUCCESS (0x00) Successful semaphore ceiling put.

TX_CEILING_EXCEEDED (0x21) Put request exceeds ceiling.

TX_INVALID_CEILING (0x22) An invalid value of zero was supplied for ceiling.

TX_SEMAPHORE_ERROR (0x03) Invalid semaphore pointer.
```

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_SEMAPHORE my_semaphore;
...
/* Increment the counting semaphore "my_semaphore" but make sure
    that it never exceeds 7 as specified in the call. */
status = tx_semaphore_ceiling_put(&my_semaphore, 7);
/* If status is TX_SUCCESS the semaphore count has been
    incremented. */
```

See Also

tx_semaphore_create, tx_semaphore_delete, tx_semaphore_get, tx_semaphore_info_get, tx_semaphore_performance_info_get, tx_semaphore_performance_system_info_get, tx_semaphore_prioritize, tx_semaphore_put, tx_semaphore_put_notify

tx_semaphore_create

Create a counting semaphore

Prototype

```
UINT tx_semaphore_create(TX_SEMAPHORE *semaphore_ptr, CHAR *name ptr, ULONG initial count)
```

Description

This service creates a counting semaphore for inter-thread synchronization. The initial semaphore count is specified as a parameter. This service initializes the Semaphore Control Block through the parameter semaphore_ptr.

Input Parameters

emaphore_ptr Pointer to a Semaphore Control Block. name_ptr Pointer to the name of the semaphore.

initial_count Specifies the initial count for this semaphore. Legal values are

from 0x00000000 to 0xFFFFFFF (inclusive).

Return Values

TX_SUCCESS⁹⁶ (0x00) Successful semaphore creation

TX_SEMAPHORE_ERROR (0x0C) Invalid semaphore pointer. Either the pointer is

NULL or the semaphore has already been

created.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

No

⁹⁶ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Create a counting semaphore with an initial value of 1. This is
   typically the technique used to create a binary semaphore. Binary
   semaphores are used to provide protection over a common resource.
   */
status = tx_semaphore_create(&my_semaphore, "my_semaphore_name", 1);
/* If status equals TX SUCCESS, my semaphore is ready for use. */
```

tx_semaphore_delete

Delete a counting semaphore

Prototype

```
UINT tx semaphore delete (TX SEMAPHORE *semaphore ptr)
```

Description

This service deletes the specified counting semaphore. All threads suspended waiting for an instance of this semaphore are resumed and receive a TX_DELETED return status.

WARNING:

It is the application's responsibility to prevent use of a deleted semaphore.

Parameter

semaphore_ptr Pointer to a previously created semaphore's Control Block.

Return Values

TX_SUCCESS ²	(0x00)	Successful counting semaphore deletion.
TX_SEMAPHORE_ERROR	(0x0C)	Invalid counting semaphore pointer.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

Yes

Example

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Delete counting semaphore. Assume that the counting semaphore has already been created. */
status = tx_semaphore_delete(&my_semaphore);
/* If status equals TX_SUCCESS, the counting semaphore is deleted.
*/
```

tx_semaphore_get

Get an instance from a counting semaphore

Prototype

Description

This service retrieves an instance (a single count) from the specified counting semaphore. As a result, the specified semaphore's count is decreased by one. This service may modify the semaphore's Control Block through the parameter semaphore_ptr.

Input Parameters

semaphore_ptr wait_option

Pointer to a previously created counting semaphore's Control Block. Defines how the service behaves if there are no instances of the

semaphore available; i.e., the semaphore count is zero. The wait options

are defined as follows:

TX_NO_WAIT (0x00000000)

TX_WAIT_FOREVER (0xFFFFFFF)

timeout value (0x00000001 to 0xFFFFFFE, inclusive)

Selecting TX_NO_WAIT results in an immediate return from this service regardless of whether or not it was successful. This is the only valid option if the service is called from a non-thread; e.g., initialization, timer, or ISR.

Selecting TX_WAIT_FOREVER causes the calling thread to suspend indefinitely until a semaphore instance becomes available. Selecting a numeric value (1-0xFFFFFFE) specifies the maximum number of timer-ticks to stay suspended while waiting for a semaphore instance.

Return Values

TX_SUCCESS ⁹⁷	(0x00)	Successful retrieval of a semaphore instance.
TX_DELETED	(0x01)	Counting semaphore was deleted while thread
		was suspended.
TX_NO_INSTANCE	(0x0D)	Service was unable to retrieve an instance of the
		counting semaphore (semaphore count is zero).
TX_WAIT_ABORTED	(0x1A)	Suspension was aborted by another thread, timer,
		or ISR.
TX_SEMAPHORE_ERROR	(0x0C)	Invalid counting semaphore pointer.
TX_WAIT_ERROR	(0x04)	A wait option other than TX_NO_WAIT was
		specified on a call from a non-thread.
		Transfer to the state of the st

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

⁹⁷ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Get a semaphore instance from the semaphore "my_semaphore." If
    the semaphore count is zero, suspend until an instance becomes
    available. Note that this suspension is only possible from
    application threads. */
status = tx_semaphore_get(&my_semaphore, TX_WAIT_FOREVER);
/* If status equals TX_SUCCESS, the thread has obtained an
    instance of the semaphore. */
```

tx_semaphore_info_get

Retrieve information about a counting semaphore

Prototype

Description

This service retrieves information about the specified semaphore.

Input Parameter

semaphore_ptr Pointer to a previously created semaphore's Control Block.

Output Parameters

name Pointer to destination for the pointer to the semaphore's

name.

current_value Pointer to destination for the current semaphore's count.

First_suspended Pointer to destination for the pointer to the thread that is first

on the suspension list of this semaphore.

suspended_count Pointer to destination for the number of threads currently

suspended on this semaphore.

next_semaphore

Pointer to destination for the pointer of the next created

semaphore.

Return Values

TX_SUCCESS ⁹⁸	(0x00)	Successful semaphore information retrieval.
TX_SEMAPHORE_ERROR	(0x0C)	Invalid semaphore pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any destination
		pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

⁹⁸ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_semaphore_performance_info_get

Get semaphore performance information

Prototype

Description

This service retrieves performance information about the specified semaphore.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_SEMAPHORE_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

semaphore_ptr Pointer to previously created semaphore.

puts Pointer to destination for the number of put requests performed on this

semaphore.

gets Pointer to destination for the number of get requests performed on this

semaphore.

suspensions Pointer to destination for the number of thread suspensions on this

semaphore.

timeouts Pointer to destination for the number of thread suspension timeouts on

this semaphore.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00) Successful semaphore performance get.

TX PTR ERROR (0x03) Invalid semaphore pointer.

TX_FEATURE_NOT_ENABLED (0xFF) The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_SEMAPHORE my_semaphore;
ULONG puts;
ULONG gets;
ULONG suspensions;
ULONG timeouts;
/* Retrieve performance information on the previously created semaphore. */
status = tx_semaphore_performance_info_get(&my_semaphore, &puts, &gets, &suspensions, &timeouts);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

```
tx_seamphore_ceiling_put, tx_semaphore_create, tx_semaphore_delete, tx_semaphore_get, tx_semaphore_info_get, tx_semaphore_performance_system_info_get, tx_semaphore_prioritize, tx_semaphore_put, tx_semaphore_put_notify
```

tx_semaphore_performance_system_info_get

Get semaphore system performance information

Prototype

Description

This service retrieves performance information about all the semaphores in the system. **NOTE:**

The Azure RTOS ThreadX library and application must be built with TX_SEMAPHORE_ENABLE_PERFORMANCE_INFO defined for this service to return performance information

Input Parameters

puts Pointer to destination for the total number of put requests

performed on all semaphores.

gets Pointer to destination for the total number of get requests performed

on all semaphores.

suspensions Pointer to destination for the total number of thread suspensions on

all semaphores.

timeouts Pointer to destination for the total number of thread suspension

timeouts on all semaphores.

Return Values

TX_SUCCESS (0x00) Successful semaphore system performance get.

TX_FEATURE_NOT_ENABLED The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

```
ULONG puts;
ULONG gets;
ULONG suspensions;
ULONG timeouts;
...
/* Retrieve performance information on all previously created semaphores. */
status = tx_semaphore_performance_system_info_get(&puts, &gets, &suspensions, &timeouts);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

tx_seamphore_ceiling_put, tx_semaphore_create, tx_semaphore_delete, tx_semaphore_get, tx_semaphore_info_get, tx_semaphore_performance_info_get, tx_semaphore_prioritize, tx_semaphore_put, tx_semaphore_put_notify

tx_semaphore_prioritize

Prioritize the semaphore suspension list

Prototype

```
UINT tx_semaphore_prioritize(TX_SEMAPHORE *semaphore_ptr)
```

Description

This service places the highest-priority thread suspended for an instance of the semaphore at the front of the suspension list. All other threads remain in the same FIFO order in which they were suspended.

Input Parameter

semaphore_ptr

Pointer to a previously created semaphore's Control Block.

Return Values

```
TX_SUCCESS<sup>5</sup> (0x00) Successful semaphore prioritize.
TX_SEMAPHORE_ERROR (0x0C) Invalid counting semaphore pointer.
```

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

```
TX_SEMAPHORE my_semaphore;
UINT status;
```

```
/* Ensure that the highest priority thread will receive the next
   instance of this semaphore. */
status = tx_semaphore_prioritize(&my_semaphore);
/* If status equals TX_SUCCESS, the highest priority suspended
   thread is at the front of the list. The next tx_semaphore_put
   call made to this queue will wake up this thread. */
```

tx_semaphore_put

Place an instance in a counting semaphore

Prototype

```
UINT tx semaphore put(TX SEMAPHORE *semaphore ptr)
```

Description

Conceptually, this service puts an instance into the specified counting semaphore. In reality, this service increments the counting semaphore by one. This service modifies the Semaphore Control Block through the parameter semaphore_ptr.

WARNING:

If this service is called when the semaphore is all ones (OxFFFFFFF), the new put operation will cause the semaphore to be reset to zero.

Input Parameter

semaphore_ptr Pointer to the previously created counting semaphore's Control Block.

Return Values

```
TX_SUCCESS<sup>6</sup> (0x00) Successful semaphore put.

TX SEMAPHORE ERROR (0x0C) Invalid pointer to counting semaphore.
```

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

```
TX_SEMAPHORE my_semaphore;
UINT status;
...
/* Increment the counting semaphore "my_semaphore." */
status = tx_semaphore_put(&my_semaphore);
/* If status equals TX_SUCCESS, the semaphore count has been incremented. Of course, if a thread was waiting, it was given the semaphore instance and resumed. */
```

tx_semaphore_put_notify

Notify application when semaphore is put

Prototype

Description

This service registers a notification callback function that is called whenever the specified semaphore is put. The processing of the notification callback is defined by the application.

Input Parameters

semaphore_ptr Pointer to previously created semaphore.

semaphore_put_notify Pointer to application's semaphore put notification function.

If this value is TX_NULL, notification is disabled.

Return Values

TX_SUCCESS (0x00) Successful registration of semaphore put

notification.

TX_SEMAPHORE_ERROR (0x0C) Invalid semaphore pointer.

TX_FEATURE_NOT_ENABLED (0xFF) The system was compiled with notification capabilities disabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

```
tx_seamphore_ceiling_put, tx_semaphore_create, tx_semaphore_delete, tx_semaphore_get, tx_semaphore_info_get, tx_semaphore_performance_info_get, tx_semaphore_performance_system_info_get, tx_semaphore_prioritize, tx_semaphore_put
```

Appendix H

Thread Services

The thread services described in this appendix include:

tx_thread_create Create an application thread tx_thread_delete Delete an application thread

tx_thread_entry_exit_notify Notify application upon thread entry and

exit

tx_thread_identify Retrieve pointer to currently executing

thread

tx_thread_info_get
Retrieve information about a thread
tx_thread_performance_info_get
Get thread performance information
tx_thread_performance_system_info_get
Get thread system performance

information

tx_thread_preemption_change Change preemption-threshold of thread tx_thread_priority_change Change priority of an application thread tx_thread_relinquish Relinquish control to other application

threads

tx_thread_reset Reset thread

tx_thread_resume Resume suspended application thread tx_thread_sleep Suspend current thread for specified time tx_thread_stack_error_notify Register thread stack error notification

callback

tx_thread_suspend Suspend an application thread tx_thread_terminate Terminate an application thread

tx_thread_time_slice_change Change time-slice of application thread tx_thread_wait_abort Abort suspension of specified thread

tx_thread_create

Create an application thread

Prototype

Description

This service creates an application thread, which will start execution at the specified task entry function. The stack, priority, preemption-threshold, and time-slice are among the attributes specified by the parameters. In addition, the auto_start parameter determines whether the thread starts executing immediately or is created in a suspended state. This service initializes the Thread Control Block through the parameter thread_ptr.

Input Parameters

thread_ptr	Pointer to a Thread Control Block.
name_ptr	Pointer to the name of the thread.
entry_function	Specifies the initial C function for thread execution. When a
	thread returns from this entry function, it is placed in a
	completed state and suspended indefinitely.
entry_input	A user-specified value to be passed as an argument to the
	thread entry function. The use of this value within the entry
	function is at the discretion of the user.
stack_start	Starting address of the stack's memory area.
stack_size	Number of bytes in the stack memory area. The thread's stack
	area must be large enough to handle its worst-case function
	call nesting and local variable usage.
priority ⁹⁹	Numerical priority of thread. Legal values are from 0 to

⁹⁹ TX_MAX_PRIORITIES is defined to be the number of priority levels. Legal values range from 32 through 1024 (inclusive) and must be evenly divisible by 32. By default, this value is set to 32

TX_MAX_PRIORITIES-1 (inclusive), where a value of 0 represents the highest priority.

preempt_thresholdHighest priority level (0-31) of disabled preemption. Only

priorities higher than this level are allowed to preempt this thread. This value must be less than or equal to the specified priority. A value equal to the thread priority disables

preemption-threshold.

time_slice Number of timer-ticks this thread is allowed to run before

other ready threads of the same priority get a chance to run. Note that using preemption-threshold disables time-slicing. Legal time-slice values range from 1 to 0xFFFFFFFF

(inclusive). A value of TX_NO_TIME_SLICE (a value of 0)

disables time-slicing of this thread.

Note: Using time-slicing results in a slight amount of system overhead. Since time-slicing is useful only in cases where multiple threads share the same priority, threads having a

unique priority should not be assigned a time-slice.

auto_start Specifies whether the thread starts immediately or is placed in

a suspended state. Legal options are TX_AUTO_START

(0x01) and TX_DONT_START (0x00). If

TX_DONT_START is specified, the application must later

call tx_thread_resume in order for the thread to run.

Return Values

 $TX_SUCCESS^{100}$ (0x00) Successful thread creation.

TX_THREAD_ERROR (0x0E) Invalid thread control pointer. Either the pointer is NULL or the thread has already been created.

TX_PTR_ERROR (0x03) Invalid starting address of the entry point, or the

stack area pointer is invalid, usually NULL.

 TX_SIZE_ERROR (0x05) Size of stack area is invalid. Threads must have at

priority levels, which we use in this book. Thus, we assume priority values in the range from 0 to 31 (inclusive).

¹⁰⁰ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

least TX_MINIMUM_STACK¹⁰¹ bytes to execute.

TX_PRIORITY_ERROR (0x0F) Invalid thread priority, which is a value outside the range of 0-31.

TX_THRESH_ERROR (0x18) Invalid preemption-threshold specified. This value must be a valid priority less than or equal to the initial priority of the thread.

TX_START_ERROR (0x10) Invalid auto-start selection.
TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

Yes

¹⁰¹ This value depends on the specific processor used and can be found in the file tx_port.h. The minimum value is 200, which is too small for most applications.

```
/* When we get here, the value of initial_input is 0x1234. See
how this was specified during creation. The real work of the
thread, including calls to other functions should be called
from here! When/if this function returns, the corresponding
thread is placed into a "completed" state and suspended. */
}
```

tx_thread_delete

Delete an application thread

Prototype

```
UINT tx thread delete(TX THREAD *thread ptr)
```

Description

This service deletes the specified application thread. Since the specified thread must be in a terminated or completed state, this service cannot be called from a thread attempting to delete itself.

NOTE:

It is the application's responsibility to manage the memory area associated with the thread's stack, which is available after this service completes. In addition, the application must not use a deleted thread.

Input Parameter

thread_ptr Po

Pointer to a previously created application thread's Control Block.

Return Values

 $^{^{102}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

completed state.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads and timer

Preemption Possible

No

Example

```
TX_THREAD my_thread;
UINT status;
...
/* Delete an application thread whose control block is
    "my_thread". Assume that the thread has already been created
    with a call to tx_thread_create. */
status = tx_thread_delete(&my_thread);
/* If status equals TX_SUCCESS, the application thread is
    deleted. */
```

tx_thread_entry_exit_notify

Notify application upon thread entry and exit

Prototype

Description

This service registers a notification callback function that is called whenever the specified thread is entered or exits. The processing of the notification callback is defined by the application.

Input Parameters

thread ptr

Pointer to previously created thread.

entry exit notify

Pointer to application's thread entry/exit notification function. The second parameter to the entry/exit notification function designates if an entry or exit is present. The value TX_THREAD_ENTRY (0x00) indicates the thread was entered, while the value TX_THREAD_EXIT (0x01) indicates the thread was exited. If this value is TX_NULL, notification is disabled.

Return Values

TX_SUCCESS (0x00) Successful registration of the thread entry/exit notification function.

TX_THREAD_ERROR (0x0E) Invalid thread pointer.

TX_FEATURE_NOT_ENABLED (0xFF) The system was compiled with notification capabilities disabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

See Also

```
tx_thread_create, tx_thread_delete, tx_thread_entry_exit_notify, tx_thread_identify, tx_thread_info_get, tx_thread_performance_info_get, tx_thread_performance_system_info_get, tx_thread_preemption_change, tx_thread_priority_change, tx_thread_relinquish, tx_thread_reset, tx_thread_resume, tx_thread_sleep, tx_thread_stack_error_notify, tx_thread_suspend, tx_thread_terminate, tx_thread_time_slice_change, tx_thread_wait_abort
```

tx_thread_identify

Retrieves pointer to currently executing thread

Prototype

```
TX THREAD* tx thread identify (VOID)
```

Description

This service returns a pointer to the currently executing thread's Control Block. If no thread is executing, this service returns a null pointer.

NOTE:

If this service is called from an ISR, the return value represents the thread running prior to the executing interrupt handler.

Parameters

None

Return Values

thread pointer Pointer to the currently executing thread's Control Block. If no

thread is executing, the return value is TX_NULL.

Allowed From

Threads and ISRs

Preemption Possible

No

Example

```
TX_THREAD *my_thread_ptr;
...
/* Find out who we are! */
my_thread_ptr = tx_thread_identify();
/* If my_thread_ptr is non-null, we are currently executing from that thread or an ISR that interrupted that thread. Otherwise, this service was called from an ISR when no thread was running when the interrupt occurred. */
```

tx_thread_info_get

Retrieve information about a thread

Prototype

Description

This service retrieves information about the specified thread.

Input Parameter

thread_ptr Pointer to a previously created thread's Control Block.

Output Parameters

name Pointer to destination for the pointer to the thread's name.

State Pointer to destination for the thread's current execution state.

Possible values are as follows:

TX_READY (0x00)

TX_COMPLETED (0x01)
TX_TERMINATED (0x02)
TX_SUSPENDED (0x03)

 $TX_SLEEP (0x04)$

TX_QUEUE_SUSP (0x05)

TX SEMAPHORE SUSP (0x06)

TX_EVENT_FLAG (0x07)

TX_BLOCK_MEMORY (0x08)
TX_BYTE_MEMORY (0x09)
TX_MUTEX_SUSP (0x0D)

TX IO DRIVER (0x0A)

run_count Pointer to destination for the thread's run count. Pointer to destination for the thread's priority.

preemption_threshold Pointer to destination for the thread's preemption-threshold.

time_slice Pointer to destination for the thread's time-slice.

next_thread Pointer to destination for next created thread pointer.

suspended_thread Pointer to destination for pointer to next thread in suspension

list.

Return Values

TX SUCCESS¹⁰³ (0x00) Successful thread information retrieval.

TX_THREAD_ERROR (0x0E) Invalid thread control pointer.

TX_PTR_ERROR (0x03) Invalid pointer (NULL) for any destination

pointer.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

¹⁰³ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_THREAD my thread;
CHAR *name;
UINT state;
ULONG run count;
UINT priority;
UINT preemption threshold;
UINT time slice;
TX THREAD *next thread;
TX THREAD *suspended thread;
UINT status;
/* Retrieve information about the previously created thread
   "my thread." */
status = tx thread info get(&my thread, &name, &state,
                             &run count, &priority,
                             &preemption threshold, &time slice,
                             &next thread, &suspended thread);
/* If status equals TX SUCCESS, the information requested is
  valid. */
```

tx_thread_performance_info_get

Get thread performance information

Prototype

Description

This service retrieves performance information about the specified thread.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_THREAD_ENABLE_PERFORMANCE_INFO defined in order for this service to return performance information.

Input Parameters

thread_ptr Pointer to previously created thread.

resumptions Pointer to destination for the number of resumptions of

this thread.

suspensions Pointer to destination for the number of suspensions of

this thread.

solicited_preemptions Pointer to destination for the number of preemptions as a

result of a Azure RTOS ThreadX API service call made

by this thread.

interrupt_preemptions Pointer to destination for the number of preemptions of

this thread as a result of interrupt processing.

priority_inversions Pointer to destination for the number of priority

inversions of this thread.

time slices Pointer to destination for the number of time-slices of

this thread.

relinquishes Pointer to destination for the number of thread

relinquishes performed by this thread.

timeouts Pointer to destination for the number of suspension

timeouts on this thread.

wait_aborts Pointer to destination for the number of wait aborts

performed on this thread.

last_preempted_by Pointer to destination for the thread pointer that last

preempted this thread.

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

```
TX_SUCCESS (0x00) Successful thread performance get.

TX_PTR_ERROR (0x03) Invalid thread pointer.

TX_FEATURE_NOT_ENABLED (0xFF) The system was not compiled with performance information enabled.
```

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX THREAD my thread;
ULONG resumptions;
ULONG suspensions;
ULONG solicited preemptions;
ULONG interrupt preemptions;
ULONG priority inversions;
ULONG time slices;
ULONG relinquishes;
ULONG timeouts;
ULONG wait aborts;
TX THREAD *last preempted by;
/* Retrieve performance information on the previously created
   thread. */
status = tx thread performance info get(&my thread, &resumptions,
                    &suspensions, &solicited preemptions,
                    &interrupt preemptions, &priority inversions,
                    &time slices, &relinquishes, &timeouts,
                    &wait aborts, &last preempted by);
/* If status is TX SUCCESS the performance information was
   successfully retrieved. */
```

See Also

tx_thread_create, tx_thread_delete, tx_thread_entry_exit_notify, tx_thread_identify, tx_thread_info_get, tx_thread_performance_system_info_get,

```
tx_thread_preemption_change, tx_thread_priority_change, tx_thread_relinquish, tx_thread_reset, tx_thread_resume, tx_thread_sleep, tx_thread_stack_error_notify, tx_thread_suspend, tx_thread_terminate, tx_thread_time_slice_change, tx_thread_wait_abort
```

tx_thread_performance_system_info_get

Get thread system performance information

Prototype

Description

This service retrieves performance information about all the threads in the system.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_THREAD_ENABLE_PERFORMANCE_INFO defined in order for this service to return performance information.

Input Parameters

resumptions Pointer to destination for the total number of thread

resumptions.

suspensions Pointer to destination for the total number of thread suspensions. solicited_preemptions Pointer to destination for the total number of thread preemptions

as a result of a thread calling a Azure RTOS ThreadX API

service.

interrupt_preemptions Pointer to destination for the total number of thread preemptions

as a result of interrupt processing.

priority_inversions Pointer to destination for the total number of thread priority

inversions.

time_slices Pointer to destination for the total number of thread time-slices. relinquishes Pointer to destination for the total number of thread relinquishes. timeouts Pointer to destination for the total number of thread suspension

timeouts.

wait_aborts Pointer to destination for the total number of thread wait aborts.

non idle returns Pointer to destination for the number of times a thread returns to

the system when another thread is ready to execute.

idle_returns Pointer to destination for the number of times a thread returns to

the system when no other thread is ready to execute (idle

system).

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS (0x00) Successful thread system performance get. TX_FEATURE_NOT_ENABLED (0xFF) The system was not compiled with performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

```
ULONG resumptions;

ULONG suspensions;

ULONG solicited_preemptions;

ULONG interrupt_preemptions;

ULONG priority_inversions;

ULONG time_slices;

ULONG relinquishes;
```

```
ULONG timeouts;
ULONG wait_aborts;
ULONG non_idle_returns;
ULONG idle_returns;
....
/* Retrieve performance information on all previously created thread. */
status = tx_thread_performance_system_info_get(&resumptions, &suspensions, &solicited_preemptions, &interrupt_preemptions, &interrupt_preemptions, &time_slices, &relinquishes, &timeouts, &relinquishes, &timeouts, &wait_aborts, &non_idle_returns, &idle_returns);
/* If status is TX_SUCCESS the performance information was successfully retrieved. */
```

See Also

tx_thread_create, tx_thread_delete, tx_thread_entry_exit_notify, tx_thread_identify, tx_thread_info_get, tx_thread_performance_info_get, tx_thread_preemption_change, tx_thread_priority_change, tx_thread_relinquish, tx_thread_reset, tx_thread_resume, tx_thread_sleep, tx_thread_stack_error_notify, tx_thread_suspend, tx_thread_terminate, tx_thread_time_slice_change, tx_thread_wait_abort

tx_thread_preemption_change

Change preemption-threshold of application thread

Prototype

Description

This service changes the preemption-threshold of the specified thread. The preemption-threshold prevents preemption of the specified thread by threads whose priority is equal

to or less than the preemption-threshold value. This service modifies the Thread Control Block through the parameter thread_ptr.

NOTE:

Using preemption-threshold disables time-slicing for the specified thread.

Input Parameters

thread_ptr Pointer to a previously created application thread's Control Block.

new_threshold New preemption-threshold priority level (0-31).

Output Parameter

old_threshold Pointer to a location to return the previous preemption-threshold.

Return Values

TX_SUCCESS¹⁰⁴ (0x00) Successful priority change.

TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_PRIORITY_ERROR (0x0F) Specified new priority is not valid (a value

otherthan 0-31).

TX_PTR_ERROR (0x03) Invalid pointer to previous priority

storagelocation.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads and timers

Preemption Possible

Yes

 $^{^{104}\,\}text{This}$ value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
TX_THREAD my_thread;
UINT my_old_threshold;
UINT status;
...
/* Disable all preemption of the specified thread. The current preemption-threshold is returned in "my_old_threshold". Assume that "my_thread" has already been created. */
status = tx_thread_preemption_change(&my_thread, 0, &my_old_threshold);
/* If status equals TX_SUCCESS, the application thread is non-preemptable by another thread. Note that ISRs are not prevented by preemption disabling. */
```

tx_thread_priority_change

Change priority of an application thread

Prototype

Description

This service changes the priority of the specified thread. Valid priorities range from 0 to 31 (inclusive), where 0 represents the highest-priority level. This service modifies the Thread Control Block through the parameter thread_ptr.

NOTE:

The preemption-threshold of the specified thread is set automatically to the new priority. If you want to give the thread a different preemption-threshold, you must call the tx_thread_preemption_change service after this call.

Input Parameters

thread ptr

Pointer to a previously created application thread's Control Block.

new_priority New thread priority level (0-31).

Output Parameter

old_priority Pointer to a location to return the thread's previous priority.

Return Values

TX_SUCCESS¹⁰⁵ (0x00) Successful priority change.

TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_PRIORITY_ERROR (0x0F) New priority not valid (a value other than 0-31).

TX_PTR_ERROR (0x03) Invalid pointer to previous priority storage location.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads and timers

Preemption Possible

Yes

Example

tx_thread_relinquish

 $^{^{105}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Relinquish control to other application threads

Prototype

```
VOID tx thread relinquish (VOID)
```

Description

This service relinquishes processor control to other ready-to-run threads at the same or higher priority.

Parameters

None

Return Values

None

Allowed From

Threads

Preemption Possible

Yes

```
ULONG run_counter_1 = 0;
ULONG run_counter_2 = 0;
...

/* Example of two threads relinquishing control to each other in an infinite loop. Assume that both of these threads are ready and have the same priority. The run counters will always stay within one count of each other. */
VOID my_first_thread(ULONG thread_input)
{
    /* Endless loop of relinquish. */
    while(1)
```

```
{
  /* Increment the run counter. */
  run_counter_1++;
  /* Relinquish control to other thread. */
  tx_thread_relinquish();
  }
}
VOID my_second_thread(ULONG thread_input)
{
  /* Endless loop of relinquish. */
  while(1)
  {
    /* Increment the run counter. */
  run_counter_2++;
    /* Relinquish control to other thread. */
  tx_thread_relinquish();
  }
}
```

tx_thread_reset

Reset thread

Prototype

```
UINT tx thread reset (TX THREAD *thread ptr);
```

Description

This service resets the specified thread to execute at the entry point defined at thread creation. The thread must be in either a TX_COMPLETED or TX_TERMINATED state for it to be reset

NOTE:

The thread must be resumed for it to execute again.

Input Parameters

thread_ptr Pointer to a previously created thread.

Return Values

TX_SUCCESS (0x00) Successful thread reset.

TX_NOT_DONE (0x20) Specified thread is not in a TX_COMPLETED or

TX_TERMINATED state.

TX_THREAD_ERROR (0x0E) Invalid thread pointer.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads

Example

```
TX_THREAD my_thread;
...
/* Reset the previously created thread "my_thread." */
status = tx_thread_reset(&my_thread);
/* If status is TX SUCCESS the thread is reset. */
```

See Also

```
tx_thread_create, tx_thread_delete, tx_thread_entry_exit_notify, tx_thread_identify, tx_thread_info_get, tx_thread_performance_info_get, tx_thread_preformance_system_info_get, tx_thread_preemption_change, tx_thread_priority_change, tx_thread_relinquish, tx_thread_resume, tx_thread_sleep, tx_thread_stack_error_notify, tx_thread_suspend, tx_thread_terminate, tx_thread_time_slice_change, tx_thread_wait_abort
```

tx_thread_resume

Resume suspended application thread

Prototype

```
UINT tx_thread_resume(TX_THREAD *thread_ptr)
```

Azure RTOS ThreadX

Description

This service resumes or prepares for execution a thread that was previously suspended by a *tx_thread_suspend* call. In addition, this service resumes threads that were created without an automatic start.

Input Parameter

thread_ptr Pointer to a suspended application thread's Control Block.

Return Values

```
TX_SUCCESS<sup>106</sup> (0x00) Successful resumption of thread.

TX_SUSPEND_LIFTED (0x19) Previously set delayed suspension was lifted.

TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_RESUME_ERROR (0x12) Specified thread is not suspended or was previously suspended by a service other than tx_thread_suspend.
```

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

```
TX_THREAD my_thread;
UINT status;
...
/* Resume the thread represented by "my_thread". */
status = tx_thread_resume(&my_thread);
/* If status equals TX_SUCCESS, the application thread is now ready to execute. */
```

 $^{^{106}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

tx_thread_sleep

Suspend current thread for specified time.

Prototype

```
UINT tx thread sleep (ULONG timer ticks)
```

Description

This service causes the calling thread to suspend for the specified number of timer-ticks. The amount of physical time associated with a timer-tick is application-specific. This service can be called only from an application thread.

Input Parameter

timer_ticks

The number of timer-ticks to suspend the calling application thread, ranging from 0 to 0xFFFFFFFF (inclusive). If 0 is specified, the service returns immediately.

Return Values

TX_SUCCESS¹⁰⁷ (0x00) Successful thread sleep.

TX_WAIT_ABORTED (0x1A) Suspension was aborted by another thread, timer, or ISR.

TX_CALLER_ERROR (0x13) Service called from a non-thread.

Allowed From

Threads

Preemption Possible

Yes

Example

UINT status;

¹⁰⁷ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
"
/* Make the calling thread sleep for 100 timer-ticks. */
status = tx_thread_sleep(100);
/* If status equals TX_SUCCESS, the currently running application
    thread slept for the specified number of timer-ticks. */
```

tx_thread_stack_error_notify

Register thread stack error notification callback.

Prototype

Description

This service registers a notification callback function for handling thread stack errors. When Azure RTOS ThreadX detects a thread stack error during execution, it will call this notification function to process the error. Processing of the error is completely defined by the application. Anything from suspending the violating thread to resetting the entire system may be done.

NOTE:

The Azure RTOS ThreadX library must be built with TX_ENABLE_STACK_CHECKING defined in order for this service to return performance information.

Input Parameters

error_handler Pointer to application's stack error handling

function. If this value is TX_NULL, the notification

is disabled.

Return Values

```
TX_SUCCESS (0x00) Successful thread reset.

TX_FEATURE_NOT_ENABLED (0xFF) The system was not compiled with
```

performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
void my_stack_error_handler(TX_THREAD *thread_ptr);
/* Register the "my_stack_error_handler" function with Azure RTOS
   ThreadX so that thread stack errors can be handled by the
   application. */
status = tx_thread_stack_error_notify(my_stack_error_handler);
/* If status is TX_SUCCESS the stack error handler is
   registered.*/
```

See Also

```
tx_thread_create, tx_thread_delete, tx_thread_entry_exit_notify, tx_thread_identify, tx_thread_info_get, tx_thread_performance_info_get, tx_thread_preformance_system_info_get, tx_thread_preemption_change, tx_thread_priority_change, tx_thread_relinquish, tx_thread_reset, tx_thread_resume, tx_thread_sleep, tx_thread_suspend, tx_thread_terminate, tx_thread_time_slice_change, tx_thread_wait_abort
```

tx_thread_suspend

Suspend an application thread

Prototype

```
UINT tx_thread_suspend(TX_THREAD *thread_ptr)
```

Description

This service suspends the specified application thread. A thread may call this service to suspend itself.

NOTE:

If the specified thread is already suspended for another reason, this new suspension is held internally until the prior suspension is lifted. When the prior suspension is lifted, this new unconditional suspension of the specified thread is performed. Further unconditional suspension requests have no effect.

Once suspended, the thread must be resumed by tx_thread_resume in order to execute again.

Input Parameter

thread_ptr Pointer to an application Thread Control Block.

Return Values

TX_SUCCESS¹⁰⁸ (0x00) Successful suspension of thread.

TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_SUSPEND_ERROR9 (0x14) Specified thread is in a terminated or completed state.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads and timers

Preemption Possible

Yes

Example

```
TX_THREAD my_thread;
UINT status;
```

¹⁰⁸ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

```
...
/* Suspend the thread represented by "my_thread". */
status = tx_thread_suspend(&my_thread);
/* If status equals TX_SUCCESS, the application thread is
unconditionally suspended. */
```

tx_thread_terminate

Terminates an application thread

Prototype

```
UINT tx thread terminate (TX THREAD *thread ptr)
```

Description

This service terminates the specified application thread regardless of whether or not the thread is suspended. A thread may call this service to terminate itself. This service modifies the Thread Control Block through the parameter thread_ptr.

NOTE:

Once terminated, the thread must be reset in order for it to execute again.

Input Parameter

thread_ptr Pointer to a previously created application thread's Control Block.

Return Values

```
TX_SUCCESS<sup>109</sup> (0x00) Successful thread termination.
TX_THREAD_ERROR (0x0E) Invalid application thread pointer.
TX_CALLER_ERROR (0x13) Invalid caller of this service.
```

Allowed From

Threads and timers

¹⁰⁹ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Preemption Possible

Yes

Example

```
TX_THREAD my_thread;
UINT status;
...
/* Terminate the thread represented by "my_thread". */
status = tx_thread_terminate(&my_thread);
/* If status equals TX_SUCCESS, the thread is terminated and cannot execute again until it is deleted and re-created. */
```

tx_thread_time_slice_change

Changes time-slice of application thread

Prototype

Description

This service changes the time-slice of the specified application thread. Selecting a time-slice for a thread ensures that it won't execute more than the specified number of timer-ticks before other threads of the same or higher priorities have a chance to execute. This service modifies the Thread Control Block through the parameter thread_ptr.

NOTE:

Using preemption-threshold disables time-slicing for the specified thread.

Input Parameters

thread_ptr Pointer to a previously created application thread's Control

Block.

 TX_NO_TIME_SLICE and numeric values from 1 to 0xFFFFFFF (inclusive).

Output Parameter

old_time_slice Pointer to location for storing the previous time-slice value of

the specified thread.

Return Values

 $TX_SUCCESS^{110}$ (0x00) Successful time-slice chance. TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_PTR_ERROR (0x03) Invalid pointer to previous time-slice storage

location.

TX_CALLER_ERROR (0x13) Invalid caller of this service.

Allowed From

Threads and timers

Preemption Possible

No

Example

¹¹⁰ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

*/

tx_thread_wait_abort

Abort suspension of specified thread

Prototype

```
UINT tx thread wait abort(TX THREAD *thread ptr)
```

Description

This service aborts a sleep or any other object's suspension of the specified thread. If the wait is aborted, a TX_WAIT_ABORTED value is returned from the service that the thread was waiting on.

NOTE:

This service does not release an unconditional suspension that was caused by the tx_thread_suspend service

Input Parameter

thread_ptr Pointer to a previously created application thread's Control Block.

Return Values

```
TX_SUCCESS (0x00) Successful thread wait abort.

TX_THREAD_ERROR (0x0E) Invalid application thread pointer.

TX_WAIT_ABORT_ERROR (0x1B) Specified thread is not in a waiting state.
```

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

Yes

Example

```
TX_THREAD my_thread;
UINT status;
...
/* Abort the suspension condition of "my_thread." */
status = tx_thread_wait_abort(&my_thread);
/* If status equals TX_SUCCESS, the thread is now ready again,
   with a return value showing its suspension was aborted
   (TX WAIT ABORTED). */
```

Appendix I

Internal System Clock Services

The time services described in this appendix are:

tx_time_get Retrieves the current time tx_time_set Sets the current time

tx_time_get

Retrieves the current time

Prototype

ULONG tx time get(VOID)

Description

This service returns the contents of the internal system clock. Each timer-tick increases the internal system clock count by one. The system clock is set to zero during initialization and can be changed to a specific value by the service *tx_time_set*.

WARNING:

The physical time interval each timer-tick represents is application-specific.

Parameters

None

Return Values

system clock ticks Value of the internal, free running, system clock.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
ULONG current_time;
...
/* Pickup the current system time, in timer-ticks. */
current_time = tx_time_get();
/* Current time now contains a copy of the internal system clock. */
```

tx_time_set

Sets the current time

Prototype

```
VOID tx_time_set(ULONG new_time)
```

Description

This service sets the internal system clock to the specified value. Each subsequent timertick increases the internal system clock count by one.

WARNING:

The physical time interval each timer-tick represents is application-specific.

Return Values

None

Allowed From

Threads, timers, and ISRs

Preemption Possible

No

Example

```
/* Set the internal system time to 0x1234. */ tx_time_set(0x1234); /* Current time now contains 0x1234 until the next timer interrupt. */
```

Appendix J

Application Timer Services

The application timer services described in this appendix include:

tx_timer_activateActivate an application timertx_timer_changeChange an application timertx_timer_createCreate an application timertx_timer_deactivateDeactivate an application timertx_timer_deleteDelete an application timer

tx_timer_info_get Retrieve information about an application

timer

tx_timer_performance_info_get Get timer performance information

tx_timer_activate

Activate an application timer

Prototype

```
UINT tx timer activate (TX TIMER*timer ptr)
```

Description

This service activates the specified application timer. The expiration routines of timers that expire at the same time are executed in the order they were activated. This service modifies the Application Timer Control Block through the parameter timer_ptr.

Input Parameter

timer_ptr Pointer to a previously created application timer's Control Block.

Return Values

TX_SUCCESS ¹¹¹	(0×00)	Successful application timer activation.
TX_TIMER_ERROR	(0×15)	Invalid application timer pointer.
TX_ACTIVATE_ERROR1	(0×17)	Timer was already active.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
TX_TIMER my_timer;
UINT status;
...
/* Activate an application timer. Assume that the application timer has already been created. */
status = tx_timer_activate (&my_timer);
/* If status equals TX_SUCCESS, the application timer is now active. */
```

tx_timer_change

Change an application timer

Prototype

 $^{^{111}}$ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Description

This service changes the expiration characteristics of the specified application timer. The timer must be deactivated prior to calling this service. This service modifies the Application Timer Control Block through the parameter timer_ptr.

WARNING:

You must call the tx_timer_activate service after calling this service in order to restart the timer.

Input Parameters

timer_ptr	Pointer to a previously created timer's Control Block.
initial_ticks	Specifies the initial number of timer-ticks for timer expiration.
	Legal values range from 1 to 03FFFFFFF (inclusive).
reschedule_ticks	Specifies the number of timer-ticks for all timer expirations after
	the first. A zero for this parameter makes the timer a one-shot
	timer. Otherwise, for periodic timers, legal values range from 1
	to 03FFFFFFF (inclusive).

Return Values

TX_SUCCESS ¹¹²	(0×00)	Successful application timer change.
TX_TIMER_ERROR	(0×15)	Invalid application timer pointer.
TX_TICK_ERROR	(0×16)	Invalid value (a zero) supplied for initial
		timer-ticks.
TX_CALLER_ERROR	(0×13)	Invalid caller of this service.

Allowed From

Threads, timers, and ISRs

Preemption Possible

No

¹¹² This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_TIMER my_timer;
UINT status;
...
/* Change a previously created and now deactivated timer to
    expire every 50 timer-ticks for initial and subsequent
    expirations. */
status = tx_timer_change (&my_timer,50, 50);
/* If status equals TX_SUCCESS, the specified timer is changed to
    expire every 50 timer-ticks. */
/* Activate the specified timer to get it started again. */
status = tx timer activate(&my timer);
```

tx_timer_create

Create an application timer

Prototype

Description

This service creates an application timer with the specified expiration function and periodic expiration interval. This service initializes the timer Control Block through the parameter timer_ptr.

Input Parameters

timer_ptr	Pointer to a timer Control Block
name_ptr	Pointer to the name of the timer.
expiration_function	Application function to call when the timer expires.
expiration_input	Input to pass to expiration function when the timer expires.

initial_ticks Specifies the initial number of timer-ticks for timer expiration.

Legal values range from 1 to 0xFFFFFFF (inclusive).

reschedule_ticks Specifies the number of timer-ticks for all timer expirations

after the first. A zero for this parameter makes the timer a one-shot timer. Otherwise, for periodic timers, legal values range

from 1 to 0xFFFFFFF (inclusive).

Auto_activate Determines whether the timer is automatically activated during

creation. If this value is TX_AUTO_ACTIVATE (0x01) the

timer is made active. Otherwise, if the value

TX_NO_ACTIVATE (0x00) is selected, the timer is created in a non-active state. In this case, a subsequent tx_timer_activate service call is necessary to get the timer actually started.

Return Values

TX_SUCCESS ¹¹³	(0x00)	Successful application timer creation.
TX_TIMER_ERROR	(0x15)	Invalid application timer pointer. Either
		the pointer is NULL or the timer has
		already been created.
TX_TICK_ERROR	(0x16)	Invalid value (a zero) supplied for initial
		timer-ticks.
TX_ACTIVATE_ERROR	(0x17)	Invalid activation selected.
TX_CALLER_ERROR	(0x13)	Invalid caller of this service.

Allowed From

Initialization and threads

Preemption Possible

No

¹¹³ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Example

```
TX_TIMER my_timer;
UINT status;
...
/* Create an application timer that executes "my_timer_function"
   after 100 timer-ticks initially and then after every 25 timer-
   ticks. This timer is specified to start immediately! */
status = tx_timer_create (&my_timer,"my_timer_name",
   my_timer_function, 0x1234, 100, 25, TX_AUTO_ACTIVATE);
/* If status equals TX_SUCCESS, my_timer_function will be called
   100 timer-ticks later and then called every 25 timer-ticks.
   Note that the value 0x1234 is passed to my_timer_function
   every time it is called. */
```

tx_timer_deactivate

Deactivate an application timer

Prototype

```
UINT tx timer deactivate (TX TIMER *timer ptr)
```

Description

This service deactivates the specified application timer. If the timer is already deactivated, this service has no effect. This service may modify the timer Control Block through the parameter timer_ptr.

Input Parameter

timer_ptr Pointer to a previously created application timer's Control Block.

Return Values

TX_SUCCESS ¹¹⁴	(0x00)	Successful application timer deactivation.
TX_TIMER_ERROR	(0x15)	Invalid application timer pointer.

¹¹⁴ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Allowed From

Initialization, threads, timers, and ISRs

Preemption Possible

No

Example

```
TX_TIMER my_timer;
UINT status;
...
/* Deactivate an application timer. Assume that the application timer has already been created. */
status = tx_timer_deactivate(&my_timer);
/* If status equals TX_SUCCESS, the application timer is now deactivated. */
```

tx_timer_delete

Delete an application timer

Prototype

```
UINT tx timer delete(TX TIMER *timer ptr)
```

Description

This service deletes the specified application timer.

WARNING:

It is the application's responsibility to prevent use of a deleted timer.

Input Parameter

timer_ptr Pointer to a previously created application timer's Control Block.

Return Values

TX_SUCCESS ¹¹⁵	(0x00)	Successful application timer deletion.
TX_TIMER_ERROR	(0x15)	Invalid application timer pointer.
TX CALLER ERROR	(0x13)	Invalid caller of this service.

Allowed From

Threads

Preemption Possible

No

Example

```
TX_TIMER my_timer;
UINT status;
...
/* Delete application timer. Assume that the application timer
  has already been created. */
status = tx_timer_delete(&my_timer);
/* If status equals TX_SUCCESS, the application timer is deleted.
*/
```

tx_timer_info_get

Retrieve information about an application timer

Prototype

 $^{^{115}\,\}text{This}$ value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Description

This service retrieves information about the specified application timer.

application timer.

Input Parameter

timer_ptr Pointer to a previously created application timer's Control Block.

Output Parameters

name	Pointer to destination for the pointer to the timer's name.
active	Pointer to destination for the timer active indication. If the
	timer is inactive or this service is called from the timer itself, a
	TX_FALSE value is returned. Otherwise, if the timer is active,
	a TX_TRUE value is returned.
remaining_ticks	Pointer to destination for the number of timer-ticks left before
	the timer expires.
reschedule_ticks	Pointer to destination for the number of timer-ticks that will be
	used to automatically reschedule this timer. If the value is zero,
	then the timer is a one-shot and won't be rescheduled.
next_timer	Pointer to destination for the pointer of the next created

Return Values

TX_SUCCESS ¹¹⁶	(0x00)	Successful timer information retrieval.
TX_TIMER_ERROR	(0x15)	Invalid application timer pointer.
TX_PTR_ERROR	(0x03)	Invalid pointer (NULL) for any
		destination pointer.

Allowed From

Initialization, threads, timers, and ISRs

¹¹⁶ This value is not affected by the TX_DISABLE_ERROR_CHECKING define that is used to disable API error checking.

Preemption Possible

No

Example

tx_timer_performance_info_get

Get timer performance information

Prototype

Description

This service retrieves performance information about the specified application timer.

NOTE:

The Azure RTOS ThreadX library and application must be built with TX_TIMER_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

timer_ptr Pointer to previously created timer.

activates Pointer to destination for the number of activation requests

performed on this timer.

reactivates Pointer to destination for the number of automatic reactivations

performed on this periodic timer.

deactivates Pointer to destination for the number of deactivation requests

performed on this timer.

expirations Pointer to destination for the number of expirations of this timer.

expiration_adjusts Pointer to destination for the number of internal expiration

adjustments performed on this timer. These adjustments are done in the timer interrupt processing for timers that are larger than the default timer list size (by default timers with expirations greater

than 32 ticks).

NOTE:

Supplying a TX_NULL for any parameter indicates the parameter is not required.

Return Values

TX_SUCCESS	(0x00)	Successful timer performance get.
TX_PTR_ERROR	(0x03)	Invalid timer pointer.
TX_FEATURE_NOT_ENABLED	(0xFF)	The system was not compiled with
		performance information enabled

Allowed From

Initialization, threads, timers, and ISRs

Example

```
TX_TIMER my_timer;
ULONG activates;
ULONG reactivates;
ULONG deactivates;
ULONG expirations;
ULONG expiration_adjusts;
...
/* Retrieve performance information on the previously created timer. */
status = tx_timer_performance_info_get(&my_timer, &activates, &reactivates, &deactivates, &reactivates, &deactivates, &reactivates, &react
```

See Also

tx_timer_activate, tx_timer_change, tx_timer_create, tx_timer_deactivate, tx_timer_delete, tx_timer_info_get, tx_timer_performance_system_info_get

tx_timer_performance_system_info_get

Get timer system performance information

Prototype

Description

This service retrieves performance information about all the application timers in the system.

NOTE:

The Azure RTOS ThreadX library and application must be built with

TX_TIMER_ENABLE_PERFORMANCE_INFO defined for this service to return performance information.

Input Parameters

activates Pointer to destination for the total number of activation requests

performed on all timers.

reactivates Pointer to destination for the total number of automatic

reactivation performed on all periodic timers.

deactivates Pointer to destination for the total number of deactivation

requests performed on all timers.

expirations Pointer to destination for the total number of expirations on all

timers.

expiration_adjusts Pointer to destination for the total number of internal expiration

adjustments performed on all timers. These adjustments are done in the timer interrupt processing for timers that are larger than the default timer list size (by default timers with expirations

greater than 32 ticks).

NOTE:

Supplying a TX_NULL for any parameter indicates that the parameter is not required.

Return Values

TX_SUCCESS	(0x00)	Successful timer system performance get.
TX_FEATURE_NOT_ENABLED	(0xFF)	The system was not compiled with
		performance information enabled.

Allowed From

Initialization, threads, timers, and ISRs

Example

```
ULONG activates;
ULONG reactivates;
ULONG deactivates;
ULONG expirations;
```

Azure RTOS ThreadX

See Also

tx_timer_activate, tx_timer_change, tx_timer_create, tx_timer_deactivate, tx_timer_delete, tx_timer_info_get, tx_timer_performance_info_get

Appendix K

Azure RTOS ThreadX API¹¹⁷

Azure RTOS ThreadX Entry

```
VOID tx kernel enter(VOID);
```

Memory Byte Pool Services

```
UINT tx byte allocate (TX BYTE POOL *pool ptr,
 VOID **memory ptr,
 ULONG memory size,
 ULONG wait option);
UINT tx byte pool create (TX BYTE POOL *pool ptr,
 CHAR *name ptr,
 VOID *pool start,
 ULONG pool size);
UINT tx byte pool delete(TX BYTE POOL *pool ptr);
UINT tx byte pool info get(TX BYTE POOL *pool ptr,
 CHAR **name,
 ULONG *available bytes,
 ULONG *fragments,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX BYTE POOL **next pool);
UINT tx byte pool performance info get(TX BYTE POOL *pool ptr,
 ULONG *allocates,
 ULONG *releases,
 ULONG *fragments searched,
 ULONG *merges,
 ULONG *splits,
 ULONG *suspensions,
```

¹¹⁷ Azure RTOS ThreadX is a registered trademark of Microsoft. The Azure RTOS ThreadX API, associated data structures, and data types are copyrights of Microsoft.

```
ULONG *timeouts);

UINT tx_byte_pool_performance_system_info_get(ULONG *allocates,
    ULONG *releases,
    ULONG *fragments_searched,
    ULONG *merges,
    ULONG *splits,
    ULONG *suspensions,
    ULONG *timeouts);

UINT tx_byte_pool_prioritize(TX_BYTE_POOL *pool_ptr);

UINT tx byte release(VOID *memory ptr);
```

Memory Block Pool Services

```
UINT tx block allocate (TX BLOCK POOL *pool ptr,
 VOID **block ptr,
 ULONG wait option);
UINT tx block pool create (TX BLOCK POOL *pool ptr,
 CHAR *name ptr,
 ULONG block size,
 VOID *pool start,
 ULONG pool size);
UINT tx block pool delete (TX BLOCK POOL *pool ptr);
UINT tx block pool info get (TX BLOCK POOL *pool ptr,
 CHAR **name,
 ULONG *available blocks,
 ULONG *total blocks,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX BLOCK POOL **next pool);
UINT tx block pool performance info get(TX BLOCK POOL *pool ptr,
 ULONG *allocates,
 ULONG *releases,
 ULONG *suspensions,
 ULONG *timeouts);
UINT tx block pool performance system info get(ULONG *allocates,
 ULONG *releases,
```

```
ULONG *suspensions,
  ULONG *timeouts);

UINT tx_block_pool_prioritize(TX_BLOCK_POOL *pool_ptr);

UINT tx_block_release(VOID *block_ptr);
```

Event Flag Services

```
UINT tx event flags create (TX EVENT FLAGS GROUP *group ptr,
 CHAR *name ptr);
UINT tx event flags delete (TX EVENT FLAGS GROUP *group ptr);
UINT tx event flags get(TX EVENT FLAGS GROUP *group ptr,
 ULONG requested flags,
 UINT get option,
 ULONG *actual flags ptr,
 ULONG wait option);
UINT tx_event_flags_info_get(TX_EVENT_FLAGS_GROUP *group ptr,
 CHAR **name,
 ULONG *current flags,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX EVENT FLAGS GROUP **next group);
UINT tx event flags performance info get (TX EVENT FLAGS GROUP
 *group ptr,
 ULONG *sets,
 ULONG *gets,
 ULONG *suspensions,
 ULONG *timeouts);
UINT tx event flags performance system info get(ULONG *sets,
 ULONG *gets, ULONG *suspensions,
 ULONG *timeouts);
UINT tx event flags set(TX EVENT FLAGS GROUP *group ptr,
 ULONG flags to set, UINT set option);
UINT tx event flags set notify(TX EVENT FLAGS GROUP *group ptr,
 VOID(*events set notify)(TX EVENT FLAGS GROUP *));
```

Interrupt Control Service

```
UINT tx_interrupt_control(UINT new_posture);
```

Message Queue Services

```
UINT tx queue create (TX QUEUE *queue ptr,
 CHAR *name ptr,
 UINT message size,
 VOID *queue start,
 ULONG queue size);
UINT tx queue delete (TX QUEUE *queue ptr);
UINT tx queue flush (TX QUEUE *queue ptr);
UINT tx queue front send(TX QUEUE *queue ptr,
 VOID *source ptr,
 ULONG wait option);
UINT tx queue info get(TX QUEUE *queue_ptr,
 CHAR **name,
 ULONG *enqueued,
 ULONG *available storage,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX QUEUE **next queue);
UINT tx queue performance info get(TX QUEUE *queue ptr,
 ULONG *messages_sent,
 ULONG *messages received,
 ULONG *empty suspensions,
 ULONG *full suspensions,
 ULONG *full errors,
 ULONG *timeouts);
UINT tx queue performance system info get(ULONG *messages sent,
 ULONG *messages received,
 ULONG *empty suspensions,
 ULONG *full suspensions,
 ULONG *full errors,
 ULONG *timeouts);
UINT tx queue prioritize (TX QUEUE *queue ptr);
```

```
UINT tx_queue_receive(TX_QUEUE *queue_ptr,
    VOID *destination_ptr,
    ULONG wait_option);

UINT tx_queue_send(TX_QUEUE *queue_ptr,
    VOID *source_ptr,
    ULONG wait_option);

UINT tx_queue_send_notify(TX_QUEUE *queue_ptr,
    VOID (*queue_send_notify)(TX_QUEUE *));
```

Semaphore Services

```
UINT tx semaphore ceiling put (TX SEMAPHORE *semaphore ptr,
 ULONG ceiling);
UINT tx semaphore create (TX SEMAPHORE *semaphore ptr,
 CHAR *name ptr,
 ULONG initial count);
UINT tx semaphore delete(TX SEMAPHORE *semaphore ptr);
UINT tx semaphore get (TX SEMAPHORE *semaphore ptr,
 ULONG wait option);
UINT tx semaphore info get(TX SEMAPHORE *semaphore ptr,
 CHAR **name,
 ULONG *current_value,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX SEMAPHORE **next semaphore);
UINT tx semaphore performance info get(TX SEMAPHORE *semaphore ptr,
 ULONG *puts,
 ULONG *gets,
 ULONG *suspensions,
 ULONG *timeouts);
UINT tx semaphore performance system info get (ULONG *puts,
 ULONG *gets,
 ULONG *suspensions,
 ULONG *timeouts);
UINT tx semaphore prioritize (TX SEMAPHORE *semaphore ptr);
UINT tx semaphore put (TX SEMAPHORE *semaphore ptr);
```

```
UINT tx_semaphore_put_notify(TX_SEMAPHORE *semaphore_ptr,
    VOID (*semaphore put notify)(TX SEMAPHORE *));
```

Mutex Services

```
UINT tx mutex create (TX MUTEX *mutex ptr,
 CHAR *name ptr,
 UINT inherit);
UINT tx mutex delete(TX MUTEX *mutex ptr);
UINT tx mutex get (TX MUTEX *mutex ptr,
 ULONG wait option);
UINT tx mutex info get (TX MUTEX *mutex ptr,
 CHAR **name,
 ULONG *count,
 TX THREAD **owner,
 TX THREAD **first suspended,
 ULONG *suspended count,
 TX MUTEX **next mutex);
UINT tx mutex performance info get(TX MUTEX *mutex ptr,
 ULONG *puts,
 ULONG *gets,
 ULONG *suspensions,
 ULONG *timeouts,
 ULONG *inversions,
 ULONG *inheritances);
UINT tx mutex performance system info get (ULONG *puts,
 ULONG *gets,
 ULONG *suspensions,
 ULONG *timeouts,
 ULONG *inversions,
 ULONG *inheritances);
UINT tx mutex prioritize (TX MUTEX *mutex ptr);
UINT tx mutex put (TX MUTEX *mutex ptr);
```

Thread Services

```
UINT tx thread create (TX THREAD *thread ptr,
 CHAR *name ptr,
 VOID(*entry function)(ULONG),
 ULONG entry input,
 VOID *stack start,
 ULONG stack size,
 UINT priority,
 UINT preempt threshold,
 ULONG time slice,
 UINT auto start);
UINT tx thread delete (TX THREAD *thread ptr);
UINT tx thread entry exit notify(TX THREAD *thread ptr,
 VOID(*entry exit notify)(TX THREAD *, UINT));
TX THREAD *tx thread identify(VOID);
UINT tx_thread_info get(TX THREAD *thread ptr,
 CHAR **name,
 UINT *state,
 ULONG *run count,
 UINT *priority,
 UINT *preemption_threshold,
 ULONG *time_slice,
 TX THREAD **next thread,
 TX THREAD **next suspended thread);
UINT tx thread performance info get(TX THREAD *thread ptr,
 ULONG *resumptions,
 ULONG *suspensions,
 ULONG *solicited preemptions,
 ULONG *interrupt preemptions,
 ULONG *priority inversions,
 ULONG *time slices,
 ULONG *relinquishes,
 ULONG *timeouts,
 ULONG *wait aborts,
 TX THREAD **last preempted by);
UINT tx thread performance system info get(ULONG *resumptions,
 ULONG *suspensions,
```

```
ULONG *solicited preemptions,
 ULONG *interrupt preemptions,
 ULONG *priority inversions,
 ULONG *time slices,
 ULONG *relinquishes,
 ULONG *timeouts,
 ULONG *wait aborts,
 ULONG *non idle returns,
 ULONG *idle returns);
UINT tx thread preemption change (TX THREAD *thread ptr,
 UINT new threshold,
 UINT *old threshold);
UINT tx thread priority change (TX THREAD *thread ptr,
 UINT new priority,
 UINT *old priority);
VOID tx thread relinquish (VOID);
UINT tx thread reset (TX THREAD *thread ptr);
UINT tx thread resume (TX THREAD *thread ptr);
UINT tx thread sleep (ULONG timer ticks);
UINT tx thread stack error notify(VOID(*error handler)
 (TX THREAD *));
UINT tx thread suspend(TX THREAD *thread ptr);
UINT tx thread terminate (TX THREAD *thread ptr);
UINT tx thread time slice change (TX THREAD *thread ptr,
 ULONG new time slice,
 ULONG *old time slice);
UINT tx thread wait abort (TX THREAD *thread ptr);
Time Services
```

```
ULONG tx_time_get(VOID);
VOID tx time set(ULONG new time);
```

Timer Services

```
UINT tx timer activate (TX TIMER *timer ptr);
UINT tx timer change (TX TIMER *timer ptr,
 ULONG initial ticks,
 ULONG reschedule ticks);
UINT tx timer create (TX TIMER *timer ptr,
 CHAR *name ptr,
 VOID(*expiration function)(ULONG),
 ULONG expiration_input,
 ULONG initial ticks,
 ULONG reschedule ticks,
 UINT auto activate);
UINT tx_timer_deactivate(TX_TIMER *timer_ptr);
UINT tx timer delete(TX TIMER *timer ptr);
UINT tx timer info get(TX TIMER *timer ptr,
 CHAR **name,
 UINT *active,
 ULONG *remaining ticks,
 ULONG *reschedule ticks,
 TX_TIMER **next_timer);
UINT tx timer performance info get (TX TIMER *timer ptr,
 ULONG *activates,
 ULONG *reactivates,
 ULONG *deactivates,
 ULONG *expirations,
 ULONG *expiration adjusts);
UINT tx timer performance system info get(ULONG *activates,
 ULONG *reactivates,
 ULONG *deactivates,
 ULONG *expirations,
 ULONG *expiration adjusts);
```

Index

abort thread suspension71
activation of timer146
allocate bytes108
allocation of memory 36, 123
application timer 39, 40, 44, 62, 64,
71, 125, 126, 127, 128, 129, 130,
131, 132, 133, 134, 135, 136, 138,
143, 144, 145, 146, 147, 161, 162,
169, 170, 194, 206, 207, 229, 251,
252, 264, 284, 294, 295, 426, 427,
428, 429, 430, 431, 432, 433, 434,
435, 437
activation146
activation options146
attributes 39
deactivation146
expiration time146
one-shot timer 39, 44, 45, 125,
130, 146, 147, 428
performance information 253,
426, 435
periodic timer 39, 44, 45, 125,
130, 145, 146, 428, 430, 436,
438
services 129, 146, 297, 426
system performance
information 426, 437
timer interrupt125, 126, 127, 146,
425, 436, 438
timer tick 126, 232, 250
applications definition 272, 274

auto start71
binary semaphore 41, 43, 44, 45,
149, 152, 157, 158, 159, 160, 161,
163, 164, 165, 166, 169, 176, 177,
188, 189, 379
block size calculation 123
change preemption-threshold 71
change priority71
change time-slice71
clearing event flags 179, 190, 200
completed state 55, 60, 65, 71, 392,
395, 396, 417
compute timing performance 146
conditional suspension60
control loop with polling 5, 6, 8
cooperative multithreading. 27, 32,
59, 71, 73
counting semaphore 40, 41, 43, 44,
45, 68, 148, 149, 150, 151, 152,
153, 154, 155, 156, 157, 158, 159,
167, 168, 169, 170, 172, 173, 174,
175, 176, 177, 178, 187, 188, 201,
211, 221, 223, 228, 229, 232, 247,
376, 377, 378, 379, 380, 381, 382,
387, 388, 389
attributes41, 152
binary semaphore 41, 43, 44, 45,
149, 152, 157, 158, 159, 160,
161, 163, 164, 165, 166, 169,
176, 177, 188, 189, 379

decrement count	current count 43, 149, 154, 156,	recovery99
information retrieval 177, 383 instance 41, 45, 148, 151, 153, 154, 155, 156, 157, 160, 161, 164, 165, 166, 167, 168, 169, 177, 178, 226, 228, 231, 376, 379, 380, 381, 382, 387, 388, 389 notification		
instance	<u>e</u>	
154, 155, 156, 157, 160, 161, 164, 165, 166, 167, 168, 169, 170, 173, 174, 176, 177, 178, 226, 228, 231, 376, 379, 380, 381, 382, 387, 388, 389 anotification		
164, 165, 166, 167, 168, 169, 170, 173, 174, 176, 177, 178, 226, 228, 231, 376, 379, 380, 381, 382, 387, 388, 389 158, 1382, 387, 388, 389 157, 376, 384 185, 186, 187, 188, 189, 190, 191, 192, 193, 195, 196, 197, 199, 200, 201, 211, 212, 213, 214, 221, 226, 227, 228, 229, 245, 246, 253, 326, 327, 328, 329, 331, 332, 333, 334, 335, 336, 337, 338, 339 18 services 151, 297, 376 suspend on semaphore 177 system performance information 376, 385 critical section 11, 13, 14, 15, 16, 19, 20, 21, 22, 40, 74, 75, 84, 86, 87, 89, 90, 91, 92, 95, 96, 98, 99, 138, 140, 141, 142, 149, 158, 160, 161, 164, 165, 167, 168, 169, 187 current count 121, 22, 88, 89, 127, 128, 134, 137, 145, 147, 423, 424 currently executing thread 17, 25, 26, 27, 32, 48, 49, 56, 59, 71, 391, 398 deactivation of timer 146 deadlock 151, 177 deadly embrace 82, 83, 98, 99, 100, 157		
170, 173, 174, 176, 177, 178, 226, 228, 231, 376, 379, 380, 381, 382, 387, 388, 389 notification		
226, 228, 231, 376, 379, 380, 381, 382, 387, 388, 389 notification		
381, 382, 387, 388, 389 notification		entry function input71
notification		event flags group41, 42, 43, 44, 45,
performance information 253, 376, 384 201, 211, 212, 213, 214, 221, 226, 291, 221, 213, 214, 221, 226, 291, 221, 228, 229, 245, 246, 253, 326, 327, 328, 329, 331, 332, 333, 334, 335, 336, 337, 338, 339 335, 336, 337, 338, 339 335, 336, 337, 338, 339 335, 336, 337, 338, 339 335, 336, 337, 338, 339 335, 336, 337, 338, 339 335, 336, 337, 338, 339 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 336, 337, 338, 339 339, 339, 339, 339, 339, 339,	381, 382, 387, 388, 389	158, 179, 180, 181, 182, 183, 184,
376, 384 201, 211, 212, 213, 214, 221, 226, place an instance	notification 157	185, 186, 187, 188, 189, 190, 191,
place an instance	performance information 253,	192, 193, 195, 196, 197, 199, 200,
put	376, 384	201, 211, 212, 213, 214, 221, 226,
retrieve an instance 177, 381 services	place an instance 169, 177	227, 228, 229, 245, 246, 253, 326,
services	•	327, 328, 329, 331, 332, 333, 334,
suspend on semaphore 177 system performance information	retrieve an instance 177, 381	335, 336, 337, 338, 339
clearing event flags . 179, 190, 200 event-chaining	services151, 297, 376	AND operation 179, 183, 190
information	suspend on semaphore 177	attributes41, 182
critical section 11, 13, 14, 15, 16, 19, 20, 21, 22, 40, 74, 75, 84, 86, 87, 89, 90, 91, 92, 95, 96, 98, 99, 138, 140, 141, 142, 149, 158, 160, 161, 164, 165, 167, 168, 169, 187 current count 43, 149, 154, 156, 158, 177, 178 current time 21, 22, 88, 89, 127, 128, 134, 137, 145, 147, 423, 424 currently executing thread 7, 25, 26, 27, 32, 48, 49, 56, 59, 71, 391, 398 deactivation of timer 146 deadlock	system performance	clearing event flags . 179, 190, 200
19, 20, 21, 22, 40, 74, 75, 84, 86, get request 179, 180, 183, 185, 87, 89, 90, 91, 92, 95, 96, 98, 99, 200, 245, 246, 248, 249, 334, 138, 140, 141, 142, 149, 158, 160, 335, 349, 351, 384, 386 161, 164, 165, 167, 168, 169, 187 initialization	information 376, 385	event-chaining193
87, 89, 90, 91, 92, 95, 96, 98, 99, 138, 140, 141, 142, 149, 158, 160, 161, 164, 165, 167, 168, 169, 187 current count 43, 149, 154, 156, 158, 177, 178 logical operations	critical section 11, 13, 14, 15, 16,	get option200
138, 140, 141, 142, 149, 158, 160, 335, 349, 351, 384, 386 161, 164, 165, 167, 168, 169, 187 initialization	19, 20, 21, 22, 40, 74, 75, 84, 86,	get request 179, 180, 183, 185,
161, 164, 165, 167, 168, 169, 187 initialization	87, 89, 90, 91, 92, 95, 96, 98, 99,	200, 245, 246, 248, 249, 334,
current count 43, 149, 154, 156, 158, 177, 178 logical operations	138, 140, 141, 142, 149, 158, 160,	335, 349, 351, 384, 386
158, 177, 178 notification	161, 164, 165, 167, 168, 169, 187	initialization200
current time 21, 22, 88, 89, 127, 128, 134, 137, 145, 147, 423, 424 OR operation 179, 180, 183, 187, 190, 200 currently executing thread 7, 25, 26, 27, 32, 48, 49, 56, 59, 71, 391, 398 performance information 253 retrieval of event flags 200 deactivation of timer	current count 43, 149, 154, 156,	logical operations200
128, 134, 137, 145, 147, 423, 424 190, 200 currently executing thread 7, 25, performance information 253 26, 27, 32, 48, 49, 56, 59, 71, 391, retrieval of event flags 200 398 satisfying a get request 183, 200 deactivation of timer	158, 177, 178	notification193
currently executing thread 7, 25, 26, 27, 32, 48, 49, 56, 59, 71, 391, 398 retrieval of event flags 200 satisfying a get request 183, 200 deactivation of timer 146 deadlock	current time 21, 22, 88, 89, 127,	OR operation 179, 180, 183, 187,
26, 27, 32, 48, 49, 56, 59, 71, 391, retrieval of event flags 200 398 satisfying a get request 183, 200 deactivation of timer	128, 134, 137, 145, 147, 423, 424	190, 200
398 satisfying a get request 183, 200 deactivation of timer	currently executing thread 7, 25,	performance information 253
deactivation of timer	26, 27, 32, 48, 49, 56, 59, 71, 391,	retrieval of event flags 200
deadlock	398	satisfying a get request 183, 200
deadly embrace 82, 83, 98, 99, 100, setting event flags	deactivation of timer146	services181, 297, 326
deadly embrace 82, 83, 98, 99, 100, setting event flags	deadlock151, 177	set option 200, 337
	deadly embrace 82, 83, 98, 99, 100,	
	151, 177	· · · · · · · · · · · · · · · · · · ·

event notification . 41, 44, 149, 167,	thread entry function. 13, 22, 36,
168, 176, 177, 187, 211, 231, 234,	45, 52, 53, 72, 85, 86, 111, 122,
241	130, 134, 135, 233, 241, 266,
event-chaining 157, 193, 211, 225,	270, 392
226, 227, 228, 229, 231, 232, 234,	timeout function 126, 128, 146
235, 241, 253	heap37, 44, 102
exclusive access 74, 75, 98, 99,	internal system clock 126, 127,
295	128, 134, 136, 145, 146, 423, 424
exclusive ownership 78, 79, 345,	interrupt. 7, 8, 25, 26, 28, 29, 32, 40,
346	56, 57, 62, 63, 64, 71, 102, 125,
executing state 65, 71	144, 250, 251, 252, 257, 258, 261,
execution context49, 71	264, 266, 267, 270, 274, 275, 281,
expiration function 39, 126, 129,	284, 285, 287, 288, 289, 291, 292,
130, 131, 135, 136, 137, 138, 145,	293, 340, 341, 398, 399, 401, 402,
146, 162, 169, 171, 177, 194, 266,	403, 404, 405, 406, 443, 446, 447
268, 270, 275, 276, 277, 279, 281,	interrupt control service 297, 340,
283, 429	443
expiration time146	interrupt handling28, 32
FIFO order 81, 103, 109, 114, 120,	interrupt service routine 7, 29, 62,
150, 155, 177, 203, 210, 310, 323,	63, 71, 102
352, 369, 387	inter-thread communication. 8, 42,
first-fit allocation44	356
fixed-size block 112, 114, 116, 118,	inter-thread mutual exclusion 11,
122, 123, 299, 311	21, 342
fragmentation. 37, 38, 44, 101, 102,	ISR. 7, 29, 44, 56, 64, 180, 206, 207,
107, 111, 112, 122, 123, 261, 269,	264, 267, 271, 274, 275, 276, 277,
295, 313	279, 281, 285, 286, 287, 288, 289,
front of queue223	291, 292, 293, 300, 314, 330, 331,
function	346, 361, 362, 370, 371, 373, 381,
expiration function. 39, 126, 129,	398, 399, 414
130, 131, 135, 136, 137, 138,	kernel
145, 146, 162, 169, 171, 177,	kernel entry21
194, 266, 268, 270, 275, 276,	logical AND 179, 183, 190
277, 279, 281, 283, 429	logical operations200
reentrant51, 71, 72	logical OR 180
	mailbox

memory block pool 10, 38, 44, 45,	359, 360, 361, 362, 363, 364, 369,
101, 104, 112, 113, 114, 115, 116,	370, 371, 372, 373
117, 118, 119, 120, 121, 122, 123,	attributes 42, 205
124, 242, 243, 244, 299, 300, 302,	creation 223, 357
303, 304, 305, 306, 307, 308, 309,	deletion223, 359
310	event-chaining211
attributes38	FIFO discipline223
block size calculation 123	front of queue223
performance information 253,	message capacity. 203, 204, 223
299, 306	message size. 42, 203, 204, 205,
services 116, 297, 299, 441	207, 213, 223, 356, 357, 370
system performance	notification211
information 299, 308	performance information 232,
memory byte pool 10, 13, 21, 37,	253, 356, 365
38, 44, 45, 85, 101, 102, 103, 104,	rear223
105, 106, 107, 108, 109, 110, 111,	receive message 203, 223
112, 123, 124, 243, 244, 261, 267,	send message 208, 223, 229,
269, 272, 273, 274, 276, 287, 294,	231, 233, 236, 241, 362, 373
295, 313, 314, 318, 320, 322, 323,	services 205, 297, 356, 443
324	storage space 204, 214, 223
allocate108	suspension 204, 223, 368
attributes37	system performance
performance information 253,	information 356, 367
313, 319	message size 42, 203, 204, 205,
services 102, 104, 297, 313, 440	207, 213, 223, 356, 357, 370
system performance	multiple mutex ownership 99
information 313, 321	multithreading 8, 51, 66
message capacity 203, 204, 223	mutex
message queue . 42, 43, 44, 45, 65,	attributes40, 77
67, 202, 203, 204, 205, 206, 207,	control block 76, 77, 80, 99, 342,
208, 209, 210, 211, 212, 213, 214,	347, 354
216, 217, 218, 220, 221, 223, 224,	get 82, 92
226, 227, 228, 232, 233, 235, 237,	information retrieval 348
238, 263, 264, 266, 269, 272, 273,	multiple mutex ownership 99
274, 275, 276, 277, 279, 282, 284,	ownership 22, 77, 99
288, 290, 294, 295, 356, 357, 358,	

performance information 253, 342, 348	priority 36, 52, 70, 97, 246, 349, 351, 393, 394, 405, 409
priority inheritance 32, 33, 40, 44,	priority ceiling31
66, 68, 76, 77, 78, 79, 82, 86,	priority inheritance 32, 33, 40, 44,
97, 98, 99, 151, 160, 176, 247,	66, 68, 76, 77, 78, 79, 82, 86, 97,
342, 343, 345, 354	98, 99, 151, 160, 176, 247, 342,
system performance	343, 345, 354
information 342, 350	priority inversion 30, 31, 32, 40, 66,
wait options99	68, 77, 98, 99, 100, 151, 177, 250,
mutex services 31, 76, 297, 342,	251, 252, 402
445	producer-consumer. 149, 167, 168,
mutual exclusion 11, 22, 40, 41, 43,	169, 170, 176, 177, 223
44, 45, 74, 99, 148, 149, 151, 157,	public resource 34, 39, 40, 41, 42,
158, 167, 176, 177, 187, 211, 223,	44, 45, 74, 98, 102, 114, 125, 148,
342, 343	180, 202, 221, 223, 261, 266, 269,
notification callback function 62,	272
157, 193, 211, 225, 226, 228, 229,	queue storage space 204, 214, 223
241, 253, 326, 338, 356, 374, 376,	queue suspension 204, 223, 368
389, 391, 396, 415	ready state 24, 25, 27, 32, 52, 65,
one-shot timer 39, 44, 45, 125, 130,	71, 72, 73, 78, 91, 99, 250
146, 147, 428	ready thread. 25, 27, 32, 36, 47, 59,
OR operation 179, 183, 187, 190, 200	63, 65, 66, 69, 70, 71, 99, 393
ownership of mutex 22, 77, 99	real-time kernel3, 6, 8
periodic interrupt 125, 146	real-time system 2, 3, 5, 7, 8, 23,
periodic timer 39, 44, 45, 125, 130,	63, 83
145, 146, 428, 430, 436, 438	rear of queue223
pointer overhead 114, 123	receive message 203, 223
preemption 65, 404, 405	recovery from deadly embrace. 99
preemption-threshold 31, 32, 33,	reentrant function 51, 71, 72
36, 44, 49, 51, 52, 53, 54, 55, 56,	relinquish processor control 71
57, 58, 61, 66, 67, 68, 71, 72, 73,	resume thread execution72
76, 85, 86, 98, 151, 273, 391, 392,	retrieval of event flags 200
393, 394, 400, 406, 407, 408, 419	retrieve an instance 177, 381
preemptive scheduling 5, 6, 7, 8,	ROMable
10	round-robin scheduling. 26, 28, 29,
	32, 59, 66, 69, 72

RTOS xvi, xvii, 2, 3, 8, 9, 23, 28, 32, 34, 71, 254, 257 run-time performance . 56, 80, 107, 133, 154, 189, 209, 225, 240, 241, 243, 245, 246, 247, 249, 251 satisfying a get request 183, 200 scalable	suspension list 25, 56, 76, 77, 79, 80, 81, 98, 99, 103, 105, 108, 109, 114, 115, 116, 119, 120, 123, 150, 151, 154, 155, 177, 180, 181, 191, 203, 205, 210, 211, 223, 250, 299, 305, 309, 310, 313, 318, 323, 332, 337, 342, 347, 352, 356, 364, 369, 376, 382, 387, 400 suspension of thread . 71, 200, 417 synchronization of threads 200
send message 208, 223, 229, 231,	synchronize thread behavior 99
233, 236, 241, 362, 373	system clock services 127, 146
service call 35, 44, 45, 53, 54, 55, 59, 60, 61, 72, 86, 120, 126, 146,	system resource 34, 35, 43, 66, 68, 157, 158, 176, 241
225, 231, 297, 402, 430	terminate thread
service return values72	terminated state 60, 65, 71
setting event flags200	thread
shared resource. 11, 30, 74, 75, 78,	abort thread suspension71
98, 99	attributes51
stack 13, 18, 49, 50, 51, 72, 85, 87,	auto start option71
88, 92, 101, 110, 121, 123, 124,	change preemption-threshold
138, 161, 215, 234, 266, 267, 273,	71
274, 284, 287, 295, 391, 415, 416	change priority71
stack size 36, 49, 72, 269	change time-slice71
static priority	conditional suspension 60
suspend on semaphore 177	control block 36, 46, 47, 48, 49,
suspend while waiting for	51, 53, 56, 71, 85, 392, 407,
memory	408, 417, 418, 419 entry function 13, 22, 36, 45, 52,
suspended state 24, 25, 32, 36, 59, 65, 71, 72, 73, 91, 99, 100, 178,	53, 72, 85, 86, 111, 122, 130,
264, 392, 393	134, 135, 233, 241, 266, 270,
suspended thread 7, 25, 32, 62, 66,	392
77, 80, 81, 103, 109, 114, 120,	event-chaining62
121, 149, 150, 155, 156, 180, 192,	execution context 49, 71
203, 208, 210, 211, 310, 324, 325,	information retrieval 400
337, 338, 354, 360, 369, 388	notification

performance information 250, 253,	terminate 61, 71
391, 401	unconditional suspension 60,
preemption 65, 404, 405	417, 418, 421
priority 36, 52, 70, 97, 246, 349,	thread design 66, 261, 262
351, 393, 394, 405, 409	thread entry function 13, 22, 36, 45,
ready state250	52, 53, 72, 85, 86, 111, 122, 130,
ready thread 25, 27, 32, 36, 47,	134, 135, 233, 241, 266, 270, 392
59, 63, 65, 66, 69, 70, 71, 99,	thread execution state72
393	completed 55, 60, 65, 71, 392,
relinquish processor control 71	395, 396, 417
reset 60, 65, 391, 398, 404, 406,	executing 7, 25, 26, 27, 32, 48,
411, 412, 416, 447	49, 56, 59, 65, 71, 391, 398
resume thread execution 72	ready 24, 25, 27, 32, 52, 65, 71,
run-count72	72, 73, 78, 91, 99
scheduling21, 63	suspended 24, 25, 32, 36, 59, 65,
scheduling loop 63, 64, 72, 73	71, 72, 73, 91, 99, 100, 178,
services 46, 48, 53, 297, 391, 446	264, 392, 393
stack 13, 18, 49, 50, 51, 72, 85,	terminated 60, 65, 71
87, 88, 92, 101, 110, 121, 123,	thread state transition65
124, 138, 161, 215, 234, 266,	tick counter126, 146
267, 273, 274, 284, 287, 295,	time services 297, 423, 447
391, 415, 416	timeout function 126, 128, 146
stack error 62, 415, 416	timer activation options 146
stack memory allocation 123	timer interrupt 125, 126, 127, 146,
stack size36, 49, 72, 269	425, 436, 438
start option72	timer tick 125, 126, 127, 146, 232,
suspended 7, 25, 32, 62, 66, 77,	250, 425, 436, 438
80, 81, 103, 109, 114, 120, 121,	time-slice. 29, 32, 33, 36, 47, 48, 49,
149, 150, 155, 156, 180, 192,	51, 55, 56, 61, 69, 72, 85, 86, 251,
203, 208, 210, 211, 310, 324,	252, 391, 392, 393, 400, 402, 405,
325, 337, 338, 354, 360, 369,	419, 420
388	unconditional suspension. 60, 417,
suspension 71, 200, 417	418, 421
synchronization99, 200	watchdog timer 40, 45, 64, 100
system performance	
information 391, 404	