
(163条消息) ThreadX内核源码分析 - ports线程上下文相关 代码分析(arm)_arm7star的博客-CSDN博客_threadx arm9

6 blog.csdn.net/arm7star/article/details/122930850

1、ports源码介绍

内核与cpu相关的关键代码基本都是用汇编语言实现的,c语言可能实现不了或者不好编写。

ThreadX官网针对ARM9 gcc的移植代码在threadx-6.1.2_rel\ports\arm9\gnu\src目录下, ThreadX文件命名规则基本是以该文件包含的函数名命名的(函数名多了一个"_"前缀,文件包里面没有""前缀),每个源文件通常只实现一个函数;ports代码目录如下:



tx thread context restore.S是 tx thread context restore函数的实现。

2、ThreadX线程上下文

ThreadX内核在ARM上使用满递减栈("满"是指栈顶指针指向的内存地址是有数据的,下一个数据要入栈,则栈顶指针需要移动到下一个内存单元才行;"递减"是指栈是从高地址往低地址增长的,栈底在内存的高地址,栈顶在内存的低地址)。

2.1、中断线程上下文

ThreadX的线程中断上下文在内存栈里面的结构如下所示:

正在执行的线程进入睡眠状态/时间片用尽/被抢占等情况让出cpu的时候,线程的上下文主动或者被动保存到线程的栈里面,这里的栈也就是c语言意义上的栈(c函数的局部变量/参数的栈),线程第一次执行前,内核会将分配给线程的栈的地址设置到sp栈指针(线程执行前,sp即指向线程栈的起始地址;以一个c函数为例,函数执行时,sp指向函数栈的起始地址,假如函数保存函数调用上下文需要2个byte,函数局部变量a占用1个byte,那么可以用sp-1、sp-2的地址保存函数调用上下文,sp-3的地址保存变量a,然后将sp-3设置为新

的sp(函数上下文/变量已经入栈),函数返回时恢复旧的sp的值,sp到sp-3这3个byte的栈空间被释放,局部变量在栈里面动态分配也就是这个原理,函数的局部变量在函数返回后就不存在了也是这个道理)。

中断上下文,中断上下文的栈顶为1,标志该栈为中断 栈,cpu发生中断时,内核并没有办法判断线程正在使 用那些寄存器,因此中断线程的上下文需要保存所有的 寄存器。



2.2、非中断线程上下文


非中断线程上下文与此不同,非中断是指线程自己调用内核函数主动让出cpu,例如调用sleep/调用互斥锁等进入睡眠或者阻塞状态,下次线程执行时,需要返回的不是保存线程上下文的函数,例如调用sleep函数,下次线程执行是不需要回到sleep函数再返回调用sleep的函数,而是直接返回到调用sleep函数的下一条指令,线程在调用sleep函数前,一般ro-r3没有任何意义了(sleep后之后的代码不会用到ro-r3)或者编译器会把ro-r3保存到栈里面(如果寄存器ro-r3的值在sleep之后还有用到,从实际反汇编代码看,编译器实际在sleep之后的代码并没有用到sleep之前的ro-r3的值),因此,线程主动让出cpu时,ro-r3寄存器如果有用的话,编译器已经保存到了栈里面,如果没有用的话,也没有保存的必要,sleep返回之后ro-r3的值并没有实际意义。

非中断线程上下文的栈顶的值为o,另外没有ro-r3。

3、线程栈创建(_tx_thread_stack_build)

线程运行的过程是"创建线程->线程执行",线程执行简单理解就是把线程入口函数的上下 文恢复到cpu上(cpu寄存器,然后让cpu跳转到线程入口执行;前面讲过了c函数执行的调用 上下文及局部变量保存在栈里面,因此线程入口函数执行前sp寄存器必须指向线程的栈地 址,对于linux带有mmu的内核,还需要设置mmu,ThreadX比较简单,所有线程在一个 地址空间指向,不需要切换mmu)

线程栈的创建函数为_tx_thread_stack_build,下图是ThreadX启动过程创建线程的一个函数调用栈,_tx_thread_create创建线程,调用_tx_thread_stack_build创建线程的栈:



线程栈创建主要是线程的入口(pc)、线程的栈sp、线程运行时模式cpsr等寄存器设置,线程创建时的栈是按中断上下文栈类型保存寄存器的,虽然很多寄存器没有实际用到,创建栈的代码如下:

```
1. 104
          .global _tx_thread_stack_build
2. 105
          .type _tx_thread_stack_build,function
3. 106 tx thread stack build:
4. 107 @
5. 108 @
          /* Build a fake interrupt frame. The form of the fake interrupt stack
6. 109 @
7. 110 @
          on the ARM9 should look like the following after it is built:
8. 111 @
9. 112 @
               Stack Top:
                               1
                                           Interrupt stack frame type
10. 113 @
                                           Initial value for CPSR
                               CPSR
11. 114 @
                               a1 (r0)
                                           Initial value for a1
12. 115 @
                                           Initial value for a2
                               a2 (r1)
13. 116 @
                               a3 (r2)
                                           Initial value for a3
14. 117 @
                               a4 (r3)
                                           Initial value for a4
15. 118 @
                               v1 (r4)
                                           Initial value for v1
16. 119 @
                                           Initial value for v2
                               v2 (r5)
17. 120 @
                               v3 (r6)
                                           Initial value for v3
18. 121 @
                               v4 (r7)
                                           Initial value for v4
                                           Initial value for v5
19. 122 @
                               v5 (r8)
20. 123 @
                               sb (r9)
                                           Initial value for sb
21. 124 @
                               sl (r10)
                                           Initial value for sl
22. 125 @
                               fp (r11)
                                           Initial value for fp
23. 126 @
                               ip (r12)
                                           Initial value for ip
24. 127 @
                               lr (r14)
                                           Initial value for lr
25. 128 @
                               pc (r15)
                                           Initial value for pc
26. 129 @
                                      For stack backtracing
27. 130 @
28. 131 @ Stack Bottom: (higher memory address) */
29. 132 @
                                                   @ Pickup end of stack area // r0为函
30. 133
           LDR
                   r2, [r0, #16]
```

数第一个参数的值thread_ptr, r2 = thread_ptr->tx_thread_stack_end, 取函数栈的高地址

(栈底)

- @ Ensure 8-byte alignment // r2(栈顶 31. 134 r2, r2, #7 BIC 确保栈的起始地址按8 byte地址对齐, arm的入栈指令必须4 byte对 地址)的低3 bit位清0, 齐(否则会产生总线错误), 8 byte对齐自然也是4 byte对齐
- 32. 135 r2, r2, #76 @ Allocate space for the stack frame **SUB** // 这里预留76 byte(19 word)个内存地址用于保存线程的栈,保存栈只需要18 word个内存,栈 底保存了一个固定的0,因此多了1个word; 另外线程创建时的栈保存了r0-r3寄存器,线程第一 次运行并不是调用用户的线程入口函数,而是内核的_tx_thread_shell_entry,由 tx thread shell entry调用用户线程入口函数, tx thread shell entry还要负责线程退出的 一些清理工作,用户线程入口函数没办法做; r2减完之后执行栈顶
- 33. 136 @
- 34, 137 @ /* Actually build the stack frame. */
- 35. 138 @

43. 146

- 36. 139 @ Build interrupt stack type // 栈类 MOV r3, #1 型设置为1(虽然不是中断上下文,但是栈里面保存了r0-r3寄存器,因此栈里面的内容与中断上 下文相同,恢复时需要按照中断上下文恢复一样,恢复r0-r3寄存器)
- STR r3, [r2, #0] 接写入栈类型在栈中的内存地址)

- @ Store stack type // 栈类型入栈(直
- 38. 141 MOV r3, #0 = 0,没有用到的寄存器入栈时默认为0
- @ Build initial register value // r3

39. 142 STR r3, [r2, #8] 入栈

@ Store initial r0 // 后续代码r0-r9

40. 143 r3, [r2, #12] STR

@ Store initial r1

41. 144 r3, [r2, #16] STR

@ Store initial r2

42. 145 r3, [r2, #20] STR

@ Store initial r3

STR r3, [r2, #24] @ Store initial r4

44. 147 STR r3, [r2, #28] @ Store initial r5

45. 148 r3, [r2, #32] STR

@ Store initial r6

46. 149 STR r3, [r2, #36] @ Store initial r7

47. 150 r3, [r2, #40] STR

@ Store initial r8

48. 151 STR r3, [r2, #44]

- @ Store initial r9
- 49. 152 r3, [r0, #12] LDR
 - @ Pickup stack starting address // r3 = thread ptr->tx thread stack start, 获取栈的低内存地址
- 50. 153 r3, [r2, #48] @ Store initial r10 (sl) // r10(栈顶 STR 指针寄存器)入栈, 栈不能超过该地址, 否则就非法访问别的内存了
- @ Pickup address of 51. 154 r3,= tx thread schedule LDR _tx_thread_schedule for GDB backtrace // 取_tx_thread schedule函数地址
- r3, [r2, #60] @ Store initial r14 (lr) // lr = _tx_thread_schedule,用于gdb栈回溯使用,如果用gdb的backtrace命令查看栈的话,可以看到 _tx_thread_schedule在调用栈的最顶端,仅给gdb用,没有实际用处
- 53. 156 MOV r3, #0

@ Build initial register value

54. 157 STR r3, [r2, #52] @ Store initial r11 // r11入栈 55. 158 r3, [r2, #56] STR @ Store initial r12 56. 159 STR r1, [r2, #64] @ Store initial pc // r1为 _tx_thread_stack_build的第二个参数function_ptr(_tx_thread_shell_entry),线程第一次执 行时,恢复_tx_thread_shell_entry到pc寄存器 57. 160 STR r3, [r2, #68] @ 0 for back-trace 58, 161 MRS r1, CPSR @ Pickup CPSR // 获取cpsr寄存器(cpsr 里面保存了cpu模式等信息(ARM/Thumb),恢复cpsr时不能随便恢复) r1, r1, #CPSR MASK @ Mask mode bits of CPSR // IRQ/FIQ BIC 禁止中断标志位等清零(线程运行时必须使能中断,否则硬件定时器中断没办法被相应,内核没 办法计时) 60. 163 r3, r1, #SVC MODE @ Build CPSR, SVC mode, interrupts ORR enabled // 设置为SVC模式(ThreadX线程全部运行在SVC特权模式,有开关中断等特权,如果线 程运行在用户模式,开关中断需要切换到特权模式才行,影响性能) 61. 164 r3, [r2, #4] @ Store initial CPSR // cpsr入栈 STR 62. 165 @ 63. 166 @ /* Setup stack pointer. */ 64. 167 @ thread_ptr -> tx_thread_stack_ptr = r2; 65. 168 @ 66. 169 r2, [r0, #8] @ Save stack pointer in thread's // STR thread_ptr->tx_thread_stack_ptr = r8(栈顶地址),线程恢复执行时,通过thread_ptr->tx_thread_stack_ptr找到线程上下文的栈顶地址,从而恢复线程上下文寄存器 67. 170 control block 68. 171 #ifdef __THUMB_INTERWORK 69. 172 lr @ Return to caller BX 70. 173 #else 71. 174 MOV pc, lr @ Return to caller 72. 175 #endif 73. 176 @} 74. 177

4、线程上下文的恢复(_tx_thread_context_restore)

线程中断后/睡眠后/阻塞后,恢复执行都是由内核调用_tx_thread_context_restore恢复线程上下文;线程被创建/被切换出去时,thread_ptr->tx_thread_stack_ptr指向了线程的栈顶,而此时的栈顶保存的是线程的上下文;

4.1、保存被切换出去的线程的上下文

恢复一个线程时,必须先保存当前正在执行的线程的上下文,ThreadX用 _tx_thread_execute_ptr指向当前正在执行的线程,_tx_thread_context_restore首先检查当前没有没线程正在执行(_tx_thread_execute_ptr是否不为空),如果有线程正在执行,先保存正在执行线程的上下文,然后调用_tx_thread_schedule执行下一个线程,否则直接调用_tx_thread_schedule执行下一个线程。

_tx_thread_context_restore保存被切换出去的线程的中断上下文的代码如下:

```
1. 100
         .global _tx_thread_context_restore
2. 101
         .type _tx_thread_context_restore,function
3. 102 tx thread context restore:
4. 103 @
5. 104 @
         /* Lockout interrupts. */
6. 105 @
7. 106
          MOV
                 r0, #IRO MODE
                                           @ Build disable interrupts CPSR
8. 107
                CPSR, r0
                                           @ Lockout interrupts // 禁止IRQ中断
          MSR
9. 108
10. 109 #ifdef TX ENABLE EXECUTION CHANGE NOTIFY
11. 110 @
12. 111 @
         /* Call the ISR exit function to indicate an ISR is complete. */
13. 112 @
14. 113
              tx execution isr exit
                                     @ Call the ISR exit function
          BL
15. 114 #endif
16. 115 @
         /* Determine if interrupts are nested. */
17. 116 @
18. 117 @ if (-- tx thread system state)
19. 118 @
         {
20. 119 @
21. 120
                 r3, =_tx_thread_system_state @ Pickup address of system state
          LDR
   variable // 检查中断嵌套(如果是内核初始化过程,中断发生后应该返回到内核初始化,只有
   等系统初始化完成后才能调度线程,内核初始化相当于第一次中断,内核初始化时
   tx thread system state设置为非0,内核初始化完成后 tx thread system state设置为0;如
   果是中断嵌套,要一层一层返回所有中断,也不能调度线程)
22. 121
          LDR
              r2, [r3]
                                            @ Pickup system state
23. 122
                 r2, r2, #1
                                            @ Decrement the counter // 中断退
          SUB
   出,中断嵌套计数器_tx_thread_system_state减1(中断进入时加1)
24. 123
          STR
                 r2, [r3]
                                            @ Store the counter
25, 124
         CMP
                 r2, #0
                                            @ Was this the first interrupt? //
   如果中断嵌套计数器_tx_thread_system_state为0,表明当前中断为最外层中断,外面没有中断
   了,没有嵌套中断
26. 125
                  _tx_thread_not_nested_restore @ If so, not a nested restore // 没
```

有嵌套中断要处理,跳转到__tx_thread_not_nested_restore恢复中断上下文或者调度线程

27. 126 @

```
28. 127 @ /* Interrupts are nested. */
29. 128 @
30. 129 @
         /* Just recover the saved registers and return to the point of
31. 130 @
         interrupt. */
32. 131 @
33. 132
          LDMIA
                sp!, {r0, r10, r12, lr} @ Recover SPSR, POI, and scratch
   regs // 恢复中断上下文
34. 133
          MSR
                 SPSR, r0
                                            @ Put SPSR back
35. 134
          LDMIA sp!, \{r0-r3\}
                                            @ Recover r0-r3
36. 135
                                            @ Return to point of interrupt // 返
          MOVS
                 pc, lr
   回被中断的中断继续处理中断
37. 136 @
38. 137 @
         }
39. 138 tx thread not nested restore: // 最外层中断退出,中断恢复
40. 139 @
41. 140 @
         /* Determine if a thread was interrupted and no preemption is required. */
           else if (((_tx_thread_current_ptr) && (_tx_thread_current_ptr ==
   tx thread execute ptr)
43. 142 @
                    || ( tx thread preempt disable))
44. 143 @
         {
45. 144 @
46. 145
                 r1, = tx thread current ptr @ Pickup address of current thread
          LDR
   ptr
47. 146
          LDR
                 r0, [r1]
                                             @ Pickup actual current thread
   pointer
48. 147
          CMP
                 r0, #0
                                             @ Is it NULL? // 检查
    tx thread current ptr是否不为空,是否有线程要被执行(中断服务程序可能唤醒更高优先级
   线程或者当前执行的线程的时间片用完了)
                 __tx_thread_idle_system_restore @ Yes, idle system was interrupted
49. 148
   // 没有线程要被执行,跳转到__tx_thread_idle_system_restore
50. 149 @
51. 150
              r3, =_tx_thread_preempt_disable @ Pickup preempt disable address
          LDR
52. 151
          LDR
                 r2, [r3]
                                             @ Pickup actual preempt disable flag
53. 152
          CMP
                 r2, #0
                                             @ Is it set? // 检查
   _tx_thread_preempt_disable禁止抢占是否被设置(有些内核函数正在做重要的事情,即使当前
   执行的线程的时间片用完了或者有高优先级就绪了,也不能立即被抢占,当前线程做完重要的事
   情后,由当前线程来检查是否要重新调度别的线程)
```

```
54. 153
                __tx_thread_no_preempt_restore @ Yes, don't preempt this thread //
   有禁止抢占,跳转到__tx_thread_no_preempt_restore,不切换线程,继续当前正在执行的线程
55. 154
        LDR
               ptr // 没有禁止抢占, 获取正在执行的线程 tx thread execute ptr
56. 155
        LDR
               r2, [r3]
                                         @ Pickup actual execute thread
   pointer
57. 156
         CMP
               r0, r2
                                         @ Is the same thread highest
   priority? // 比较是否为同一个线程(下一个要执行的线程是否为当前正在执行的线程)
                                        @ No, preemption needs to happen //
               tx thread preempt restore
   不是同一个线程,_tx_thread_execute_ptr被_tx_thread_current_ptr抢占或者时间片轮转到
   tx thread current ptr执行,需要换出当前正在执行的线程 tx thread execute ptr
59. 158 @
60. 159 @
61. 160 tx thread no preempt restore: // 正在执行的线程没有被抢占,继续被中断的线程
62. 161 @
        /* Restore interrupted thread or ISR. */
63. 162 @
64. 163 @
65. 164 @
        /* Pickup the saved stack pointer. */
66. 165 @
        tmp ptr = tx thread current ptr -> tx thread stack ptr;
67. 166 @
68. 167 @ /* Recover the saved context and return to the point of interrupt. */
69. 168 @
70. 169
         LDMIA sp!, {r0, r10, r12, lr}
                                       @ Recover SPSR, POI, and scratch
   regs // 恢复r0(cpsr), r10, r12, lr(pc)
71. 170
         MSR
               SPSR, r0
                                         @ Put SPSR back
72. 171
         LDMIA
               sp!, {r0-r3}
                                         @ Recover r0-r3 // 恢复r0-r3(c函数如
   果用到r4-r12的寄存器的话,c函数进入时会保存这些寄存器,退出时会恢复这些寄存器,所以c
   函数不保护的r0-r3寄存器,中断汇编代码使用r0-r3及调用c函数前需要保存r0-r3寄存器,另
   外, 很明显汇编代码只用到了ro-r3寄存器, 因此中断退出时, 只需要恢复ro-r3寄存器即可)
73. 172
               pc, lr
         MOVS
                                         @ Return to point of interrupt //
   MOVS带S后缀时,会将spsr恢复到cpsr寄存器,1r为中断返回地址,该指令即返回到中断的线程
   继续执行
74. 173 @
75. 174 @
         }
76. 175 @
        else
77. 176 @
78. 177 __tx_thread_preempt_restore: // 当前执行的线程被抢占或者轮转出去
79. 178 @
```

80. 179 LDMIA sp!, {r3, r10, r12, lr} @ Recover temporarily saved registers // 恢复中断的寄存器r3(cpsr), r10, r12, lr(pc) 81. 180 MOV r1, lr @ Save lr (point of interrupt) // 保 存中断返回地址到r1(当前线程恢复地址pc,模式切换后1r(irq)寄存器不能访问) 82. 181 MOV r2, #SVC_MODE @ Build SVC mode CPSR 83. 182 MSR CPSR, r2 @ Enter SVC mode // 切换到SVC模式 84. 183 STR r1, [sp, #-4]! @ Save point of interrupt // 切换到 SVC模式后,进入到线程模式下面,此时的sp是线程的栈指针,pc入中断上下文的栈(跟创建线程 是的栈不同, 栈底没有预留0),!执行指令后更新sp寄存器 @ Save upper half of registers // STMDB sp!, {r4-r12, lr} STMDB的DB为先减的意思,执行指令前sp指向了pc,r4-r12,、1r入栈,r4在低内存地址!!! 86. 185 MOV r4, r3 @ Save SPSR in r4 // 线程的cpsr保存 到r4寄存器 87. 186 MOV r2, #IRQ MODE @ Build IRQ mode CPSR 88. 187 MSR CPSR, r2 @ Enter IRQ mode // 切换回IRQ模式(需 要访问IRQ的sp寄存器) 89. 188 LDMIA sp!, {r0-r3} @ Recover r0-r3 // 恢复r0-r3寄存器 90. 189 r5, #SVC MODE MOV @ Build SVC mode CPSR @ Enter SVC mode // 切换到SVC模式(线 91. 190 MSR CPSR, r5 程上下文) 92. 191 STMDB sp!, {r0-r3} @ Save r0-r3 on thread's stack // r0-r3入栈 93. 192 MOV r3, #1 @ Build interrupt stack type // 栈的 类型为中断栈(保存有r0-r3寄存器) 94. 193 STMDB sp!, $\{r3, r4\}$ @ Save interrupt stack type and SPSR // 栈类型、cpsr入栈 95. 194 LDR r1, =_tx_thread_current_ptr @ Pickup address of current thread ptr // 获取正在执行的线程(被中断的线程) tx thread current ptr 96. 195 LDR r0, [r1] @ Pickup current thread pointer 97. 196 STR sp, [r0, #8] @ Save stack pointer in thread control 98. 197 block // 线程栈顶地址保存到 thread ptr->tx thread stack ptr, 至此线程的中断上下文已经保存到线程的栈里面了 99. 198 @ /* Save the remaining time-slice and disable it. */ 100. 199 @ 101. 200 @ if (_tx_timer_time_slice) 102. 201 @ { 103. 202 @ 104. 203 LDR r3, =_tx_timer_time_slice @ Pickup time-slice variable address

```
105. 204
                  r2, [r3]
           LDR
                                               @ Pickup time-slice
                                                @ Is it active? // 检查线程的时间片
106. 205
           CMP
                   r2, #0
    _tx_timer_time_slice是否为0,不为0的话,需要保存线程的时间片,时间片为0表示线程不使
    用时间片(可以无限执行)
                                              @ No, don't save it // 没有启用时间
107. 206
                   __tx_thread_dont_save_ts
           BEQ
    片,跳转到__tx_thread_dont_save_ts,不需要保存_tx_timer_time_slice
108. 207 @
109. 208 @
                _tx_thread_current_ptr -> tx_thread_time_slice = _tx_timer_time_slice;
110. 209 @
                _tx_timer_time_slice = 0;
111. 210 @
                                               @ Save thread's time-slice //
112. 211
           STR
                 r2, [r0, #24]
    _tx_thread_current_ptr -> tx_thread_time_slice = _tx_timer_time_slice;
113. 212
           MOV
                  r2, #0
                                               @ Clear value
114. 213
           STR
                  r2, [r3]
                                                @ Disable global time-slice flag //
    _tx_timer_time_slice设置为0,正在执行的线程被切换出去,还没有线程被执行前,
    tx timer time slice设置为0,不需要对 tx timer time slice进行计数
115. 214 @
116. 215 @
117. 216 tx thread dont save ts:
118. 217 @
119. 218 @
120. 219 @
           /* Clear the current task pointer. */
121. 220 @
           _tx_thread_current_ptr = TX_NULL;
122. 221 @
123. 222
                  r0, #0
           MOV
                                               @ NULL value
124. 223
           STR
                   r0, [r1]
                                                @ Clear current thread pointer //
    _tx_thread_current_ptr = TX_NULL; 线程信息已经保存了, 当前cpu上没有线程在执行
125. 224 @
126. 225 @
          /* Return to the scheduler. */
127. 226 @
            _tx_thread_schedule();
128. 227 @
                                               @ Return to scheduler // 调用
129. 228
                  _tx_thread_schedule
    _tx_thread_schedule调度新的线程
130. 229 @
          }
131. 230 @
```

132. 231 __tx_thread_idle_system_restore:

```
133. 232 @
```

134. 233 @ /* Just return back to the scheduler! */

135. 234 @

136. 235 MOV r0, #SVC MODE

@ Build SVC mode CPSR

137. 236 MSR CPSR, r0 @ Enter SVC mode // 切换到SVC模式 (IRQ模式下跳转到 tx thread idle system restore, 调用调度函数需要切换到SVC内核模式)

138. 237 B __tx_thread_schedule
 _tx_thread_schedule

@ Return to scheduler // 调用

139. 238 @}

140. 239



5、线程调度(_tx_thread_schedule)

_tx_thread_schedule主要检查是否有线程需要执行,有的话就恢复线程上下文,没有的话就循环检测; ARM9没有看到省电唤醒指令,所以是不断循环等待,看到有cortex-m之类的处理器有类似睡眠指令,中断的时候唤醒cpu。

_tx_thread_schedule一定程度上可以看作是一个idle线程,没有其他线程可以执行的时候就执行idle线程。

有就绪线程的话,内核会设置_tx_thread_execute_ptr指向最高优先级的就绪线程,例如 定时器计时检查到sleep的timer过期了,唤醒sleep线程,唤醒操作会设置 tx thread execute ptr, tx thread schedule只要检查 tx thread execute ptr即可;

_tx_thread_schedule主要设置_tx_thread_current_ptr = _tx_thread_execute_ptr,恢复线程之前的时间片,恢复线程的寄存器,_tx_thread_schedule的代码实现如下:

```
2. 110
            .type _tx_thread_schedule,function
3. 111 tx thread schedule:
4. 112 @
5. 113 @
        /* Enable interrupts. */
6. 114 @
7. 115 MRS
             r2, CPSR
                                          @ Pickup CPSR
8. 116 BIC
             r0, r2, #ENABLE INTS
                                          @ Clear the disable bit(s) // 清除禁
   止中断标志位, 允许中断
9. 117 MSR
               CPSR cxsf, r0
                                          @ Enable interrupts // 设置cpsr中断
   标志位为0(允许中断)
10. 118 @
11. 119 @ /* Wait for a thread to execute. */
12. 120 @ do
13. 121 @ {
14. 122
               r1, =_tx_thread_execute_ptr @ Address of thread execute ptr
        LDR
15. 123 @
16. 124 __tx_thread_schedule_loop: // 等待_tx_thread_execute_ptr不为空(需要执行的线程)
17. 125 @
18. 126
               r0, [r1]
                                           @ Pickup next thread to execute
        LDR
19. 127
        CMP
               r0, #0
                                           @ Is it NULL?
20. 128
        BEQ
              __tx_thread_schedule_loop @ If so, keep looking for a thread
21. 129 @
22. 130 @
23. 131 @
         while(_tx_thread_execute_ptr == TX_NULL);
24. 132 @
25. 133 @ /* Yes! We have a thread to execute. Lockout interrupts and
26. 134 @ transfer control to it. */
27. 135 @
28. 136 MSR
                                          @ Disable interrupts // 禁止中断,接
                CPSR_cxsf, r2
   着需要恢复线程
29. 137 @
```

30. 138 @ /* Setup the current thread pointer. */

```
31. 139 @
         _tx_thread_current_ptr = _tx_thread_execute_ptr;
32. 140 @
33. 141
          LDR
                 r1, = tx thread current ptr @ Pickup address of current thread
   // 当前正在执行的线程_tx_thread_current_ptr(新线程即将被执行,_tx_thread_current_ptr
   记录cpu上执行的线程)
34. 142
          STR
                 r0, [r1]
                                              @ Setup current thread pointer //
   _tx_thread_current_ptr = _tx_thread_execute_ptr
35. 143 @
         /* Increment the run count for this thread. */
36. 144 @
37. 145 @
           _tx_thread_current_ptr -> tx_thread_run_count++;
38. 146 @
39. 147
          LDR
              r2, [r0, #4]
                                              @ Pickup run counter //
   _tx_thread_current_ptr -> tx_thread_run_count
40. 148
                 r3, [r0, #24]
                                              @ Pickup time-slice for this thread
          LDR
   // 取出线程的运行时间片_tx_thread_current_ptr->tx_thread_time_slice(上次运行时间,
   ThreadX的线程运行时间是累计的,如果每次都从一个全新的时间片开始运行,而且线程每次都
   没执行完一个时间片就被切换出去,那么该线程之后的同优先级的线程就得不到调度,因此,线
   程的时间片是累计的)
41. 149
          ADD
                 r2, r2, #1
                                              @ Increment thread run-counter // 线
   程运行次数加1
42. 150
          STR
                r2, [r0, #4]
                                            @ Store the new run counter
43. 151 @
44. 152 @ /* Setup time-slice, if present. */
45. 153 @
         _tx_timer_time_slice = _tx_thread_current_ptr -> tx_thread_time_slice;
46. 154 @
47. 155
          LDR
                r2, = tx timer time slice
                                            @ Pickup address of time-slice
48. 156
                                                variable
49. 157
          LDR
                 sp, [r0, #8]
                                              @ Switch stack pointers // sp =
   _tx_thread_current_ptr->tx_thread_stack_ptr, sp指向之前保存线程上下文的栈顶
50. 158
          STR
                 r3, [r2]
                                              @ Setup time-slice //
   _tx_timer_time_slice = _tx_thread_current_ptr -> tx_thread_time_slice,线程运行过程
   中 tx timer time slice代表线程剩余的时间片,定时器对 tx timer time slice计数,线程换
   出时, tx timer time slice写回到 tx thread current ptr -> tx thread time slice
51. 159 @
52. 160 @
         /* Switch to the thread's stack. */
53. 161 @
         sp = _tx_thread_execute_ptr -> tx_thread_stack_ptr;
54. 162 @
55. 163 #ifdef TX_ENABLE_EXECUTION_CHANGE_NOTIFY
```

- 56. 164 @

 57. 165 @ /* Call the thread entry function to indicate the thread is executing. */

 58. 166 @
- 59. 167 BL _tx_execution_thread_enter @ Call the thread execution enter function
- 60. 168 #endif
- 61. 169 @
- 62. 170 @ /* Determine if an interrupt frame or a synchronous task suspension frame
- 63. 171 @ is present. */
- 64. 172 @
- 65. 173 LDMIA sp!, {r0, r1} @ Pickup the stack type and saved CPSR // 栈类型、cpsr出栈
- 66. 174 CMP r0, #0 @ Check for synchronous context switch // 判断栈类型(中断上下文栈保存了r0-r3, 需要检查是否恢复r0-r3)
- 67. 175 MSRNE SPSR_cxsf, r1 @ Setup SPSR for return // 中断栈 类型, spsr = r1(cpsr)
- 68. 176 LDMNEIA sp!, {r0-r12, lr, pc}^ @ Return to point of thread interrupt // 中断栈类型恢复r0-r12, lr, pc并且恢复cpsr(指令带有^), 此处pc已经恢复了,中断栈后面指令不会执行了
- 69. 177 LDMIA sp!, {r4-r11, lr} @ Return to thread synchronously // 非中断栈类型(主动让出cpu), r0-r3由编译器恢复(编译器根据需要在调用函数前保存r0-r3, 调用完后恢复)或者不需要恢复
- 70. 178 MSR CPSR_cxsf, r1

@ Recover CPSR // 直接恢复cpsr

- 71. 179 #ifdef __THUMB_INTERWORK
- 72. 180 BX lr

@ Return to caller

- 73. 181 #else
- 74. 182MOVpc, lr@ Return to caller // 寄存器等都恢复好了,直接跳转到线程让出cpu前的下一个地址即可
- 75. 183 #endif

6、线程上下文保存(_tx_thread_context_save)

6.1、中断处理流程

以下是中断的顶层代码,__tx_irq_handler为中断入口,IRQ中断向量直接调用"B__tx_irq_handler"即可,这样_tx_thread_context_save函数调用时,除了irq专有寄存器被修改外(例如pc、cpsr),其他寄存器都没有动过,因此_tx_thread_context_save读

取的就是没有被改过的寄存器,_tx_thread_context_save也是通过"B"指令跳转过去的,然后通过"B"指令跳转返回的,BL指令会修改lr,所以简单起见都用不修改要保护的寄存器的指令间接实现函数调用。

6.2、中断上下文入栈

_tx_thread_context_save函数主要把中断代码用到或者影响到的一些关键寄存器入栈 (IRQ栈),有中断发生并不一定会切换线程,如果有线程执行,需要在真正换出线程的时候在保存线程上下文。

嵌套中断上下文保存/线程中断上下文寄存器保存代码如下:

```
1. 092
          .global _tx_thread_context_save
2. 093
          .type _tx_thread_context_save,function
3. 094 tx thread context save:
4. 095 @
5. 096 @
          /* Upon entry to this routine, it is assumed that IRQ interrupts are locked
            out, we are in IRQ mode, and all registers are intact. */
6. 097 @
7. 098 @
8. 099 @
           /* Check for a nested interrupt condition. */
9. 100 @
          if ( tx thread system state++)
10. 101 @
          {
11. 102 @
12. 103
           STMDB
                 sp!, {r0-r3}
                                                @ Save some working registers // r0-
   r3保存到IRQ栈里面
13. 104 #ifdef TX ENABLE FIQ SUPPORT
14. 105
           MRS
                 r0, CPSR
                                                @ Pickup the CPSR
15. 106
                  r0, r0, #DISABLE_INTS
           ORR
                                               @ Build disable interrupt CPSR
16. 107
           MSR
                  CPSR cxsf, r0
                                                @ Disable interrupts
17. 108 #endif
18. 109
                 r3, =_tx_thread_system_state @ Pickup address of system state
           LDR
   variable
19. 110
                 r2, [r3]
           LDR
                                                @ Pickup system state
20. 111
           CMP
                r2, #0
                                                @ Is this the first interrupt?
                  __tx_thread_not_nested_save
21. 112
                                               @ Yes, not a nested context save //
           BEO
   第一次进入中断, 非嵌套中断, 跳转到 tx thread not nested save
22. 113 @
23. 114 @
          /* Nested interrupt condition. */
24. 115 @
25. 116
         ADD
                  r2, r2, #1
                                                @ Increment the interrupt counter //
   嵌套中断,嵌套中断计数器加1
26. 117
           STR
                r2, [r3]
                                                @ Store it back in the variable
27. 118 @
28. 119 @ /* Save the rest of the scratch registers on the stack and return to the
```

calling ISR. */

29. 120 @

```
31. 122 MRS
               r0, SPSR
                                             @ Pickup saved SPSR
32. 123 SUB
               lr, lr, #4
                                            @ Adjust point of interrupt // 中断
   返回地址修正
         STMDB sp!, {r0, r10, r12, lr}
33. 124
                                           @ Store other registers // cprs,
  r10, r12, lr(pc)入栈, 后面会用到或者有指令会修改这些寄存器
34. 125 @
35. 126 @ /* Return to the ISR. */
36. 127 @
37. 128 MOV r10, #0
                                             @ Clear stack limit
38. 129
39. 130 #ifdef TX ENABLE EXECUTION CHANGE NOTIFY
40. 131 @
41. 132 @ /* Call the ISR enter function to indicate an ISR is executing. */
42. 133 @
43. 134
         PUSH {lr}
                                            @ Save ISR lr
44. 135
                 _tx_execution_isr_enter
                                           @ Call the ISR enter function
         BL
45. 136 POP
                {lr}
                                            @ Recover ISR lr
46. 137 #endif
47. 138
48. 139 B __tx_irq_processing_return @ Continue IRQ processing // 嵌套中
   断上下文已经保存,返回_tx_thread_context_save下一条指令
49. 140 @
50. 141 __tx_thread_not_nested_save: // 非嵌套中断
51. 142 @ }
52. 143 @
53. 144 @ /* Otherwise, not nested, check to see if a thread was running. */
54. 145 @ else if (_tx_thread_current_ptr)
55. 146 @
         {
56. 147 @
57. 148 ADD
                 r2, r2, #1
                                            @ Increment the interrupt counter //
   非嵌套中断,嵌套中断计数器加1
58. 149
              r2, [r3]
                                            @ Store it back in the variable
         STR
```

30. 121 @

```
59. 150
           LDR
                  r1, =_tx_thread_current_ptr
                                                @ Pickup address of current thread
   ptr
60. 151
           LDR
                   r0, [r1]
                                                 @ Pickup current thread pointer
61. 152
           CMP
                   r0, #0
                                                 @ Is it NULL?
62. 153
           BEQ
                   __tx_thread_idle_system_save
                                                 @ If so, interrupt occurred in
63. 154
                                                     scheduling loop - nothing needs
   saving! // 检查有没有线程在执行,没有的话跳转到 tx thread idle system save,不需要
   保存线程上下文
64. 155 @
          /* Save minimal context of interrupted thread. */
65. 156 @
66. 157 @
67. 158
                  r2, SPSR
                                                 @ Pickup saved SPSR // r2 = cpsr
           MRS
68. 159
                   lr, lr, #4
                                                 @ Adjust point of interrupt // 修正
           SUB
   中断返回地址
69. 160
           STMDB
                  sp!, {r2, r10, r12, lr}
                                                @ Store other registers // cpsr,
   r10, r12, lr(pc)入栈(IRQ栈)(前面r0-r3已经入栈了, 所以这里可以使用r0-r3作为工作寄存器
   了)
70. 161 @
71. 162 @
          /* Save the current stack pointer in the thread's control block. */
72. 163 @
            _tx_thread_current_ptr -> tx_thread_stack_ptr = sp;
73. 164 @
74. 165 @
           /* Switch to the system stack. */
75. 166 @
          sp = _tx_thread_system_stack_ptr@
76. 167 @
77. 168
           MOV
                  r10, #0
                                                 @ Clear stack limit
78. 169
79. 170 #ifdef TX ENABLE EXECUTION CHANGE NOTIFY
80. 171 @
81. 172 @
           /* Call the ISR enter function to indicate an ISR is executing. */
82. 173 @
83. 174
           PUSH
                   {1r}
                                                 @ Save ISR lr
84. 175
           BL
                   _tx_execution_isr_enter
                                                @ Call the ISR enter function
85. 176
           POP
                   {1r}
                                                 @ Recover ISR lr
86. 177 #endif
```

87. 178

88. 179 B __tx_irq_processing_return @ Continue IRQ processing // 部分用 到的寄存器已经保存到IRQ的栈里面了,返回到 tx thread context save的下一条指令

89. 180 @



非嵌套中断也没有线程在执行时,没有保存上下文,如果中断没有唤醒线程,中断退出将调用_tx_thread_schedule,_tx_thread_schedule没有参数也没有局部变量(不需要栈),_tx_thread_schedule需要的只是寄存器,而且所有寄存器的值都是从内存加载,根本不需要保存,被中断的_tx_thread_schedule也不需要被恢复,重新调用_tx_thread_schedule即可:

如果有线程唤醒,那么_tx_thread_schedule也是不需要恢复的,_tx_thread_schedule没有任何数据,跟再次调用_tx_thread_schedule一个道理; 前面已经讲过 tx thread context restore了,中断退出时就调用 tx thread context restore。

6.3、中断服务程序调用

必要的寄存器保存完成后,就可以调用C语言的中断服务程序了,本文只使用了定时器中断,所以就是定时器中断服务程序,定时器函数对线程时间片计数以及内核定时器timer计时,这里面可能唤醒新的线程。

6.4、中断上下文恢复

_tx_thread_context_restore上面章节已经讲过了;中断服务程序如果有线程唤醒或者抢占等情况发生,只会设置或者改变_tx_thread_execute_ptr,_tx_thread_execute_ptr指向最高优先级的线程(不考虑抢占就是最高优先级,考虑抢占就要把抢占阈值计算进来),_tx_thread_context_restore来判断是恢复中断、恢复线程、调度先线程还是什么,最终由_tx_thread_schedule恢复线程上下文。

主动让出cpu的上下文保存比较简单,根据上下文恢复代码,不难理解保存上下文代码,在 此略过。

7、总结

ThreadX内核代码与Nucleus Plus内核代码很多地方非常相似,上下文保存恢复调度基本逻辑相同,Nucleus Plus非开源,ThreadX微软已经在github开源了,支持很多cpu,在裸机代码上,把定时器/IRQ中断入口代码稍作修改即可运行在开发板上。

针对ARM Versatile/PB移植好的代码,地址如下,里面有修改几行代码,官网新版本已经修复: GitHub - arm7star/ThreadXContribute to arm7star/ThreadX development by creating an account on GitHub.



https://github.com/arm7star/ThreadX