
- https://github.com/xlloss/rockchip-rk3399-nanopi-m4-uboot.git
- 0001-add-led-cmd-for-rk.patch



```
4 Include/configs/rk_default_config.h []
           @@ -444,6 +444,10 @@
444
      444
445 445
          #undef CONFIG_UBOOT_CHARGE
446 446
      447
           + #define CONFIG_STATUS_LED
      448
           + #define CONFIG BOARD SPECIFIC LED
      449
           + #define CONFIG_CMD_LED
      450
447
      451
          #endif /* CONFIG LCD */
448 452
449
      453
```

```
✓ 2 ■■■■ board/rockchip/rk33xx/rk33xx.c [<sup>a</sup>]
             @@ -509,7 +509,7 @@ int board_late_init(void)
509
       509
510
       510
                     setup_serial();
511
       511
                     setup_macaddr();
512
       512
                       _led_init(STATUS_LED_BIT, STATUS_LED_ON);
513
       513
                     load_disk_partitions();
514
       514
515
       515
               #ifdef CONFIG RK PWM REMOTE
```

```
ZIU
       ZIJ
      216
217
      217
              #elif defined(CONFIG_BOARD_SPECIFIC_LED)
      218
            + #define GPIO_AO 0
      219
            + #define GPIO_B5 13
      220
            + #define GPIO GROUP 0 (0 << 8)
      221
            + #define GPIO_GROUP_1 (1 << 8)
      222
      223
            + #define STATUS_LED_BIT (GPIO_GROUP_0 | GPIO_B5)
      224
            + #define STATUS_LED_STATE 0
      225
            + #define STATUS_LED_PERIOD 0
      226
218
      227
              /* led_id_t is unsigned long mask */
219
      228
           typedef unsigned long led id t;
220
      229
```

common/Makefile

```
obj-$(CONFIG_CMD_IMMAP) += cmd_immap.o
obj-$(CONFIG_CMD_INI) += cmd_ini.o
obj-$(CONFIG_CMD_IRQ) += cmd_irq.o
obj-$(CONFIG_CMD_ITEST) += cmd_itest.o
obj-$(CONFIG_CMD_JFFS2) += cmd_jffs2.o
obj-$(CONFIG_CMD_CRAMFS) += cmd_cramfs.o
obj-$(CONFIG_CMD_LDRINFO) += cmd_ldrinfo.o
obj-$(CONFIG_CMD_LED) += cmd_led.o
obj-$(CONFIG_CMD_LICENSE) += cmd_license.o
ifndef CONFIG_ROCKCHIP
obj-y += cmd_load.o
endif
```

common/cmd_led.c

```
/* rk lcd total size = fb size + kernel logo size */
#define CONFIG RK LCD SIZE SZ 32M
#define CONFIG RK FB SIZE
                               SZ 16M
#endif
#define CONFIG BRIGHTNESS DIM
                                   64
#undef CONFIG UBOOT CHARGE
#define CONFIG STATUS LED
#define CONFIG BOARD SPECIFIC LED
#define CONFIG CMD LED
```

include/status_led.h

```
#elif defined(CONFIG_BOARD_SPECIFIC_LED)
#define GPIO_A0 0
#define GPIO_B5 13
#define GPIO_GROUP_0 (0 << 8)
#define GPIO_GROUP_1 (1 << 8)

#define STATUS_LED_BIT (GPIO_GROUP_0 | GPIO_B5)
#define STATUS_LED_STATE 0
#define STATUS_LED_PERIOD_0</pre>
```