

Radd Keep Tabletop Fire Pit




User Warning

Do not use this product before reading the operating instructions and user warnings. Serious injury and property damage may occur.

Warning: For outdoor use only.

- ➔ This tabletop fire pit is intended for outdoor use only. Do not use it in enclosed spaces.
- ➔ Do not use the tabletop fire pit for indoor heating, as combustion produces carbon monoxide. Accumulation of carbon monoxide in enclosed spaces can lead to carbon monoxide poisoning.
- ➔ The tabletop fire pit reaches extremely high temperatures during use. Do not touch or move it while in operation or until completely cooled. Direct contact can cause serious injury.
- ➔ The tabletop fire pit poses a safety hazard for children. This product is not a toy and should not be used by children.
- ➔ Do not leave the tabletop fire pit unattended during heating or cooling. Especially if flammable materials are nearby, even if you believe it has cooled down.
- ➔ Do not use the tabletop fire pit on windy days. Keep all cables away during use and do not lean against it.
- ➔ If the tabletop fire pit has not been used for a period of time, inspect for any damage before maintenance and cleaning. Do not operate if damaged.
- ➔ After using the tabletop fire pit, dispose of ashes safely and properly in the ash tray. If the customer does not fully comply with the above instructions, they assume full responsibility for safety.



Instructions for Use

Product Inclusions




Carrying Bag




Frame Ring

1. Frame Ring
2. Ash Tray
3. Stove Body
4. Carrying Bag




Ash Tray


Stove Body



✓
(CORRECT)



✗
(INCORRECT)






Lighting Pellets

1. Place dry tinder in the center of the combustion chamber.

A small amount of gel fire starter may be used.



2. Use a long lighter to ignite the tinder.




3. Once the tinder is burning steadily, carefully add pellets until they are below the ventilation holes.

Do not overfill the fire pit. Overfilling restricts airflow and may cause smoke.



Ash Removal

The tabletop fire pit ash tray accessory is specifically designed for easy removal to facilitate ash removal. Wait for the fire pit to cool for 24 hours, then simply remove and dump the ash tray from the fire pit.



Storage and Care

It is recommended to store the fire pit in a cool, dry place after each use, covered to reduce the possibility of oxidation or rust when not in use.

Technical Specifications

Material: Stainless Steel

Dimensions: Length x Width x Height: 6 x 6 x 8.3 inches

Weight: 2.15 pounds