

Juniper Networks

FIPS 140-3 Non-Proprietary Security Policy

Juniper Networks EX, QFX and ACX Series with MACsec

Version: Junos OS 22.3R2-S1

Prepared for:


Juniper Networks, Inc.
1133 Innovation Way
Sunnyvale, California 94089
USA
408.745.2000
1.888 JUNIPER
www.juniper.net

Prepared by:


www.teronlabs.com

Table of Contents

1 General	6
1.1 Overview	6
1.2 Security Levels.....	6
2 Cryptographic Module Specification.....	6
2.1 Description.....	6
2.2 Tested and Vendor Affirmed Module Version and Identification.....	10
2.3 Excluded Components	11
2.4 Modes of Operation	11
2.5 Algorithms	11
2.6 Security Function Implementations	14
2.7 Algorithm Specific Information	16
2.8 RBG and Entropy	17
2.9 Key Generation	17
2.10 Key Establishment.....	17
2.11 Industry Protocols	18
3 Cryptographic Module Interfaces	18
3.1 Ports and Interfaces	18
4 Roles, Services, and Authentication.....	19
4.1 Authentication Methods.....	19
4.2 Roles	19
4.3 Approved Services.....	20
4.4 Non-Approved Services.....	23
4.5 External Software/Firmware Loaded.....	23
5 Software/Firmware Security.....	23
5.1 Integrity Techniques.....	23
5.2 Initiate on Demand	23
6 Operational Environment	24
6.1 Operational Environment Type and Requirements	24
6.2 Configuration Settings and Restrictions.....	24
7 Physical Security	24
7.1 Mechanisms and Actions Required	24
8 Non-Invasive Security	24
9 Sensitive Security Parameters Management	24
9.1 Storage Areas.....	24

9.2 SSP Input-Output Methods	25
9.3 SSP Zeroization Methods	25
9.4 SSPs	26
9.5 Transitions	30
10 Self-Tests	30
10.1 Pre-Operational Self-Tests	30
10.2 Conditional Self-Tests	30
10.3 Periodic Self-Test Information	33
10.4 Error States	35
10.5 Operator Initiation of Self-Tests	36
11 Life-Cycle Assurance	36
11.1 Installation, Initialization, and Startup Procedures	36
11.2 Administrator Guidance	36
11.2.1 Installing the Junos OS firmware image	36
11.2.2 Configure the device for the Approved mode	37
11.2.3 Zeroizing the System	37
11.3 Non-Administrator Guidance	38
11.4 Design and Rules	38
11.4.1 Module Design Rules	38
11.4.2 Module Operation Rules	38
11.5 Maintenance Requirements	38
11.6 End of Life	39
12 Mitigation of Other Attacks	39

List of Tables

Table 1: Security Levels	6
Table 2: Tested Module Identification – Hardware	10
Table 3: Modes List and Description	11
Table 4: Approved Algorithms - OpenSSL 1.0.2	12
Table 5: Approved Algorithms - MACsec	12
Table 6: Approved Algorithms - MACsec PHY	13
Table 7: Approved Algorithms - OpenSSL 1.1.1	13
Table 8: Approved Algorithms - Kernel	13
Table 9: Approved Algorithms - LibMD	13
Table 10: Vendor-Affirmed Algorithms	14
Table 11: Security Function Implementations	16
Table 12: Entropy Certificates	17
Table 13: Entropy Sources	17
Table 14: Ports and Interfaces	19
Table 15: Authentication Methods	19
Table 16: Roles	19
Table 17: Approved Services	23
Table 18: Mechanisms and Actions Required	24
Table 19: Storage Areas	25
Table 20: SSP Input-Output Methods	25
Table 21: SSP Zeroization Methods	25
Table 22: SSP Table 1	27
Table 23: SSP Table 2	30
Table 24: Pre-Operational Self-Tests	30
Table 25: Conditional Self-Tests	33
Table 26: Pre-Operational Periodic Information	33
Table 27: Conditional Periodic Information	35
Table 28: Error States	35

List of Figures

Figure 1 – EX4400-24P Ethernet switch (front)	7
Figure 2 – EX4400-24P Ethernet switch (rear)	7
Figure 3 – EX4400-24T Ethernet switch (front)	7
Figure 4 – EX4400-24T Ethernet switch (rear)	8
Figure 5 – EX4400-48T Ethernet switch (front)	8
Figure 6 – EX4400-48T Ethernet switch (rear)	8
Figure 7 – EX4400-48P Ethernet switch (front)	8
Figure 8 – EX4400-48P Ethernet switch (rear)	8
Figure 9 – EX4400-48F Ethernet switch (front)	8
Figure 10 – EX4400-48F Ethernet switch (rear)	8
Figure 11 – EX4400-24MP Ethernet switch (front)	9
Figure 12 – EX4400-24MP Ethernet switch (rear)	9
Figure 13 – EX4400-48MP Ethernet switch (front)	9
Figure 14 – EX4400-48MP Ethernet switch (rear)	9

Figure 15 – QFX5120-48YM switch (front).....	9
Figure 16 – QFX5120-48YM switch (rear).....	9
Figure 17 – ACX5448-M Router – Front.....	9
Figure 18 – ACX5448-M Router – Rear	10

1 General

1.1 Overview

This is a non-proprietary Cryptographic Module Security Policy for the Juniper Networks EX, QFX and ACX series network devices running Junos OS 22.3R2-S1.

1.2 Security Levels

The cryptographic module is designed to meet FIPS 140-3 Level 1 overall. The table below shows the security levels claimed for each section of the security requirements.

Section	Title	Security Level
1	General	1
2	Cryptographic module specification	1
3	Cryptographic module interfaces	1
4	Roles, services, and authentication	2
5	Software/Firmware security	1
6	Operational environment	1
7	Physical security	1
8	Non-invasive security	N/A
9	Sensitive security parameter management	1
10	Self-tests	1
11	Life-cycle assurance	1
12	Mitigation of other attacks	N/A
	Overall Level	1

Table 1: Security Levels

2 Cryptographic Module Specification

2.1 Description

Purpose and Use:

The following models are included in this validation and provide network switching and routing functionality:

- EX4400-24T
- EX4400-24P
- EX4400-48T
- EX4400-48P
- EX4400-48F
- EX4400-24MP
- EX4400-48MP
- QFX5120-YM
- ACX5448-M

The cryptographic module runs Junos OS, Juniper's reliable, high-performance, modular network operating system that is supported across all of Juniper's physical and virtual routing, switching, and security platforms.

The cryptographic module provides for an encrypted connection, using SSH, between the management station and the module. The cryptographic modules also provide for an encrypted connection, using MACsec, between devices. All other data input or output from the modules are considered plaintext for this FIPS 140-3 validation.

Module Type:

The cryptographic module is a Hardware cryptographic module.

Module Embodiment:

The cryptographic module is defined as a MultiChipStand module that executes Junos OS 22.3R2-S1 firmware on any of the identified Juniper Networks devices.

Module Characteristics:

There are no additional characteristics relevant to this module.

Cryptographic Boundary:

The cryptographic boundary encompasses the entire Tested Operational Environment Physical Perimeter (TOEPP), which is defined as the outer edge of the chassis. The chassis is a rigid sheet-metal structure that houses all components of the device.

The cryptographic module is FIPS-compliant when installed and configured with Junos OS 22.3R2-S1 validated firmware as specified in section 11.1.

The physical form of the module is depicted in Figure 1 to Figure 18.



Figure 1 – EX4400-24P Ethernet switch (front)



Figure 2 –EX4400-24P Ethernet switch (rear)



Figure 3 –EX4400-24T Ethernet switch (front)



Figure 4 – EX4400-24T Ethernet switch (rear)




Figure 5 – EX4400-48T Ethernet switch (front)



Figure 6 – EX4400-48T Ethernet switch (rear)




Figure 7 – EX4400-48P Ethernet switch (front)



Figure 8 – EX4400-48P Ethernet switch (rear)



Figure 9 – EX4400-48F Ethernet switch (front)



Figure 10 – EX4400-48F Ethernet switch (rear)



Figure 11 – EX4400-24MP Ethernet switch (front)



Figure 12 – EX4400-24MP Ethernet switch (rear)




Figure 13 – EX4400-48MP Ethernet switch (front)



Figure 14 – EX4400-48MP Ethernet switch (rear)



Figure 15 – QFX5120-48YM switch (front)



Figure 16 – QFX5120-48YM switch (rear)



Figure 17 – ACX5448-M Router – Front



Figure 18 – ACX5448-M Router – Rear

2.2 Tested and Vendor Affirmed Module Version and Identification

Tested Module Identification – Hardware:

The following models of the module were tested.

Model and/or Part Number	Hardware Version	Firmware Version	Processors	Features
EX4400-48F	EX4400-48F	JUNOS 22.3R2-S1.9	Intel Atom C3558R	12 x 10GbE SFP+ ports; 36 x 1GbE SFP fiber access ports
QFX5120-48YM	QFX5120-48YM	JUNOS 22.3R2-S1.9	Intel Xeon D-1627	48 x 1/10/25GbE SFP/SFP+ ports; 8 x 40/100GbE QSFP+/QSFP28
ACX5400-M	ACX5400-M	JUNOS 22.3R2-S1.9	Intel Xeon D-1528	44 x 1GbE/10GbE SFP+/SFP ports; 6 x 40GbE/100GbE QSFP28 ports.
EX4400-24T	EX4400-24T	JUNOS 22.3R2-S1.9	Intel Atom C3558R	24 x 1GbE non-PoE ports
EX4400-24P	EX4400-24P	JUNOS 22.3R2-S1.9	Intel Atom C3558R	24 x 1GbE PoE ports
EX4400-48T	EX4400-48T	JUNOS 22.3R2-S1.9	Intel Atom C3558R	48 x 1GbE non-PoE ports
EX4400-48P	EX4400-48P	JUNOS 22.3R2-S1.9	Intel Atom C3558R	48 x 1GbE PoE ports
EX4400-24MP	EX4400-24MP	JUNOS 22.3R2-S1.9	Intel Atom C3558R	24 x 100M/1/2.5/5/10GbE PoE ports
EX4400-48MP	EX4400-48MP	JUNOS 22.3R2-S1.9	Intel Atom C3558R	12 x 100M/1/2.5/5/10GbE and 36 x 100M/1/2.5GbE PoE access ports

Table 2: Tested Module Identification – Hardware

Tested Module Identification – Software, Firmware, Hybrid (Executable Code Sets): N/A

The module is not classified as software, firmware, or hybrid; thus, this section is not applicable.

Tested Module Identification – Hybrid Disjoint Hardware: N/A

The module is not classified as hybrid disjoint hardware; thus, this section is not applicable.

Tested Operational Environments - Software, Firmware, Hybrid: N/A

The module is not classified as software, firmware, or hybrid; thus, this section is not applicable.

Vendor-Affirmed Operational Environments - Software, Firmware, Hybrid: N/A

There are no vendor-affirmed operational environments claimed.

2.3 Excluded Components

No components are excluded from the requirements of FIPS PUB 140-3.

2.4 Modes of Operation

The module supports an Approved mode only. The module enters Approved mode as a result of successful installation, initialization and configuration steps described in section 11. Until these procedures have been followed, the module is non-compliant.

Mode Name	Description	Type	Status Indicator
Approved	Approved mode of operation.	Approved	Suffix string ":fips" in the cli prompt

Table 3: Modes List and Description

2.5 Algorithms

Approved Algorithms:

Although the module may have been tested for additional algorithms or modes, only those listed below are utilized by the module.

OpenSSL 1.0.2

Algorithm	CAVP Cert	Properties	Reference
AES-CBC	A4210	Direction - Decrypt, Encrypt Key Length - 128, 192, 256	SP 800-38A
AES-CTR	A4210	Direction - Decrypt, Encrypt Key Length - 128, 192, 256	SP 800-38A
ECDSA KeyGen (FIPS186-4)	A4210	Curve - P-256, P-384, P-521 Secret Generation Mode - Testing Candidates	FIPS 186-4
ECDSA KeyGen (FIPS186-4)	A6440	Curve - P-256, P-384, P-521 Secret Generation Mode - Testing Candidates	FIPS 186-4
ECDSA KeyVer (FIPS186-4)	A4210	Curve - P-256, P-384, P-521	FIPS 186-4
ECDSA KeyVer (FIPS186-4)	A6440	Curve - P-256, P-384, P-521	FIPS 186-4
ECDSA SigGen (FIPS186-4)	A4210	Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4
ECDSA SigGen (FIPS186-4)	A6440	Component - No Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4
ECDSA SigVer (FIPS186-4)	A4210	Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4

Algorithm	CAVP Cert	Properties	Reference
ECDSA SigVer (FIPS186-4)	A6440	Component - No Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4
HMAC-SHA-1	A4210	Key Length - Key Length: 160	FIPS 198-1
HMAC-SHA2-256	A4210	Key Length - Key Length: 256	FIPS 198-1
HMAC-SHA2-512	A4210	Key Length - Key Length: 512	FIPS 198-1
KAS-ECC-SSC Sp800-56Ar3	A4387	Domain Parameter Generation Methods - P-256, P-384, P-521 Scheme - ephemeralUnified - KAS Role - initiator, responder	SP 800-56A Rev. 3
KDF SSH (CVL)	A4347	Cipher - AES-128, AES-192, AES-256 Hash Algorithm - SHA-1, SHA2-256, SHA2-384, SHA2-512	SP 800-135 Rev. 1
RSA KeyGen (FIPS186-4)	A4210	Key Generation Mode - B.3.3 Modulo - 2048, 3072, 4096 Primality Tests - Table C.2 Private Key Format - Standard	FIPS 186-4
RSA SigGen (FIPS186-4)	A4210	Signature Type - PKCS 1.5 Modulo - 2048, 3072, 4096	FIPS 186-4
RSA SigVer (FIPS186-4)	A4210	Signature Type - PKCS 1.5 Modulo - 2048, 3072, 4096	FIPS 186-4
SHA-1	A4210	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4
SHA2-256	A4210	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4
SHA2-384	A4210	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4
SHA2-512	A4210	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4

Table 4: Approved Algorithms - OpenSSL 1.0.2

MACsec

Algorithm	CAVP Cert	Properties	Reference
AES-CBC	A4416	Direction - Decrypt, Encrypt Key Length - 128, 256	SP 800-38A
AES-CMAC	A4416	Direction - Generation, Verification Key Length - 128, 256	SP 800-38B
AES-KW	A4416	Direction - Decrypt, Encrypt Key Length - 128	SP 800-38F
KDF SP800-108	A4416	KDF Mode - Counter Supported Lengths - Supported Lengths: 128, 256	SP 800-108 Rev. 1

Table 5: Approved Algorithms - MACsec

MACsec PHY

Algorithm	CAVP Cert	Properties	Reference
AES-GCM	AES 3969	Direction - Decrypt, Encrypt Key Length - 128, 256	SP 800-38D
AES-GCM	AES 4544	Direction - Decrypt, Encrypt Key Length - 128, 256	SP 800-38D
AES-GCM	AES 4545	Direction - Decrypt, Encrypt Key Length - 128, 256	SP 800-38D

Algorithm	CAVP Cert	Properties	Reference
AES-GCM	AES 4550	Direction - Decrypt, Encrypt Key Length - 128, 256	SP 800-38D
AES-GCM	C1869	Direction - Decrypt, Encrypt IV Generation - External Key Length - 128, 256	SP 800-38D
AES-GCM	C996	Direction - Decrypt, Encrypt IV Generation - External Key Length - 128, 256	SP 800-38D

Table 6: Approved Algorithms - MACsec PHY

OpenSSL 1.1.1

Algorithm	CAVP Cert	Properties	Reference
ECDSA SigVer (FIPS186-4)	A4211	Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4
ECDSA SigVer (FIPS186-4)	A6401	Component - No Curve - P-256, P-384, P-521 Hash Algorithm - SHA2-256, SHA2-384, SHA2-512	FIPS 186-4
SHA2-256	A4211	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4

Table 7: Approved Algorithms - OpenSSL 1.1.1

Kernel

Algorithm	CAVP Cert	Properties	Reference
HMAC DRBG	A4417	Prediction Resistance - Yes Mode - SHA2-256	SP 800-90A Rev. 1
HMAC-SHA2-256	A4417	Key Length - Key Length: 256	FIPS 198-1
SHA2-256	A4417	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4
SHA2-512	A3330	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4
SHA2-512	A3355	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4
SHA2-512	A3498	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4

Table 8: Approved Algorithms - Kernel

LibMD

Algorithm	CAVP Cert	Properties	Reference
HMAC-SHA-1	A4208	Key Length - Key Length: 112, 160	FIPS 198-1
HMAC-SHA2-256	A4208	Key Length - Key Length: 160, 256	FIPS 198-1
SHA-1	A4208	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4
SHA2-256	A4208	Message Length - Message Length: 0-51200 Increment 8	FIPS 180-4
SHA2-512	A4208	Message Length - Message Length: 0-65536 Increment 8	FIPS 180-4

Table 9: Approved Algorithms - LibMD

Vendor-Affirmed Algorithms:

Name	Properties	Implementation	Reference
CKG	Key type:Asymmetric	Junos 22.3R2-S1 - OpenSSL 1.0.2	SP 800-133 Rev.2 Section 4, example 1 direct output from DRBG.

Table 10: Vendor-Affirmed Algorithms

Non-Approved, Allowed Algorithms:

N/A for this module.

Non-Approved, Allowed Algorithms with No Security Claimed:

N/A for this module.

Non-Approved, Not Allowed Algorithms:

N/A for this module.

2.6 Security Function Implementations

The module implements the security functions listed in the following table.

Name	Type	Description	Properties	Algorithms
Enc/Dec (SSH)	BC-UnAuth	Unauthenticated encryption for SSH		AES-CBC: (A4210) AES-CTR: (A4210)
KAS-SSC (SSH)	KAS-SSC	Key Agreement Scheme Shared Secret Computation for SSH		KAS-ECC-SSC Sp800-56Ar3: (A4387)
KeyGen (SSH)	AsymKeyPair-KeyGen	Key Generation used for SSH authentication keys		ECDSA KeyGen (FIPS186-4): (A4210, A6440) ECDSA KeyVer (FIPS186-4): (A4210, A6440) RSA KeyGen (FIPS186-4): (A4210) HMAC DRBG: (A4417) CKG: ()
SigGen (SSH)	DigSig-SigGen	Signature Generation for peer authentication in SSH		ECDSA SigGen (FIPS186-4): (A4210, A6440) RSA SigGen (FIPS186-4): (A4210) SHA2-256: (A4210) SHA2-384: (A4210) SHA2-512: (A4210)

Name	Type	Description	Properties	Algorithms
SigVer (SSH)	DigSig-SigVer	Signature Verification for peer authentication in SSH		ECDSA SigVer (FIPS186-4): (A4210, A6440) RSA SigVer (FIPS186-4): (A4210) SHA2-256: (A4210) SHA2-384: (A4210) SHA2-512: (A4210)
MAC (SSH)	MAC	Message authentication for SSH		HMAC-SHA-1: (A4210) HMAC-SHA2-256: (A4210) HMAC-SHA2-512: (A4210) SHA-1: (A4210) SHA2-256: (A4210) SHA2-512: (A4210)
KAS KeyGen (SSH)	KAS-KeyGen	Key Generation for Key Agreement in SSH		ECDSA KeyGen (FIPS186-4): (A4210) ECDSA KeyVer (FIPS186-4): (A4210) CKG: () HMAC DRBG: (A4417)
KDF (SSH)	KAS-135KDF	Key derivation function for SSH		KDF SSH: (A4347) SHA-1: (A4210) SHA2-256: (A4210) SHA2-384: (A4210) SHA2-512: (A4210)
Full KAS (SSH)	KAS-Full	Full Key Agreement for SSH		ECDSA KeyGen (FIPS186-4): (A4210, A6440) ECDSA KeyVer (FIPS186-4): (A4210, A6440) KAS-ECC-SSC Sp800-56Ar3: (A4387) SHA-1: (A4210) SHA2-256: (A4210) SHA2-384: (A4210) SHA2-512: (A4210) KDF SSH: (A4347)
KTS (SSH)	KTS-Wrap	Key transport using SSH as per IG D.G provisions	KTS:128, 256, 384, 521, 2048, 3072, 4096 bit keys provide between 112 and 256 bits of encryption strength	AES-CBC: (A4210) AES-CTR: (A4210) HMAC-SHA-1: (A4210) HMAC-SHA2-256: (A4210) HMAC-SHA2-512: (A4210)
SHA (LibMD)	SHA	Message Digest Generation		SHA-1: (A4208) SHA2-256: (A4208) SHA2-512: (A4208)

Name	Type	Description	Properties	Algorithms
MAC (LibMD)	MAC	Message Authentication		HMAC-SHA-1: (A4208) HMAC-SHA2-256: (A4208) SHA-1: (A4208) SHA2-256: (A4208)
DRBG (Kernel)	DRBG	Random Bit Generation		HMAC DRBG: (A4417) HMAC-SHA2-256: (A4417) SHA2-256: (A4417)
SHA (Kernel)	SHA	Entropy source conditioning component		SHA2-512: (A3355, A3498, A3330)
Verify image	DigSig-SigVer	Verification of firmware image		ECDSA SigVer (FIPS186-4): (A4211, A6401) SHA2-256: (A4211)
Key derivation (MACsec)	KAS-56CKDF	Derivation of MACsec MKA keys		KDF SP800-108: (A4416) AES-CBC: (A4416) AES-CMAC: (A4416)
Key wrap (MACsec)	KTS-Wrap	Distribution of MACsec SAKs	KTS:128 and 256 bit keys provide between 128 and 256 bits of encryption strength	AES-KW: (A4416)
Enc/Dec (MACsec)	BC-Auth	Encryption and decryption of MACsec data		AES-GCM: (AES 3969, AES 4544, AES 4545, AES 4550, C1869, C996)
Integrity (MACsec)	MAC	MACsec protocol data integrity protection		AES-CMAC: (A4416)
Entropy Source	ENT-ESV	Entropy source		SHA2-512: (A3355, A3498, A3330)

Table 11: Security Function Implementations

2.7 Algorithm Specific Information

In reference to the MACsec protocol, the modules can take on the role of Peer or Authenticator.

The AES GCM IV construction is performed in compliance with IG C.H scenario 1c (MACsec per IEEE 802.1AE and its amendments).

The module includes ECDSA algorithms that have been validated using FIPS 186-4 CAVP tests, which are mathematically identical to FIPS 186-5 CAVP tests. Per IG C.K, all RSA and ECDSA algorithms implemented by the module are claimed compliant with FIPS 186-5.

The module complies with IG C.F. RSA Key Generation, Signature Generation and Signature Verification have been tested and validated using CAVP testing for all implemented modulus lengths (2048, 3072 and 4096 bits). The number of Miller-Rabin tests used for primality testing as part of RSA Key Generation is consistent with Table C.3.

The module implements the following Approved key agreement methods which have been CAVP tested and validated:

- KAS-ECC per SP 800-56A Rev. 3 (FIPS 140-3 IG D.F Scenario 2, path 2).

The module obtains the FIPS 140-3 IG D.F required key agreement assurances in accordance with Section 5.6.2 of SP800-56A Rev. 3. All the key agreement protocols implemented by the module are Diffie-Hellman based.

2.8 RBG and Entropy

The tables below indicate the entropy source used by the module and their associated certificates.

Cert Number	Vendor Name
E89	Juniper Networks

Table 12: Entropy Certificates

Name	Type	Operational Environment	Sample Size	Entropy per Sample	Conditioning Component
EX4400 - Junos OS 22.3 Entropy Source (E89)	Non-Physical	Intel Atom C3558R	512 bits	448 bits	A3355 (SHA2-512)
QFX5120-48YM - Junos OS 22.3 Entropy Source (E89)	Non-Physical	Intel Xeon D-1627	512 bits	448 bits	A3498 (SHA2-512)
ACX5448-M - Junos OS 22.3 Entropy Source (E89)	Non-Physical	Intel Xeon D-1528	512 bits	448 bits	A3330 (SHA2-512)

Table 13: Entropy Sources

The entropy source is used to seed the module's HMAC DRBG with the minimum required 256-bits of entropy. Each 512-bit block of conditioned output from the entropy source contains 448 bits of entropy. The HMAC DRBG is used for all random data required by the module, including key generation.

There are no initialization procedures required by the users of the module to operate the entropy source in a compliant manner. The module complies with the ESV Public Use document of the validated entropy source (Cert. [E89](#)).

2.9 Key Generation

The cryptographic module implements the key generation methods listed above in the Security Functions implementation table.

2.10 Key Establishment

The cryptographic module implements the key establishment methods listed above in the Security Functions implementation table.

2.11 Industry Protocols

The cryptographic module supports the protocols listed below. No part of these protocols, other than the approved cryptographic algorithms and the KDFs, have been tested by the CAVP and CMVP. The SSH algorithms allow independent selection of key exchange, authentication, cipher, and integrity. In reference to the supported protocols table below, each column of options for a given protocol is independent and may be used in any viable combination.

Protocol	Key Exchange	Auth	Cipher	Integrity
SSHv2	EC Diffie-Hellman P-256 EC Diffie-Hellman P-384 EC Diffie-Hellman P-521	ECDSA P-256 ECDSA P-384 ECDSA P-521 RSA 2048 RSA 3072 RSA 4096	AES CBC 128/192/256 AES CTR 128/192/256	HMAC-SHA-1 HMAC-SHA2-256 HMAC-SHA2-512
MACsec	MACsec Key Agreement (SP800-108 KDF, AES-CMAC-128/256, AES-KW 128/256)	Shared secret	AES-GCM-128 AES-GCM-256	

3 Cryptographic Module Interfaces

3.1 Ports and Interfaces

The following table maps each physical interface to one or more logical interface types defined in the FIPS 140-3 standard. The module does not have a Control Output Interface.

Physical Port	Logical Interface(s)	Data That Passes
Ethernet (data)	Data Input Data Output Control Input Status Output	LAN communications
Ethernet (mgmt.)	Data Input Data Output Control Input Status Output	Remote management
Serial	Data Input Data Output Control Input Status Output	Console serial port management
Power	Power	Power
Reset button	Control Input	Reset
USB	Data Input Control Input	Firmware load port

Physical Port	Logical Interface(s)	Data That Passes
LED	Status Output	Status indicator lighting
SFP28 (EX4400 only)	Data Input Data Output Control Input Status Output	Virtual chassis ports
Timing interface ports: PPS and 10M GPS (ACX5448 and QFX5120 models only)	Control Input	Clock and timing signals from external devices

Table 14: Ports and Interfaces

4 Roles, Services, and Authentication

4.1 Authentication Methods

The module implements two forms of role-based authentication methods, as described in the following table.

Method Name	Description	Security Mechanism	Strength Each Attempt	Strength per Minute
Password authentication	User and CO authentication via SSH or consol. Minimum of 10 ASCII character passwords.	SHA (LibMD)	Probability of guessing: $1/(96^{10}) < 1/1,000,000$.	Timed access mechanism allows max of 10 attempts / min. Probability of guessing: $10/(96^{10}) < 1/100,000$.
Signature authentication	User/CO authentication via SSH	SigVer (SSH)	Strength of signature algorithm, minimum 112-bits. Probability of success for random attempt: $1/(2^{112}) < 1/1,000,000$.	A rate of 1 CPU cycle per failed authentication for the Intel Xeon D-1627 processor (4 cores, 2.9 GHz) allows for the probability of success by brute-force attack: $60 \times 4 \times 2.9 \times 10^9 \times 1/(2^{112}) < 1/100,000$.

Table 15: Authentication Methods

4.2 Roles

Name	Type	Operator Type	Authentication Methods
Crypto Officer	Role	CO	Password authentication Signature authentication
User	Role	Monitor	Password authentication Signature authentication

Table 16: Roles

The module supports two roles: Cryptographic Officer (CO) and User. The module supports role-based operator authentication for assuming these roles, using methods specified in Section 4.1.

The module supports concurrent operators but does not support a maintenance role and/or bypass capability. The module enforces the separation of roles using either of the role-based operator authentication methods in Section 4.1.

The Cryptographic Officer role configures and monitors the module via a console or SSH connection. As root or super-user, the Cryptographic Officer has permission to view and edit secrets within the module.

The User role monitors the module via the console or SSH. The user role cannot change the configuration.

4.3 Approved Services

Name	Description	Indicator	Inputs	Outputs	Security Functions	SSP Access
Configure Security	Security relevant configuration	':fips' suffix in CLI prompt	CLI Command	Status	SHA (Kernel) Entropy Source KeyGen (SSH) SHA (LibMD) MAC (LibMD) DRBG (Kernel)	Crypto Officer - HMAC DRBG V value: E - HMAC DRBG Key value: E - HMAC DRBG Entropy Input: E - HMAC DRBG Seed: E - User-PW: W - CO-PW: W - Root-PW: W - SSH PUB: G,R,W - SSH PHK: G,R,W - MACsec CAK: W - MACsec CKN: R,W
Configure	Non-security relevant configuration	None	CLI Command	Status	None	Crypto Officer
Secure Traffic	MACsec encrypted transfer of data, distribution of keys	':fips' suffix in CLI prompt	MACsec traffic frames	MACsec traffic frames	Key wrap (MACsec) Enc/Dec (MACsec) Integrity (MACsec)	Crypto Officer - MACsec KEK: G,E - MACsec SAK: G,E - MACsec ICK: G,E
Show status	Show status	None	None	':fips' suffix in CLI prompt	None	Crypto Officer User
Zeroize	Zeroize all CSPs	None	CLI command	None (completion indicator is implicitly provided by the module rebooting)	None	Crypto Officer - HMAC DRBG V value: Z - HMAC DRBG Key value: Z - HMAC DRBG Entropy Input: Z - HMAC DRBG

Name	Description	Indicator	Inputs	Outputs	Security Functions	SSP Access
						Seed: Z - SSH DH Shared Secret: Z - SSH PHK: Z - SSH PUB: Z - SSH DH PRV: Z - SSH DH PUB: Z - SSH DH Pub (peer): Z - SSH-SEKS: Z - CO-PW: Z - Root-PW: Z - User-PW: Z - Auth-CO Pub: Z - Auth-User Pub: Z - Root-CA: Z - Package-CA: Z - MACsec CAK: Z - MACsec CKN: Z - MACsec SAK: Z - MACsec KEK: Z - MACsec ICK: Z
SSH connect	Initiate SSH connection for SSH monitoring and control (CLI)	:fips' suffix in CLI prompt	SSH packets	SSH packets, Status	Enc/Dec (SSH) KAS-SSC (SSH) SigGen (SSH) SigVer (SSH) MAC (SSH) KAS KeyGen (SSH) KDF (SSH) Full KAS (SSH) KTS (SSH) SHA (Kernel) Entropy Source	Crypto Officer - HMAC DRBG Value: E - HMAC DRBG Key value: E - HMAC DRBG Entropy Input: E - HMAC DRBG Seed: E - SSH DH Shared Secret: G,E - SSH DH PRV: G,E - SSH DH PUB: G - SSH-SEKS: G,E - SSH DH Pub (peer): E - CO-PW: E User - HMAC DRBG Value: E - HMAC DRBG Key value: E - HMAC DRBG Entropy Input: E - HMAC DRBG Seed: E - SSH DH Shared Secret: G,E - SSH DH PRV: G,E - SSH DH PUB: G

Name	Description	Indicator	Inputs	Outputs	Security Functions	SSP Access
						- SSH-SEKs: G,E - SSH DH Pub (peer): E - User-PW: E
MACsec connect	Initiate MACsec connection	:fips' suffix in CLI prompt	MACsec link configuration, CKN, CAK	MACsec frames, Status	Key derivation (MACsec) Key wrap (MACsec) Enc/Dec (MACsec) Integrity (MACsec)	Crypto Officer - MACsec ICK: E - MACsec SAK: E,W,R - MACsec KEK: E
Console access	Console monitoring and control (CLI)	None	CLI Command	Status	None	Crypto Officer - CO-PW: E - Root-PW: E User - User-PW: E
Remote reset	Software initiated reset, performs self-tests on demand.	None	CLI command	Status	None	Crypto Officer - HMAC DRBG V value: Z - HMAC DRBG Key value: Z - HMAC DRBG Entropy Input: Z - HMAC DRBG Seed: Z - SSH DH Shared Secret: Z - SSH DH PRV: Z - SSH DH PUB: Z - SSH-SEKs: Z - SSH DH Pub (peer): Z - MACsec SAK: Z - MACsec KEK: Z - MACsec ICK: Z
Local reset	Hardware reset or power cycle	None	Main power cycle	Status	None	Unauthenticated - HMAC DRBG V value: Z - HMAC DRBG Key value: Z - HMAC DRBG Entropy Input: Z - HMAC DRBG Seed: Z - SSH DH Shared Secret: Z - SSH DH PRV: Z - SSH DH PUB: Z - SSH-SEKs: Z - SSH DH Pub (peer): Z - MACsec SAK: Z - MACsec KEK: Z - MACsec ICK: Z

Name	Description	Indicator	Inputs	Outputs	Security Functions	SSP Access
Traffic	Traffic requiring no cryptographic services	None	Traffic in	Traffic out	None	Unauthenticated
Load Image	Loading of firmware image	':fips' suffix in CLI prompt	CLI Command	Status	Verify image	Crypto Officer - Root-CA: E - Package-CA: Z
Perform self-test	On demand execution of all pre-operational and conditional algorithm self-tests	None	Local or remote reset	Status	None	Crypto Officer User Unauthenticated
Show module version	Show system information identifying module	None	CLI command	Status	None	Crypto Officer User

Table 17: Approved Services

4.4 Non-Approved Services

The module does not offer any non-approved services.

N/A for this module.

4.5 External Software/Firmware Loaded

The module includes a firmware load service that is used to install the Junos OS firmware image as part of installation of the module, as described in Section 11.1. The loaded firmware is a complete image replacement and constitutes an entirely new module and version of Junos OS which would require a separate FIPS 140-3 validation.

5 Software/Firmware Security

5.1 Integrity Techniques

The cryptographic module implements a firmware integrity self-test that uses ECDSA P-256 with SHA2-256 to ensure the integrity of all Junos OS firmware components. The self-test is automatically run on power-up.

5.2 Initiate on Demand

The firmware integrity test can be run on demand by the module's operator by power cycling the module.

6 Operational Environment

6.1 Operational Environment Type and Requirements

Type of Operational Environment: Non-Modifiable

The module consists of hardware containing a non-modifiable operational environment as per the FIPS 140-3 definitions. It includes a firmware load service to support necessary updates. The loaded firmware is a complete image replacement and constitutes an entirely new module and version of Junos OS which would require a separate FIPS 140-3 validation.

6.2 Configuration Settings and Restrictions

There are no security rules, settings, or restrictions to the configuration of the operational environment beyond the initialization instructions to set the module in Approved mode.

7 Physical Security

7.1 Mechanisms and Actions Required

The module's physical embodiment meets Level 1 Physical Security requirements. The module is completely enclosed in a rectangular nickel or clear zinc coated, cold rolled steel, plated steel and brushed aluminum enclosure. There are no ventilation holes, gaps, slits, cracks, slots, or crevices that would allow for any sort of observation of any component contained within the cryptographic boundary.

Mechanism	Inspection Frequency	Inspection Guidance
Opaque metal enclosure	n/a	n/a

Table 18: Mechanisms and Actions Required

8 Non-Invasive Security

This section is not applicable, as there are currently no approved non-invasive mitigation techniques specified in ISO/IEC 19790:2012.

9 Sensitive Security Parameters Management

9.1 Storage Areas

The table below lists the areas within the module's cryptographic boundary where SSPs can be stored.

Storage Area Name	Description	Persistence Type
RAM	Random Access Memory	Dynamic
Flash	Internal flash memory storage drive	Static

Table 19: Storage Areas

9.2 SSP Input-Output Methods

The table below lists the method used by the module for the input and output of SSPs.

Name	From	To	Format Type	Distribution Type	Entry Type	SFI or Algorithm
Manual CLI entry	Local CO	RAM	Plaintext	Manual	Direct	
Entry via SSH	Remote CO	RAM	Encrypted	Automated	Electronic	KTS (SSH)
Entry via console	Local CO	RAM	Plaintext	Manual	Electronic	
Output via SSH	RAM	Remote CO	Encrypted	Automated	Electronic	KTS (SSH)
Output via console	RAM	Local CO	Plaintext	Manual	Electronic	
Entry as part of KAS	Remote peer	RAM	Plaintext	Automated	Electronic	Full KAS (SSH)
Output as part of KAS	RAM	Remote peer	Plaintext	Automated	Electronic	Full KAS (SSH)
Pre-loaded	Manufacturer	Flash	Plaintext	Manual	Direct	
MACsec Key Agreement Input	Remote device	RAM	Encrypted	Automated	Electronic	Key wrap (MACsec)
MACsec Key Agreement Output	RAM	Remote device	Encrypted	Automated	Electronic	Key wrap (MACsec)

Table 20: SSP Input-Output Methods

9.3 SSP Zeroization Methods

The table below describes the SSP zeroization methods employed by the module.

Zeroization Method	Description	Rationale	Operator Initiation
Zeroize CLI command	This command erases all data, including all configuration information, returning the module to its factory default state. The system is then rebooted.	This command erases all keys and CSPS from storage. The forced power cycle also zeroizes SSPs in volatile memory.	Yes, CO via invocation of zeroize CLI command.
Reset	Zeroization of SSPs in RAM via invocation of local or remote reset service.	RAM is volatile and all data is lost when power is taken off. Zeroization is practically instantaneous.	Yes, both User and CO, via invocation of Local Reset or Remote Reset services.
Explicit zeroize function	Zeroization of SSPs in memory when no longer needed.	Use of explicit zeroization function destroys SSP information immediately by overwriting memory area with zeroes.	No. The operator cannot directly initiate this method.

Table 21: SSP Zeroization Methods

The Zeroize CLI command method is detailed in section 11.2.3.

The completion of zeroization is indicated implicitly. If the zeroization is initiated using a zeroization command or explicit delete command, completion of the command indicates that zeroization has successfully completed. If the zeroization is initiated by power cycling the

module, then successful reboot of the module indicates that zeroization has completed successfully. In the case of zeroization initiated by session termination, SSPs are zeroized when the session terminates, and session termination is indicated in the log.

9.4 SSPs

All SSPs used by the module are described in this section.

Name	Description	Size - Strength	Type - Category	Generated By	Established By	Used By
HMAC DRBG V value	A critical value of the internal state of DRBG	256 - 256	DRBG internal state - CSP	DRBG (Kernel)		DRBG (Kernel)
HMAC DRBG Key value	A critical value of the internal state of DRBG	256 - 256	DRB internal state - CSP	DRBG (Kernel)		DRBG (Kernel)
HMAC DRBG Entropy Input	A critical value of the internal state of DRBG provided by entropy source	256 - 256	Entropy source output - CSP	Entropy Source		DRBG (Kernel)
HMAC DRBG Seed	Seed material used to seed or reseed the HMAC DRBG	256 - 256	DRBG internal state - CSP	DRBG (Kernel)		DRBG (Kernel)
SSH DH Shared Secret	Shared DH value computed from the ephemeral DH key-pairs as part of SSH and used to derive session keys.	256, 384, 521 - 128, 192, 256	DH shared value - CSP		KAS-SSC (SSH)	KDF (SSH)
SSH PHK	SSH Private host key. 1st time SSH is configured, the keys are generated.	2048, 256, 4096, 384, 521 - 112, 128, 152, 192, 256	Asymmetric private key - CSP	KeyGen (SSH)		SigGen (SSH)
SSH PUB	SSH Public Host Key	2048, 256, 4096, 384, 521 - 112, 128, 152, 192, 256	Asymmetric public key - PSP	KeyGen (SSH)		SigVer (SSH)
SSH DH PRV	SSH KAS private key	256, 384, 521 - 128, 192, 256	Asymmetric private key - CSP	KAS KeyGen (SSH)		KAS-SSC (SSH) Full KAS (SSH)
SSH DH PUB	SSH KAS public key	256, 384, 521 - 128, 192, 256	Asymmetric public key - PSP	KAS KeyGen (SSH)		
SSH DH Pub (peer)	SSH KAS public key from peer	256, 384, 521 - 128, 192, 256	Asymmetric public key - PSP			KAS-SSC (SSH) Full KAS (SSH)
SSH-SEKs	SSH Session Encryption Keys	128, 192, 256 - 128, 192, 256	Symmetric key - CSP		KDF (SSH) Full KAS (SSH)	Enc/Dec (SSH) MAC (SSH)

Name	Description	Size - Strength	Type - Category	Generated By	Established By	Used By
CO-PW	Password used to authenticate the CO.	Min 10 characters - n/a	Authentication password - CSP		KTS (SSH)	SHA (LibMD)
Root-PW	Password used by CO to authenticate as 'root'.	Min 10 characters - n/a	Authentication password - CSP		KTS (SSH)	SHA (LibMD)
User-PW	Password used to authenticate User	Min 10 characters - n/a	Authentication password - CSP		KTS (SSH)	SHA (LibMD)
Auth-CO Pub	SSH CO Authentication Public Key	2048, 4096, 256, 384, 521 - 112, 128, 152, 192, 256	Asymmetric public key - PSP		KTS (SSH)	SigVer (SSH)
Auth-User Pub	SSH User Authentication Public Key	2048, 4096, 256, 384, 521 - 112, 128, 152, 192, 256	Asymmetric public key - PSP		KTS (SSH)	SigVer (SSH)
Root-CA	X.509 Certificate used to verify the validity of the Juniper Package CA	256, 384 - 128, 196	Asymmetric public key - PSP			Verify image
Package-CA	X.509 Certificate used to verify the validity the Juniper Image at software load and also at runtime for integrity.	256 - 128	Asymmetric public key - PSP			Verify image
MACsec CAK	Externally generated pre-shared key entered when MACsec static connectivity association key (CAK) security mode is enabled.	32 (hex) characters for 128-bit AES keys, 64 (hex) characters for 256-bit AES keys - 128, 256	Symmetric key - CSP			
MACsec CKN	Externally generated pre-shared key used to identify the CAK (64 characters)	64 characters - n/a	Identifier - PSP			
MACsec SAK	Security Association Key used to encrypt/decrypt traffic for a given session	128, 256 - 128, 256	Symmetric key - CSP	Key derivation (MACsec)	Key wrap (MACsec)	Enc/Dec (MACsec)
MACsec KEK	Key Encryption Key used to transmit SAK to other members of a MACsec connectivity association	128, 256 - 128, 256	Symmetric key - CSP	Key derivation (MACsec)		Key wrap (MACsec)
MACsec ICK	Integrity Check Key used to verify the integrity and authenticity of MPDUs.	128, 256 - 128, 256	Symmetric key - CSP	Key derivation (MACsec)		Integrity (MACsec)

Table 22: SSP Table 1

Name	Input - Output	Storage	Storage Duration	Zeroization	Related SSPs
HMAC DRBG V value		RAM:Plaintext	Until updated by HMAC_DRBG_Update()	Zeroize CLI command Reset	
HMAC DRBG Key value		RAM:Plaintext	Until updated by HMAC_DRBG_Update()	Zeroize CLI command Reset	
HMAC DRBG Entropy Input		RAM:Plaintext	Until HMAC_Instantiate_Update() or HMAC_DRBG_Reseed() complete	Zeroize CLI command Reset	
HMAC DRBG Seed		RAM:Plaintext	Until HMAC_Instantiate_Update() or HMAC_DRBG_Reseed() complete	Zeroize CLI command Reset	
SSH DH Shared Secret		RAM:Plaintext	Until SSH session termination	Zeroize CLI command Reset Explicit zeroize function	
SSH PHK	Entry via SSH Entry via console Output via SSH Output via console	RAM:Plaintext Flash:Plaintext	Until SSH session termination (RAM)	Zeroize CLI command	SSH PUB:Paired With
SSH PUB	Entry via SSH Entry via console Output via SSH Output via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	SSH PHK:Paired With
SSH DH PRV		RAM:Plaintext	Until SSH session termination	Reset Explicit zeroize function	SSH DH PUB:Paired With
SSH DH PUB	Output as part of KAS	RAM:Plaintext	Until SSH session termination	Reset Explicit zeroize function	SSH DH PRV:Paired With
SSH DH Pub (peer)	Entry as part of KAS	RAM:Plaintext	Until SSH session termination	Reset Explicit zeroize function	
SSH-SEKs		RAM:Plaintext	Until SSH session termination	Reset Explicit zeroize function	

Name	Input - Output	Storage	Storage Duration	Zeroization	Related SSPs
CO-PW	Manual CLI entry Entry via SSH Entry via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
Root-PW	Manual CLI entry Entry via SSH Entry via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
User-PW	Manual CLI entry Entry via SSH Entry via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
Auth-CO Pub	Entry via SSH Entry via console Output via SSH Output via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
Auth-User Pub	Entry via SSH Entry via console Output via SSH Output via console	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
Root-CA	Pre-loaded	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
Package-CA	Pre-loaded	RAM:Plaintext Flash:Plaintext		Zeroize CLI command	
MACsec CAK	Entry via SSH Entry via console	RAM:Plaintext Flash:Obfuscated		Zeroize CLI command	
MACsec CKN	Entry via SSH Entry via console	RAM:Plaintext Flash:Obfuscated		Zeroize CLI command	
MACsec SAK	MACsec Key Agreement Input MACsec Key Agreement Output	RAM:Plaintext		Zeroize CLI command Reset	
MACsec KEK		RAM:Plaintext		Zeroize CLI command Reset	

Name	Input - Output	Storage	Storage Duration	Zeroization	Related SSPs
MACsec ICK		RAM:Plaintext		Zeroize CLI command Reset	

Table 23: SSP Table 2

9.5 Transitions

The following transitions apply to algorithms used by this module:

SHA-1: The SHA-1 hash algorithm will be non-Approved for cryptographic protection purposes after December 31, 2030.

10 Self-Tests

On power up or reset, the module performs the pre-operational self-tests and the indicated conditional cryptographic algorithm self-tests described below. All KATs must be completed successfully prior to any other use of cryptography by the module. The CASTs for algorithms utilized in the pre-operational Firmware integrity check are performed prior to the Firmware integrity check.

10.1 Pre-Operational Self-Tests

Algorithm or Test	Test Properties	Test Method	Test Type	Indicator	Details
Firmware integrity check	ECDSA P-256 with SHA2-256	KAT	SW/FW Integrity	PASS/FAIL console output	ECDSA verify
Critical functions test	SHA2-256	KAT	Critical Function	PASS/FAIL console output	Checks that any file that is executed is registered in a manifest of executable files that comes with the firmware. Test verifies the integrity of the operational environment is being enforced by having the kernel attempt to run a specific executable file that does not contain a hash in the manifest file, verifying it cannot be executed.

Table 24: Pre-Operational Self-Tests

10.2 Conditional Self-Tests

Algorithm or Test	Test Properties	Test Method	Test Type	Indicator	Details	Conditions
Entropy Source (start-up)	n/a	APT, RCT	CAST	PASS/FAIL console output	Start-up	On-power up

Algorithm or Test	Test Properties	Test Method	Test Type	Indicator	Details	Conditions
Entropy Source (continuous)	n/a	APT, RCT	CAST	Console output / output of entropy source	Continuous	Data output from noise source
AES-CBC (A4210) Encrypt	Key size: 128, 192, 256	KAT	CAST	PASS/FAIL console output	Encrypt	On power-up
AES-CBC (A4210) Decrypt	Key size: 128, 192, 256	KAT	CAST	PASS/FAIL console output	Decrypt	On power-up
HMAC-SHA-1 (A4210)	Key size: 160	KAT	CAST	PASS/FAIL console output	MAC	On power-up
HMAC-SHA2-256 (A4210)	Key size: 256	KAT	CAST	PASS/FAIL console output	MAC	On power-up
HMAC-SHA2-384 (A4210)	Key size: 384	KAT	CAST	PASS/FAIL console output	MAC	On power-up
HMAC-SHA2-512 (A4210)	Key size: 512	KAT	CAST	PASS/FAIL console output	MAC	On power-up
RSA SigGen (FIPS186-4) (A4210)	RSA 2048 w/ SHA2-256, RSA 4096 w/ SHA2-256	KAT	CAST	PASS/FAIL console output	Sign	On power-up
RSA SigVer (FIPS186-4) (A4210)	RSA 2048 w/ SHA2-256, RSA 4096 w/ SHA2-256	KAT	CAST	PASS/FAIL console output	Verify	On power-up
ECDSA SigGen (FIPS186-4) (A4210)	P-256, P-384, P-521	KAT	CAST	PASS/FAIL console output	Sign	On power-up
ECDSA SigGen (FIPS186-4) (A6440)	P-256, P-384, P-521	KAT	CAST	PASS/FAIL console output	Sign	On power-up
ECDSA SigVer (FIPS186-4) (A4210)	P-256, P-384, P-521	KAT	CAST	PASS/FAIL console output	Verify	On power-up
ECDSA SigVer (FIPS186-4) (A6440)	P-256, P-384, P-521	KAT	CAST	PASS/FAIL console output	Verify	On power-up
KAS-ECC-SSC Sp800-56Ar3 (A4387)	P-256, P-384, P-521	KAT	CAST	PASS/FAIL console output	ECDH Computation	On power-up

Algorithm or Test	Test Properties	Test Method	Test Type	Indicator	Details	Conditions
KDF SSH (A4347)	SHA-1, SHA2- 256, SHA2- 384	KAT	CAST	PASS/FAIL console output	Key derivation Computation	On power-up
RSA KeyGen (FIPS186-4) (A4210)	n/a	PCT	PCT	Returned key/transit ion soft error state	Generatio n and Verificatio n of signature	On key generatio n
ECDSA KeyGen (FIPS186-4) (A4210)	n/a	PCT	PCT	Returned key/transit ion soft error state	Generatio n and Verificatio n of signature	On key generatio n
ECDSA KeyGen (FIPS186-4) (A6440)	n/a	PCT	PCT	Returned key/transit ion soft error state	Generatio n and Verificatio n of signature	On key generatio n
ECDSA SigVer (FIPS186-4) (A4211)	P-256	KAT	CAST	PASS/FAIL console output	Verify	On power-up
FW Load	ECDSA P-256 with SHA2-256	KAT	SW/FW Load	PASS/FAIL console output	Verificatio n of ECDSA signature on FW	On FW load
HMAC DRBG (A4417)	256, SHA2- 256	KAT	CAST	PASS/FAIL console output	Instantiat e, re-seed, and generate	On power-up
HMAC-SHA-1 (A4417)	Key size: 160	KAT	CAST	PASS/FAIL console output	MAC	On power-up
HMAC-SHA2-256 (A4417)	Key size: 256	KAT	CAST	PASS/FAIL console output	MAC	On power-up
SHA2-384 (A4417)	n/a	KAT	CAST	PASS/FAIL console output	Hash	On power-up
SHA2-512 (A3355)	n/a	KAT	CAST	PASS/FAIL console output	Hash	On power-up
HMAC-SHA2-256 (A4208)	Key size: 256	KAT	CAST	PASS/FAIL console output	MAC	On power-up
HMAC-SHA-1 (A4208)	Key size: 256	KAT	CAST	PASS/FAIL console output	MAC	On power-up
SHA2-512 (A4208)	n/a	KAT	CAST	PASS/FAIL console output	Hash	On power-up

Algorithm or Test	Test Properties	Test Method	Test Type	Indicator	Details	Conditions
KDF SP800-108 (A4416)	Key size: 128	KAT	CAST	PASS/FAIL console output	Derive	On power-up
AES-KW (A4416) Wrap	Key size: 128, 192, 256	KAT	CAST	PASS/FAIL console output	Wrap	On power-up
AES-KW (A4416) Unwrap	Key size: 128, 192, 256	KAT	CAST	PASS/FAIL console output	Unwrap	On power-up
AES-CMAC (A4416)	Key size: 128, 256	KAT	CAST	PASS/FAIL console output	MAC	On power-up
AES-GCM Encrypt (AES3969/AES4544/AES4545/AES4550/C 1869/C996)	128,256	KAT	CAST	Internal status: power-up continues or errors	Encrypt	On power-up
AES-GCM Decrypt (AES3969/AES4544/AES4545/AES4550/C 1869/C996)	128,256	KAT	CAST	Internal status: power-up continues or errors	Decrypt	On power-up
ECDSA SigVer (FIPS186-4) (A6401)	P-256	KAT	CAST	PASS/FAIL console output	Verify	On power-up
SHA2-512 (A3498)	n/a	KAT	CAST	PASS/FAIL console output	hash	On power-up
SHA2-512 (A3330)	n/a	KAT	CAST	PASS/FAIL console output	hash	On power-up
Manual SSP entry	n/a	Duplicate entry	Manual Entry	PASS/FAIL console output	Duplicate entry	On manual, direct entry of SSP

Table 25: Conditional Self-Tests

10.3 Periodic Self-Test Information

The module does not implement periodic self-testing.

Algorithm or Test	Test Method	Test Type	Period	Periodic Method
Firmware integrity check	KAT	SW/FW Integrity	On demand	Manually
Critical functions test	KAT	Critical Function	On demand	Manually

Table 26: Pre-Operational Periodic Information

Algorithm or Test	Test Method	Test Type	Period	Periodic Method
Entropy Source (start-up)	APT, RCT	CAST	On demand	Manually
Entropy Source (continuous)	APT, RCT	CAST	Continuous	Automatically
AES-CBC (A4210) Encrypt	KAT	CAST	On Demand	Manually
AES-CBC (A4210) Decrypt	KAT	CAST	On Demand	Manually
HMAC-SHA-1 (A4210)	KAT	CAST	On Demand	Manually
HMAC-SHA2-256 (A4210)	KAT	CAST	On Demand	Manually
HMAC-SHA2-384 (A4210)	KAT	CAST	On Demand	Manually
HMAC-SHA2-512 (A4210)	KAT	CAST	On Demand	Manually
RSA SigGen (FIPS186-4) (A4210)	KAT	CAST	On Demand	Manually
RSA SigVer (FIPS186-4) (A4210)	KAT	CAST	On Demand	Manually
ECDSA SigGen (FIPS186-4) (A4210)	KAT	CAST	On Demand	Manually
ECDSA SigGen (FIPS186-4) (A6440)	KAT	CAST	On Demand	Manually
ECDSA SigVer (FIPS186-4) (A4210)	KAT	CAST	On Demand	Manually
ECDSA SigVer (FIPS186-4) (A6440)	KAT	CAST	On Demand	Manually
KAS-ECC-SSC Sp800-56Ar3 (A4387)	KAT	CAST	On Demand	Manually
KDF SSH (A4347)	KAT	CAST	On Demand	Manually
RSA KeyGen (FIPS186-4) (A4210)	PCT	PCT	On trigger condition	Automatic
ECDSA KeyGen (FIPS186-4) (A4210)	PCT	PCT	On trigger condition	Automatic
ECDSA KeyGen (FIPS186-4) (A6440)	PCT	PCT	On trigger condition	Automatic
ECDSA SigVer (FIPS186-4) (A4211)	KAT	CAST	On Demand	Manually
FW Load	KAT	SW/FW Load	On FW load request	Automatic
HMAC DRBG (A4417)	KAT	CAST	On Demand	Manually
HMAC-SHA-1 (A4417)	KAT	CAST	On Demand	Manually
HMAC-SHA2-256 (A4417)	KAT	CAST	On Demand	Manually
SHA2-384 (A4417)	KAT	CAST	On Demand	Manually

Algorithm or Test	Test Method	Test Type	Period	Periodic Method
SHA2-512 (A3355)	KAT	CAST	On Demand	Manually
HMAC-SHA2-256 (A4208)	KAT	CAST	On Demand	Manually
HMAC-SHA-1 (A4208)	KAT	CAST	On Demand	Manually
SHA2-512 (A4208)	KAT	CAST	On Demand	Manually
KDF SP800-108 (A4416)	KAT	CAST	On Demand	Manually
AES-KW (A4416) Wrap	KAT	CAST	On Demand	Manually
AES-KW (A4416) Unwrap	KAT	CAST	On Demand	Manually
AES-CMAC (A4416)	KAT	CAST	On Demand	Manually
AES-GCM Encrypt (AES3969/AES4544/AES4545/AES4550/C1869/C996)	KAT	CAST	On Demand	Manually
AES-GCM Decrypt (AES3969/AES4544/AES4545/AES4550/C1869/C996)	KAT	CAST	On Demand	Manually
ECDSA SigVer (FIPS186-4) (A6401)	KAT	CAST	On demand	Manually
SHA2-512 (A3498)	KAT	CAST	On demand	Manually
SHA2-512 (A3330)	KAT	CAST	On demand	Manually
Manual SSP entry	Duplicate entry	Manual Entry	On condition trigger	Automatic

Table 27: Conditional Periodic Information

10.4 Error States

Name	Description	Conditions	Recovery Method	Indicator
Critical Failure State	The cryptographic module ceases to perform cryptographic operations, inhibits all data output, and provides status of the error via syslog messages and console status output	On any power-up self-test error	Power cycle	Console status indicator
Soft Error State	A non-critical self-test failure occurs, causing a failure of the triggering operation	PCT, firmware load test, continuous entropy health test failure	The module processes the error, and resumes normal operation	Console displays error

Table 28: Error States

The module enters error state upon failure of any self-tests, causing the kernel to ‘panic’ and all execution to halt. The only way to exit from this state is to reboot the module, which causes the self-tests to be repeated and pass successfully before the corresponding algorithms are usable.

10.5 Operator Initiation of Self-Tests

Self-tests that are performed at power-up are available on demand by power cycling the module.

11 Life-Cycle Assurance

11.1 Installation, Initialization, and Startup Procedures

The module must be correctly installed and configured to enter a FIPS compliant state and operate in the Approved mode. The required procedures are as follows:

1. Install the Junos OS firmware image - the procedure is detailed in section 11.2.1
2. Configure device for the Approved mode - the procedure is section 11.2.2.

To continue using the module in a FIPS compliant way, the Module Operation Rules in section 11.4.2 must be followed.

11.2 Administrator Guidance

11.2.1 Installing the Junos OS firmware image

1. Download the validated firmware image from <https://www.juniper.net/support/downloads/junos.html>. Log in to the Juniper Networks authentication system using the username (generally your e-mail address) and password supplied by Juniper Networks representatives. Select the validated firmware image. Download the firmware image to a local host or to an internal software distribution site.

The cryptographic module devices use the following firmware images

EX4400	jinstall-host-ex-4e-x86-64-22.3R2-S1.7-secure-signed.tgz
QFX5120	jinstall-host9-qfx-5e-ng-x86-64-22.3R2-S1.7-secure-signed.tgz
ACX5448	junos-vmhost-install-acx-x86-64-22.3R2-S1.7.tgz

2. Connect to the console port on the device from your management device, and log in to the Junos OS CLI.
3. Install the new package on the device (package may be a local file copied to the device, or a file on a remote server):

```
user@host> request system software add <package>
```
4. Reboot the device to load the installation:

```
user@host> request system reboot
```
5. After the reboot has completed, log in and use the show version command to verify that the new version of the software is successfully installed.

```
user@host> show version
```

11.2.2 Configure the device for the Approved mode

To configure the device for the Approved mode:

1. Zeroize the device to delete all CSPs before entering the Approved mode.

```
root@host# request system zeroize
```
2. After the device comes up, login using username “root” and password blank.
3. Configure root authentication with password at least 10 characters or more.

```
root@host# set system root-authentication plain-text-password
```
4. Load configuration onto device and commit new configuration.

NOTE: SSH key-exchange configuration must not include ‘dh-group14-sha1’. It is not approved for this module.
5. Configure crypto-officer and login with crypto-officer credentials.
6. Set the fips level to 1.

```
crypto-officer@host# set system fips chassis level 1
```



```
crypto-officer@host# set system fips level 1
```
7. Commit and reboot the device.

```
crypto-officer@host# commit
```



```
crypto-officer@host# run request system reboot
```

11.2.3 Zeroizing the System

CAUTION: Perform system zeroization with care. After the zeroization process is complete, no data is left on the device. The device is returned to the factory default state, equivalent to a fresh installation of the firmware, without any configured users or configuration files.

After zeroizing the system, the module is no longer in a FIPS compliant state. (Installation and configuration as per section 11.1 is required to enter the FIPS compliant state and enable the Approved mode of operation).

NOTE: The Crypto-Officer must retain control of the module while zeroization is in progress.

To zeroize the device:

1. Login to the device as Crypto Officer and from CLI, enter

```
crypto-officer@host# request system zeroize
```

warning: System will be rebooted and may not boot without configuration
Erase all data, including configuration and log files? [yes, no] (no)
2. To initiate the zeroization process, type yes at the prompt:

```
Erase all data, including configuration and log files? [yes, no] (no)
```



```
yes
```

11.3 Non-Administrator Guidance

No specific non-administrator guidance is required to operate the module.

11.4 Design and Rules

11.4.1 Module Design Rules

The module design implements the following security rules:

1. The module clears previous authentications on power cycle.
2. Power up self-tests do not require any operator action.
3. Data output is inhibited during key generation, self-tests, zeroization, and error states.
4. Status information does not contain CSPs or sensitive data that if misused could lead to a compromise of the module.
5. There are no restrictions on which SSPs are zeroized by the zeroization service.
6. The module does not support a maintenance interface or role.
7. The module does not output intermediate key values.
8. The module requires two independent internal actions to be performed prior to outputting plaintext CSPs.
9. If the module loses power and then it is restored, then a new key shall be established for use with the AES GCM encryption/decryption processes.

11.4.2 Module Operation Rules

The following are requirements for compliant usage of the module:

1. The cryptographic officer must retain control of the module while zeroization is in process.
2. The cryptographic officer shall verify that the firmware image to be loaded on the module is a FIPS validated image.
3. Before pushing the factory reset button on the device, the cryptographic officer shall perform the zeroize command as described in section 11.2.3.
4. The password minimum-length must be configured to be at least 10.
5. Virtual Chassis features must not be configured.
6. Dynamic CAK mode shall not be configured for MACsec.
7. Only the AES-GCM cipher suites shall be configured for MACsec.
8. The module shall only be used with CMVP-validated modules when supporting the MACsec protocol for providing Peer, Authenticator functionality.
9. The link between the Peer and Authenticator, used in the MACsec communication, shall be secure to prevent the possibility for an attacker to introduce foreign equipment into the local area network.
10. The module shall not be configured to use a radius server and the radius server capability shall be disabled.
11. SSH key-exchange must not be configured to include 'dh-group14-sha1'.

11.5 Maintenance Requirements

No special maintenance requirements are required.

11.6 End of Life

When disposing of the cryptographic module, the cryptographic officer shall perform the zeroize command as described in Section 11.2.3.

12 Mitigation of Other Attacks

The module does not implement mechanisms to mitigate other attacks beyond what is described in this security policy.