Embedded Systems Programming Lecture 7

Verónica Gaspes www2.hh.se/staff/vero



CENTER FOR RESEARCH ON EMBEDDED SYSTEMS
School of Information Science, Computer and Electrical Engineering

Real Time?

In what ways can a program be related to time in the environment (the *real time*)?

Time



Real Time could be . . .



Real Time could be . . .

An external process to sample

Reading a real-time clock is like sampling any other external process value!

Real Time could be ...

An external process to sample

Time

Reading a real-time clock is like sampling any other external process value!

An external process to react to

A program can let certain points in time denote events (e.g. by means of interrupts of a clock) to which it has to react in some way or another.

An external process to be constrained by

A program might be required to hurry enough so that some externally visible action can be performed before a certain point in time (comming later on in the course)

Time

Real Time could be . . .

An external process to sample

Reading a real-time clock is like sampling any other external process value!

An external process to react to

A program can let certain points in time denote events (e.g. by means of interrupts of a clock) to which it has to react in some way or another.

An external process to be constrained by

A program might be required to hurry enough so that some externally visible action can be performed before a certain point in time (comming later on in the course)

Requires a hardware clock that can be read like a regular external device.

- Units? Seconds? Milliseconds? Cpu cycles?
- Since when? Program start? System boot? Jan 1 1970
- Real time? Time that stops when other threads are running?
 Time that stops when CPU sleeps? Time that cannot be set
 - Time that stops when CPU sleeps? Time that cannot be set and always increases?

Requires a hardware clock that can be read like a regular external device.

- Units? Seconds? Milliseconds? Cpu cycles?
- Since when? Program start? System boot? Jan 1 1970?
- Real time? Time that stops when other threads are running?
 Time that stops when CPU sleeps? Time that cannot be set and always increases?

Requires a hardware clock that can be read like a regular external device.

- Units? Seconds? Milliseconds? Cpu cycles?
- Since when? Program start? System boot? Jan 1 1970?
- Real time? Time that stops when other threads are running?
 Time that stops when CPU sleeps? Time that cannot be set and always increases?

device.

Requires a hardware clock that can be read like a regular external

- Units? Seconds? Milliseconds? Cpu cycles?
- Since when? Program start? System boot? Jan 1 1970?
- Real time? Time that stops when other threads are running?
 Time that stops when CPU sleeps? Time that cannot be set and always increases?

Requires a hardware clock that can be read like a regular external device.

- Units? Seconds? Milliseconds? Cpu cycles?
- Since when? Program start? System boot? Jan 1 1970?
- Real time? Time that stops when other threads are running?
 Time that stops when CPU sleeps? Time that cannot be set and always increases?

What about the 16-bit counter (accessible through register TCNT1)?

Units

CPU clock (8Mhz) divided by a programmable prescaling value (1, 8, 64, 256, 1024).

Since when

System reset, timer reset or timer overflow (whichever was last).

Real time

Shows real time although it can be stopped

What about the 16-bit counter (accessible through register TCNT1)?

Units

CPU clock (8Mhz) divided by a programmable prescaling value (1, 8, 64, 256, 1024).

Since when

System reset, timer reset or timer overflow (whichever was last).

Real time

Shows real time although it can be stopped.

Real-time events

Timer/Counter1 on the AVR

Time

What about the 16-bit counter (accessible through register TCNT1)?

Units

CPU clock (8Mhz) divided by a programmable prescaling value (1, 8, 64, 256, 1024).

Since when

System reset, timer reset or timer overflow (whichever was last).

Real time

Shows real time although it can be stopped

Real-time events

Timer/Counter1 on the AVR

Time

What about the 16-bit counter (accessible through register TCNT1)?

Units

CPU clock (8Mhz) divided by a programmable prescaling value (1, 8, 64, 256, 1024).

Since when

System reset, timer reset or timer overflow (whichever was last).

Real time

Shows real time although it can be stopped.

What about the 16-bit counter (accessible through register TCNT1)?

Units

CPU clock (8Mhz) divided by a programmable prescaling value (1, 8, 64, 256, 1024).

Since when

System reset, timer reset or timer overflow (whichever was last).

Real time

Shows real time although it can be stopped.

Timestamps

In general clock readings become meaningful only when they are associated with other events: we are interested to sample to know when an event has occurred.

Example

The clock showed 11:25 when the teacher left

In program terms, associating a clock reading with some other event means doing the reading in close proximity to the event



Timestamps

In general clock readings become meaningful only when they are associated with other events: we are interested to sample to know when an event has occurred.

Example

The clock showed 11:25 when the teacher left.

n program terms, associating a clock reading with some other event means doing the reading in close proximity to the event



Timestamps

In general clock readings become meaningful only when they are associated with other events: we are interested to sample to know when an event has occurred.

Example

The clock showed 11:25 when the teacher left.

In program terms, associating a clock reading with some other event means doing the reading in close proximity to the event detection.



The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?

- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message sage.
- All these are internal to a program under execution and have no meaning to an external observer!

The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?

- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message?

The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?

- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message?

The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?

- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message?

The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?

- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message?

The difference between two timestamps is a value that is independent of the nominal clock values — it is a time span (characterized only by the clock resolution).

What could each timestamp mean?


- The time of some arbitrary program instruction?
- The beginning or end of a function call?
- The time of sending or receiving an asynchronous message?

In a scheduled system

What looks like . . .



might very well be ...




Close proximity is not the same as subsequent statements!

In a scheduled system

What looks like . . .



might very well be ...



Close proximity is not the same as subsequent statements!

What we really want is to associate timestamps with the externally observable events that *drive* a system!

Ideal

Read the clock inside the interrupt handler that detects the associated event

- Other interrupts are disabled while the CPU runs an interrupt handler, hence no scheduling of threads might interfere!
- There is a tight upper bound on the timestamp error, which can be calculated from CPU data and speed!

Example

What we really want is to associate timestamps with the externally observable events that *drive* a system!

Idea!

Read the clock inside the interrupt handler that detects the associated event

- Other interrupts are disabled while the CPU runs an interrupt handler, hence no scheduling of threads might interfere!
- There is a tight upper bound on the timestamp error, which can be calculated from CPU data and speed!

Example

What we really want is to associate timestamps with the externally observable events that *drive* a system!

Idea!

Read the clock inside the interrupt handler that detects the associated event

- Other interrupts are disabled while the CPU runs an interrupt handler, hence no scheduling of threads might interfere!
- There is a tight upper bound on the timestamp error, which can be calculated from CPU data and speed!

Example

What we really want is to associate timestamps with the externally observable events that *drive* a system!

Idea!

Read the clock inside the interrupt handler that detects the associated event

- Other interrupts are disabled while the CPU runs an interrupt handler, hence no scheduling of threads might interfere!
- There is a tight upper bound on the timestamp error, which can be calculated from CPU data and speed!

Example

What we really want is to associate timestamps with the externally observable events that *drive* a system!

Idea!

Read the clock inside the interrupt handler that detects the associated event


- Other interrupts are disabled while the CPU runs an interrupt handler, hence no scheduling of threads might interfere!
- There is a tight upper bound on the timestamp error, which can be calculated from CPU data and speed!

Example

Example

Calculate the speed

For a rotating wheel, measuring the time between two subsequent detections of a passing tap.




```
typedef struct{
   Object super;
   int previous;
} Speedo;
...
Speedo speedo:
Other client;
INTERRUPT(SIG_XX,
```

ASYNC(&speedo, detect, TCNT1)

Example

Calculate the speed

For a rotating wheel, measuring the time between two subsequent detections of a passing tap.



Calculate the speed

For a rotating wheel, measuring the time between two subsequent detections of a passing tap.

Calculate the speed

For a rotating wheel, measuring the time between two subsequent detections of a passing tap.


DIFF will have ot take care of timer overflows!

We know how to sample the real-time clock to obtain externally meaningful information about the passage of time.

Now suppose we want to take some action when a certain amount of time has passed.

Example

The wheel is an engine crankshaft and we have to emit ignition signals to each cylinder




We would need a way to postpone program execution until certain points in the future. We know how to sample the real-time clock to obtain externally meaningful information about the passage of time.

Now suppose we want to take some action when a certain amount of time has passed.

Example

The wheel is an engine crankshaft and we have to emit ignition signals to each cylinder



We would need a way to postpone program execution until certain points in the future.

Very poor man's solution

Consume a fixed amount of CPU cycles in a (silly) loop

```
int i;
for(i=0;i<N;i++); // wait
do_future_action();</pre>
```

- Determine N by testing!
- N will be highly platform dependent!
- A lot of CPU cycles will simply be wasted!

Very poor man's solution

Consume a fixed amount of CPU cycles in a (silly) loop

```
int i;
for(i=0;i<N;i++); // wait
do_future_action();</pre>
```

- Oetermine N by testing!
- 2 N will be highly platform dependent!
- A lot of CPU cycles will simply be wasted!

Very poor man's solution

Consume a fixed amount of CPU cycles in a (silly) loop

```
int i;
for(i=0;i<N;i++); // wait
do_future_action();</pre>
```

- Determine N by testing!
- ② N will be highly platform dependent!
- A lot of CPU cycles will simply be wasted!

Very poor man's solution

Consume a fixed amount of CPU cycles in a (silly) loop

```
int i;
for(i=0;i<N;i++); // wait
do_future_action();</pre>
```

- Determine N by testing!
- N will be highly platform dependent!
- A lot of CPU cycles will simply be wasted!

Very poor man's solution

Consume a fixed amount of CPU cycles in a (silly) loop

```
int i;
for(i=0;i<N;i++); // wait
do_future_action();</pre>
```

- Oetermine N by testing!
- N will be highly platform dependent!
- A lot of CPU cycles will simply be wasted!

The nearly as poor man's solution

Configure a timer/counter with a known clock speed, and busy-wait for a suitable time increment

```
unsigned int i = TCNT1+N;
while(TCNT1<i); // wait
do_future_action();</pre>
```

Problems

Determine N by calculation so platform dependency disapears
 Still a lot of wasted CPUI

The nearly as poor man's solution

Configure a timer/counter with a known clock speed, and busy-wait for a suitable time increment

```
unsigned int i = TCNT1+N;
while(TCNT1<i); // wait
do_future_action();</pre>
```

- Determine N by calculation so platform dependency disapears
- Still a lot of wasted CPU!

The nearly as poor man's solution

Configure a timer/counter with a known clock speed, and busy-wait for a suitable time increment

```
unsigned int i = TCNT1+N;
while(TCNT1<i); // wait
do_future_action();</pre>
```

- Determine N by calculation so platform dependency disapears.
- Still a lot of wasted CPU!

The nearly as poor man's solution

Configure a timer/counter with a known clock speed, and busy-wait for a suitable time increment

```
unsigned int i = TCNT1+N;
while(TCNT1<i); // wait
do_future_action();</pre>
```

- Determine N by calculation so platform dependency disapears.
- Still a lot of wasted CPU!

The standard solution

Use an Operating system call that *fakes* the timer increment busy-wait loop while making better use of the CPU resources

```
delay(N);  // wait (blocking OS call)
do_future_action();
```

- No platform dependency!
- No wasted CPU cycles (at the expense of complex OS internals)

Still a problem ...

The standard solution

Use an Operating system call that *fakes* the timer increment busy-wait loop while making better use of the CPU resources

```
delay(N);  // wait (blocking OS call)
do_future_action();
```

- No platform dependency!
- No wasted CPU cycles (at the expense of complex OS internals)

Still a problem ...

The standard solution

Use an Operating system call that *fakes* the timer increment busy-wait loop while making better use of the CPU resources

```
delay(N);  // wait (blocking OS call)
do_future_action();
```

- No platform dependency!
- No wasted CPU cycles (at the expense of complex OS internals)

Still a problem ...

The standard solution

Use an Operating system call that *fakes* the timer increment busy-wait loop while making better use of the CPU resources

```
delay(N);  // wait (blocking OS call)
do_future_action();
```

- No platform dependency!
- No wasted CPU cycles (at the expense of complex OS internals)

Still a problem ...

The standard solution

Use an Operating system call that *fakes* the timer increment busy-wait loop while making better use of the CPU resources


```
delay(N);  // wait (blocking OS call)
do_future_action();
```

- No platform dependency!
- No wasted CPU cycles (at the expense of complex OS internals)


Still a problem ...

In a scheduled system

What looks like . . .




might very well be ...




Had we known the scheduler's choice, a smaler N had been used

In a scheduled system

What looks like ...



might very well be . . .



Had we known the scheduler's choice, a smaler N had been used!

relative time:

The problem is that these delay services are always specified using

- The constructed real-time event will occur at a time obtained by adding the delay parameter N to now.
- But now is not a very meaningful time reference in a scheduled system, as it is not related to any externally observable signals.

Other common OS services share this problem: sleep, usleep and nanosleep.

The problem is that these delay services are always specified using relative time:

- The constructed real-time event will occur at a time obtained by adding the delay parameter N to now.
- But now is not a very meaningful time reference in a

Relative delays

The problem is that these delay services are always specified using relative time:

- The constructed real-time event will occur at a time obtained by adding the delay parameter N to *now*.
- But now is not a very meaningful time reference in a scheduled system, as it is not related to any externally observable signals.

Other common OS services share this problem: sleep, usleep and nanosleep.

Relative delays

The problem is that these delay services are always specified using relative time:

- The constructed real-time event will occur at a time obtained by adding the delay parameter N to *now*.
- But now is not a very meaningful time reference in a scheduled system, as it is not related to any externally observable signals.

Other common OS services share this problem: sleep, usleep and nanosleep.

Relative delays

The problem is that these delay services are always specified using relative time:

- The constructed real-time event will occur at a time obtained by adding the delay parameter N to *now*.
- But now is not a very meaningful time reference in a scheduled system, as it is not related to any externally observable signals.

Other common OS services share this problem: sleep, usleep and nanosleep.

Even if other threads were not to interfere, using delay services as a means of specifying future points in time has another fundamental drawback.

Example

Consider a task running a CPU-heavy function do_work() every 100 millisecods. Using delay(), the naive implementation would be:

```
while(1){
  do_work();
  delay(100)
```


Yet another problem

Even if other threads were not to interfere, using delay services as a means of specifying future points in time has another fundamental drawback.

Example

Consider a task running a CPU-heavy function do_work() every 100 millisecods. Using delay(), the naive implementation would be:


```
while(1){
   do_work();
   delay(100);
}
```



X is the time take to do_work

With relative delays, each turn in the loop will take at least 100+X milliseconds.


A drift of X milliseconds will accumulate every turn



X is the time take to do_work

With relative delays, each turn in the loop will take at least 100+X milliseconds.


A drift of X milliseconds will accumulate every turn!




X is the time take to do_work

With relative delays, each turn in the loop will take at least 100+X milliseconds.

A drift of X milliseconds will accumulate every turn!



With other threads in the system, the already bad scenario gets worse!



With other threads in the system, the already bad scenario gets worse!

That means that even if we knew X, we wouldn't be able to compensate the delay time in any predictable manner!


What we need is a stable time reference to use as a basis whenever we specify a relative time (instead of now).

Baselines

We introduce the baseline of a message to mean the earliest time a message is allowed to start.

Time stamps of interrupts

The baseline of an event is its timestamp




What we need is a stable time reference to use as a basis whenever we specify a relative time (instead of now).

Baselines

We introduce the baseline of a message to mean the earliest time a message is allowed to start.

Time stamps of interrupts!

The baseline of an event is its timestamp




What we need is a stable time reference to use as a basis whenever we specify a relative time (instead of now).

Baselines

We introduce the baseline of a message to mean the earliest time a message is allowed to start.

Time stamps of interrupts!


The baseline of an event is its timestamp:




SYNC

Calling methods with SYNC doesn't change the baseline (the call inherits the baseline)

Baseline: start after




same baseline: start after




ASYNC

By default ASYNC method calls will inherit the baseline




For ASYNC we may also consider adding a baseline offset N!



Periodic tasks


To create a cyclic reaction, simply call **self** with the same method and a new baseline:



SEC is a convenient macro that makes the call independent of current timer resolution.

Periodic tasks

To create a cyclic reaction, simply call **self** with the same method and a new baseline:



SEC is a convenient macro that makes the call independent of current timer resolution.

Implementing AFTER

- Let the baseline be stored in every message (as part of the
- AFTER is the same as ASYNC, but

Implementing AFTER

- Let the baseline be stored in every message (as part of the Msg structure)
- 2 AFTER is the same as ASYNC, but
 - New baseline is MAX(now. offset+current->baseline)
 - If baseline > now , put message in a timerQ instead of readvQ
 - Set up a timer to generate an interrupt after earliest baseline
 - At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt

- Let the baseline be stored in every message (as part of the Msg structure)
- AFTER is the same as ASYNC, but

Time

- New baseline is
- If baseline > now , put message in a timerQ instead of
- Set up a timer to generate an interrupt after earliest baseline
- At each timer interrupt, move first timerQ message to readyQ

Implementing AFTER

- Let the baseline be stored in every message (as part of the Msg structure)
- AFTER is the same as ASYNC, but

Time

- New baseline is MAX(now, offset+current->baseline)
- If baseline > now , put message in a timerQ instead of readyQ
- Set up a timer to generate an interrupt after earliest baseline
- At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt

piementing AFTER

- Let the baseline be stored in every message (as part of the Msg structure)
- AFTER is the same as ASYNC, but
 - New baseline is MAX(now, offset+current->baseline)
 - If baseline > now , put message in a timerQ instead of readyQ
 - Set up a timer to generate an interrupt after earliest baseline
 - At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt

Implementing AFTER

- Let the baseline be stored in every message (as part of the Msg structure)
- 2 AFTER is the same as ASYNC, but
 - New baseline is MAX(now, offset+current->baseline)
 - If baseline > now , put message in a timerQ instead of readyQ
 - Set up a timer to generate an interrupt after earliest baseline
 - At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt

Implementing AFTER

- Let the baseline be stored in every message (as part of the Msg structure)
- AFTER is the same as ASYNC. but

Time

- New baseline is MAX(now, offset+current->baseline)
- If baseline > now , put message in a timerQ instead of readyQ
- Set up a timer to generate an interrupt after earliest baseline
- At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt

• Let the becaling he stored in every massage (as part of the

- Let the baseline be stored in every message (as part of the Msg structure)
- AFTER is the same as ASYNC, but
 - New baseline is MAX(now, offset+current->baseline)
 - If baseline > now , put message in a timerQ instead of readyQ
 - Set up a timer to generate an interrupt after earliest baseline
 - At each timer interrupt, move first timerQ message to readyQ and configure a new timer interrupt