# Embedded Systems Programming Lecture 5

Verónica Gaspes www2.hh.se/staff/vero



CENTER FOR RESEARCH ON EMBEDDED SYSTEMS
School of Information Science, Computer and Electrical Engineering

## What we are looking at

## struct Params params;

```
void controller_main() {
  int dist, signal;
  while(1){
    dist = sonar_read();
    control(dist,
           &signal,
           &params);
    servo_write(signal);
```

```
void decoder main() {
   struct Packet packet;
   while(1){
      radio_read(&packet);
      decode(&packet,&params);
```

## What we are looking at

#### struct Params params;

```
void controller_main() {
  int dist, signal;
  while(1){
    dist = sonar_read();
    control(dist,
           &signal,
           &params);
    servo_write(signal);
```

```
void decoder main() {
   struct Packet packet;
   while(1){
      radio_read(&packet);
      decode(&packet,&params);
```

We provide means for these two mains to execute concurrently! As if we had 2 CPUs!

```
main(){
  spawn(decoder_main);
  controller_main();
```

```
main(){
  spawn(decoder_main);
  controller_main();
```

Notice that the function spawn takes a function as an argument!

```
main(){
    spawn(decoder_main);
    controller_main();
}
```

Notice that the function spawn takes a *function* as an argument!

whe should also provide a way of interleaving fragments of the threads.

The role of spawn is to provide one extra **Program Counter** and **Stack Pointer** 

We introduced a way of yielding execution so that another thread can take over. Let's see how this function might be invoked.

```
main(){
    spawn(decoder_main);
    controller_main();
}
```

Notice that the function spawn takes a *function* as an argument!

We should also provide a way of interleaving fragments of the threads.

The role of spawn is to provide one extra **Program Counter** and **Stack Pointer** 

We introduced a way of yielding execution so that another thread can take over. Let's see how this function might be invoked.

```
main(){
    spawn(decoder_main);
    controller_main();
}
```

Notice that the function spawn takes a *function* as an argument!

The role of spawn is to provide one extra **Program Counter** and **Stack Pointer** 

We should also provide a way of interleaving fragments of the threads.

We introduced a way of yielding execution so that another thread can take over. Let's see how this function might be invoked.

#### Explicitly

ld a, r1
ld b, r2
add r, r2
st r2, c
jsr yield

ld c, r0
cmp #37, r0
ble label34

. . .

yield:

sub #2, sp

mov #0 r0

rts

## Explicitly

```
ld a, r1
ld b, r2
add r, r2
st r2, c
jsr yield
ld c, r0
cmp #37, r0
```

ble label34

```
yield:
sub #2, sp
...
mov #0, r0
rts
```

#### **Implicitly**

ld a, r1
ld b, r2
add r, r2
st r2, c

← Interrupt on pin 3!

ld c, r0
cmp #37, r0
ble label34

. . .

push r0-r2 jsr yield pop r0-r2

sub #2, sp
...
mov #0, r0

#### Implicitly

ld a, r1
ld b, r2
add r, r2
st r2, c

 $\leftarrow$  Interrupt on pin 3!

ld c, r0 cmp #37, r0 ble label34

. . .

push r0-r2 jsr yield pop r0-r2

sub #2, sp ... mov #0, r0

```
Implicitly
```

```
ld a, r1
ld b, r2
add r, r2
st r2, c
```

```
\longleftarrow Interrupt on pin 3!
```

```
ld c, r0
cmp #37, r0
ble label34
```

. . .

```
vector_3:
   push r0-r2
   jsr yield
   pop r0-r2
   rti
```

```
sub #2, sp
...
mov #0, r0
```

#### Implicitly

```
ld a, r1
ld b, r2
add r, r2
st r2, c
```

 $\leftarrow$  Interrupt on pin 3!

```
ld c, r0
cmp #37, r0
ble label34
```

. . .

```
vector_3:
   push r0-r2
   jsr yield
   pop r0-r2
   rti
```

```
yield:
sub #2, sp
...
mov #0, r0
rts
```

## Installing interrupt handlers

```
#include<avr/interrupt.h>
...
ISR(interrupt_name){
...
// code as in a function body!
...
}
```

```
Preventing interrupts in avr-gcc cli();
// ... code that must not be interrupted ... sei();
```

## Installing interrupt handlers

```
#include<avr/interrupt.h>
...
ISR(interrupt_name){
...
// code as in a function body!
...
}
```

#### Preventing interrupts in avr-gcc

```
cli();
// ... code that must not be interrupted ...
sei();
```

# Preventing interrupts

Why should we consider disabling interrupts? What parts of the program should be protected?

## The critical section problem

What will happen if the params struct is read (by the controller) at the same time as it is written (by the decoder)?

## The critical section problem

What will happen if the params struct is read (by the controller) at the same time as it is written (by the decoder)?

I.e., what if the scheduler happens to insert some decoder instructions while some, but not all, of the controller's reads have been done?

## The critical section problem

What will happen if the params struct is read (by the controller) at the same time as it is written (by the decoder)?

I.e., what if the scheduler happens to insert some decoder instructions while some, but not all, of the controller's reads have been done?

This problem is central to concurrent programming where there is any ammount of sharing!

## Our embedded system

## struct Params p;

```
while(1){
    ...
    p.minDistance = e1;
    p.maxSpeed = e2;
}
```

```
while(1){
   local_minD = p.minDistance;
   local_maxS = p.maxSpeed;
   ...
}
```

```
Possible interleaving
p.minDistance = 1;
p.maxSpeed = 1;
local_minD = 1;
p.minDistance = 200;
p.maxSpeed = 150;
local_maxS = 150
```

## Our embedded system

## struct Params p;

```
while(1){
    ...
    p.minDistance = e1;
    p.maxSpeed = e2;
}

while(1){
    local_minD = p.minDistance;
    local_maxS = p.maxSpeed;
    ...
}
```

#### Possible interleaving

```
p.minDistance = 1;
p.maxSpeed = 1;
p.minDistance = 200;
p.maxSpeed = 150;
```

```
local_minD = 1;
```

```
local_maxS = 150
```

#### The classical solution

Apply an access protocol to the critical sections that ensures mutual exclusion

#### The classical solution

Apply an access protocol to the critical sections that ensures mutual exclusion

Require that all parties follow the protocol

#### The classical solution

Apply an access protocol to the critical sections that ensures mutual exclusion

Require that all parties follow the protocol

Access protocols are realized by means of a shared datastructure known as a mutex or a lock.

#### Mutual exclusion

```
struct Params p;
mutex m;
```

```
while(1){
    ...
    lock (&m);
    p.minDistance = e1;
    p.maxSpeed = e2;
    unlock (&m);
}

while(1){
    lock (&m);
    local_minD = p.minDistance;
    local_maxS = p.maxSpeed;
    unlock (&m);
    ...
}
```

The datatype mutex and the operations lock and unlock are defined in the kernel: each mutex has a queue of threads that are not in the ready queue. The operations move threads to and from the ready queue!

- We know how to read and write to I/O device registers
- We know how to run several computations in parallel by
- We know how to protect critical sections by means of a mutex

- We know how to read and write to I/O device registers
- We know how to run several computations in parallel by
- We know how to protect critical sections by means of a mutex

- We know how to read and write to I/O device registers
- We know how to run several computations in parallel by time-slicing the CPU
- We know how to protect critical sections by means of a mutex

- We know how to read and write to I/O device registers
- We know how to run several computations in parallel by time-slicing the CPU
- We know how to protect critical sections by means of a mutex

- We know how to read and write to I/O device registers
- We know how to run several computations in parallel by time-slicing the CPU
- We know how to protect critical sections by means of a mutex

But . . .

```
void controller_main() {
  int dist, signal;
  while(1){
    dist = sonar_read();
    control(dist,
             &signal,
             &params);
    servo_write(signal);
```

```
void decoder_main() {
   struct Packet packet;
   while(1) {
      radio_read(&packet);
      decode(&packet,&params);
   }
}
```

```
\longleftarrow \mathsf{Time}\;\mathsf{slicing} \longrightarrow
```

Each thread gets half of the CPU cycles, irrespective of whether it is waiting or computing!


```
void controller_main() {
  int dist, signal;
  while(1){
    dist = sonar_read();
    control(dist,
             &signal,
             &params);
    servo_write(signal);
```

```
void decoder_main() {
   struct Packet packet;
   while(1) {
      radio_read(&packet);
      decode(&packet,&params);
   }
}
```

 $\longleftarrow$  Time slicing  $\longrightarrow$ 


Each thread gets half of the CPU cycles, irrespective of whether it is waiting or computing!

# Consequence 1




Say each thread gets **T**ms for execution, both waiting and computing!

## Consequence 1



Say that an event that **A** is waiting for occurs now . . .


# Consequence 1



...it will not be noticed until now!

# Consequence 1

With N threads in the system, each getting Tms for execution, a status change might have to wait up to  $T^*(N-1)$ ms to be noticed!



Busy waiting makes waiting indistinguishable from computing. Thread A cannot keep up with event rate!

#### Minus . . .

### Minus . . .

- Not a satisfactory technique for input synchronization if the system must meet real-time constraints!

#### Minus . . .


- Not a satisfactory technique for input synchronization if the system must meet real-time constraints!
- 2 Not a satisfactory technique for a system that is battery driven: 100% CPU cycle usage (100% power usage!).


#### Minus . . .

- Not a satisfactory technique for input synchronization if the system must meet real-time constraints!
- 2 Not a satisfactory technique for a system that is battery driven: 100% CPU cycle usage (100% power usage!).

### Could we do otherwise?

An input synchronization technique that does not require the receiver of data to actively ask whether data has arrived.





## You are expecting delivery of your latest web-shop purchase

You are expecting delivery of your latest web-shop purchase

## Busy waiting

Go to the post-office again and again to check if the delivery has arrived.

Reacting to an interrupt Receive a note in your mailbox that the goods can be picked up.

The CPU reacts to an interrupt signal by executing a designated ISR (interrupt service routine)

You are expecting delivery of your latest web-shop purchase

## Busy waiting

Go to the post-office again and again to check if the delivery has arrived.

## Reacting to an interrupt

Receive a note in your mailbox that the goods can be picked up.

The CPU reacts to an interrupt signal by executing a designated ISR (interrupt service routine)

You are expecting delivery of your latest web-shop purchase

## Busy waiting

Go to the post-office again and again to check if the delivery has arrived.

## Reacting to an interrupt

Receive a note in your mailbox that the goods can be picked up.

The CPU reacts to an interrupt signal by executing a designated ISR (interrupt service routine)

You are expecting delivery of your latest web-shop purchase

## Busy waiting

Go to the post-office again and again to check if the delivery has arrived.

## Reacting to an interrupt

Receive a note in your mailbox that the goods can be picked up.

The CPU reacts to an interrupt signal by executing a designated ISR (interrupt service routine)

## Busy waiting

We defined functions like sonar read that can be called in the program. The CPU decides when to call the function:

```
while(1){
   sonar_read();
   control();
```

## Busy waiting

We defined functions like sonar\_read that can be called in the program. The CPU decides when to call the function:

```
while(1){
    sonar_read();
    control();
}
```

Input detection = the exit from the busy waiting fragment (a function return)

## Busy waiting

We defined functions like sonar read that can be called in the program. The CPU decides when to call the function:

```
while(1){
   sonar_read();
   control();
```

Input detection = the exit from the busy waiting fragment (a function return)

## Reacting

We define ISRs. These are not called from the program, but the code is executed when an interrupt occurs:

```
ISR(SIG_SONAR) {
  control();
```

## Busy waiting

We defined functions like sonar\_read that can be called in the program. The CPU decides when to call the function:

```
while(1){
    sonar_read();
    control();
}
```

Input detection = the exit from the busy waiting fragment (a function return)

## Reacting

We define ISRs. These are not called from the program, but the code is executed when an interrupt occurs:

```
ISR(SIG_SONAR){
  control();
}
```

Input detection = invocation of the ISR (as if the hardware did a function call)

## CPU centric

One thread of control that runss from start to stop (or forever) reading and writing data as it goes.

### Reacting CPU

A set of code fragments that constitute the reactions to recognized events.

The main part of the course from now on will focus on the reactive view.

### CPU centric

One thread of control that runs from start to stop (or forever) reading and writing data as it goes.

## CPU centric

One thread of control that runs from start to stop (or forever) reading and writing data as it goes.

## Reacting CPU

A set of code fragments that constitute the reactions to recognized events.

The main part of the course from now on will focus on the reactive view.

## CPU centric


One thread of control that runs from start to stop (or forever) reading and writing data as it goes.

## Reacting CPU


A set of code fragments that constitute the reactions to recognized events.

The main part of the course from now on will focus on the reactive view.

## The reactive embedded system



## The reactive embedded system



## Boxes

Represent software or hardware reactive objects that:

- Maintain an internal state (variables, registers, etc)
- Provide a set of methods as reactions to external events (ISRs, etc)
- Simply rest between reactions!

#### Arrows

Represent event or signal or message flow between objects that can be either

- synchronous
- asvnchronous

# Reactive Objects

### Boxes

Represent software or hardware reactive objects that:

- Maintain an internal state (variables, registers, etc)
- Provide a set of methods as reactions to external events.
- Simply rest between reactions!

# Reactive Objects

### Boxes

Represent software or hardware reactive objects that:

- Maintain an internal state (variables, registers, etc)
- Provide a set of methods as reactions to external events (ISRs, etc)
- Simply rest between reactions!

#### Arrows

Represent event or signal or message flow between objects that can be either

• synchronous

# Reactive Objects

### Boxes

Represent software or hardware reactive objects that:

- Maintain an internal state (variables, registers, etc)
- Provide a set of methods as reactions to external events (ISRs, etc)
- Simply rest between reactions!

### Arrows

Represent event or signal or message flow between objects that can be either

- asynchronous
- synchronous

## Hardware devices are reactive objects

A black box that does nothing unless stimulated by external events.

## Hardware devices are reactive objects

A black box that does nothing unless stimulated by external events.

## Serial port - state


Internal registers

#### Serial port - stimul

- Signal change
- Bit pattern received
- Clock pulse

## Serial port - emissions

- Signal change
- Interrupt signal



## Hardware devices are reactive objects

A black box that does nothing unless stimulated by external events.

## Serial port - state


Internal registers

## Serial port - stimuli

- Signal change
  - Bit pattern received
  - Clock pulse

## Serial port - emissions

- Signal change
- Interrupt signal



## Hardware devices are reactive objects

A black box that does nothing unless stimulated by external events.

### Serial port - state


Internal registers

## Serial port - stimuli

- Signal change
  - Bit pattern received
  - Clock pulse

## Serial port - emissions

- Signal change
- Interrupt signal



# Software objects

We would like to regard software objects as reactive objects . . .

```
The Counter example

class Counter{
  int x;
  Counter(){x=0;}
  void inc(){x++;}
  int read(){return x;}
  void reset(){x=0;}
  void show(){
    System.out.print(x);}
```

Counter - stimuli inc(), read(), reset(), show()

print() to the object System.out

# Software objects

We would like to regard software objects as reactive objects . . .

## The Counter example

```
class Counter{
  int x;
  Counter(){x=0;}
  void inc(){x++;}
  int read(){return x;}
  void reset(){x=0;}
  void show(){
     System.out.print(x);}
}
```

# Software objects

We would like to regard software objects as reactive objects . . .

## The Counter example

```
class Counter{
  int x;
  Counter(){x=0;}
  void inc(){x++;}
  int read(){return x;}
  void reset(){x=0;}
  void show(){
      System.out.print(x);}
```

## Counter state

X

#### Counter - stimuli

inc(), read(),
reset(), show(

## Counter - emissions

print() to the object
System.out

We would like to regard software objects as reactive objects . . .

## The Counter example

```
class Counter{
  int x;
  Counter(){x=0;}
  void inc(){x++;}
  int read(){return x;}
  void reset(){x=0;}
  void show(){
      System.out.print(x);}
```

## Counter state

X

## Counter - stimuli

```
inc(), read(),
reset(), show()
```

### Counter - emissions

print() to the object
System.out

# rtware objects

We would like to regard software objects as reactive objects . . .

# The Counter example

```
class Counter{
  int x;
  Counter(){x=0;}
  void inc(){x++;}
  int read(){return x;}
  void reset(){x=0;}
  void show(){
      System.out.print(x);}
```

### Counter state

X


#### Counter - stimuli

```
inc(), read(),
reset(), show()
```

### Counter - emissions

print() to the object
System.out

# Back to our running example



All messages/events are asynchronous! Either generated by the CPU or by the sonar hw or by the communication hardware.

# **Object Oriented Programming?**

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

# **Object Oriented Programming?**

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

# Object Oriented Programming?

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

### Examples of intuitive objects

People, cars, molecules, . . .

#### Bonus

Principles and methodologies from OOP become applicable to embedded, event-driven and concurrent systems!

# Object Oriented Programming?

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

### Examples of intuitive objects

People, cars, molecules, . . .

#### Bonus

Principles and methodologies from OOP become applicable to embedded, event-driven and concurrent systems!

# **Object Oriented Programming?**

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

# **Object Oriented Programming?**

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

### Examples of intuitive objects

People, cars, molecules, ...

# Object Oriented Programming?

- Objects have local state
- Objects export methods
- Objects communicate by sending messages
- Objects rest between method invocation

### Examples of intuitive objects

People, cars, molecules, ...

### **Bonus**

Principles and methodologies from OOP become applicable to embedded, event-driven and concurrent systems!

# The Counter example again

```
class Counter{
   int x;
   Counter(){x=0;}
   void inc(){x++;}
   int read(){return x;}
   void reset(){x=0;}
}
```

#### One thread

```
public static void main(){
  Counter c = new Counter();
  c.inc();
  System.out.println(c.read());
}
```

Creating a new object just creates a passive piece of storage! Not a thread of control!

Other threads that use the same counter are sharing the state

# The Counter example again

```
class Counter{
   int x;
   Counter(){x=0;}
   void inc(){x++;}
   int read(){return x;}
   void reset(){x=0;}
}
```

### One thread

```
public static void main(){
   Counter c = new Counter();
   c.inc();
   System.out.println(c.read());
}
```

Creating a new object just creates a passive piece of storage! Not a thread of control!

Other threads that use the same counter are sharing the state

# The Counter example again

```
class Counter{
   int x;
   Counter(){x=0;}
   void inc(){x++;}
   int read(){return x;}
   void reset(){x=0;}
}
```

### One thread

```
public static void main(){
  Counter c = new Counter();
  c.inc();
  System.out.println(c.read());
}
```

Creating a new object just creates a passive piece of storage! Not a thread of control!

Other threads that use the same counter are sharing the state

# Java? C++?

# The Counter example again

```
class Counter{
   int x;
   Counter(){x=0;}
   void inc(){x++;}
   int read(){return x;}
   void reset(){x=0;}
}
```

### One thread

```
public static void main(){
  Counter c = new Counter();
  c.inc();
  System.out.println(c.read());
}
```

Creating a new object just creates a passive piece of storage! Not a thread of control!

Other threads that use the same counter are sharing the state!

# Java? C++?

# The Counter example again

```
class Counter{
   int x;
   Counter(){x=0;}
   void inc(){x++;}
   int read(){return x;}
   void reset(){x=0;}
}
```

### One thread

```
public static void main(){
  Counter c = new Counter();
  c.inc();
  System.out.println(c.read());
}
```

Creating a new object just creates a passive piece of storage! Not a thread of control!

Other threads that use the same counter are sharing the state!

Counting visitors to a park

# OO Languages:

- An object is a passive piece
- A method is a function
- Sending a message is calling

- An object is an independent
- A method is a process
- Sending a message is

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling

- An object is an independent
- A method is a process
- Sending a message is

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling

- An object is an independent process with local state
- A method is a process
- Sending a message is

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling

- An object is an independent process with local state
- A method is a process
- Sending a message is

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling

- An object is an independent process with local state
- A method is a process fragment
- Sending a message is

### OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling a function

- An object is an independent process with local state
- A method is a process fragment
- Sending a message is

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling a function

- An object is an independent process with local state
- A method is a process fragment
- Sending a message is interprocess communication

## OO Languages:

- An object is a passive piece of global state
- A method is a function
- Sending a message is calling a function

## Our model says

- An object is an independent process with local state
- A method is a process fragment
- Sending a message is interprocess communication

This is one of the reasons why we choose to build our own kernel supporting reactive objects and programming in C.

# We will need to provide ways for

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

This will be the contents of a kernel called TinyTimber that we will learn how to design and use!

# We will need to provide ways for

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

This will be the contents of a kernel called TinyTimber that we will learn how to design and use!

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

- Create reactive objects
- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

# We will need to provide ways for • Create reactive objects

- Declare protected local state
- Receive messages
  - synchronously
  - asynchronously
- Bridge the hardware/software divide (run ISRs)
- Schedule a system of reactive software objects.

This will be the contents of a kernel called TinyTimber that we will learn how to design and use!