Adressering av komponenter på DSP-plattform Adress pinne

Chip	Benämning	Aktiv	31	30	29	28 2	7 26	5 25	24	23	22 2	21 2	0 1	9 18	3 17	7 1	6 1	5 1	14 1	13 13	2 1	1 1	0 9	9	8	7	6	5	4 :	3 2	2 1	0		Adress	Allokerar minne
SRAM	CS0	L	1	0	1	1							1	1 x	×	: >	x :	x															(0000 0000 OxB	128kb
Servo 0	CS1	Н	1	0	1	1							(0 0	0	(0 (0															(0xB000 0000	32kb
Servo 1	CS2	Н	1	0	1	1							(0 0	0	(0	1															(0xB000 8000	32kb
Servo 2	CS3	Н	1	0	1	1							(0 0	0	1	1 (0															(0xB001 0000	32kb
Servo 3	CS4	Н	1	0	1	1							(0 0	0	1	1 .	1															(0xB001 8000	32kb
Dig I/O	CS5	Н	1	0	1	1							(0 0	1	(0 (0															(0xB002 0000	32kb
Kamera	CS6	Н	1	0	1	1							(0 0	1	(0	1															(0xB002 8000	32kb
DC-Motor	CS7	Н	1	0	1	1							(0 0	1	1	1 (0															(0xB003 0000	32kb
A/D 0	CS8	L	1	0	1	1							(0 0	1	1	1 .	1															(0xB003 8000	32kb
A/D 1	CS9	L	1	0	1	1							(0 1	0	(0 (0															(0xB004 0000	32kb
Encoder	CS10	L	1	0	1	1							(0 1	0	(0	1															(0xB004 8000	32kb
Reserv 1	CS11	L	1	0	1	1							(0 1	0	1	1 (0															(0xB005 0000	32kb
Reserv 2	CS12	L	1	0	1	1							(0 1	0	1	1 .	1															(0xB005 8000	32kb
Reserv 3	CS13	L	1	0	1	1							(0 1	1	(0 (0															(0xB006 0000	32kb

Adressering på DSP-kort

LED	IO_PORT	0x90080000	
Switch	IO_PORT	0x90080000	
	SDRAM	0x80000000	4Mb
	FLASH	0x90000000	128kb
	RAM	0x00000000	64kb