
TTGO T-Display



³1.Install the following dependency library files:

- TFT_eSPI
- Button2

².TFT_eSPI settings

- Install TFT_eSPI, in TFT_eSPI/User_Setup_Select.h, comment out the default settings #include <User_Setup.h> , select #include <User_Setups/Setup25_TTGO_T_Display.h> , Save Settings.
- Like the picture below

```
C User_Setup_Select.h > ...
  #ifndef USER_SETUP_LOADED // Lets PlatformIO users define settings in
  // Only ONE lin
                                                  Add extra lines and files as neede
  //#include <User_Setups/Setup1_ILI9341.h> // Setup file configured for my ILI934
 //#include <User Setups/Setup23 TTGO TM.h>
  //#include <User_Setups/Setup24_ST7789.h>
#include <User_Setups/Setup25_TTGO_T_Display.h>
                                                      // Se)up file for ESP32 and TT
  //#include <User_Setups/Setup43_S17735.h>
```

3.Board choose

• The board can choose ESP32 Dev Module, other settings can keep the default

³Pinout

Name	V18
TFT Driver	ST7789
TFT_MISO	N/A
TFT_MOSI	19
TFT_SCLK	18

Name	V18
TFT_CS	5
TFT_DC	16
TFT_RST	N/A
TFT_BL	4
I2C_SDA	21
I2C_SCL	22
ADC_IN	34
BUTTON1	35
BUTTON2	0
ADC Power	14

2019/08/06:

• The TFT_eSPI and Button2 libraries have been synchronized to the main branch