


GM HEI Wiring

Ideally wire the 12V feed to the coil pack from the fuel pump relay.



On the 7 pinned modules:

• tach signal is a purple wire with a white trace [pin R]

* advance control signal is a white wire [pin E]

* override (cranking) signal is a tan wire with a black trace [pin B]

* ground is a black wire with a red trace [grounded to distributor case]

For all modules wire the MS ECU so:

Pin R connects to pin 24 of the MS ECU, (Red trigger wire in screen)

Pin E connects to pin 36 of the MS ECU (yellow or grey spark output wire)

Pin B connects to pin 6 of the MS ECU (Blue crank override wire)

www.ExtraEFI.co.uk