



## Spartan Lambda Wiring / Calibration



## **Tuner Studio Settings**

Calibrating the MS2-Extra and MS3 ECU to the Spartan Lambda:

Power the ECU up and connect to Tuner Studio, go into Tools - Unlock Calibration.



Select Unlocked and Burn then Tools - Calibrate AFR Table.



The Spartan is set to give a 0-5V output as 10-20AFR, so select "Innovate / PLX 0.0  $5.0\ 10.1-20.1$ " as above, then click "Write to Controller"

Now the ECU will read the voltage from the Spartan correctly and display the AFR on the main screen.

www.ExtraEFI.co.uk