


VW, Seat, Audi, Skoda Coil pack # 19020007


This is a superb device as it has a built in ignitor for the coils, so noise is kept away from the ECU. This needs a 5V signal from the ECU to fire it.




It doesn't appear to control dwell so settings should be started at:

Cranking 6.0mS and Running 3.0mS

MS1 - Spark Settings need to be Spark Output Inverted "NO"



MS2 - Spark Ouput set to "Going Low(Normal)"



www.ExtraEFI.co.uk