

ANALOG Wireless Transmitter

- Accuracy: 1/10,000 for any indicator
- Load cell: 1 to 12 load cells 350Ω
- Frequency bands: 433MHz
- 270 hours under weighing mode for one load cell 350Ω
- Range: 150 meters
- Working temperature: -10°C to +60°C

AD transmitter LED indication

LED location	Status	Indication
Communicate LED (left)	10Hz frequency flash	Normal communication
	0.3 Hz frequency flash	Sleeping status, communication break
Battery voltage LED (middle)	Flashing	Battery voltage too low, need to charge
	Not flashing	Battery voltage in good status
Charger LED (right)	Red light on	Charging status
	Green light on	Battery is full
	Neither red or green light on	Charger adapter is not connecting

DA receiver LED indication

LED location	Status	Indication
Communicate LED (left)	10Hz frequency flash	Normal communication
	Not flashing	Communicate break
Battery voltage LED (middle)	Flashing	Battery voltage in AD transmitter too low, need to recharge
	Not flashing	Battery voltage in good status
Charger LED (right)	Red light on	Power supply status
	Green light off	Power off status

